



MANUAL

VBG-PB-KF-R4

AS-INTERFACE/PROFIBUS GATEWAY

IN ACC. TO SPECIFICATION 2.11



With regard to the supply of products, the current issue of the following document is applicable:
The General Terms of Delivery for Products and Services of the Electrical Industry, as published by
the Central Association of the 'Elektrotechnik und Elektroindustrie (ZVEI) e.V.',
including the supplementary clause "Extended reservation of title"

We at Pepperl+Fuchs recognise a duty to make a contribution to the future.
For this reason, this printed matter is produced on paper bleached without the use of chlorine.

Table of Contents

1	Declaration of Conformity	3
2	The Used Symbols	5
3	Safety	7
3.1	Intended Use	7
3.2	General Safety Information	7
4	General Information	9
5	Connections, Displays and Operating Keys	11
5.1	AS-i/PROFIBUS-DP gateway in KF-Housing	11
5.1.1	Device Schematics	11
5.1.2	Displays and Controls	12
5.1.3	Mounting and Connections	13
5.1.4	The PROFIBUS Interface	14
5.2	Factory-Reset	15
6	Operating the AS-i/PROFIBUS Gateway	17
6.1	Master Start-Up	17
6.2	Configuration Mode	17
6.3	Protected Operating Mode	18
6.3.1	Switching to Protected Operating Mode	18
6.3.2	Configuration Errors in Protected Operating Mode	18
6.4	Assigning an AS-i Address in Configuration Mode	19
6.4.1	Assigning a Slave Address	19
6.4.2	Erasing the Slave Address	19
6.5	Programming the Address in Case of Configuration Errors	20
6.5.1	Automatic Address Assignment	20
6.5.2	Manual Address Assignment	20
6.6	Setting of the PROFIBUS Station Address	21
6.6.1	PROFIBUS Station Address	21
6.7	Error Messages	21
7	Advanced Diagnostics for AS-i Masters	23
7.1	List of Corrupted AS-i Slaves (LCS)	23
7.2	Error Counters: Counters of Corrupted Data Telegrams	23
7.3	Off-line Phase on Configuration Errors (LOS)	24
8	PROFIBUS-DP	25
8.1	DP Telegrams	25
8.1.1	Diagnosis	25
8.1.2	Configuration DP V0 (cyclic data)	28
8.1.3	I/O-Data	29
8.2	DP V1	32

Issue date 9.11.2001

8.3	Mailbox	32
8.3.1	Construction	32
8.3.2	Mailbox commands	35
8.3.3	Mailbox example	60
9	Commissioning Tools and Accessories	63
9.1	Windows Software AS-i Control Tools	63
9.2	PROFIBUS-DP master simulator	65
10	Appendix: Displays of the Figure Display	67
11	Appendix: The First Commissioning of AS-i	69
12	Appendix: Putting PROFIBUS into Operation with a Siemens S5	71
12.1	Putting into Operation in Easy Mode	71
12.2	Putting into Operation in Professional Mode	74

1 Declaration of Conformity

The AS-i/PROFIBUS gateway VBG-PB-KF-R4 has been developed and produced in accordance with the applicable European standards and directives.



Note

The corresponding of conformity can be requested from the manufacturer.

The manufacturer of the product, Pepperl+Fuchs Group in D-68301 Mannheim, possesses a certified quality assurance system in accordance with ISO 9001.



AS-Interface Declaration of Conformity

issue date 9.11.2001

2 The Used Symbols



Warning

This symbol warns the user of possible danger. Failure to heed this warning can lead to personal injury or death and/or damage to equipment.



Attention

This symbol warns the user of a possible failure. Failure to heed this warning can lead to total failure of the equipment or any other connected equipment.



Note

This symbol gives the user important hints.

3 Safety

3.1 Intended Use



Warning

The protection of operating personnel and the system against possible danger is not guaranteed if the control interface unit is not operated in accordance with its intended use.

The device may only be operated by appropriately qualified personnel in accordance with this operating manual.

3.2 General Safety Information



Warning

Safety and correct functioning of the device cannot be guaranteed if any operation other than that described in this operation manual is performed.

The connecting of the equipment and any maintenance work to be carried out with voltage applied to the equipment must only be performed by appropriately qualified electrotechnical personnel.

In the case that a failure cannot be repaired, the device must be taken out of operation and kept from inadvertently put back into operation.

Repair work is to be carried out by the manufacturer only. Additions or modifications to the equipment are not allowed and void the warranty.



Note

The operator is responsible for the observance of local safety standards.

4 General Information

This operating instruction is for use with the following device of the Pepperl+Fuchs GmbH:

- AS-i/PROFIBUS-DP gateway in KF-housing VBG-PB-KF-R4

The AS-i/PROFIBUS-Gateways serve to connect AS-Interface systems to the PROFIBUS. They act as a Master for the AS-Interface and as a slave for the PROFIBUS.

New AS-i Specification 2.1

The AS-i/PROFIBUS-DP Gateways already fulfil the new AS-i Specification 2.1. This means:

- Up to 62 AS-Interface slaves can be connected per 1 AS-i network
- The transfer of analog signals via AS-i is integrated in the Masters
- All further functions of the new specification as e.g. the diagnosis of the AS-i peripheral fault are implemented.

All AS-i functions are provided cyclically via PROFIBUS-DP V0 and acyclically via PROFIBUS-DP V1.

In the cyclic data transfer optionally up to 32 bytes I/O data are transferred for the binary data of 1 AS-i network. Furthermore analog signals and all further commands of the new AS-i specification can be transferred in the management channel via PROFIBUS.

The AS-i Control Tools can be used for the monitoring of the AS-i data online via the PROFIBUS-DP V1.

Advanced Diagnostics

Diagnostics, which go far beyond the standard diagnostics facilitate the simple detection of the occasionally occurring configuration errors and further irritations towards the AS-i communication. So in case of an error the down time of machines can be minimized or you can initiate preventive maintenance.

Commissioning and monitoring

The AS-i/PROFIBUS Gateways can be commissioned respectively programmed with the help of the software "AS-i Control Tools" in combination with the PROFIBUS-DP Master Simulator. The GSD file are included in the package.

Commissioning, debugging and setting up of the AS-i parameters without the software can only be accomplished with the use of the push-buttons, the display and the LEDs directly on the system.

Accessories:

Software "AS-i Control Tools"

PROFIBUS-DP Master Simulator


5 Connections, Displays and Operating Keys

5.1 AS-i/PROFIBUS-DP gateway in KF-Housing


5.1.1 Device Schematics

The following are found on the front of the AS-i/PROFIBUS Gateway (see diagram below):

1. Connection terminals for the AS-i circuit, also used for the power supply
2. A nine pin SUB-D connector as a PROFIBUS-serial interface,
3. 7 LEDs
4. A four position, seven section display for indicating the gateway's operating status
5. 2 buttons for projecting the gateway
6. A rotary switch for bus termination..



The following diagram provides the dimensions of the AS-i/PROFIBUS gateway.



5.1.2 Displays and Controls

The seven LEDs on the front of the gateway signal the following:

power	The gateway is sufficiently supplied with power.
ser active	LED on: The PROFIBUS communications are serial interface is active. LED off: The PROFIBUS communications are serial interface is inactive.
config err	A configuration error is imminent or no PROFIBUS communications are taking place (when the "ser active" LED is not illuminated). This means that with configuration errors, at least one projected slave is missing or the actual configuration data does not correspond with the reference configuration data for a projected and recognized slave. This LED blinks if there is at least one periphery fault at one AS-i slave in the AS-i network. If there are configuration errors as well as periphery faults, only configuration error is displayed.
U AS-i	The AS-i line is sufficiently supplied with power. (AS-i Flag "APO").
AS-i active	Standard operation is active (AS-i Flag "Protected Mode").
prg enable	Automatic address programming is possible (AS-i Flag "Auto_prog_available"). Precisely one slave is missing in the protected operating mode. This slave can be replaced with a slave of similar design and an address of 0. The gateway automatically programs the new slave to the faulty address and thereby resolves the configuration error.
prj mode	The gateway is in the projection mode (AS-i Flag "projecting_active").

Issue date 9.11.2011

The two buttons have the following functions:

- | | |
|------|--|
| mode | Used to switch between the projection mode and the protected operating mode and to store the actual AS-i configuration as the reference configuration. |
| set | Selection and storage of an AS-i slave address. |

5.1.3 Mounting and Connections

Mounting

The KF... design of the gateway can be mounted on a 35 mm DIN rail in accordance with EN 50022 and facilitates electrical connection through the "Power Rail". It is also possible to use the more conventional and expensive method of cable connections to terminals with this design.

The gateway is snapped directly onto the DIN rail. When using the power rail, an electrical connection is automatically made (to the AS-i Bus) by snapping the gateway onto the rail leads.




Connection via the Power Rail

The PR-05 power rail is an insert for the DIN rail in accordance with EN 50 022. The UPR-05 is delivered with the appropriate DIN rail.

The 5 pin version of the power rail must be used during the establishment of AS-In-terface circuits. Two of the five power rails make up the AS-i bus.

Lead breakage as well as a short circuit caused by the power rail is prevented due to the power rail's solid construction.



UPR-05




PR-05

Device Terminal Connections

In addition to or in combination with power rail connections, the KF... designs can be conventionally connected by means of removable device terminals. The terminal arrangement is shown below.

The device terminals consist of screw type cable piercing terminals which allow for the connection of 14 AWG cables (2.5 mm²). The connectors are 3 pin connectors; they can be keyed to prevent connection errors.

Removable terminals simplify the assembly of the switch enclosure and allow for the replacement of components without taking the system off line.



Gateway Power Supply

The gateway is supplied through the AS-i circuit. A connection to the AS-i cable is established by means of the power rail and/or with the device terminals. The master is powered by the AS-i network. An AS-i connection is established by means of the power rail or the device terminals. The terminal layout is displayed in the diagram below.

It is important to note when using the power unit that these AS-Interfaces are compatible and have the necessary decoupling coils.

5.1.4 The PROFIBUS Interface

The serial interface is a 9 pin SUB-D connector. It is located on the right side of the device front. The other possibility is to use the device terminals. The wiring is shown in the picture before.

The AS-i/PROFIBUS gateway with an RS 485 interface transmits and receives through pins 3 and 8 of the SUB-D connector or terminals 25 and 26 of the device terminals. The RxD/TxD-P signal (B cable per PROFIBUS specifications) is assigned

Issue date 9.11.2001

to pin 3 and to terminal 25. The RxD/TxD-N signal (A cable per PROFIBUS specifications) is assigned to pin 8 and to terminal 26.

In order to prevent equalizing currents, the interface cable's shielding is connected with the gateway's grounding clamp through a capacitor. Otherwise, it should be galvanically grounded.

Bus Termination Resistors

If the AS-i/PROFIBUS gateway is at the end of the PROFIBUS line, turn the rotary switch with a screwdriver clockwise for approximately 60 degrees to terminate the bus with the built-in termination resistors.

If the gateway is not at the end of the line, switch off the termination resistors by turning the rotary switch counter-clockwise for approx. 60 degrees.

5.2 Factory-Reset

With factory reset the AS-i master is set to the factory default settings. All non volatile stored data - e.g. the AS-i configuration - will be erased.

To reset the AS-i master to factory default settings both buttons have to be pressed until the "88" in the display disappears while powering up the AS-i master.

6 Operating the AS-i/PROFIBUS Gateway

6.1 Master Start-Up

After powering on, all segments of the figure display and all LEDs light up for approximately one second (self-test). Afterwards, the LEDs display the condition of their respective flags. The figure display shows the condition of the master:

40 Off-line Phase

The AS-i master initializes - there is no data communication on the AS-i.



If the AS-i circuit is insufficiently powered ("U AS-i" does not light up) or there is no communication relationship between the PROFIBUS master and the AS-i/PROFIBUS gateway, the master remains in the off-line phase.

In configuration mode or when an AS-i Control program is started automatically the device can leave the off-line phase.

In protected mode, if the PROFIBUS communication is interrupted, the AS-i master switches to the off-line phase after the watchdog time of the PROFIBUS has expired unless an AS-i Control program is running and was started automatically.

41 Detection Phase

Start of the start-up phase, where the system looks for slaves located on the AS-i. The master remains in the detection phase until it finds at least one slave.

42 Activation Phase

Condition at the end of the start-up operation where the parameters are transmitted to all connected and recognized slaves. This enables access to the AS-i slaves' data connections.

43¹ Start of Normal Operation

In normal operation the AS-i master can exchange data with all active slaves. It transmits management messages and looks for and activates newly connected slaves. During normal operation, the system keeps the maximum cycle time of 5 milliseconds.

6.2 Configuration Mode

The configuration mode serves to configure the AS-i circuit.



In the configuration mode, all recognized slaves are activated even when the desired and actual configurations do not match.

1. Activation phase and the start of normal operation maybe so short that the numbers can not be seen in the display.

Pressing the “mode” button for at least five seconds switches the master to configuration mode. While in configuration mode, the yellow “prj mode” LED lights up.

The system then displays one after the other all detected slaves at a speed of two per second. If the display is empty, no slaves were detected on the AS-i circuit.

In configuration mode, all recognized slaves are activated except of slave zero. The AS-i master is in normal operation. There is data exchange between the AS-i master and all AS-i slaves detected by the master regardless of whether the detected AS-i slaves were projected before.



When delivered the device is in configuration mode.

6.3 Protected Operating Mode



Note

In contrast with the configuration mode in the protected mode there is only data exchange between the AS-i master and the projected AS-i slaves.

6.3.1 Switching to Protected Operating Mode

The configuration mode can be left by pressing the “mode” button.

Pressing the button shortly:

Exits the configuration mode without projecting the current AS-i configuration.

Pressing the button for more than five seconds:

Exits the configuration mode and projects the actual AS-i configuration. Simultaneously the actual AS-i configuration is stored as nominal configuration in the EEPROM.



Note

If the system detects an AS-i slave with address zero on the AS-i, it can not leave the configuration mode.

In the protected operating mode, only AS-i slaves that are projected and whose actual configurations match the nominal configurations will be activated.

6.3.2 Configuration Errors in Protected Operating Mode

As long as there is no configuration error, the numeric display is turned off while in protected operating mode. Otherwise, the address with a faulty assignment is displayed. A faulty assignment occurs when a slave has been recognized or projected but cannot be activated.

If there are more than one faulty assignments the one that was first detected is displayed. Pressing the “set” button shortly displays the next higher faulty address.

Issue date 9.11.2011

Shortly appearing configuration errors are stored in the device (advanced AS-i diagnosis). The last error that occurred can be displayed by pressing the set button. If a short AS-i power failure is responsible for the configuration error the display shows a "39".

6.4 Assigning an AS-i Address in Configuration Mode

AS-i can be put into operation in a very comfortable manner by using the Windows software AS-i Control Tools (see chapter 9.1)(addressing directly or with the AS-i address assistant).

Furthermore you can use a hand held addressing device.

If you don't have neither a PC nor a hand held addressing device, address assigning of the AS-i slaves is also possible with the AS-i/PROFIBUS gateway using the push buttons. How it works is described as follows.

6.4.1 Assigning a Slave Address

(assigning an available address to a slave with address zero)

In configuration mode, the addresses of all detected slaves are displayed one after the other. To display the next higher available operating address, press the "set" button shortly. Each time you press the "set" button, the next available address is displayed.

Choose the displayed address as your target address by pressing the button for more than five seconds. The address display blinks. The master is ready for programming; pressing the "set" button again addresses the connected slave with address zero to the target (blinking address).

Any errors will be displayed by their error codes according to chapter 10. Otherwise, the detected slaves are displayed again as described in chapter 6.2..



Note

Only slaves with address 0 can get a new address by the master.



Attention

There must not be two AS-i slaves with the same address on the AS-i circuit.

6.4.2 Erasing the Slave Address

(assigning address zero to a detected slave)

In configuration mode, the addresses of all recognized slaves are displayed one after the other. By pressing and releasing the "set" button, the master displays the next available address. If you press the button for more than five seconds while the address of a detected slave is displayed, this slave will get the address zero and the display shows "00".

When you release the button, the display continues to display the detected slaves.

6.5 Programming the Address in Case of Configuration Errors

6.5.1 Automatic Address Assignment



Note

One of AS-i's great advantages is the automatic address assignment. If a slave fails, it can be replaced by one of the same type with address zero. The master will detect the replacement and automatically addresses the new slave with the address of the faulty one.

For automatic programming to work, some requirements must be met:

1. The AS-i master must be in the protected operating mode.
2. The "Auto_Address_Assign" release flag must be set.
3. Only one of the projected slaves may not be detected.

If these requirements are met, the AS-i master's "**prg enable**" LED lights up and a slave with address zero will be automatically assigned to the operating address of the missing slave. The "Automatic Address Assignment" can be activated and deactivated via the software "AS-i Control Tools".



Attention

If the two slaves have different configuration data, i.e. are not of the same type as far as AS-i is concerned, the automatic address assignment will not be carried out.

6.5.2 Manual Address Assignment



Note

If several slaves fail, they cannot be replaced automatically by the AS-i master. Then these addresses have to be set manually. If this should not be done via the host interface (using the AS-i Control Tools) or with a hand held addressing device, the slave addresses can also be changed with the help of the push buttons and the figure display of the device.

In protected operating mode, wrong assignments are displayed as errors (see chapter 6.3). By pressing the "set" button, you can display all faulty assignments one after the other. By pressing the "set" button for more than five seconds, you can select the currently displayed address as a potential target address, and the display starts to blink.

If the faulty slave was previously replaced by a slave with address zero, the new slave can now be programmed for the blinking address by pressing the "set" key again. As a requirement, the new slave's configuration data must match the configuration data for the blinking address.

After the address has been successfully set, the next faulty assignment is displayed and the address assignment can begin from the start. Otherwise, the system displays an error code (chapter 10). When all faulty assignments are eliminated the display is empty.

6.6 Setting of the PROFIBUS Station Address

6.6.1 PROFIBUS Station Address



Note

The addressing of the AS-i/PROFIBUS gateway as a PROFIBUS slave can be done locally at the gateway or via PROFIBUS according to the PROFIBUS standard.

Station addresses from 1 to 99 can be set, when delivered station address 3 is set. For the relocation, both the “set” button and the “mode” button have to be pushed simultaneously for at least 5 seconds until the current bus address is shown on the LCD display. With every pushing of the “set” button, the station address can now be increased by 1.

Once the desired PROFIBUS station address is shown on the display, it will be stored non-volatile in the EEPROM by pushing the “mode” button.

6.7 Error Messages



Attention

The system displays error codes for error messages that do not point to faulty assignments on the AS-i circuit. The code numbers are larger than 50 and are therefore outside the slave address range. These codes are described in the appendix, chapter 10.

7 Advanced Diagnostics for AS-i Masters

The advanced AS-i diagnostics serve to locate occasionally occurring errors and to judge the quality of data transmission on AS-i without additional diagnostics tools.

The "AS-i Control Tools" (software for the comfortable commissioning of the AS-Interface and the programming of AS-i Control) support the operation of the advanced diagnostics (LCS, error counters and LOS).

7.1 List of Corrupted AS-i Slaves (LCS)

To locate occasionally occurring short-time configuration errors the AS-i masters with advanced diagnostics manage beside the list of projected slaves (*LPS*), the list of detected slaves (*LDS*) and the list of activated slaves (*LAS*) a forth list, the **list of corrupted slaves (LCS)**. This list contains entries of all AS-i slaves which were responsible for at least one configuration error since powering up the AS-i master or reading the list. Short-time AS-i power failures are represented in the *LCS* at the position of AS-i slave with address 0.



Note

With every read access the LCS will be deleted.



Note

The last short-time configuration error can also be displayed on the AS-i Master:

Pressing the "set" button of the AS-i master shows the AS-i slave which was responsible for the last short-time configuration error. If there was a short-time AS-i power failure the display shows "39" after pressing the "set" button.

This function is only available if device is in the normal operation mode of the protected mode (display empty) or in the off-line-phase.

7.2 Error Counters: Counters of Corrupted Data Telegrams

The AS-i master with advanced diagnostics has an error counter for each AS-i slave, which is increased every time there is a corrupted AS-i telegram. This makes it possible to judge the quality of the AS-i network, even if only a few corrupted telegrams occurred and the AS-i slave did not cause any configuration errors.



Note

The counter values can be read via the host interface and will be deleted with every read access. The counter value is limited to 254. 255 means counter overflow.

The error counter is included in the command master | AS-i Diagnostics of "AS-i Control Tools".

7.3 Off-line Phase on Configuration Errors (LOS)

The AS-i masters with advanced diagnostics offer the possibility to put themselves into the off-line Phase when a configuration error on the AS-Interface occurs. In this way the security of the application can be ensured. The reaction to a configuration error is very fast and the host can be relieved from this task. If there are any problems on the AS-i network, the AS-interface can be switched to a secure state.

There are two different ways to parameterize the AS-i master for this feature:

- Every configuration error during normal operation in protected mode releases the off-line phase.
- For each slave address can be chosen whether a configuration error on this address will release the off-line phase or not. This information is stored in the List of Off-line Slaves (LOS).

The user himself can decide how the system reacts to a configuration error on the AS-Interface. The AS-i master can release the off-line phase in critical situations, i. e. only with certain slave addresses, while in less critical situations (if one of the other AS-i slaves have a configuration error) only the error message configuration error is sent to the host, but AS-i is still running.

The parameterization of off-line phase on configuration error is also supported by the "AS-i Control Tools" from version 3.0 (command Master | Identity | Offline on configuration error).

8 PROFIBUS-DP

This chapter contains all the necessary information to operate the AS-i/PROFIBUS gateway in a PROFIBUS-DP network.

8.1 DP Telegrams

8.1.1 Diagnosis

DP Diagnosis					
PDU byte	user byte		DP	DPV1	user
1	–	station_status 1	✓		
2	–	station_status 2	✓		
3	–	station_status 3	✓		
4	–	master address	✓		
5	–	ident high	✓		
6	–	ident low	✓		
7	1	header	✓	✓	
8	2	type		✓	
9	3	slot		✓	
10	4	spec		✓	
11	5	ec-flags (high)			✓
12	6	ec-flags (low)			✓
13	7	delta (0...7)			✓
14	8	delta (8...15)			✓
...			
20	14	delta (56...63)			✓
21	15	LPF (0...7)			✓
...			
28	22	LPF (56...63)			✓
29	23	LCS (0...7)			✓
...			
36	30	LCS (56...63)			✓

ec-flags (high):

Bit 0: periphery fault

ec-flags (low):

Bit 0: configuration error

Bit 1: slave with address0 detectd

Bit 2: Auto_address_assignment not possible

Bit 3: Auto_address_assingment available

Bit 4: configuration mode actice

Bit 5: not in normal operation

Bit 6: AS-i power fail

Bit 7: AS-i master is offline

Delta List: List of AS-i slaves with configuration error:

- 1: ConfigError
- 0: no ConfigError

LPF: List of AS-i slaves with periphery fault:

- 1: periphery fault
- 0: no periphery fault

LCS: List of Corrupted slaves (see chapter 7).

Each element of the user diagnosis (ec-flags and slave lists) can be switched off by setting the appropriate bit in the parameter telegram.

Each element that is not used will be filled up with zeros. This way the data elements in the diagnosis telegram will keep its designated position (and clear text diagnosis fits to the data furthermore).

Only if an element at the end of the user diagnosis is not used, the length of the diagnosis will be shortened.

ExtDiag will be set if at least one of the following conditions is fulfilled:

- ConfigError \equiv 1
- APF \equiv 1
- PeripheryFault \equiv 1
- LCS is not empty

The conditions when to set the ExtDiag bit can be chosen using the user parameters or the mailbox commands.

The GSD file includes the following presettings:

- The PROFIBUS diagnosis displays: EC-flags, delta list and LPF. The LCS is not displayed.
- ExtDiag will be set if ConfigError = 1 and APF = 1. ExtDiag will not be set if there is a periphery fault or if there is an entry in the LCS.

If an AS-i/PROFIBUS-DP Gateway with 2 AS-i masters is used, the User-Diagnosis-Bytes 5 to 30 represent AS-i network 1 and the User-diagnosis bytes 31 to 56 represent AS-i network 2.

User Parameters

With the User Parameters can be selected which slave lists will be displayed in the PROFIBUS diagnosis. Furthermore can be selected which conditions have to be fulfilled to set the ExtDiag bit within the diagnosis telegram.

DP Parameters						
PDU byte	user byte		DP	DPV1	user	default
1	—	station_status	✓			
2	—	WD_Fact_1	✓			
3	—	WD_Fact_2	✓			
4	—	min T _{sdr}	✓			
5	—	ident high	✓			
6	—	ident low	✓			

Issue date 9.11.2001

DP Parameters						
PDU byte	user byte		DP	DPV1	user	default
7	–	group_ident	✓			
8	1	DPV status 1		✓		80 ₁₆
9	2	DPV status 2		✓		00 ₁₆
10	3	DPV status 3		✓		00 ₁₆
11	4	slave lists			✓	0B ₁₆
12	5	ExtDiag			✓	06 ₁₆

The bits in "slave lists" and "ExtDiag" have following meanings:

Slave lists								
	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
	–			LCS	LPF	–	D	F
default	0	0	0	0	1	0	1	1

ExtDiag								
	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
	–			CS	PF	APF	CF	–
default	0	0	0	0	0	1	1	0

LCS: 1: LCS will be displayed in PROFIBUS diagnosis

0: LCS will not be displayed

LPF: 1: LPF will be displayed in PROFIBUS diagnosis

0: LPF will not be displayed

D: 1: Delta list will be displayed in PROFIBUS diagnosis

0: Delta list will not be displayed

F: 1: EC flags will be displayed in PROFIBUS diagnosis

0: EC flags will not be displayed

CS: 1: ExtDiag will be set, if there is an entry in the LCS

0: ExtDiag will not be set, if there is an entry in the LCS

PF: 1: ExtDiag will be set, if there is a periphery fault at the AS-i line

0: ExtDiag will not be set.

APF: 1: ExtDiag will be set, if there is an AS-i Power Fail

0: ExtDiag will not be set.

CF: 1: ExtDiag will be set, if there is an Configuration error at the AS-i line

0: ExtDiag will not be set.

The GSD's default user parameter telegram is:

80 ₁₆	00 ₁₆	00 ₁₆	0B ₁₆	06 ₁₆
------------------	------------------	------------------	------------------	------------------

(DPV1 enabled, diagnosis settings according chapter 8.1.1)

8.1.2 Configuration DP V0 (cyclic data)

AS-i V2.04 easy mode



Note

The AS-i/PROFIBUS-DP Gateway V2.1 can be used that it can replace Bihl+Wiedemann's AS-i/PROFIBUS-DP Gateway according to the specification 2.04 which has been commissioned in easy mode. In this mode the AS-i I/O data are shown in the PROFIBUS process data as 16 bytes I/O data with or without consistency.

The PROFIBUS diagnosis is displayed as described in chapter 8.1.1.

Even if the PROFIBUS-DP gateway V2.1 shall be used in this V2.04 easy mode, the GSD file which comes together with the gateway has to be used. The GSD file of the V2.04 gateway can not be used.

AS-i V2.1 mode

In AS-i V2.1 mode the input and output data field can be used with various "special IDs".

The advantages of special input and output IDs are: They can include up to 64 elements (bytes or words) and the length of input and output data can be different. Furthermore "manufacturer specific" data bytes are possible. These "manufacturer specific" data bytes describe the which type ID is.

The following types are possible:

Areas of the I/O-data fields			
type		input data length (bytes)	output data length (bytes)
00 ₁₆	empty	0...128	0...128
01 ₁₆	digital process data out of AS-i circuit 1	0...32	0...32
02 ₁₆	digital process data out of AS-i circuit 2	0...32	0...32
03 ₁₆	mailbox	2...36	2...34
10 ₁₆	analog input data circuit 1, slave 31	2...128	0
11 ₁₆	analog input data circuit 1, slave 15	2...120	0
12 ₁₆	analog output data circuit 1, slave 31	0	2...128
13 ₁₆	analog output data circuit 1, slave 15	0	2...120
14 ₁₆	analog input data circuit 2, slave 31	2...128	0
15 ₁₆	analog input data circuit 2, slave 15	2...120	0
16 ₁₆	analog output data circuit 2, slave 31	0	2...128
17 ₁₆	analog output data circuit 2, slave 15	0	2...120

The consistency of the digital process data is ignored. At least each word of the analog data has to be consistent. The mailbox commands have to be consistent. The GSD file submits the corresponding entry.

Issue date 9.11.2001

The IDs can be used in different sequences. But in the I/O data field can only be one area with each type.

8.1.3 I/O-Data

AS-i V2.04 easy mode

byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
0	slave 1/1A				flags			
	D3	D2	D1	D0	F3	F2	F1	F0
1	slave 3/3A				slave 2/2A			
2	slave 5/5A				slave 4/4A			
3	slave 7/7A				slave 6/6A			
4	slave 9/9A				slave 8/8A			
5	slave 11/11A				slave 10/10A			
6	slave 13/13A				slave 12/12A			
7	slave 15/15A				slave 14/14A			
8	slave 17/17A				slave 16/16A			
9	slave 19/19A				slave 18/18A			
10	slave 21/21A				slave 20/20A			
11	slave 23/23A				slave 22/22A			
12	slave 25/25A				slave 24/24A			
13	slave 27/27A				slave 26/26A			
14	slave 29/29A				slave 28/28A			
15	slave 31/31A				slave 30/30A			

AS-i V2.1 mode

Process data



Note

In V2.1 mode the AS-i I/O data are mapped in the PROFIBUS process data as known from the Siemens and AS-i/InterBus masters. That means the lower nibble describes the data of the AS-i slave with the higher slave address. The EC flags resp. HI-flags are additionally mapped at the nibble of AS-i slave 0.

byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
0	flags				slave 1/1A			
	F3	F2	F1	F0	D3	D2	D1	D0
1	slave 2/2A				slave 3/3A			
2	slave 4/4A				slave 5/5A			
3	slave 6/6A				slave 7/7A			
4	slave 8/8A				slave 9/9A			
5	slave 10/10A				slave 11/11A			
6	slave 12/12A				slave 13/13A			

byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
7		slave 14/14A				slave 15/15A		
8		slave 16/16A				slave 17/17A		
9		slave 18/18A				slave 19/19A		
10		slave 20/20A				slave 21/21A		
11		slave 22/22A				slave 23/23A		
12		slave 24/24A				slave 25/25A		
13		slave 26/26A				slave 27/27A		
14		slave 28/28A				slave 29/29A		
15		slave 30/30A				slave 31/31A		
16		reserved				slave 1B		
17		slave 2B				slave 3B		
18		slave 4B				slave 5B		
19		slave 6B				slave 7B		
20		slave 8B				slave 9B		
21		slave 10B				slave 11B		
22		slave 12B				slave 13B		
23		slave 14B				slave 15B		
24		slave 16B				slave 17B		
25		slave 18B				slave 19B		
26		slave 20B				slave 21B		
27		slave 22B				slave 23B		
28		slave 24B				slave 25B		
29		slave 26B				slave 27B		
30		slave 28B				slave 29B		
31		slave 30B				slave 31B		

Flags		
	input data	output data
F0	ConfigError	Off-line
F1	APF	LOS-master-bit
F2	PeripheryFault	→ ConfigurationMode
F3	ConfigurationActive	→ ProtectedMode

ConfigError: 0=ConfigOK, 1=ConfigError
 APF: 0=AS-i-Power OK, 1=AS-i-Power Fail
 PeripheryFault: 0=PeripheryOK, 1=PeripheryFault
 ConfigurationActive: 0=ConfigurationActive, 1=ConfigurationInactive
 Off-Line: 0=OnLine, 1=Off-Line
 LOS-master-bit 0=Off-Line by ConfigError deactivated
 1=Off-Line by ConfigError deactivated

A rising edge of the "LOS master bit" effects that all bits in the LOS are set. A falling edge effects that all bits are reset.

Analog data

The 16 bit values of AS-i slaves according to the profile 7.3 can read and written within each PROFIBUS cycle or via the mailbox.

If analog values are written cyclic and acyclic via the mailbox or via DPV1 at the same time, the values transmitted cyclically will overwrite the acyclic values.

Analog data								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	slave 31-n/8, channel 1, high byte							
2	slave 31-n/8, channel 1, low byte							
3	slave 31-n/8, channel 2, high byte							
4	slave 31-n/8, channel 2, low byte							
...	...							
n-1	slave 31, channel 4, high byte							
n	slave 31, channel 4, low byte							

Mailbox

Only using the IDs of the process data field the AS-i/PROFIBUS gateway can be used as M0 AS-i master. Using the mailbox (see chapter 8.1) the functions of a M3 master are available.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	command							
2	T	circuit						
3	request parameter byte 1							
...	...							
36	request parameter byte 34							
Answer								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	command (mirrored)							
2	T	result						
3	response parameter byte 1							
...	...							
34	response parameter byte 32							

A mailbox command will be treated if the toggle bit T has changed. In that way the same command can be used many times.

The mailbox commands can also be activated with PROFIBUS-DP V1. Even the process data exchange is possible via the mailbox. In that way the configuration software "AS-i Control Tools" can run the whole communication via DP V1.

8.2 DP V1

To exchange data between the PROFIBUS master and the AS-i/PROFIBUS gateway via PROFIBUS-DP V1 only one data block is used - slot 1, index 16. Within this data block a mailbox is installed like the one used in the DP telegram.

The DP V1-mailboxes are processed every time they are called. Therefore it is possible, to execute the same command several times without changing "command" or "circuit".

8.3 Mailbox

8.3.1 Construction

If an AS-i slave is addressed in a command or in a response, the address is structured as shown below:

Request															
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰							
1	command														
2	T	circuit													
3	request parameter byte 1														
...	...														
36	request parameter byte 34														

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	command							
2	T	result						
3	response parameter byte 1							
...	...							
34	response parameter byte 32							

Command byte and T-bit are always part of the response. The T-bit is necessary to operate the mailbox via a MSC1 connection (PROFIBUS-DP V0). In that way the same mailbox command can be used two times directly one command after the other with different parameters.

The execution of a mailbox command is declined, if the number of the transferred parameters is too small, that means the mailbox in the cyclic channel is too small or the DP V1-telegram is too short.

The mailbox commands are valid as well for PROFIBUS DP V0 as PROFIBUS DP V1.

Circuit = 0 If AS-i gateway with one AS-i master or the master 1 of an AS-i gateway with 2 masters is choosen.

Issue date 9.11.2011

Circuit = 1 If AS-i gateway with 2 masters and the master 2 is choosen.

Values for command

Values for command					
	value	meaning	Req Len	Res Len	ACC Grp
IDLE	00 ₁₆	No order	2	2	A
READ_IDI	41 ₁₆	Read IDI	2	36	A
WRITE_ODI	42 ₁₆	Write_ODI	34	2	D
SET_PP	43 ₁₆	Set_Permanent_Parameter	4	2	C
GET_PP	01 ₁₆	Get_Permanent_Parameter	3	3	A
WRITE_P	02 ₁₆	Write_Parameter	4	3	C
READ_PI	03 ₁₆	Read_Parameter	3	3	A
STORE_PI	04 ₁₆	Store_Actual_Parameter	2	2	C
SET_PCD	25 ₁₆	Set_Permanent_Config	5	2	C
GET_PCD	26 ₁₆	Get_Permanent_Config	3	4	A
STORE_CDI	07 ₁₆	Store_Actual_Configuration	2	2	C
READ_CDI	28 ₁₆	Read_Actual_Configuration	3	4	A
SET_LPS	29 ₁₆	SET_LPS	11	2	C
GET_LPS	44 ₁₆	Get_LPS	2	10	A
GET_LAS	45 ₁₆	Get_LAS	2	10	A
GET_LDS	46 ₁₆	Get_LDS	2	10	A
GET_FLAGS	47 ₁₆	Get_Flags	2	5	A
SET_OP_MODE	0C ₁₆	Set_Operation_Mode	3	2	C
SET_OFFLINE	0A ₁₆	Set_Offline_Mode	3	2	D
SET_DATA_EX	48 ₁₆	Set_Data_Exchange_Active	3	2	C
SLAVE_ADDR	0D ₁₆	Change_Slave_Address	4	2	C
SET_AAE	0B ₁₆	Set_Auto_Adress_Enable	3	2	D
EXEC_CMD	49 ₁₆	Execute_Command	4	3	C
GET_LPF	3E ₁₆	Get_LPF	2	10	A
WRITE_XID1	3F ₁₆	Write_Extended_ID-Code_1	3	2	C
RD_7X_IN	50 ₁₆	Read 1 7.3-slave in.data	3	10	A
WR_7X_OUT	51 ₁₆	Write 1 7.3-slave out.data	11	2	C
RD_7X_OUT	52 ₁₆	Read 1 7.3-slave out.data	3	10	A
RD_7X_IN_X	53 ₁₆	Read 4 7.3-slaves in.data	3	34	A
WR_7X_OUT_X	54 ₁₆	Write 4 7.3-slaves out.data	35	2	C
RD_7X_OUT_X	55 ₁₆	Read 4 7.3-slaves out.data	3	34	A

Issue date 9.11.2001

Values for command					
	value	meaning	Req Len	Res Len	ACC Grp
READ_ODI	56 ₁₆	Read ODI	2	34	A
GET_LISTS	30 ₁₆	Get LDS, LAS, LPS, Flags	2	29	A
GET_LCS	60 ₁₆	Get LCS	2	10	B
GET_LOS	61 ₁₆	GET_LOS	2	10	A
SET_LOS	62 ₁₆	SET_LOS	10	2	C
GET_TECA	63 ₁₆	Get transm.err.counters	2	34	B
GET_TECB	64 ₁₆	Get transm.err.counters	2	34	B
GET_TECX	66 ₁₆	Get transm.err.counters	4	34	B
EXT_DIAG	71 ₁₆	ExtDiag generation	6	2	A
OPTIONS	74 ₁₆	Software options	2	18	A
BUTTONS	75 ₁₆	Disable pushbuttons	3	2	A
RD_EXT_DIAG	7B ₁₆	Read ExtDiag Settings	2	7	A
INVERTER	7C ₁₆	Configure Inverter Slaves	12	4	C

Values for results

Values for result			
	value	place	meaning
OK	00 ₁₆	–	execution without fault
HI_NG	11 ₁₆	HI	general fault
HI_OPCODE	12 ₁₆	HI	illegal value in command
HI_LENGTH	13 ₁₆	HI	length of the mailbox in the I/O-data area respectively the length of the DPV1-Requests is too short
HI_ACCESS	14 ₁₆	HI	no access right
EC_NG	21 ₁₆	EC	general fault
EC_SND	22 ₁₆	EC	„slave (source addr) not detected“
EC_SD0	23 ₁₆	EC	„slave 0 detected“
EC_SD2	24 ₁₆	EC	„slave (target addr) not detected“
EC_DE	25 ₁₆	EC	„delete error“
EC_SE	26 ₁₆	EC	„set error“
EC_AT	27 ₁₆	EC	„address temporary“
EC_ET	28 ₁₆	EC	„extended ID1 temporary“
EC_RE	29 ₁₆	EC	„read (extended ID1) error“

issue date 9.11.2011

8.3.2 Mailbox commands

IDLE:

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	00 ₁₆							
2	T	circuit						

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	00 ₁₆							
2	T	result						

READ_IDI:

With this call the input data values of all AS-i slaves are read out of the AS-i/PROFIBUS Gateway in addition to the cyclic data exchange. Though the mailbox command READ_IDI transmits all Execution-Control-Flags (bytes 3 and 4).

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	41 ₁₆							
2	T	circuit						

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	41 ₁₆							
2	T	result						
3	–							Pok
4	OR	APF	NA	CA	AAv	AAs	s0	Cok
5	–				slave 1A			
6	slave 2A				slave 3A			
...	...							
30	slave 30B				slave 31B			

- Pok Periphery_Ok
- S0 LDS.0
- AAs Auto_Address_Assign
- AAv Auto_Address_Available
- CA Configuration_Active
- NA Normal_Operation_Active
- APF APF
- OR Offline_Ready
- Cok Config_Ok

Issue date 9.11.2001

WRITE ODI:

With this call the output data values of all AS-i slaves are written in addition to the cyclic data exchange.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	42 ₁₆							
2	T	circuit						
3	—				slave 1A			
4	slave 2A				slave 3A			
...	...							
34	slave 30B				slave 31B			

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	42 ₁₆							
2	T	result						

Set Permanent Parameter (SET PP):

With this call, a parameter value for the specified AS-i slave is configured on the AS-i/PROFIBUS Gateway. The value is stored permanently in the EEPROM of the Gateway.

The configured parameter is not transferred immediately by the AS-i/PROFIBUS Gateway to the AS-i slave. The configured parameter value is only transferred when the AS-i slave is activated after turning on the power supply on the AS-i/PROFIBUS Gateway.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	43 ₁₆							
2	T	circuit						
3	–		B	slave address				
4	–				PP			

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	43 ₁₆							
2	T	result						

Get Permanent Parameter (GET PP):

With this call, a slave-specific parameter value stored on the EEPROM of the AS-i/ PROFIBUS Gateway is read.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	01 ₁₆							
2	T	circuit						
3	–		B	slave address				

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	01 ₁₆							
2	T	result						
3	–				PP			

Write Parameter (WRITE P):

The AS-i slave parameter value transferred with the command is passed on to the addressed AS-i slave.

The parameter is stored on the AS-i/PROFIBUS Gateway only temporarily and is not entered as a configured parameter in the EEPROM!

The AS-i slave transfers its current parameter value in the response (parameter echo). This can deviate from the value that has just been written according to the AS-i master specification. The AS-i slave response is returned as a parameter echo in the response data.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	02 ₁₆							
2	T	circuit						
3	–		B	slave address				
4	–				parameter			

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	02 ₁₆							
2	T	result						
3	–				slave response			

Meaning of bit B:

B = 0 Single AS-i slave or A-slave

B = 1 B-slave

Read Parameter (READ PI):

This call returns the current parameter value (actual parameter) of an AS-i slave sent by the AS-i/PROFIBUS Gateway.

This value must not be confused with the parameter echo that is supplied by the AS-i slave as a response to the write_parameter job.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	03 ₁₆							
2	T	circuit						
3	–		B	slave address				

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	03 ₁₆							
2	T	result						
3	–				PI			

Meaning of bit B:

B = 0 Single AS-i slave or A-slave

B = 1 B-slave

Store Actual Parameters (STORE PI):

With this call, the configured parameters stored on the EEPROM are overwritten with the current, permanently stored (actual) parameters; in other words, the parameters of all the AS-i slaves are configured.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	04 ₁₆							
2	T	circuit						

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	04 ₁₆							
2	T	result						

Set Permanent Configuration (SET_PCD):

This call sets the following configuration data for the addressed AS-i slave:

- I/O configuration
- ID code
- Extended ID1 code
- Extended ID2 code

The configuration data are stored permanently on the EEPROM of the AS-i/PROFIBUS Gateway and are used as the expected configuration by the AS-i master in the protected mode. The configuration data are specified by the manufacturer of the AS-i slave.

If the addressed AS-i slave does not support an extended ID code 1/2, the value F_{hex} must be specified.

When this command is executed, the AS-i master changes to the offline phase and then changes back to the normal mode (warm restart on the AS-i master).

This command can only be executed in the configuration mode.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	25_{16}							
2	T	circuit						
3	–		B	slave address				
4	xID2				xID1			
5	ID				I0			

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	25_{16}							
2	T	result						

Meaning of bit B:

B = 0 Single AS-i slave or A-slave

B = 1 B-slave

Get Extended Permanent Configuration (GET_PCD):

This call reads the following configuration data (configured data) of an addressed AS-i slave stored on the EEPROM of the AS-i master:

- I/O configuration
- ID code
- Extended ID1 code
- Extended ID2 code

The configuration data are specified by the manufacturer of the AS-i slave.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	26 ₁₆							
2	T	circuit						
3	–		B	slave address				

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	26 ₁₆							
2	T	result						
3	xID2				xID1			
4	ID				IO			

Meaning of bit B:

B = 0 Single AS-i slave or A-slave

B = 1 B-slave

Store Actual Configuration (STORE_CDI):

With this call, the (actual) configuration data (I/O configuration, ID code, extended ID1 code and extended ID2 code) of all AS-i slaves are stored permanently in the EEPROM as the (expected) configuration data. The list of activated AS-i slaves (LAS) is adopted in the list of permanent AS-i slaves (LPS).

When this command is executed, the AS-i master changes to the offline phase and then changes back to the normal mode (warm restart on the AS-i master).

This command can only be executed in the configuration mode.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	07 ₁₆							
2	T	circuit						

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	07 ₁₆							
2	T	result						

Read Actual Configuration (READ CDI):

With this call, the following configuration data of an addressed AS-i slave obtained by the AS-i master on the AS-Interface are read.

- I/O configuration
- ID code
- Extended ID1 code
- Extended ID2 code

The configuration data are specified by the manufacturer of the AS-i slave.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	28 ₁₆							
2	T	circuit						
3	–		B	slave address				
Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	28 ₁₆							
2	T	result						
3	xID2				xID1			
4	ID				IO			

Meaning of bit B:

B = 0 Single AS-i slave or A-slave

B = 1 B-slave

SET LPS:

With this call, the list of configured AS-i slaves is transferred for permanent storage in the EEPROM of the master.

When this command is executed, the AS-i master changes to the offline phase and then changes back to the normal mode (warm restart on the AS-i master).

This command can only be executed in the configuration mode.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	29 ₁₆							
2	T	circuit						
3	00 ₁₆							
4	7A	&A	5A	4A	3A	2A	1A	–
...	...							
11	31B	30B	29B	28B	27B	26B	25B	24B

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	29 ₁₆							
2	T	result						

GET LPS:

With this call, the following entry is read out of the AS-i/PROFIBUS Gateway: The list of projected AS-i slaves (LPS).

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	44 ₁₆							
2	T	circuit						

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	44 ₁₆							
2	T	result						
3	7A	&A	5A	4A	3A	2A	1A	0A
...	...							
10	31B	30B	29B	28B	27B	26B	25B	24B

GET LAS:

With this call, the following entry is read out of the AS-i/PROFIBUS Gateway: The list of activated slaves (LAS).

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	45 ₁₆							
2	T	circuit						

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	45 ₁₆							
2	T	result						
3	7A	&A	5A	4A	3A	2A	1A	0A
...	...							
10	31B	30B	29B	28B	27B	26B	25B	24B

Issue date 9.11.2011

GET LDS:

With this call, the following entry is read out of the AS-i/PROFIBUS Gateway: The list of detected AS-i slaves (LDS).

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	46 ₁₆							
2	T	circuit						
Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	46 ₁₆							
2	T	result						
3	7A	&A	5A	4A	3A	2A	1A	0A
...	...							
10	31B	30B	29B	28B	27B	26B	25B	24B

GET FLAGS:

With this call, the following entry is read out of the AS-i/PROFIBUS Gateway: The flags according to the AS-i slave specification.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	47 ₁₆							
2	T	circuit						
Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	47 ₁₆							
2	T	response						
3	–							Pok
4	OR	APF	NA	CA	AAv	AA _s	S0	Cok
5	–					AA _e	OL	DX

Pok Periphery_Ok
This flag is set when no AS-i slave is signaling a peripheral fault.

S0 LDS.0
This flag is set when an AS-i slave exists with address 0.

- AAs** **Auto_Address_Assign**
This flag is set when the automatic address programming is possible (in other words, **AUTO_ADDR_ENABLE** = 1 and there is no "incorrect" slave connected to the AS-i Interface).
- AAv** **Auto_Address_Available**
This flag is set when the automatic address programming can be executed (in other words, exactly one AS-i slave is currently out of operation).
- CA** **Configuration_Active**
The flag is set in the configuration mode and reset in the protected mode.
- NA** **Normal_Operation_Active**
This flag is set when the AS-i master is in normal operation.
- APF** **APF**
This flag is set when the voltage on the AS-i cable is too low.
- OR** **Offline_Ready**
The flag is set when the offline phase is active.
- Cok** **Config_Ok**
This flag is set when the desired (configured) and actual configuration match.
- AAe** **Auto_Address_Enable**
This flag indicates whether the automatic address programming is enabled (bit = 1) or disabled (bit = 0) by the user.
- OL** **Off-line**
This flag is set when the mode is to be changed to OFFLINE or this mode has already been adopted.
- DX** **Data_Exchange_Active**
If the "Data_Exchange_Active" flag is set, the data exchange between AS-i master and slaves is available in the dataexchange phase. If this bit is not set the data exchange is not available. The read ID telegrams are transmitted to the slave.
The bit is set if the AS-i master enters the offline phase.

SET_OP_MODE:

This call changes the module between the configuration mode and the protected mode.

In the protected mode, only AS-i slaves are activated that are entered in the LPS and whose expected and actual configurations match, in other words, when the I/O configuration and ID codes of the detected AS-i slaves are identical to the configured values.

In the configuration mode, all detected AS-i slaves (except for AS-i slave "0") are activated. This also applies to AS-i slaves in which there are differences between the expected and actual configuration.

The "OPERATION MODE" bit is stored permanently; in other words, it is retained following a cold/warm restart.

When you change from the configuration mode to the protected mode, there is a warm restart on the AS-i master (change to the offline phase followed by a change to the online mode).



Note

If an AS-i slave with address "0" is entered in the LDS, the AS-i/PROFIBUS Gateway cannot change from the configuration mode to the protected mode.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	0C ₁₆							
2	T	circuit						
3	operation mode							
Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	0C ₁₆							
2	T	result						

Meaning of bit operation mode:

0 = protected mode

1 = configuration mode

SET OFFLINE:

This call switches between the online and offline mode.

The online mode is the normal operating situation for the AS-i master. Here, the following jobs are processed cyclically:

- During the data exchange phase, the fields of the output data are transferred to the slave outputs for all AS-i slaves in the LAS. The addressed AS-i slaves transfer the values of the slave inputs to the master when the transfer was free of errors.
- This is followed by the inclusion phase in which there is a search for the existing AS-i slaves and newly added AS-i slaves are entered in the LDS or LAS.
- In the management phase, jobs from the user such as writing parameters are executed.

In the offline mode, the AS-i/PROFIBUS Gateway only processes jobs from the user. (Jobs that involve the immediate addressing of an AS-i slave are rejected with an error.) There is no cyclic data exchange with the AS-i slaves.

The OFFLINE = TRUE bit is not permanently stored; in other words, following a cold/warm restart, the AS-i/PROFIBUS Gateway is once again in the online mode.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	0A ₁₆							
2	T	circuit						
3	Off-Line							

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	0A ₁₆							
2	T	result						

The master changes to the Offline phase, if there is a 1 written in byte 3.

The master will change to online mode if there is a 0 written in byte 3.

SET DATA EX:

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	48 ₁₆							
2	T	circuit						
3	Data_Exchange_Active							

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	48 ₁₆							
2	T	result						

Change Slave Address (SLAVE_ADDR):

With this call, the AS-i address of an AS-i slave can be modified.

This call is mainly used to add a new AS-i slave with the default address "0" to the AS-Interface. In this case, the address is changed from "AS-i slave address old" = 0 to "AS-i slave address new".

This change can only be made when the following conditions are fulfilled:

1. An AS-i slave with "AS-i slave address old" exists.
2. If the old AS-i slave address is not equal to 0, then an AS-i slave with address "0" cannot be connected at the same time.
3. The "AS-i slave address new" must have a valid value.
4. An AS-i slave with "AS-i slave address new" must not exist.

Note: When the AS-i slave address is changed, the AS-i slave is not reset, in other words, the output data of the AS-i slave are retained until new data are received at the new address.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	0D ₁₆							
2	T	circuit						
3	–		B	source address				
4	–		B	target address				

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	0D ₁₆							
2	T	result						

Meaning of bit B:

B = 0 Single AS-i slave or A-slave

B = 1 B-slave

Set Auto Address Enable (SET_AAE):

This call can enable or disable the "automatic address programming" function

The AUTO_ADDR_ENABLE bit is stored permanently; in other words, it is retained after a warm/hot restart on the AS-i master.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	0B ₁₆							
2	T	circuit						
3	Auto_Address_Enable							

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	0B ₁₆							
2	T	result						

EXEC CMD:

With this call the master gets a message from the host that a message should be transmitted to the AS-i slaves.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	49 ₁₆							
2	T	circuit						
3	–		B	slave address				
4	–			info5				

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	49 ₁₆							
2	T	result						
3	–			info4				

Meaning of bit B:

B = 0 Single AS-i slave or A-slave

B = 1 B-slave

GET LPF:

With this call, the list of peripheral faults (LPF) signaled by the AS-i slaves is read out from the AS-i master. The LPF is updated cyclically by the AS-i master. Whether an when an AS-i slave signals faults of the attached peripherals (for example wire break) can be found in the description of the AS-i slave.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	3E ₁₆							
2	T	circuit						

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	3E ₁₆							
2	T	result						
3	7A	&A	5A	4A	3A	2A	1A	0A
...	...							
10	31B	30B	29B	28B	27B	26B	25B	24B

Issue date 9.11.2001

Write AS-i Slave Extended ID1 (WRITE_XID1):

With this call, the extended ID1 code of an AS-i slave with address "0" can be written directly over the AS-i cable. The call is intended for diagnostic purposes and is not required in the normal master mode.

The AS-i master passes on the extended ID1 code to the AS-i slave without any plausibility check.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	3F ₁₆							
2	T	circuit						
3	–				xID1			

Response								
Byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	3F ₁₆							
2	T	result						

RD_7X_IN:

With this command the four 16 bit channels of an AS-i input slave according to the slave profil 7.3 can be read.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	50 ₁₆							
2	T	circuit						
3	–		0	slave address				

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	50 ₁₆							
2	T	result						
3	channel 1, high byte							
...	...							
10	channel 4, low byte							

WR 7X OUT:

With this command the four 16 bit channels of an AS-i output slave according to the slave profil 7.3 can be written.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	51 ₁₆							
2	T	circuit						
3	—		0	slave address				
4	channel 1, high byte							
...	...							
11	channel 4, low byte							

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	51 ₁₆							
2	T	result						

RD 7X OUT:

With this command the four 16 bit channels of an AS-i output slave according to the slave profil 7.3 can be read out of the AS-i/PROFIBUS Gateway.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	52_{16}							
2	T	circuit						
3	–		0	slave address				

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	52_{16}							
2	T	result						
3	channel 1, high byte							
...	...							
10	channel 4, low byte							

RD 7X IN X:

With this command the four 16 bit channels of 4 AS-i input slaves with successive addresses according to the slave profil 7.3 can be read.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	53_{16}							
2	T	circuit						
3	—		0	1st slave address				
Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	53_{16}							
2	T	result						
3	1st slave, channell 1, high byte							
...	...							
34	4th slave, channel 4, low byte							

WR 7X OUT X:

With this command the four 16 bit channels of 4 AS-i output slaves with successive addresses according to the slave profil 7.3 can be written.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	54 ₁₆							
2	T	circuit						
3	—		0	1st slave address				
4	1st slave, channel 1, high byte							
...	...							
35	4th slave, channel 4, low byte							
Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	54 ₁₆							
2	T	result						

RD 7X OUT X:

With this command the four 16 bit channels of 4 AS-i output slaves with successive addresses according to the slave profile 7.3 can be read.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	55 ₁₆							
2	T	circuit						
3	–		0	1st slave address				

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	55 ₁₆							
2	T	result						
3	1st slave, channel 1, high byte							
...	...							
34	4th slave, channel 4, low byte							

READ ODI:

With this call the output data values of all AS-i slaves is read out of the AS-i/ PROFIBUS Gateway.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	56 ₁₆							
2	T	circuit						

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	56 ₁₆							
2	T	result						
3	–				slave 1A			
	slave 2A				slave 3A			
...				...				
34	slave 30B				slave 31B			

Get LPS. Get LAS. Get LDS. Get Flags (GET LISTS):

With this call, the following entries are read out of the AS-i/PROFIBUS Gateway:

- The list of active AS-i slaves (LAS)
- The list of detected AS-i slaves (LDS)
- The list of projected AS-i slaves (LPS)
- The flags according to the AS-i slave specification

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	30 ₁₆							
2	T	circuit						

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	30 ₁₆							
2	T	result						
3	7A	6A	5A	4A	3A	2A	1A	0A
...	LAS							
10	31B	30B	29B	28B	27B	26B	25B	24B
11	7A	6As	5A	4A	3A	2A	1A	0A
...	LDS							
19	31B	30B	29B	28B	27B	26B	25B	24B
20	7A	6As	5A	4A	3A	2A	1A	0A
...	LPS							
26	31B	30B	29B	28B	27B	26B	25B	24B
27	—							Pok
28	OR	APF	NA	CA	AAv	AAs	S0	Cok
29	—					AAe	OL	DX

Pok Periphery_Ok
 S0 LDS.0
 AAs Auto_Address_Assign
 AAv Auto_Address_Available
 CA Configuration_Active
 NA Normal_Operation_Active
 APF APF
 OR Offline_Ready
 Cok Config_Ok
 AAe Auto_Address_Enable
 OL Off-line
 DX Data_Exchange_Active

GET LCS:

With this call, the List of Corrupted Slaves (LCS) is read out of the AS-i/PROFIBUS Gateway.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	60_{16}							
2	T	circuit						

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	60_{16}							
2	T	result						
3	7A	6A	5A	4A	3A	2A	1A	0A
...	...							
10	31B	30B	29B	28B	27B	26B	25B	24B

GET LOS:

With this call, the List of Offline Slaves (LOS) is read out of the AS-i/PROFIBUS Gateway (see chapter 7).

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	61_{16}							
2	T	circuit						

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	61_{16}							
2	T	result						
3	7A	6A	5A	4A	3A	2A	1A	0A
...	...							
10	31B	30B	29B	28B	27B	26B	25B	24B

SET LOS:

With this call, the List of Offline Slaves is written to the AS-i/PROFIBUS Gateway (see chapter 7).

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	62_{16}							
2	T	circuit						
3	7A	6A	5A	4A	3A	2A	1A	0A
...	...							
10	31B	30B	29B	28B	27B	26B	25B	24B

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	62_{16}							
2	T	result						

GET TECA:

With this call the error counters of all single slaves / A-slaves can be read (see chapter 7).

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	63 ₁₆							
2	T	circuit						

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	63 ₁₆							
2	T	result						
3	APF							
4	slave 1A							
...	...							
34	slave 31A							

GET TECB:

With this call the counts of the error counters for B-slaves are read out (see chapter 7).

With every read out of the counts the error counters are restarted.

The counts are read out via the correspondending host interface and will be deleted with every read access. The counter value is limited to 254. 255 means counter overflow.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	64_{16}							
2	T	circuit						

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	64 ₁₆							
2	T	result						
3	APF							
4	slave 1B							
...	...							
34	slave 31B							

GET TEC X:

With this call beginning by a definite slave address the counts of the n error counters are read out (see chapter 7).

With every read out of the counts the error counters are restarted.

The counts are read out via the correspondending host interface and will be deleted with every read access. The counter value is limited to 254. 255 means counter overflow.

Anfrage								
Byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	66 ₁₆							
2	T	Kreis						
3	1. Slave-Adresse							
4	Anzahl der Zähler							

Antwort															
Byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰							
1	66 ₁₆														
2	T	Ergebnis													
3	Zähler 1														
...	...														
n	Zähler n - 2														

EXT DIAG:

With this call, the conditions when to set the ExtDiag bit can be selected.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	71 ₁₆							
2	T	circuit						
3	CF							
4	APF							
5	PF							
6	CS							

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	71 ₁₆							
2	T	result						

- CF ExtDiag is set, if ConfigError ≡ 1
APF ExtDiag is set, if APF ≡ 1
PF ExtDiag is set, if PeripheryFault ≡ 1
CS ExtDiag is set, if LCS is not empty

OPTIONS:

With this call, the options string is read out of the AS-i/PROFIBUS Gateway.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	74 ₁₆							
2	T	circuit						

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	74 ₁₆							
2	T	result						
3	character 1							
...	...							
18	character 16							

BUTTONS:

With this call, the use of the buttons can be enabled/disabled.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	75 ₁₆							
2	T	circuit						
3	ButtonsDisabled							

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	75 ₁₆							
2	T	result						

RD_EXT_DIAG:

With this call, the conditions when the ExtDiag bit is set can be read.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	7B ₁₆							
2	T	circuit						

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	75 ₁₆							
2	T	result						
3	CF							
4	APF							
5	PF							
6	CS							
7	FD							

issue date 9.11.2001

- CF ExtDiag is set by ConfigError \equiv 1
- APF ExtDiag is set by APF \equiv 1
- PF ExtDiag is set by PeripheryFault \equiv 1
- CS ExtDiag is set, if LCS is not empty
- FD Diagnosis will updated still only then, if this is dictated by the norm of PROFIBUS.
Diagnosis data are doubtful not actual

INVERTER:

With that call an AS-i slave for frequency inverters is switched to the mode to get four 16 bit values via the AS-i analog profile 7.3 and afterwards switched to the selcted destination parameter.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	7C ₁₆							
2	T	circuit						
3	slave address							
4	destination parameter							
5	value 1, high byte							
6	value 1, low byte							
7	value 2, high byte							
8	value 2, low byte							
9	value 3, high byte							
10	value 3, low byte							
11	value 4, high byte							
12	value 4, low byte							

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	7C ₁₆							
2	T	result						

8.3.3 Mailbox example

Command RD_7X_IN: Reading of analog input values

PROFIBUS-DP V0: cyclic data exchange

Used ID/module in the GSD file: 12 bytes management

Meaning of the bytes:

Request: RD_7X_IN	
Byte 1	50 _{hex} (RD_7X_IN)
Byte 2	00 _{hex} (master 1, single master)
Byte 3	1D _{hex} (slave address 29)
Byte 4	00 _{hex}
...	...
Byte 12	00 _{hex}

Response	
Byte 1	00 _{hex}
Byte 2	00 _{hex}
Byte 3	00 _{hex}
Byte 4	00 _{hex}
...	...
Byte 12	00 _{hex}

The mailbox call has not been answered with the valid values, because the toggle bit has not been set.

Set of Toggle bit:

Request	
Byte 1	50 _{hex}
Byte 2	80 _{hex} (Toggle bit, master 1, single master)
Byte 3	1D _{hex} (slave address 29)
Byte 4	00 _{hex}
...	...
Byte 12	00 _{hex}

Response	
Byte 1	50 _{hex}
Byte 2	80 _{hex} (Toggle bit, master1)
Byte 3	analog channel 1 high byte _{hex}
Byte 4	analog channel 1 low byte _{hex}
Byte 5	analog channel 2 high byte _{hex}
Byte 6	analog channel 2 low byte _{hex}
Byte 7	analog channel 3 high byte _{hex}
Byte 8	analog channel 3 low byte _{hex}
Byte 9	analog channel 4 high byte _{hex}
Byte 10	analog channel 4 low byte _{hex}
Byte 11	00 _{hex} not usedt
Byte 12	00 _{hex} not usedt

To get the input data again, the T-bit has to be reset aso.

If a mailbox command is used via PROFIBUS-DP V1, it is not necessary to use the toggle bit.

9 Commissioning Tools and Accessories


The AS-i circuit on the AS-i/PROFIBUS Gateway can be put into operation with the comfortable Windows software "AS-i Control" Tools.

This software communicates with the AS-i/PROFIBUS gateway by means of a PROFIBUS DP Mastersimulator DP V1 or Serial PROFIBUS Master, which converts the RS 232-signals of the PC to PROFIBUS.

9.1 Windows Software AS-i Control Tools


The Windows software AS-i Control Tools enables you to configure the AS-i circuit in a very comfortable manner.

1. For that purpose plug in a PROFIBUS-DP Master Simulator DP V1 or serial PROFIBUS Master to the D-SUB-connector of the AS-i/PROFIBUS gateway and connect the device with a fully covered cable to the serial interface of your PC.
2. Start the AS-i Control Tools.
3. Call the command Master | New.




4. Choose PROFIBUS as protocol.


- Do the appropriate settings. (e.g. serial interface COM 2, station address <auto>, AS-i circuit 1)



- Call the command Master | AS-i configuration.
The AS-i configuration editor will be started. All detected and projected AS-i slaves are displayed in this window.



7. Click on a slave entry to open the dialogbox slave configuration.



The 'Slave configuration' dialog box contains the following fields and controls:

- Selected Slave:** A text box containing the value '2'.
- Change address to:** A text box containing the value '2'.
- Buttons:** 'Close', 'Help', 'Less...', and 'Store' are located on the right side.
- Inputs:** Three checkboxes labeled '0', '1', and '2', all of which are checked.
- Outputs:** A checkbox labeled '3' which is unchecked.
- Current parameters:** Four checkboxes labeled '0', '1', '2', and '3'. '0', '2', and '3' are checked; '1' is unchecked.
- Power up parameters:** Four checkboxes labeled '0', '1', '2', and '3'. '0', '1', '2', and '3' are all checked.
- Detected:** A text box containing '11' and a dropdown menu showing 'AS-i sensor'.
- Projected:** A text box containing '10' and a dropdown menu showing '2x2 input module'.
- Username:** An empty text box.
- Device Type:** An empty dropdown menu.

This dialog box is for changing a slave address, setting AS-i parameters or AS-i configuration data. Additionally you can test inputs and outputs.

A very easy approach to configure the AS-i circuit is connecting each AS-i slave to the line and setting the AS-i slave address one after the other. After that press the button "Store configuration" to adopt the detected AS-i circuit to the AS-i master as projected data.

Moreover you can use the **AS-i Address Assistant**. This tool changes automatically the address of an AS-i slave to the desired address after plugging the slave to the AS-i line. The desired AS-i configuration can be created off-line before and stored to a file. When you build up the plant you only have to plug the AS-i slaves to the AS-i line one after the other.

Further descriptions to all features of the software can be obtained from the integrated help.

9.2 PROFIBUS-DP master simulator

The PROFIBUS DP master simulator is a simple universal tool for data exchange with PROFIBUS slaves of almost all manufacturers via PROFIBUS DP. The PROFIBUS DP master simulator can exchange data with a PROFIBUS slave even without GSD file, without type file and without a PROFIBUS master. Without further inputs or additional files the PROFIBUS slave can be put into operation with the default I/O width. Input data can be read and output data be written. This is particularly important with time-critical troubleshoot at the PROFIBUS, if e.g. diskettes of several manufacturers are not seizable. Beyond that the PROFIBUS DP master simulator enables also the

use of GSD files, of course, as well as the input of special configurations for starting data exchange with PROFIBUS slaves. Addressing of PROFIBUS slaves - above all the IP67-Module without address switches - is likewise possible.

The scope of supply of the PROFIBUS DP master simulator contains a simple PROFIBUS converter. The PROFIBUS converter is the ideal interface converter between the RS 232 interface of the PC and the PROFIBUS. The converter is very compact and needs no additional external power supply. Therefore it is in the best way suitable also for mobile build-up with a laptop or a notebook. The PROFIBUS converter can simply be connected between the PROFIBUS slave and the RS 232 interface cable.

10 Appendix: Displays of the Figure Display

In the basic state of the configuration mode, the display shows one after the other the addresses of all detected slaves at a rate of two per second. A blank display means that the *LDS* is empty, i.e. no slaves were detected.

In the basic state of the protected operating mode, the display is either blank or displays the address of a faulty assignment (see chapter 6.3.2).

During manual address programming, the slave address display has a different meaning (see chapter 6.4 and 6.5).

All displayed numbers that are bigger than 31 and therefore can not be interpreted as a slave address are status or error messages of the master. They have the following meanings:

39	Advanced AS-i diagnostics: If a 39 appears on the display after pressing the 'set'-button a short-time AS-i power failure occurred.
40	The AS-i master is in off-line phase.
41	The AS-i master is in detection phase.
42	The AS-i master is in activation phase.
43	The AS-i master starts the normal operating mode.
70	Hardware error: The AS-i master's EEPROM cannot be written to.
72	Hardware error: The PIC processor does not respond.
73	Hardware error: The PIC processor does not respond.
74	Checksum error in the EEPROM.
75	Error in the external RAM.
76	Error in the external RAM.
77	AS-i control software error: Stack overflow (AS-i control II)
78	AS-i control software error: Checksum error in the control program.
80	Error while attempting to exit the configuration mode: A slave with address zero exists.
81	General error while changing a slave address.
82	The front panel operation is blocked. Until the next power-up of the AS-i master the accessing to the device only from the host via the interface.
83	Program reset of the AS-i Control programm: The AS-i Control programm is just read out of EEPROM and copied into the RAM.
88	Display test while starting up the AS-i master
90	Error while changing a slave address in protected operating mode: No slave with address 0 existing.
91	Error while changing slave address: Target address is already occupied.
92	Error while changing slave address: New address could not be set.
93	Error while changing slave address: New address could only be stored volatile in the slave.
94	Error while changing slave address in protected operating mode: Slave has wrong configuration data.

95	Error while changing slave address in protected operating mode: The configuration error was caused by one slave too many (instead of one missing slave).
----	--

11 Appendix: The First Commissioning of AS-i



Note

In this chapter an example is given of how to put an AS-i network into operation quickly and easily and without the need for external devices. The addressing of the components connected to the AS-i network can be performed directly on the AS-i master. It is of course more comfortable to do the addressing with a hand-held programming device or with the Windows software AS-i Control Tools. However, it is possible to configure even complex networks using only the AS-i master.

What to do ?	How to go about it?
See to it that the AS-i master is properly supplied with power.	Connect the AS-i power supply unit to the terminals AS-i + and AS-i - of the master, connect the ground terminal. Turn on the power supply.
After the self-test: the LEDs "power", "config err", "U ASI" and "prj mode" are on. The figure display shows "40": the AS-i master is in the off-line phase. Shortly after that a "41" will be displayed: the AS-i master stays in the detection phase.	
Switch the device to the projecting mode, if the yellow LED does not light up.	Press the "modeMODE"-button for approx. five seconds.
The yellow LED "prj mode" lights up. The device is now in projecting mode.	
Add a slave with the address 0 to the AS-i line.	Connect the slave's terminals with the terminals AS-i +/- of the master.
The green LED "ASI active" lights up. The figure display shows "0". This means the AS-i master has detected the slave.	
Change the slave address to address 1.	Select address 1 by pressing the "set" button shortly, if necessary repeatedly. When a "1" appears on the display press the "set" button for approx. five seconds until the display blinks. Press again shortly the "set" button to assign the new address to the slave.
The AS-i master detects the slave with address 1 and displays "1".	
Connect another slave with address 0 to the AS-i line and allocate the address 2 to it.	Connect the slave to the AS-i line. The addressing is the same as for the previous slave.
The addresses of all slaves detected are now displayed sequentially.	
Change to the protected operating mode and store the AS-i configuration.	Leave the configuration mode by pressing the "mode" button for at least five seconds until the "prj mode" LED goes out.

AS-Interface Appendix: The First Commissioning of AS-i

What to do ?	How to go about it?
<p>The configuration of the AS-i master is now finished. Now the hierarchically higher fieldbus system can be put into operation. The gateway stays in the off-line phase (Display dark, the LED ASI active is out), until the hierarchically higher fieldbus system operates properly.</p>	

issue date 9.11.2001


12 Appendix: Putting PROFIBUS into Operation with a Siemens S5

This chapter shows exemplarily the putting into operation of an AS-i/PROFIBUS gateway on PROFIBUS for the PLC Simatic S5 135 of Siemens with the PROFIBUS master card IM 308 C. The configuration software used is the Siemens COM PROFIBUS 3.0 (German version).

12.1 Putting into Operation in Easy Mode


1. Copy the GSD-file "bwes1742.gsd" (or all GSD-files) from the diskette "AS-i/PROFIBUS Gateway IBM PC Software" from the directory A:\GSD to the directory \GSD of the software COM PROFIBUS 3.0.
2. Start the configuration software COM PROFIBUS 3.0
3. Execute the command "File | Scan GSD-Files".
4. Execute the command "File | New".

The dialog box "Master & Host Selection" appears.




Select your PROFIBUS master.

5. With the command "Configure | Master Parameters..." you can select the baudrate and other bus parameters.



Appendix: Putting PROFIBUS into Operation with a Siemens S5

6. In the window "DP Master System" there is a ledge with several PROFIBUS slaves. Click on AS-i and drag the icon to the PROFIBUS in the window above.



7. After a second mouse click the dialogbox for the selection of the PROFIBUS station address appears. Setting of the AS-i/PROFIBUS gateway's station address see chapter 6.6:




AS-i/PROFIBUS Gateway

Appendix: Putting PROFIBUS into Operation with a Siemens S5


8. and afterwards the dialogbox for the selection of the device type (Slave Parameters):

Choose "AS-i/DP" as station type. This name stands for the GSD-file with the settings for the easy mode.

9. Afterwards, your PROFIBUS system looks as follows:



10. Select the PROFIBUS slave. With the command "Configure | Slave Parameters... | Configure..." you get to the dialogbox "Configure".



The fields "I Addr." and "O Addr." hold the start addresses for the AS-i data. The easiest way to set the addresses is with "Auto Addr.". From these addresses 16 bytes of AS-i data each are mapped to the address space of your PLC.

This AS-i data can be processed with your user program by means of load and transfer operations.

11. After closing this dialogbox save your project with the command "File | Save".
 12. The last step is exporting the data to a memory card with the command "File | Export | Memory Card..."

12.2 Putting into Operation in Professional Mode

The AS-i/PROFIBUS-DP gateway shall now be put into operation for the following AS-i circuit:

3 AS-i slaves, all slaves AS-i ID 0

Slave 1: 4 inputs

Slave 2: 4 outputs

Slave 3: 2 inputs, 2 outputs

The transmission of AS-i Control user memory shall be possible:

from user memory byte 0 read 21 user memory bytes


don't write user memory bytes

1. Copy the GSD file "bwps1742.gsd" (or all GSD files) from the diskette "AS-i/PROFIBUS-Gateway IBM PC Software" from the directory A:\GSD to the directory \GSD of the software COM PROFIBUS 3.0.
2. Start the configuration software COM PROFIBUS 3.0
3. Execute the command "File | Scan GSD-Files".

AS-i/PROFIBUS Gateway


Appendix: Putting PROFIBUS into Operation with a Siemens S5

4. Execute the command “File | New”.




The dialogbox “Master & Host Selection” appears.
Select your PROFIBUS master.

5. With the command “Configure | Master Parameters...” you can select the baudrate and other bus parameters.



Appendix: Putting PROFIBUS into Operation with a Siemens S5

6. In the window "DP Master System" there is a ledge with several PROFIBUS slaves.



Click on AS-i and drag the icon to the PROFIBUS in the window above.


7. After a second mouse click the dialogbox for the selection of the PROFIBUS station address appears:



AS-i/PROFIBUS Gateway


Appendix: Putting PROFIBUS into Operation with a Siemens S5

8. and afterwards the dialogbox for the selection of the device type (Slave Parameters):



Choose "AS-i/DP-Profi" as station type. This name stands for the GSD-file with the settings for the professional mode.


9. Afterwards, your PROFIBUS system looks like as follows:



10. Select the PROFIBUS slave. With the command “Configure | Slave Parameters... | Configure...” you get to the dialogbox “Configure”.



11. Choose as first identification from the dialogbox “Order No.” an identification for the largest used AS-i slave address:



12. Choose as second identification from the dialogbox “Order No.” the identification “Managementkanal 3 Byte E/A”.

13. Choose as third identification from the dialogbox "ID" the appropriate length for user flag bytes.

14. If the AS-i Control user memory field is bigger than 16 bytes the identification has to be put together out of several identification bytes. Therefore a fourth identification with the length 5 bytes has to be added, to transmit a whole user memory field of 21 bytes.

15. The dialogbox "Configure" now looks as follows:

Konfigurieren: AS i/DP M3 #4					
	Kennung	Bestellnummer	Kommentar	E-Adr.	A-Adr.
0	16DX	2 Byte E/A (2-3 Slaves)		P000	P000
1	24DX	Managementkanal 3 Byte E/A		P002	P002
2	03I		Merkerkennung 1	P005	
3	020		Merkerkennung 2	P021	
4					
5					
6					
7					
8					
9					
10					
11					
12					
13					

The fields "I Addr." and "O Addr." hold the start addresses for the AS-i data, the management channel and the user memory bytes. The easiest way to set the addresses is with "Auto Addr."

Appendix: Putting PROFIBUS into Operation with a Siemens S5

16. Select the PROFIBUS slave. With the command "Configure | Slave parameters... | Parameterize..." you get to the dialogbox "Parameterize".

	0	1	2	3	4	5	6	7	8	9
0	20	00	15	00	00	00	0f	08	0f	03
10	0f	FF	FF	FF	FF	FF	FF	FF	FF	FF
20	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF
30	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF
40	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF
50	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF
60	FF	FF	FF	FF	FF	FF	FF			

Edit the dialogbox as shown above, to set the user memory fields and to state the AS-i configuration in the parameterization telegram.

17. After closing this dialogbox save your project with the command "File | Save".
18. The last step is exporting the data to a memory card with the command "File | Export | Memory Card..."

The general terms of delivery for products and services produced or provided by the electrical industry as published by the Zentralverband Elektrotechnik und Elektroindustrie (ZVEI) e.V. in its most recent edition as well as the supplementary proviso: "Extended property proviso" are applicable.

We at Pepperl+Fuchs feel obligated to contribute to the future;
this publication is, therefore, printed on paper bleached without the use of chlorine.

One Company, Two Divisions.



Factory Automation Division

Product Range


- Digital and analogue sensors
- in different technologies
 - Inductive and capacitive sensors
 - Magnetic sensors
 - Ultrasonic sensors
 - Photoelectric sensors
- Incremental and absolute rotary encoders
- Counters and control equipment
- Identification Systems
- AS-Interface

Areas of Application

- Machine engineering
- Conveyor or transport
- Packaging and bottling
- Automotive industry

Service Area

Worldwide sales, customer service and consultation via competent and reliable Pepperl+Fuchs associates ensure that you can contact us wherever or whenever you need us. We have subsidiaries worldwide for your convenience.



Process Automation Division

Product Range

- Signal conditioners
- Intrinsically safe interface modules
- Remote Process Interface (RPI)
- Intrinsically safe field bus solutions
- Level control sensors
- Process measuring and control systems engineering at the interface level
- Intrinsic safety training

Areas of Application

- Chemical industry
- Industrial and community sewage
- Oil, gas and petrochemical industry
- PLC and process control systems
- Engineering companies for process systems

<http://www.pepperl-fuchs.com>

USA Headquarters

Pepperl+Fuchs Inc. • 1600 Enterprise Parkway
Twinsburg, Ohio 44087 • Cleveland-USA
Tel. (330) 4 25 35 55 • Fax (330) 4 25 46 07
e-mail: sales@us.pepperl-fuchs.com

Asia Pacific Headquarters

Pepperl+Fuchs Pte Ltd. • P+F Building
18 Ayer Rajah Crescent • Singapore 139942
Tel. (65) 7 79 90 91 • Fax (65) 8 73 16 37
e-mail: sales@sg.pepperl-fuchs.com

Worldwide Headquarters

Pepperl+Fuchs GmbH • Königsberger Allee 87
68307 Mannheim • Germany
Tel. +49 621 7 76-0 • Fax +49 621 7 76-10 00
e-mail: fa-info@de.pepperl-fuchs.com



PEPPERL+FUCHS