





## Operating instructions


### DA5-IU-2K-C/DA5-IU-2K-V

Digital LED display with  
analogue inputs and limit  
values





on  
 Auto  
 000000  
 000000  
 ..f--  
 on  
 Auto  
 000000  
 000000  
 ..f--



YES  
 YES  
 YES  
 YES  
 50 H2  
 19700  
 00  
 000000  
 no

WerkEinstellung  
 factory preset  
 réglage usine

<b>1. Safety instructions and warnings</b>	
1.1 Use according to the intended purpose .....	4
<b>2. Technical Data</b>	
2.1 Miscellaneous Data .....	5
2.2 Electrical Data .....	5
2.2.1 Power Supply .....	5
2.2.2 Inputs .....	5
2.2.3 Outputs .....	6
2.3 Mechanical Data .....	7
2.4 Environmental conditions .....	7
2.5 Delivery .....	7
<b>3. Mounting</b> .....	8
<b>4. Electrical Connections</b>	
4.1 Measuring inputs .....	8
4.2 Control Inputs and Auxiliary Power Supply .....	9
4.3 Power Supply and Alarm Outputs .....	9
<b>5. Parameter Setup</b>	
5.1 Parameter mode .....	10
5.2 Parameter input for Instantaneous Value .....	11
5.2.1 Select range for the input signal .....	11
5.2.2 Set the decimal point for the actual value .....	11
5.2.3 Change the range limits .....	12
5.2.4 Scaling Slope .....	13
5.3 Setting the Scaling Slope	
5.3.1 Enter the number of Scaling points .....	14
5.3.2 Define first Scaling point .....	15
5.3.3 Define second Scaling point .....	15
5.3.4 Define further Scaling points .....	15
5.4 Alarms/Alarm Outputs	
5.4.1 Alarm 1/Output 1 .....	16
5.4.1.1 Alarm 1 off/on .....	16
5.4.1.2 Select mode for output threshold 1 .....	16
5.4.1.3 Hysteresis for threshold 1 .....	17
5.4.1.4 Reset Latch signal at output 1 .....	18
5.4.1.5 Select signal form for output threshold 1 .....	19

5.4.2	Alarms 2/Output 2.....	19
5.4.2.1	Alarm 2 off/on .....	19
5.4.2.2	Select mode for output threshold 2 .....	19
5.4.2.3	Hysteresis for output 2 .....	20
5.4.2.4	Reset Latch signal at output 2.....	20
5.4.2.5	Select signal form for output threshold 2 .....	21
5.5	MIN/MAX value acquisition .....	21
5.5.1	Maximum value monitoring .....	21
5.5.1.1	Resetting the maximum value.....	22
5.5.2	Minimum value monitoring.....	22
5.5.2.1	Resetting the minimum value .....	22
5.5.3	Effect of Overflow/Underflow for MIN/MAX value .....	22
5.6	Mains Hum Filter .....	23
5.7	Setting default value.....	23
5.8	End of setup .....	23
5.9	Check/alter parameters .....	24
<b>6.</b>	<b>Operation .....</b>	<b>24</b>
6.1	Switching over the display during operation .....	25
6.2	Setting the limits during operation.....	26
6.3	Resetting the MIN/MAX value .....	26
6.4	Display Hold .....	27

## 1. Safety instructions and warnings

Only use this display



- in a way according to its intended purpose
- if its technical condition is perfect
- adhering to the operating instructions and the general safety instructions.

1. Before carrying out any installation or maintenance work, make sure that the power supply of the digital display is switched off.
2. Only use this digital display in a way according to its intended purpose.
3. If its technical condition is perfect.
4. Adhering to the operating instructions and the general safety instructions.
5. Adhere to country or user specific regulations.
6. The digital display is not intended for use in areas with risks of explosion and in the branches excluded by the standard EN 61010 Part 1.
7. The digital display shall only operated if it has been correctly mounted in a panel, in accordance with the chapter "Main technical features".

### 1.1 Use according to the intended purpose

The digital display only may be used as a panel-mounted device. Applications of this product may be found in industrial processes and controls, in the branch of the manufacturing lines for the metal, wood, plastics, paper, glass, textile, etc., processing industries.

Overvoltages at the terminals of the digital display must be limited to the values of overvoltage category II.

If the digital display is used to monitor machines or processes in which, in case of a failure of the device or an error made by the operator, there might be risks of damaging the machine or causing accidents to the operators, it is up to you to take appropriate safety measures.

## 2. Technical Data

### 2.1 Miscellaneous Data

Display	5 digit red LED 14.2 mm high
Display range	-19999 ... 99999, with leading zeros suppression
Out of Range Indication	Under-range uuuuu / Over-range ooooo
Data storage	EEPROM, 1 Million storage cycles or 10 Years
Test voltages	EN 61010 Part 1 ; overvoltage category 2, level 2
EMC	Interference emissions EN 50081-2 / EN 55011 Class B Interference resistance EN 61000-6-2

### 2.2 Electrical Data

#### 2.2.1 Power supply

AC power supply	90 ... 260 V AC/max. 6 VA external fuse 100 mA/T
DC power supply	10 ... 30 V DC, max. 2 W, galvanically isolated with inverse polarity protection external fuse 250 mA/T
Mains Hum Filter	digital filter 50 Hz or 60 Hz, programmable

#### 2.2.2 Inputs

Measurement ranges	
Current input (DC)	
Ranges	0 ... 20 mA, 4 ... 20 mA
Resolution	2 $\mu$ A
Voltage drop	max. 2 V bei 20 mA
Max. current	50 mA
Voltage input (DC)	
Ranges	0 ... 10 V, 2 ... 10 V, $\pm$ 10 V
Resolution	1 mV
Input resistance	> 2 M $\Omega$
Max. voltage	$\pm$ 30 V

A/D converter	Dual-Slope
Measuring speed	approx. 2 measurements/s
Linearity	< 0,1% $\pm$ 1 Digit for the whole measuring range at an ambient temperature of 20°C
Zero calibration	automatic
Temperature drift	100 ppm/K





### 2.3 Mechanical Data

Housing	Housing for control panel 96 x 48 mm according to DIN 43 700, RAL 7021
Dimensions (W x H x D)	96 x 48 x 90 mm
Panel cut-out (B x H)	92 <sup>+0,8</sup> x 45 <sup>+0,6</sup> mm
Mounting depth	approx. 83 mm
Weight	approx. 220 g
Protection	IP 65 (on the front side)

#### Connections

Power supply and output: 1 x screw terminal, 8-pole, RM 5.08

Measurement and control input: 1 x screw terminal, 11-pole, RM 3.81

Interfaces: (\*) 1 x screw terminal, 5-pole, RM 3.81

#### Cleaning:

The front of the unit is only to be cleaned with a soft wet (water !) cloth.

### 2.4 Environmental Conditions

Ambient temperature -20°C ... +65°C

Storage temperature -40°C ... +85°C

Climatic stability relative humidity < 75%, without condensation

### 2.5 Delivery includes:

Process display: **DA5-IU-2K-C** oder **DA5-IU-2K-V**

Screw terminal, 8-pole, RM 5.08

Screw terminal, 11-pole, RM 3.81

Screw terminal, 5-pole, RM 3.81(\*)

Clamping bracket


Gasket

Multilingual operating instructions

1 set of self-adhesive symbols


\* only with the interface option

### 3. Mounting



## 4. Electrical connections

View of rear of unit



**Warning:** for 90 ... 260 V AC version. Please apply the power supply after the complete installation. Danger of Death! Please check unit label before applying the power supply.


### 4.1 Measuring Inputs

Current input




1	Current input (I) 0 ... 20 mA / 4 ... 20 mA
2	GND1 (Analogue)

Voltage input



2	GND1 (Analogue)
3	Voltage input (U) 0 ... 10 V, 2 ... 10 V, -10 ... +10 V

### 4.2 Control inputs and auxiliary power supply (U<sub>out</sub>)




1 Alternatively connect directly to DC supply (galvanic separation of control and measurement inputs)

9	GND3 (for U <sub>out</sub> )
10	U <sub>out</sub> +10 V/30 mA
11	U <sub>out</sub> +24 V/50 mA only for power supply 90 ... 260 V AC
8	MP-Input "Reset-Alarm-Latch/Display-Hold"
7	GND2 (KEY/MPI)
6	Keypad lock-out "Key"

### 4.3 Power supply and alarm outputs

Relay output



	DC voltage	AC voltage
7	10 ... 30 V DC	90 ... 260 V AC (N~)
8	GND4 (0 V DC)	90 ... 260 V AC (L~)



**Warning:** at 90 ... 260 V AC version. Please apply the power supply after the complete installation. Danger of Death! Please check unit label before applying the power supply.

## 5. Parameter setup

The parameters have to be set up before putting the unit into operation.

### – Input parameter



The parameters of the scaling slope must be set up depending on the sensor used.

### – Scaling scope

The correspondence between the input signal and the displayed value is given by the scaling slope. The scaling slope is set up by entering pairs of values.

### 5.1 Parameter Mode

To put the unit into set-up mode

1. keep the  key pressed
2. connect the unit with the power supply
3. When the display shows  release the key.

### Getting acquainted with the displays and keys


The selection or the settings can be run through as often as required thanks to the step-through programming method

### Menu item:

The display alternates every 2 seconds between

Menu	<->	Selection
		

Where negative values are permitted, the highest digit will switch from "9" to "-" and only then to "0".

Press the  key to switch to the next digit.

### – Alarms/outputs

Either none, one or two alarm values can be active. Hysteresis and output parameters are also set up. If the set-point is exceeded, a signal will be sent out at the corresponding output and the corresponding LED will be switched on.

The alarms themselves are set up in the operating mode!

### – Mains Hum Filter


To reduce operational interference caused by the 50/60 Hz mains supply you can choose the local mains frequency.

### Entering into the menu:


Either a selection has to be made or a value has to be set up.

Press the  key. The display stops alternating.

### – Making a selection:

Pressing the  key displays all the possible settings one after the other.


### – Enter the selection:


Press the  key. The selected parameter will be stored. The next menu item appears

### – Entering a value:

The flashing digit indicates that it is enabled for entry.

Press the  key, the number will be incremented.


Enter value: Press the  key, the value will be stored. The next menu item appears.

## 5.2 Input Parameters for Instantaneous value

All set-ups related to the input signal and the corresponding displayed value are carried out here.


The displayed value is displayed from the input signal via the scaling slope.

### 5.2.1 Select range for the input signal

Menu <->	Selection	Display range
<b>r R n G E</b>	<b>0 . 1 0 V</b>	(-0,500 ... 10,500)
	<b>2 . 1 0 V</b>	2 ... 10 V (01,500 ... 10,500)
	<b>1 0 . 1 0 V</b>	-10 ... +10 V (-10,500 ... 10,500)
	<b>0 2 0 m A</b>	... 20 mA (-01,000 ... 21,000)
	<b>4 2 0 m A</b>	4 ... 20 mA (03,000 ... 21,000)
	<b>0 . 1 0 V</b>	0 ... 10 V (-0,500 ... 10,500)

press key **(P)** to accept the selection

### 5.2.2 Set the decimal point for the Instantaneous value

Menu <->	Selection	Display range
<b>d P</b>	<b>0</b>	-19999 ... 99999
	<b>0 0</b>	-1999,9 ... 9999,9
	<b>0,0</b>	-199,99 ... 999,99
	<b>0,00</b>	-19,999 ... 99,999
	<b>0,000</b>	-1,9999 ... 9,9999
	<b>0,0000</b>	-0,19999 ... 0,99999

press key **(P)** to accept the selection

The position of the decimal point has no influence on the measuring accuracy. The maximum display value must be within the display range. After the decimal point is set up, the leading zeros in the display will be suppressed.

### 5.2.3 Changing the Range Limits

The given limits for the input range can be entered as is, or adjusted.

	Parameter $l_{o.inP}$ Possible range of values	Parameter $h_{i.inP}$ Possible range of values
0 .. 10 V	-0.500 ... 10.500	-0.500 ... 10.500
2 .. 10 V	01.500 ... 10.500	01.500 ... 10.500
-10 .. +10 V	-10.500 ... 10.500	-10.500 ... 10.500
0 .. 20 mA	-1.000 ... 21.000	-1.000 ... 21.000
4 .. 20 mA	03.000 ... 21.000	03.000 ... 21.000

If the measured signal falls below or exceeds the programmed value, then the display alternates between  $l_{o}$  and the measured value or

between  $h_{i}$  and the the measured value. Setting values out of the range is not possible. It is only possible to continue with the set-up, using the **P** key, when the settings are correct.

#### Lower limit

Menu <-> Selection

$l_{o.inP}$   Example: -5.000

Select digit

Set digit

Select digit

Set digit

press the **P** key to accept the selection

#### Upper limit

Menu <-> Selection

$h_{i.inP}$   Example: 9,000

Select digit

Set digit

press the **P** key to accept the selection

When the signal drops below the value set here, then the signal alternates with the message  $l_{o}$


**Under-range:** if the signal is less then -13,60 V than  $uuuuu$  appears in the display. Current values < 0.0 mA will not be measured.

When the signal exceeds the value set here, then the signal alternates with the message  $h_{i}$

**Over-range:** if the signal is higher than 11.00 V or 21.5 mA, then  $ooooo$  appears in the display.

## 5.2.4 Changing the Scaling Slope

Menu ↔ Selection



Example: Yes

use the scaling slope curve, → Chapter 5.4, 15

Enter or alter scaling slope curve → Chapter 5.3, 13

press the **P** key to accept the selection

## 5.3 Setting the Scaling Slope


At least two points (2 pairs of value) for the starting and the end points respectively of the characteristic curve are required. The curve can be ascending or descending.

At least two points (2 pairs of values) are required for the start point and end point of the scaling slope. This slope can be rising or falling. A maximum of 24 scaling points can be used.


However it should be noted that in all cases, whether the slope rises or falls, the values that are inputted (InP.01 ... InP.24) must increase sequentially.

The scaling slope must lie within the limits of the input and display ranges. The first and last points can lie on the limits.

**Input range 0 ... 10 V, 2 ... 10 V, 0 ... 20 mA, 4 ... 20 mA**




## Input range -10 ... +10 V



## Example with 4 scaling points

For the input range -10 ... +10 V




Scaling point range	Input	Display value
1	-5,000	-250,0
2	2,000	300,0
3	7,000	700,0
4	9,000	950,0


It is advisable to make a note of the desired pairs of values for the scaling points of the slope before starting the set-up.

## 5.3.1 Enter the number of scaling points

Menu &lt;-&gt; Selection



Example: 2


Pressing the  key will increase the value by one. After reaching 24 the value jumps back to 2.

press the  key to accept the selection

### 5.3.2 Define first Scaling point

Firstly set the **input value** for the start of the slope using the respective unit (mA, V)


Menu <-> Selection



press the (P) key to accept

Then set the **display value** for the start of the slope

Menu <-> Selection



press the (P) key to accept

### 5.3.3 Define the second scaling point

Set **input value**

Menu <-> Selection



press the (P) key to accept

Set **display value**

Menu <-> Selection



press the (P) key to accept



### 5.3.4 Define further scaling points

Additional scaling points will be requested only, when in section 5.3.1 more than 2 scaling points are defined.



## 5.4 Alarms/Alarm outputs

One, two or no alarms can be active.

When exceeding	Signal on	LED display
Alarm 1	Output 1	 on
Alarm 2	Output 2	 on

### 5.4.1 Alarm 1/Alarm output 1

#### 5.4.1.1 Alarm 1 off/on

Menu <-> Selection

Example: on






Alarm 1 not active → Chapter 5.5.2  23



Alarm 1 active

press the  key to accept the selection

#### 5.4.1.2 Mode for Alarm output 1


Menu <-> Selection







Latch mode, Latch signal reset at output 1

→ Chapter 5.4.1.5  22



Auto mode

press the  key to accept the selection



Alarm a: threshold exceeded  
b: below threshold

**Output mode "Auto"**: automatic resetting of output when the signal falls below threshold, signal set to 0, LED extinguished.

**Output mode "Latch"**: Manual and/or electrical resetting of signal and LED


### 5.4.1.3 Alarm 1 Hysteresis

Here hysteresis means: The difference in thresholds between switching on and switching off. This difference should be selected large enough to avoid undesired switching actions at the output due to the variations of the current instantaneous value.

#### Note:

Alarm value and hysteresis are always based on the displayed current value and not on the input signal value.

#### For positive alarm value:




Switching on value = alarm + switching on hysteresis  $\Delta a$

Switching off value = alarm - switching off hysteresis  $\Delta b$

The switching on value **must be greater** than the switching off value.

#### For negative alarm value:



Switching on value = alarm - switching on hysteresis  $\Delta a$

Switching off value = alarm + switching off hysteresis  $\Delta b$

The switching on absolute value (numerical value without sign)

**must be greater** than the absolute value for switching off.

**Set switching on hysteresis  $\Delta a$  for alarm 1**

Menu &lt;-&gt; Selection

o.n.h.y.t.	000000	Example 1.0
------------	--------	-------------



000000	Select digit
--------	--------------



000100	Set digit
--------	-----------

press the **P** key to accept the selection**Set switching off hysteresis  $\Delta b$  for limit 1**

Menu &lt;-&gt; Selection

o.f.h.y.t.	000000	Example: 1,0
------------	--------	--------------



000000	Select digit
--------	--------------



000100	Set digit, then select signal form for output 1,
--------	--

Chapter 5.4.1.5 19

press the **P** key to accept the selection**5.4.1.4 Reset Latch signal at output 1**

Menu &lt;-&gt; Selection

r.o.u.t.t.	P.P.R.n
------------	---------



P.P.R.n	Manual reset with red key
---------	---------------------------

Alarm output can only be reset manually if **R.c.t.**, **P.P.i.n** or **P.P.R.H** is selected as the function and is displayed.

E.L.E.c.t.	Electrical reset with MPI-Input
------------	---------------------------------

Alarm output can only be reset electrically, if **R.c.t.**, **P.P.i.n** or **P.P.R.H** is selected as the function and is displayed.**Note:** The Display Hold funktion is off.


E.L.P.P.R	Both manual and electrical reset
-----------	----------------------------------

Alarm output can either be reset manually via the red key or via a reset pulse on the MP input.

**Note:** The Display Hold funktion is off.press the **P** key to accept

### 5.4.1.5 Select Signal Form for Output 1

Menu ↔ Selection




press the **(P)** key to accept

## 5.4.2 Alarm 2/Alarm output 2


### 5.4.2.1 Alarm2 on / off

Menu ↔ Selection



### 5.4.2.2 Mode for Alarm output 2

Menu ↔ Selection



press the **(P)** key to accept the selection

### 5.4.2.3 Hysteresis for Alarm 2


#### Set switching on hysteresis $\Delta a$ for Alarm 2

Menu <-> Selection

o n h 4 2    0 0 0 0 0

  Select digit

  Set digit

press the  key to accept the selection

#### Set switching off hysteresis $\Delta b$ for Alarm 2

Menu <-> Selection

o F h 4 2    0 0 0 0 0

  Select digit







  Set digit  Chapter 5.4.2.5 select signal for output 2






press key  to accept



### 5.5.2.4 Reset Latch signal at Output 2

Menu <-> Selection

L R t c h    P P R n

  Manual reset with red key   
Alarm output can only be reset manually if  
,  or  is selected..


  Electrical reset with MPI-Input  
Alarm output can only be reset electrically, if  
,  or  is selected as the function and is  
displayed.

  Both, manual and electrical reset  
Alarm output can either be reset manually via the red key or via a reset pulse on the  
MP input.  
**Note:** The Display Hold function is off.

press the  key to accept

### 5.4.2.5 Select signal form for output 2

Menu <-> Selection




press the **(P)** key to accept

## 5.5 MIN/MAX value acquisition

The maximum value may be captured, saved and consulted during operation by pressing a key.

### 5.5.1 Capture of MIN/MAX Values


Menu <-> Selection



press the **(P)** key to accept the selection

#### 5.5.1.1 Reset Maximum value


Menu <-> Selection



press the **(P)** key to accept

## 5.5.2 MIN Value Monitor


Menu <-> Selection



press the **P** key to accept the selection

### 5.5.2.1 Reset Minimum value

Menu <-> Selection



press the **P** key to accept

## 5.5.3 Effects resulting from exceeding the measuring range limits or of Overload/Underload on MIN/MAX.

If the signal measured lies outside the measuring range limits  $L_{o.inP}$  or  $h_{i.inP}$  then the current measured value will be recorded either as a MIN value  $uuuuu$  or as a MAX value  $ooooo$ . If the signal is in an overload or underload condition, then it

will be saved either as as a MIN value  $uuuuu$  or as a MAX value  $ooooo$ .

## 5.6 Mains Hum Filter

To reduce the interference from mains line and the environment (mains hum), the instrument must be set to the local mains frequency.

Menu <-> Selection



press the **P** key to accept the selection

## 5.8 Setting Default Values

The user has the possibility to set all parameters back to their default values by using the parameter **dEfc**. This parameter **dEfc** must be programmed with the value **07000**. If you then proceed to the next parameter using the keys, then all

parameters are reset to their default values. It is not necessary to finish the programming; a new programming cycle can take place immediately.


Menu <-> Selection



press the **P** key to accept the selection

## 5.9 End of Setup Yes/No?

Menu <-> Selection



press the **P** key to accept the selection

## 5.10 Check/Alter Parameters

Menu <-> Selection



- after every 2 seconds the menu changes to Selection
- If the setting is as desired, then switch to the next menu with **P** key, otherwise, start the set-up again.



## 6. Operation

The unit is in the operating mode, when the power supply is switched on or at the end of the set-up. One of the following will be displayed during operation.

3268 i

326.81 The measuring signal has been applied and lies within the limits of the measuring range. The display will show either the current measured value, the totalizer value, the MAX value or the MIN value.

l o

The input value is below the lower limit of the measuring range. This message alternates with the current measured value.

h i

The input value is higher than the upper limit of the measuring range. This message alternates with the current measured value.

u u u u u

The input value is less than -13.6 V. Current inputs below 0.0 mA are not measured.


o o o o o

The input value is higher than 11.0 V or above 21.5 mA

### 6.1 Changing the Display during Operation

Pressing the P key once for 2 sec will identify the function currently selected. If within these 2 sec the P key is pressed again, then the display will proceed to the next display function.

The new identification will be displayed for 2 sec to confirm this. After 2 sec the corresponding value of the selected function will be displayed.



<sup>1</sup>Following actuation the corresponding value of the chosen function remains in the display. During a PowerOff the function currently selected will be saved. At the next PowerOn the corresponding value of this function will be shown again in the display.  
<sup>2</sup>After 4 sec the display automatically switches back to

the current measured value and the LED indicators Pr1 or Pr2 are turned off.

#### Note:

When an alarm value is shown in the display, its set value can be changed.

This can be prevented by disabling the panel keys using the "Key" lock.

### 6.2 Setting the Alarms during Operation

When an alarm value is shown in the display, its set value can be changed.

**Note:** the "key-lock" should not be enabled.

Alarm 1 is displayed. LED 'Pr1' is illuminated

#### Set Alarm

Display



Action



Select digit position and



set digit.



Example: 300.0

press the  key to accept and go to Alarm 2

Alarm 2 is displayed. LED 'Pr2' is illuminated

#### Set Alarm

Display



Action




Select digit position and



set digit.



Example 800.0

press the  key to accept the selection

### 6.3 Resetting MIN/MAX value

Resetting is only possible if this has been enabled in the parameter mode.

Select Min/Max value display

- press the red key.
- the stored value is cleared

#### 6.4 Display Hold



The Display Hold function is only available for use with the current measured value and for the totalizer value. For as long as a high level signal (> 4 V DC) is present at the MP input, then the display

is "frozen".

The MIN/MAX capture, alarm monitoring and totalizer functions continue in the background.

The Display Hold function is only active with the following parameter settings:

	Parameter	Settings
Alarm	<code>prES1</code> / <code>prES2</code>	<code>off</code>
Alarms	<code>prES1</code> / <code>prES2</code>	<code>on</code>
Output Mode	<code>prOUI</code> / <code>prOU2</code>	<code>Relo</code>
Alarms	<code>prES1</code> / <code>prES2</code>	<code>on</code>
Output Mode	<code>prOUI</code> / <code>prOU2</code>	<code>latch</code>
Reset-Alarm-Latch	<code>rou1</code> / <code>rou2</code>	<code>prRn</code>



## FACTORY AUTOMATION – SENSING YOUR NEEDS

For half a century, Pepperl+Fuchs have been continually providing new stimuli for the world of automation. The company is also setting standards in quality and innovative technology. We develop, produce and distribute electronic sensors and interface modules on a global scale. By means of our world-wide presence and our high flexibility in production and customer service we are able to individually offer complete solutions – right where you need us. We know what we are talking about – Pepperl+Fuchs have established a good reputation in supplying the world's biggest offer of industrial sensor technology for a large scale of applications. **Our signals move the world.**



### Worldwide Headquarters

Pepperl+Fuchs GmbH  
68307 Mannheim · Germany  
Tel. +49 621 776-0  
E-Mail: [info@de.pepperl-fuchs.com](mailto:info@de.pepperl-fuchs.com)

### USA Headquarters

Pepperl+Fuchs Inc.  
Twinsburg, Ohio 44087 · USA  
Tel. +1 330 4253555  
E-Mail: [sales@us.pepperl-fuchs.com](mailto:sales@us.pepperl-fuchs.com)

### Asia Pacific Headquarters

Pepperl+Fuchs Pte Ltd. · P+F Building  
Singapore 139942  
Tel. +65 6779-9091  
E-Mail: [sales@sg.pepperl-fuchs.com](mailto:sales@sg.pepperl-fuchs.com)

**PF** **PEPPERL+FUCHS**  
SENSING YOUR NEEDS



[www.pepperl-fuchs.com](http://www.pepperl-fuchs.com)

Subject to reasonable modifications due to technical advances  
Copyright PEPPERL+FUCHS • Printed in Germany

DA5-IU-2K-C/DA5-IU-2K-V  
R.600.020.9396  
08/2010