


MANUAL

**AS-I 3.0**  
**ETHERNET/IP+MODBUS**  
**TCP GATEWAY WITH**  
**INTEGR. SAFETY MONITOR**



With regard to the supply of products, the current issue of the following document is applicable: The General Terms of Delivery for Products and Services of the Electrical Industry, published by the Central Association of the Electrical Industry (Zentralverband Elektrotechnik und Elektroindustrie (ZVEI) e.V.) in its most recent version as well as the supplementary clause: "Expanded reservation of proprietorship".

# Table of contents

## AS-i 3.0 EtherNet/IP+Modbus TCP Gateway with integr. Safety Monitor

### Table of contents

<b>1</b>	<b>Introduction.....</b>	<b>9</b>
<b>2</b>	<b>Declaration of conformity .....</b>	<b>10</b>
2.1	Declaration of conformity.....	10
<b>3</b>	<b>Safety .....</b>	<b>11</b>
3.1	Symbols relevant to safety.....	11
3.2	General notes on safety .....	11
3.3	Disposal .....	11
<b>4</b>	<b>General .....</b>	<b>12</b>
4.1	Product information.....	12
4.1.1	AS-i 3.0 EtherNet/IP+Modbus TCP Gateway with integr. Safety Monitor .....	12
4.2	New Generation of AS-i Gateways with ethernet diagnostics interface ...	13
4.3	Brief description.....	13
4.4	Conformity statement .....	14
4.5	Certification according to DIN EN ISO 9001 : 2000 .....	14
<b>5</b>	<b>Specifications .....</b>	<b>15</b>
5.1	Technical data .....	15
5.2	Safety-relevant characteristic data.....	16
5.2.1	Overview of parameter for determining the failure rates .....	17
5.3	Reaction times.....	18
5.3.1	Local electronic input -> local electronic output .....	18
5.3.2	Sensor -> local relay output.....	18
5.3.3	Sensor -> local electronic output .....	19
5.3.4	Sensor -> AS-i relay output.....	19
5.3.5	Sensor -> AS-i electronic output.....	20
5.3.6	System reaction times – example calculations .....	21
5.4	Scope of delivery .....	24

<b>6</b>	<b>Installation .....</b>	<b>25</b>
6.1	Dimensions .....	25
6.2	Connections .....	25
6.3	Installing in the control cabinet.....	26
6.4	Removing .....	26
6.5	Startup .....	27
6.5.1	Switching to advanced display mode.....	27
6.5.2	Select Modbus TCP .....	27
6.5.2.1	Displaying of Ethernet properties.....	28
6.5.2.2	Setting of Ethernet properties .....	28
6.5.2.3	Setting of watchdog time .....	29
6.5.3	Select EtherNet/IP .....	29
6.5.3.1	Setting of EtherNet/IP properties .....	30
6.5.4	Connecting AS-i Slaves .....	30
6.5.5	Quick setup .....	31
6.6	Error tracing .....	32
6.6.1	Faulty slaves .....	32
6.6.2	Error display (last error).....	32
6.7	Addressing .....	33
6.7.1	Assigning address 15 to slave currently at address 2.....	33
6.8	Local parameter setting of safe AS-i Gateways and Monitors .....	34
6.9	Replacing a defective safety-related AS-i slave .....	36
6.10	Replacing the chip card .....	37
6.11	Replacing a defective device.....	38
6.11.1	Teaching the group manager after replacing a device .....	40
6.12	Replacing the monitor .....	41
6.13	Safe configuration using ASIMON 3 G2 .....	44
<b>7</b>	<b>Maintenance .....</b>	<b>46</b>
7.1	Checking for safe turn-off.....	46
<b>8</b>	<b>Electrical connection.....</b>	<b>47</b>
8.1	Overview of terminals, indicators and operating elements.....	47
8.1.1	VBG-ENX-K30-DMD-S16-C1, VBG-ENX-K30-DMD-S16.....	47
8.1.2	VBG-ENX-K30-DMD-S16-EV.....	48
8.2	AS-i bus connection .....	49
8.3	Information about the device types .....	49
8.4	AS-i and power supply terminal assignments .....	49
8.4.1	Electrical connection VBG-ENX-K30-DMD-S16-C1, VBG-ENX-K30-DMD-S16-EV .....	50
8.4.2	Electrical connection VBG-ENX-K30-DMD-S16 .....	51
8.5	Diagnostics interface .....	52
8.5.1	VBG-ENX-K30-DMD-S16-C1, VBG-ENX-K30-DMD-S16.....	52
8.5.2	VBG-ENX-K30-DMD-S16-EV.....	52
8.5.3	SafeLink via ethernet (VBG-ENX-K30-DMD-S16-EV).....	52

8.6	Chip card.....	53
8.7	Ethernet interface.....	53
8.8	Release circuits.....	54
8.8.1	Wiring overview of safety unit.....	54
8.9	Indicators and operating elements.....	55
8.9.1	LED indicators – master.....	55
8.9.2	LED indicators - safety unit.....	56
8.9.3	Buttons.....	57
9	Function and startup of the Safety Monitor .....	58
9.1	Powering up the device .....	58
9.2	Configuration of the safety functions .....	58
9.2.1	Description of configuration using ASIMON 3 G2 software .....	59
9.2.2	Description of configuration using chip card with master configuration .....	59
9.2.3	Configuration using a chip card with complete configuration.....	60
9.3	Safety-relevant documentation of the application .....	61
9.4	Diagnostic data .....	61
9.5	Switch-off history.....	61
9.6	Diagnostic values in the IDI .....	62
9.7	Password protection.....	63
9.7.1	Procedure for configuring and teaching code sequences .....	63
9.7.2	Function of the ESC/Service key.....	64
9.8	Safe coupling slaves on the AS-i circuits .....	64
9.9	Chip card.....	64
9.9.1	Unsafe data .....	64
9.9.1.1	Card unformatted .....	65
9.9.1.2	Data not compatible.....	65
9.9.1.3	Card empty .....	65
9.9.1.4	Data compatible.....	65
9.9.1.5	Data in the device and on the chip card identical .....	66
9.9.1.6	Data in the device and on the chip card not identical .....	66
9.9.2	Safe data.....	66
9.9.2.1	Data incompatible .....	66
9.9.2.2	Data compatible.....	67
9.9.2.3	Complete configuration .....	67
9.9.2.4	Data on the chip card and in the device are identical .....	67
9.9.2.5	Data not identical .....	68
9.9.2.6	Operating the chip card from the menu .....	68
9.9.3	Working with multiple memory banks .....	68
10	Operation in advanced display mode.....	70
11	Advanced Diagnostics for AS-i Masters.....	71
11.1	List of corrupted AS-i Slaves (LCS) .....	71
11.2	Protocol analysis: Counters for corrupted data telegrams .....	71
11.3	Offline Phase for Configuration Errors .....	72

11.4	<b>Functions of the AS-i Fault Detector .....</b>	<b>72</b>
11.4.1	Duplicate address detection.....	72
11.4.2	Earth/Ground Fault Detector .....	73
11.4.3	Noise Detector .....	73
11.4.4	Over-voltage Detector .....	73
11.5	<b>Functions of the new generation of AS-i Gateways .....</b>	<b>74</b>
11.5.1	C-programmable Gateways .....	74
11.5.2	Interchangeable memory card.....	74
11.5.3	Earth fault monitor.....	74
11.5.4	Current can be read directly on the unit.....	75
11.5.5	Self-resetting fuses .....	76
11.5.6	AS-i Power24V capable .....	76
11.5.7	Ethernet diagnostics interface with web server .....	77
11.5.8	Transitionless operating mode changes .....	77
<b>12</b>	<b>EtherNet/IP Interface.....</b>	<b>78</b>
12.1	Identity object .....	79
12.2	Device Level Ring Object.....	80
12.3	Quality of Service Object .....	81
12.4	Assembly Object.....	83
12.4.1	Assembly Objects for VBG-ENX-K30-DMD-S16-C1, VBG-ENX-K30-DMD-S16.....	85
12.4.2	Assembly Objects for VBG-ENX-K30-DMD-S16-EV.....	86
12.5	AS-i Master Object.....	88
12.6	AS-i slave Object .....	91
12.7	I/O Data Object .....	92
12.8	Advanced Diagnostics Object .....	94
12.9	Short Command Interface Object.....	96
12.10	Long Command Interface Object .....	96
12.11	<b>Safety Control/Status .....</b>	<b>97</b>
12.11.1	<b>Internal monitor .....</b>	<b>97</b>
12.11.1.1	Safety Control Status internal monitor for VBG-ENX-K30-DMD-S16-C1, VBG-ENX-K30-DMD-S1697	
12.11.1.2	Feldbus bits internal monitor for VBG-ENX-K30-DMD-S16-EV.....	99
12.11.2	<b>External Monitor .....</b>	<b>100</b>
12.11.2.1	Safety Control Status external Monitor .....	100
<b>13</b>	<b>The Modbus Address Table .....</b>	<b>102</b>
13.1	<b>Safety Control/Status .....</b>	<b>114</b>
13.1.1	Internal Monitor for VBG-ENX-K30-DMD-S16-C1, VBG-ENX-K30-DMD-S16.....	114
13.1.2	Internal Monitor for VBG-ENX-K30-DMD-S16-EV.....	116
13.1.3	Safety fieldbus bits for VBG-ENX-K30-DMD-S16-EV .....	117
13.1.4	External monitor, AS-i circuit 1/2 .....	117
13.2	<b>AS-i circuit 1 data .....</b>	<b>119</b>
13.2.1	Permanent configuration data.....	119
13.2.2	Enhanced diagnostic.....	119
13.2.3	Function invocation.....	120
13.3	<b>AS-i circuit 1 analog data.....</b>	<b>121</b>
13.3.1	16 bit output data of AS-i slaves according to slave profile 7.3 or 7.4 .....	121

13.3.2	16 bit input data of AS-i slaves according to slave profile 7.3 or 7.4 .....	121
13.4	<b>AS-i circuit 2 data .....</b>	<b>122</b>
13.4.1	Process data and actual configuration data .....	122
13.4.2	Permanent configuration data .....	122
13.4.3	Enhanced diagnostic .....	122
13.4.4	Function invocation .....	123
13.5	<b>AS-i circuit 2 analog data .....</b>	<b>124</b>
13.5.1	16 bit output data of AS-i slaves according to slave profile 7.3 or 7.4 .....	124
13.5.2	16 bit input data of as-i slaves according to slave profile 7.3 or 7.4 .....	124
13.6	<b>Modbus watchdog .....</b>	<b>125</b>
<b>14</b>	<b>Operation via Ethernet IP (Modbus/TCP) .....</b>	<b>126</b>
14.1	Message Structure .....	126
14.2	Ethernet TCP/IP functions .....	127
14.2.1	Function 3 (3hex): "Read multiple registers" .....	127
14.2.2	Function 16 (10hex): "Write multiple registers" .....	127
14.2.3	Function 23 (17hex): "Read/Write multiple registers" .....	128
14.2.4	Exception codes .....	128
<b>15</b>	<b>Data Transfer using CIP Messages in RSLogix5000 .....</b>	<b>131</b>
15.1	MSG instruction and Message Type Tag .....	131
15.2	Example 1: read LAS .....	133
15.3	Example 2: read/write 16-bit (analog) data .....	134
<b>16</b>	<b>System startup using AS-i Control Tools .....</b>	<b>135</b>
<b>17</b>	<b>Configuration with Windows Software ASIMON 3 G2 .....</b>	<b>138</b>
<b>18</b>	<b>Safe Link .....</b>	<b>139</b>
18.1	General introduction .....	139
18.2	Configuration .....	140
18.2.1	Configuration using ASIMON .....	141
18.3	Diagnostics .....	142
<b>19</b>	<b>Appendix, examples .....</b>	<b>144</b>
19.1	Commissioning with RSLogix5000 V20 or higher .....	144
19.2	The first commissioning with CompactLogix .....	154
19.2.1	Working with sample files .....	158
19.3	Safety diagnostics in the input data image (IDI) .....	159
19.3.1	Representation of the diagnostic information .....	159
19.3.2	Other representation variants .....	160
19.3.3	Changing the default setting .....	160

<b>20</b>	<b>Status indication, faults and fault elimination .....</b>	<b>162</b>
20.1	Spontaneous display of faults from the safety unit .....	162
20.2	Replacing a defective safety-configured AS-i slave.....	163
20.3	Replacing a defective AS-i Safety Monitor .....	164
20.4	Forget the password? What do I do now? .....	164
<b>21</b>	<b>Codes indicated by the display .....</b>	<b>166</b>
<b>22</b>	<b>Reference List .....</b>	<b>168</b>
22.1	Manual: "ASIMON 3 G2 Configuration Software" .....	168
22.2	Sources.....	168
<b>23</b>	<b>Glossary.....</b>	<b>169</b>

## 1. Introduction

### Congratulations

You have chosen a device manufactured by Pepperl+Fuchs. Pepperl+Fuchs develops, produces and distributes electronic sensors and interface modules for the market of automation technology on a worldwide scale.

Before installing this equipment and put into operation, read this manual carefully. This manual contains instructions and notes to help you through the installation and commissioning step by step. This makes sure bring such a trouble-free use of this product. This is for your benefit, since this:

- ensures the safe operation of the device
- helps you to exploit the full functionality of the device
- avoids errors and related malfunctions
- avoids costs by disruptions and any repairs
- increases the effectiveness and efficiency of your plant

Keep this manual at hand for subsequent operations on the device.

After opening the packaging please check the integrity of the device and the number of pieces of supplied.

### Symbols used

The following symbols are used in this manual:



#### **Information!**

*This symbol indicates important information.*



#### **Attention!**

*This symbol warns of a potential failure. Non-compliance may lead to interruptions of the device, the connected peripheral systems, or plant, potentially leading to total malfunctioning.*



#### **Warning!**

*This symbol warns of an imminent danger. Non-compliance may lead to personal injuries that could be fatal or result in material damages and destruction.*

### Contact

If you have any questions about the device, its functions, or accessories, please contact us at:

Pepperl+Fuchs GmbH  
Lilienthalstraße 200  
68307 Mannheim  
Telephone: +49 621 776-4411  
Fax: +49 621 776-274411  
E-Mail: [fa-info@pepperl-fuchs.com](mailto:fa-info@pepperl-fuchs.com)

## 2. Declaration of conformity

### 2.1 Declaration of conformity

This product was developed and manufactured under observance of the applicable European standards and guidelines.



#### **Information!**

*A Declaration of Conformity can be requested from the manufacturer.*

The product manufacturer, Pepperl+Fuchs GmbH, D-68307 Mannheim, has a certified quality assurance system that conforms to ISO 9001.

### 3. Safety

#### 3.1 Symbols relevant to safety

**Information!**

*This symbol indicates important information.*

**Attention!**

*This symbol warns of a potential failure. Non-compliance may lead to interruptions of the device, the connected peripheral systems, or plant, potentially leading to total malfunctioning.*

**Warning!**

*This symbol warns of an imminent danger. Non-compliance may lead to personal injuries that could be fatal or result in material damages and destruction.*

#### 3.2 General notes on safety

Only instructed specialist staff may operate the device in accordance with the operating manual.

User modification and or repair are dangerous and will void the warranty and exclude the manufacturer from any liability. If serious faults occur, stop using the device. Secure the device against inadvertent operation. In the event of repairs, return the device to your local Pepperl+Fuchs representative or sales office.

The connection of the device and maintenance work when live may only be carried out by a qualified electrical specialist.

The operating company bears responsibility for observing locally applicable safety regulations.

Store the not used device in the original packaging. This offers the device optimal protection against impact and moisture.

Ensure that the ambient conditions comply with regulations.

#### 3.3 Disposal

**Information!**

*Electronic waste is hazardous waste. Please comply with all local ordinances when disposing this product!*

*The device does not contain batteries that need to be removed before disposing it.*

## 4. General

### 4.1 Product information

This system manual applies to the following Pepperl+Fuchs GmbH equipment:

#### 4.1.1 AS-i 3.0 EtherNet/IP+Modbus TCP Gateway with integr. Safety Monitor

Article no.	Type	Inputs safety, expandable to	Outputs Safety, SIL 3, cat. 4	Safety outputs, independent according to SIL 3, expandable to	Safety communication	Number of AS-i networks, number of AS-i Master	1 power supply, 1 gateway for 2 AS-i networks, inexpensive power supplies	Diagnostic and configuration interface
<b>VBG-ENX-K30-DMD-S16-C1</b>	Safety, EtherNet/IP + Modbus TCP	max. 62 x 2-channels	4 release circuits; 2 x relay, 2 x fast electronic safe outputs	max. 16	—	2 AS-i networks, 2 AS-i Masters	yes, max. 4A/ AS-i network	RS 232 + Ethernet
<b>VBG-ENX-K30-DMD-S16</b>	Safety, EtherNet/IP + Modbus TCP	max. 62 x 2-channels	4 release circuits; 2 x relay, 2 x fast electronic safe outputs	max. 16	—	2 AS-i networks, 2 AS-i Masters	no, max. 8A/AS-i network, redundant supply	RS 232 + Ethernet
<b>VBG-ENX-K30-DMD-S16-EV</b>	Safety, EtherNet/IP + Modbus TCP	max. 62 x 2 channels, max. 1922 in max. configuration	4 release circuits; 2 x relay, 2 x fast electronic safe outputs	max. 32, max. 992 in max. configuration	Safe-Link <sup>1</sup>	2 AS-i networks, 2 AS-i Masters	yes, max. 4A/ AS-i network	Ethernet

Tab. 4-1.

1. SafeLink via ethernet. Please refer here to the information in the section <Safe Link>.

## 4.2 New Generation of AS-i Gateways with ethernet diagnostics interface

### The plus points of the new Gateway generation at a glance:

- Gateways now programmable in C
- Ethernet diagnostics interface for remote diagnostics
- Integrated web server: diagnostics for the Gateways and the AS-i circuits over Ethernet possible with no additional software
- GSD configuration files already stored in the web server
- Earth fault monitor distinguishes between AS-i cable and sensor cable
- Current from both AS-i circuits in the "1 Gateway, 1 power supply for 2 AS-i circuits" version can now be read directly on the unit
- Self-resetting fuses in the "1 Gateway, 1 power supply for 2 AS-i circuits" version
- Device temperature display
- AS-i Power24V capable
- Interfaces for virtually every bus system and Ethernet solution



### **Information!**

See also section <Functions of the new generation of AS-i Gateways> for further information.

## 4.3 Brief description

The actuator-sensor interface (AS-i) has established itself as a system for networking primarily binary sensors and actuators at the lowest level of the automation hierarchy. The high number of installed systems, the ease of use and the reliable operating behaviour also make the AS-i interesting in the area of machine safety.

The **safety** AS-i system is intended for safety applications up to Category 4/SIL 3. Mixed operation of standard components and safe components is possible.

The AS-i Safety Monitor monitors within an AS-i system the safe slaves which have been assigned according to the configuration specified by the user with the configuration software. In the event of a stop request or a defect, the AS-i Safety Monitor switches off the system in protective operation mode with a maximum reaction time of 40 ms.

AS-i/Gateway with integrated Safety Monitor




Fig. 4-1. Safe and standard components in an AS-i network

Multiple AS-i Safety Monitors can be used within an AS-i system. In this way, a safe slave can be monitored by multiple AS-i Safety Monitors.

#### 4.4 Conformity statement

The device has been developed and manufactured in accordance with the applicable European standards and directives.



**Information!**

The corresponding conformity statement can be found at the very beginning of this system manual.

#### 4.5 Certification according to DIN EN ISO 9001 : 2000

The manufacturer of the product possesses a certified quality assurance system in accordance with ISO 9001.



**Information!**

The current certificate can be viewed in internet: <http://www.pepperl-fuchs.com>.

## 5. Specifications

### 5.1 Technical data

The technical data are placed in the data sheet. Please view the current version on the web page: <http://www.pepperl-fuchs.com>.



#### **Attention!**

*The AS-I power supply for the AS-I components must have isolation per IEC 60 742 and be able to handle momentary power interruptions of up to 20 ms. The power supply for the 24 V supply must also have isolation per IEC 60 742 and be able to handle momentary power interruptions of up to 20 ms. The maximum output voltage of the power supply must also be less than 42 V in case of a fault.*

**5.2 Safety-relevant characteristic data**

Characteristic data	Value	Standard
Safety category	4	EN 954-1
Safety category	4	EN ISO 13849-1: 2008
Performance Level (PL)	e	
Safety Integrity Level (SIL)	3	EN 61508: 2001
Lifespan (TM) in years	20	EN ISO 13849-1: 2008
Maximum switch-on time in months	12	EN 61508: 2001
Max. system reaction time in milliseconds	40	EN 61508: 2001

Tab. 5-2.



**Attention!**

*In addition to the system reaction time of max. 40 ms, the reaction times of the safe AS-interface sensor slave, of the sensor being used for monitoring, of the safe AS-interface actuator slave and of the actuator used for this purpose must still be added. Please note that additional reaction times may likewise arise through the configuration of the safety monitor.*



**Notice!**

*Refer to the technical data for the slaves as well as to that for the sensors and actuators for the reaction times to be added.*



**Attention!**

*The system reaction times of the daisy-chained AS-interface components are added up.*

5.2.1 Overview of parameter for determining the failure rates

nop/y	switching intervals $t_{\text{cycle}}$ [s]	B10d value	electromechanics		Standard
			MTTF <sub>d</sub> [years]	PFH [1/h]	
105.120	300	2.500.000	237,82	$9,908 \times 10^{-9}$	EN ISO 13849-1
52.560	600		475,65	$4,853 \times 10^{-9}$	
8.760	3600		2853,88	$9,054 \times 10^{-10}$	


Tab. 5-3.

nop/y	switching intervals $t_{\text{cycle}}$	B10d value	electronics PFH	electromechanics		PFH total	Standard	
				MTTF <sub>d</sub>	PFH			
105.120	300	2.500.000	$4,76 \text{ E}^{-09}$	237,82	$1,12 \times 10^{-8}$	$1,6 \times 10^{-8}$	EN 62061 EN 61508	
52.560	600			475,65	$5,09 \times 10^{-9}$			$9,85 \times 10^{-9}$
8.760	3600			2853,88	$7,82 \times 10^{-10}$			$5,54 \times 10^{-9}$

Tab. 5-4.

**5.3 Reaction times**


**5.3.1 Local electronic input -> local electronic output**



$t_s$  = maximal reaction time of the sensor (see data sheet)

$t_{react}$  = maximal system reaction time

**5.3.2 Sensor -> local relay output**




$t_s$  = maximal reaction time of the sensor (see data sheet)

$t_{react}$  = maximal system reaction time


12.9.2013

**5.3.3 Sensor -> local electronic output**




$t_s$  = maximal reaction time of the sensor (see data sheet)  
 $t_{react}$  = maximal system reaction time

**5.3.4 Sensor -> AS-i relay output**



$t_s$  = maximal reaction time of the sensor (see data sheet)  
 $t_{react}$  = maximal system reaction time

5.3.5 Sensor -> AS-i electronic output



$t_s$  = maximal reaction time of the sensor (see data sheet)  
 $t_{react}$  = maximal system reaction time

5.3.6 System reaction times – example calculations

System components:		
<b>ASI1</b>	AS-i network 1	
<b>ASI2</b>	AS-i network 2	
<b>S1-1</b>	Safe sensor slave	(EMERGENCY-OFF switch: $t_{R\ S1-1} = 100\text{ ms}$ )
<b>S1-2</b>	Safe sensor slave	(safety light barrier: $t_{R\ S1-2} = 18\text{ ms}$ )
<b>S2-1</b>	Safe sensor slave	(EMERGENCY-OFF switch: $t_{R\ S2-1} = 100\text{ms}$ )
<b>A2-1</b>	Safe actuator slave	(motor starter: $t_{R\ A2-1} = 50\text{ms}$ )
<b>SM1-1</b>	Safety monitor with 16 relais circuits and one safe AS-i output in AS-i network 1	
<b>SM1-2</b>	Safety monitor with 2 relais circuits and one safe AS-i output in AS-i network 1	
<b>SM2-1</b>	Safety monitor with 16 relais circuits and one safe AS-i output in AS-i network 2	

Tab. 5-5.

**System configuration - example 1: Calculation of the system reaction time**




Fig. 5-2.

Upon activation of safety light barrier S1-2, the relay safety output of safety monitor SM1-2 is controlled.

Calculation of the AS-i relevant system reaction time:

$$t_{\text{System total a)}} = t_{R \text{ S1-2}} + t_{R \text{ System}} = 18\text{ms} + 40\text{ms} = \underline{58\text{ms}}$$

**System configuration - example 2: Calculation of the system reaction time**




Fig. 5-3.

Upon locking of the EMERGENCY-OFF switch S2-1, the motor starter is controlled via the safe AS-interface output of safety monitor SM2-1.

Calculation of the AS-interface-relevant system reaction time:

$$t_{\text{System total b)}} = t_{\text{R S2-1}} + t_{\text{R System}} + t_{\text{R A2-1}} = 100\text{ms} + 40\text{ms} + 50\text{ms} = \underline{190\text{ms}}$$

**System configuration - example 3: Calculation of the system reaction time**




Fig. 5-4.

Upon locking of the EMERGENCY-OFF switch S1-1, the relay output of safety monitor SM2-1 is controlled via the coupling of the safe AS-interface output of safety monitor SM1-1.

Calculation of the AS-i relevant system reaction time:

$$t_{\text{System total c)}} = t_{\text{R S1-1}} + t_{\text{R System ASi1}} + t_{\text{R System ASi2}} = 100\text{ms} + 40\text{ms} + 40\text{ms} = \underline{180\text{ms}}$$

**5.4 Scope of delivery**

The **basic unit** consists of:

AS-i 3.0 EtherNet/IP+Modbus TCP Gateway with integr. Safety Monitor.


The following **accessories** are available:

Software CD with

- **ASIMON 3 G2** communication software for Microsoft® Windows 2000/XP/ Vista/Windows 7/Windows 8®
- System manual in PDF format (Adobe® Reader® Version 7.x or newer is required for viewing the files)

## 6. Installation

### 6.1 Dimensions



#### **Warning!**

Cover the top of the gateway when doing any drilling work above the unit. No particles, especially metal chips, should be allowed to enter the housing, since this could cause a short circuit.



#### **Information!**

Please refer to installation instruction for this device for detailed mounting information.

### 6.2 Connections

	0,2 ... 2,5 mm <sup>2</sup>
	0,2 ... 2,5 mm <sup>2</sup>
AWG	24 ... 12



#### **Attention!**

The AS-I power supply for the AS-I components must have isolation per IEC 60 742 and be able to handle momentary power interruptions of up to 20 ms. The power supply for the 24 V supply must also have isolation per IEC 60 742 and be able to handle momentary power interruptions of up to 20 ms. The maximum output voltage of the power supply must also be less than 42 V in case of a fault.

### 6.3 Installing in the control cabinet


The AS-I/Gateway is installed in the control cabinet on 35mm DIN rails per DIN EN 50 022.




#### **Information!**

The enclosure of the AS-I/Gateway is made of stainless steel. The unit is also suitable for exposed wall mounting.

To install, place the unit on the upper edge of the DIN rail and then snap in the lower edge.




### 6.4 Removing



To remove, press the holding clamps [2] down using a screwdriver [1], press the unit firmly against the upper rail guide and lift out.


## 6.5 Startup

### 6.5.1 Switching to advanced display mode




*The device handels multiple protocols! Please select one of them during the initial operation.*


### 6.5.2 Select Modbus TCP



### 6.5.2.1 Displaying of Ethernet properties




### 6.5.2.2 Setting of Ethernet properties




If you do not have DHCP client access, please contact your network administrator. /

### 6.5.2.3 Setting of watchdog time




### 6.5.3 Select EtherNet/IP




Restart the gateway to assume your changes


### 6.5.3.1 Setting of EtherNet/IP properties



### 6.5.4 Connecting AS-i Slaves




### 6.5.5 Quick setup




## 6.6 Error tracing

### 6.6.1 Faulty slaves




### 6.6.2 Error display (last error)




## 6.7 Addressing


### 6.7.1 Assigning address 15 to slave currently at address 2



## 6.8 Local parameter setting of safe AS-i Gateways and Monitors



**Sichere Daten / Safe data/  
Données sécurisées/  
Dati sicuri / Datos seguros**



- **Stamm-/Vollständige Konfiguration auf der Chipkarte enthalten**  
/Master configuration or complete configuration on the card
- **Gerät enthält validierte Konfiguration, Daten *ungleich***  
/There is a validated configuration on the card, data not equal
- **Beide Konfigurationen *gleich***  
Both configurations not equal

- **Gerät enthält *keine* validierte Konfiguration**  
/No validated configuration in the device/
- **Stamm-/Vollständige Konfiguration auf der Chipkarte**  
/Master configuration or complete configuration on the card
- **Gerät enthält validierte Konfiguration**  
/There is a validated configuration on the card
- **Beide Konfigurationen *gleich***  
Both configurations identical

- **Gerät enthält *keine* validierte Konfiguration**  
/No validated configuration in the device/
- **Stamm-/Vollständige Konfiguration auf der Chipkarte**  
/Master configuration or complete configuration on the card

- **Keine validierte Konfiguration im Gerät + Chipkarte**  
/No validated configuration in the device + chip card/
- **Validierte Konfiguration im Gerät, Chipkarte leer**  
/Validated configuration in the device, chip card empty

- **Keine Daten auf der Chipkarte nicht kompatibel zum Gerät**  
/Safe data on the chip card not compatible to the device/
- **Daten werden synchronisiert**  
/Data being synchronized/

- **Sichere Daten auf der Chipkarte nicht kompatibel zum Gerät**  
/Safe data on the chip card not compatible to the device/
- **Daten werden synchronisiert**  
/Data being synchronized/

**Fehlermeldung:  
/Error message/**  
**ERROR.  
CHIPCARD AND  
SAFETY DATA  
DIFFERENT.  
DELETE CHIPCARD  
OR SAFETY DATA**

**Keine Meldung  
/No message/**

**Datentfreigabe per  
Release-Code notwendig:  
/Data release via release code  
required/**  
**COPY BANK A TO  
MONITOR  
RELEASE CODE:  
1BDF  
TYPE CODE  
1BDF OK**

**Daten werden synchronisiert:  
/Data being synchronized/**  
**CHIPCARD FOUND  
SAFETY DATA WILL  
BE SYNCHRONIZED**

**Daten werden synchronisiert:  
/Data being synchronized/**  
**CHIPCARD FOUND  
SAFETY DATA WILL  
BE SYNCHRONIZED**

**Fehlermeldung:  
/Error message/**  
**CHIPCARD NOT  
COMPATIBLE**

**Daten löschen  
/Clear data/  
/Supprimer données /  
/Cancellare dati  
/Borrar datos**

**Keine Aktion erforderlich  
/No action required/  
/Aucune action requise/  
/Nessuna azione richiesta/  
/Ninguna acción requirida/**

**Konfiguration per  
Release-Code freigeben  
/Validate the configuration  
via release code/  
/Respecter les indications  
de sécurité exposées  
dans le manuel ASIMON  
/Osservare le istruzioni di  
sicurezza riportate nel  
manuale ASIMON  
/Habilitar la configuración  
via código de liberación/**

**Keine Aktion erforderlich  
/No action required/  
/Aucune action requise/  
/Nessuna azione richiesta/  
/Ninguna acción requirida/**

**Keine Aktion erforderlich  
/No action required/  
/Aucune action requise/  
/Nessuna azione richiesta/  
/Ninguna acción requirida/**

**Karte löschen  
/Clear the card/  
/Supprimer carte/  
/Cancellare chipcard/  
/Borrar chip/**




For further information see manual, section <Chip card>

### 6.9 Replacing a defective safety-related AS-i slave




The new slave must be able to send code sequences and must have the same address as the old one. The addressing of the new slave is carried out automatically by default for all Pepper+Fuchs AS-i Masters. Only one missing slave is allowed!



### 6.10 Replacing the chip card






*Always turn off power before inserting or removing the card!*




### 6.11 Replacing a defective device




*If Safe Link is used, it is necessary to teach the group manager after replacing a defective device (see next section)!*










### 6.11.1 Teaching the group manager after replacing a device




6.12 Replacing the monitor







Safety configuration + AS-i configuration different!




Error:  
Chip Card and  
Safety Data  
Different.  
Delete Chip  
Card or Safety  
Data




Chipcard and  
AS-i Data  
Different  
Chipcard->Master  
Master->Chipcard  
Continue




☺Press OK for Menu  
Output Circuit  
1:OFF 2:OFF  
3:OFF 4:OFF




QUICK SETUP  
SAFETY  
DIAGNOSIS  
SLAVE ADR TOOL  
TEST




SAFE CHIPCARD  
ACTIVE: BANK A  
VIEW  
CARD -> MONITOR  
MONITOR -> CARD  
CLEAR CODES  
LCD CONTRAST






 **Safety configuration + AS-i configuration identic!** 



### 6.13 Safe configuration using ASIMON 3 G2



*Before commissioning the safety unit, put the gateway into operation!*

#### ASIMON 3 G2 Software

Change the preset password during the first use of the device (Monitor/change password!)

#### ASIMON 3 G2 Software

Create the desired configuration.

#### ASIMON 3 G2 Software

Download the configuration with MONITOR / PC-> MONITOR into the device. Enter the password for this purpose.

**ASIMON 3 G2 Software**

You can acknowledge the request TEACH CODE SEQUENCES? selecting "Yes", or you can do it later via display selecting "No".



**ASIMON 3 G2 Software**

Check the configuration log (respect instructions in <chap. 5.8> of the ASIMON manual!).




**ASIMON 3 G2 Software**

Validate the configuration with MONITOR → VALIDATION.



**ASIMON 3 G2 Software**

Start the monitor with MONITOR → START.



The device is in the protected mode now.



*If you have assigned the safety monitor its own address in the software ASIMON 3 G2, adjust the configuration in the AS-i master (Quick Setup)! This is also valid when using simulated slaves.*



*Please consider notes on safety in the software manual ASIMON 3 G2!*

## 7. Maintenance

### 7.1 Checking for safe turn-off

The safety representative is responsible for checking flawless function of the AS-i Safety Monitor within the safety system.

Safe turn-off when an associated safe sensor or switch is triggered must be checked at least once a year.



**Attention!**

*To do this, actuate each safe AS-i slave and observe the switching behavior of the output circuits of the AS-i Safety Monitor.*



**Attention!**

*Note the maximum turn-on duration and the overall turn-on operating duration. These values depend on the PFD value selected (see section <Safety-relevant characteristic data>).*



*When the maximum turn-on duration is reached (three, six or twelve months), check the complete safety system and its proper function.*


*When the total operating time (20 years) has been reached, the device must be returned to the manufacturer to check for proper function.*

## 8. Electrical connection

### 8.1 Overview of terminals, indicators and operating elements

#### 8.1.1 VBG-ENX-K30-DMD-S16-C1, VBG-ENX-K30-DMD-S16






i	
	0,2 ... 2,5 mm <sup>2</sup>
	0,2 ... 2,5 mm <sup>2</sup>
AWG	24 ... 12

#### Legend:

- [1] LEDs
- [2] Ethernet interface
- [3] LC display
- [4] Buttons
- [5] Terminals: Supply voltage and AS-i circuit
- [6] Terminals: Safety unit
- [7] Chip card slot
- [8] RS 232 diagnostics port<sup>1</sup>

8.1.2 VBG-ENX-K30-DMD-S16-EV




i	
	0,2 ... 2,5 mm <sup>2</sup>
	0,2 ... 2,5 mm <sup>2</sup>
AWG	24 ... 12

**Legend:**


- [1] LEDs
- [2] Ethernet diagnostic port<sup>1</sup>
- [3] RJ45 ports for Ethernet
- [4] LC display
- [5] Buttons
- [6] Terminals: Supply voltage and AS-i circuit
- [7] Terminals: Safety unit
- [8] Chip card slot

1. Only together with ASIMON 3 G2 Software or AS-i Control Tools

## 8.2 AS-i bus connection



Yellow AS-i ribbon cable



2-conductor AS-i round cable  
(Recommended: flexible power cable  
H05VV-F2x1,5 per DIN VDE 0281)



### **Information!**

*Electrical work is to be performed only by electrical technicians.*

## 8.3 Information about the device types



### **Information!**

*A listing of the individual devices and their features can be found in section <Product information>.*

## 8.4 AS-i and power supply terminal assignments



### **Information!**

*The cable indicated by grey must not have slaves or repeaters connected to it.  
The yellow cable must not have AS-i power suppliers or additional masters connected to it.*



### **Information!**


*The function ground can be connected either to the grounding screw or to the terminal.  
The function ground should be made with as short a cable as possible to ensure good EMC characteristics.  
Therefore function grounding using the grounding screw is preferred.*



### **Attention!**

*The AS-I power supply for the AS-I components must have isolation per IEC 60 742 and be able to handle momentary power interruptions of up to 20 ms. The power supply for the 24 V supply must also have isolation per IEC 60 742 and be able to handle momentary power interruptions of up to 20 ms. The maximum output voltage of the power supply must also be less than 42 V in case of a fault.*

**8.4.1 Electrical connection VBG-ENX-K30-DMD-S16-C1, VBG-ENX-K30-DMD-S16-EV**



Terminal	Signal / Description
+ASI 1-	Connection to AS-i Circuit 1
+AS-i 2-	Connection to AS-i Circuit 2
ASI +PWR-	Supply voltage for AS-i Circuits (max. 8 A)
FG	Function ground



**Information!**


AS-i Circuit 1 and 2 are both powered from a Pepperl+Fuchs power supply!  
No other power supplies are approved!



**Information!**

For additional information, please refer to the section <AS-i and power supply terminal assignments>.

8.4.2 Electrical connection VBG-ENX-K30-DMD-S16



Terminal	Signal / Description
+ASI 1-	Connection to AS-i Circuit 1
+ASI 2-	Connection to AS-i Circuit 2
ASI 1 +PWR-	Supply voltage for AS-i Circuit 1 (max. 8 A)
ASI 2 +PWR-	Supply voltage for AS-i Circuit 2 (max. 8 A)
FG	Function ground



**Information!**

AS-i Circuits 1 and 2 are powered by separate power supplies.

**Information!**


For additional information, please refer to the section <AS-i and power supply terminal assignments>.

## 8.5 Diagnostics interface

The service and diagnostics interface (in conjunction with **AS-i Control Tools** or **ASIMON 3 G2** software) is used for communication between the PC and the unit.


### 8.5.1 VBG-ENX-K30-DMD-S16-C1, VBG-ENX-K30-DMD-S16

The service and diagnostics interface is configured as a mini DIN-6 female and it is placed on the front plate, on the left hand side.




### 8.5.2 VBG-ENX-K30-DMD-S16-EV

The service and diagnostics interface in these devices is as RJ45 female configured and it is placed on the front plate, on the left hand side.



### 8.5.3 SafeLink via ethernet (VBG-ENX-K30-DMD-S16-EV)


The device supports SafeLink via Ethernet. In order to establish a safe coupling between several devices, they should be connected via the ethernet diagnostics interface to a switch.



#### **Information!**

Please refer here to the information in the section <Safe Link>.

### 8.6 Chip card



The configuration is stored in a fixed installed EEPROM and can be overwritten by the chip card. The chip card does not have to be inserted in operation.



**Warning!**

*Power must always be turned off when removing or inserting the chip card!*


### 8.7 Ethernet interface



The ethernet interface consists of two RJ-45 sockets. It is placed on the left housing side (see section <Overview of terminals, indicators and operating elements>). The ethernet interface is driven according to the IEEE 802.3

## 8.8 Release circuits

### 8.8.1 Wiring overview of safety unit



#### 1.Y1 (EDM 1/Start 1), 2.Y1 (EDM 2/Start 2), 1.Y2 (EDM 3/Start 3), 2.Y2 (EDM 4/Start 4)

The safety unit provides 4 inputs. The EDM & START inputs can be defined freely. The inputs may not be connected to other potentials, but rather only directly or through potential-free switches to + (for EDM/START). Switching current static 4 mA at 24 V, dynamic 30 mA at 24 V (T=100 µs).

#### 3.14, 4.14

Semiconductor outputs. Max. contact load: 0.5 A DC-13 at 30 V.

#### 1.13, 1.14; 2.13, 2.14

Potential-free relay contacts. Safety relay with one contact set for read-back. Max. contact load: 3 A AC-15 at 30 V, 3 A DC-13 at 30 V.

#### 0 V, 24 V


Semiconductor outputs are powered by separate 24 V DC.

#### +1, +2, +3, +4 (for EDM/Start)

Output supply, powered by AS-i. May not be connected to other potentials, but rather only directly or through potential-free switches to one of the EDM or START inputs. Voltage 30 ... 15 V<sub>DC</sub>.

## 8.9 Indicators and operating elements

### 8.9.1 LED indicators – master



The LED's on the front panel of the device indicate:

#### **Power**

The master is receiving sufficient power.

**net** (the bi-color LED indicates the state of the ethernet port)

LED red: no valid ENIP- or CIP connection.  
LED green: at least one ENIP- or CIP connection present

#### **config error**

Configuration error.  
At least one configured slave is missing, or at least one detected slave is not configured, or for at least one configured and detected slave the actual configuration data does not match the nominal configuration data, or the master is in the startup process.  
This LED flashes if a peripheral fault has been detected for at least one AS-i slave on the AS-i network. If there are configuration errors as well as periphery faults, only the configuration error is displayed.

#### **U AS-i**

The AS-i network is sufficiently powered.

#### **AS-i active**

Normal operation is active


#### **prg enable**

Automatic single node replacement is enabled.  
Exactly one slave is missing in the protected operating mode. The slave can be replaced by another slave of the same type with address zero. The master automatically addresses the new slave to the faulty address and thus corrects the configuration error

#### **prj mode**

The AS-i master is in configuration mode.

### 8.9.2 LED indicators - safety unit



The LED's on the safety unit indicate:

#### Aux

24 V supply for the semiconductor outputs is present.

#### 1Y.1, 1Y2, 2Y.1, 2Y.2

Input 1.Y1 (EDM 1/Start 1), 2.Y1 (EDM 2/Start 2), 1.Y2 (EDM 3/Start 3), 2.Y2 (EDM 4/Start 4) is turned on.

#### K1, K2

Contact sets 1.13, 1.14 (K1) resp. 2.13, 2.14 (K2) closed.

#### K3, K4

semiconductor output 3.14 (K3) resp.4.14 (K4) is turned on.



#### Information!

If there is no auxiliary voltage connection available, LEDs are turned off, even if the corresponding release circuit is turned on.

### 8.9.3 Buttons

The buttons are used for the following:

**Mode/↑**

Switching between configuration mode and protected operating mode, and saving the current AS-i configuration as the nominal configuration.

**Set/↓**

Selecting the address of and assigning an address to a slave.

**OK**

Change to extended mode.

**ESC/Service**

For teaching the code table for a new safe slave, when exactly one safe slave is being replaced, and for unlocking the Safety Monitor. This button is also used to exit extended mode.

For additional information see:

- <Section <Function of the ESC/Service key>
- <Section <Replacing a defective safety-configured AS-i slave>
- <Section <Operation in advanced display mode>.

## 9. Function and startup of the Safety Monitor

Configuration and startup of the AS-i Safety Monitor is accomplished using a PC/ Notebook and the **ASIMON 3 G2** configuration software.

The operating language of the device can be set for the respective country (see section <Operation in advanced display mode>).



### **Information!**

*The description of the **ASIMON 3 G2** software and startup of the AS-i Safety Monitor can be found in the manual "**ASIMON 3 G2 AS-i Safety Monitor Configuration Software for Microsoft®-Windows®**".*

*The software manual is an important component of the operating manual for the AS-i Safety Monitor. It is not possible to configure and start up the AS-i Safety Monitor without the **ASIMON 3 G2** software.*

Configuration may be performed only by a safety authorized person. All safety-related commands are password protected.

### 9.1 Powering up the device

As soon as supply voltage is present on the device an internal system test is started. This operating state is indicated by lighting of the upper LED row.

### 9.2 Configuration of the safety functions

The device can be configured in several ways:

1. Using **ASIMON 3 G2** software  
The **ASIMON 3 G2** software represents the most universal method of configuring the Safety Monitor. Here the behavior of the Safety Monitor can be determined by linking various monitoring modules. After being sent to the Safety Monitor, this configuration is verified and can then be validated. For additional information, refer to the separate manual for the **ASIMON 3 G2** configuration software.
2. Using a chip card with the master configuration  
Configurations stored on the chip card, which are validated but which do not contain any code sequences, can be sent to the device. The code sequences must then be taught to the corresponding safety AS-i slaves. This procedure is useful when you want to use a safety program in several safety monitors without any changes.



### **Information!**

*For additional information refer to section <Description of configuration using chip card with master configuration>.*

3. Using a chip card with complete configuration  
In contrast to the master configuration, the complete configuration also contains the code sequences for all included slaves. Sending the complete configuration from the chip card to the Safety Monitor can make replacement of the device enormously simpler and faster.



**Information!**

For additional information refer to <Configuration using a chip card with complete configuration>.

### 9.2.1 Description of configuration using ASIMON 3 G2 software

The following description represents a short guide to configuring the AS-i Safety Monitor. For a detailed description of the **ASIMON 3 G2** software, refer to the corresponding manual for the **ASIMON 3 G2** configuration software.

The **ASIMON 3 G2** software is responsible for the following:

- Configuring the AS-i Safety Monitor
- Documenting the device configuration
- Starting up the AS-i Safety Monitor
- Diagnosing the AS-i Safety Monitor



**Information!**

The description of the **ASIMON 3 G2** program can be found in the separate software manual.

Proceed as follows:

- Install the program on your PC.
- Apply power to the AS-i Safety Monitor



**Information!**

To prevent ESD damage, we recommend grounding at an appropriate location before plugging in the interface cable to the Safety Monitor.

- Connection of monitors with a RS 232 diagnostics interface
  - To connect, plug the diagnostic cable end with the PS2 connector into the socket of the diagnostic interface (RS 232) of the monitor and the other end with the 9-pin Sub-D socket connector to a free COM port (serial RS232 interface) on your PC (see section "Connection between the AS-i Safety Monitor and the PC" in the software manual).
- Configure the AS-i Safety Monitor and start it up as described in the software manual.



**Attention!**

Before starting up the device you must adapt the device configuration to your application. This means configuring the AS-i Safety Monitor according to the software manual so that the location to be protected is in fact protected by the device.

### 9.2.2 Description of configuration using chip card with master configuration

Generating a master configuration:

- Generate a configuration using the **ASIMON 3 G2** software
- Load the configuration into the device
- Release (validate) the configuration, but do not teach the code sequences
- The code sequences will be taught on the physical AS-i circuit



**Attention!**

*Safety advisory:*

*Ensure that the chip card contains the configuration intended for and released for the application!*

*This can be done by comparing the release codes on the display (section <Operation in advanced display mode>):*

- The safety representative who generated and validated the release code stores the release code for the master configuration and approves use of the configuration for specific equipment.
- The person performing the startup reads out the release code on the display before teaching the code and compares it with the release code stored and approved for the equipment.

*After the chip card has been used to load the configuration into the device, the safety functions of the device must be checked in the equipment.*

*Checking of the release code and testing the system must be documented in writing and is part of the system documentation.*

### 9.2.3 Configuration using a chip card with complete configuration

The chip card contains the complete configuration if:

- An empty chip card is plugged into an AS-i Safety Monitor which already contains a complete configuration, or
- The chip card is already inserted while the configuration is being written into the device using **ASIMON 3 G2** software and before validating the code sequences.

If the AS-i Safety Monitor needs to be replaced, the stored configuration can be transferred by simply plugging the chip card from the old device into the new one.



**Attention!**

*Safety advisory:*

*Power must always be turned off when removing or inserting the chip card!*

*Ensure that the chip card contains the configuration intended for and released for the application!*

*This can be done by comparing the release codes on the display (section <Operation in advanced display mode>):*

- The safety representative who generated and validated the release code stores the release code for the master configuration and approves use of the configuration for specific equipment.
- The person performing the startup reads out the release code on the display before starting the equipment and compares it with the release code stored and approved for the equipment.

*After the chip card has been used to load the configuration into the device, the safety functions of the device must be checked in the equipment.*

*Checking of the release code and testing the system must be documented in writing and is part of the system documentation.*

### 9.3 Safety-relevant documentation of the application



**Information!**

*The detailed description of the safety-relevant documentation of the configuration for your application can be found in the separate software manual.*

Proceed as follows:

- Create the configuration of the AS-i Safety Monitor for your application.
- Validate the configuration (done by the safety supervisor).
- Print out the final configuration protocol and optionally the configuration overview (see Section "Configuration documentation" in the software manual).
- Sign the final configuration protocol (done by the safety supervisor).
- Take the protocol for the safety-relevant documentation for your application (machine documentation) and keep it in a safe place.

### 9.4 Diagnostic data



**Information!**

*A detailed description of the setting for diagnostics mode is described in the section "Setting diagnostics type" in the separate manual "AS-i 3.0 Command Interface".*

Diagnostics data can be obtained in any of 4 ways:

- Display
- Ethernet
- **ASIMON 3 G2** software via diagnostic interface
- AS-i Control Tools via diagnostic interface or Ethernet

The following diagnostics can be displayed (see section <INT MON (internal monitor)>):

- Display of the switching state of the outputs
- State ("color") of the devices and sub-devices<sup>1</sup>; distinction when turning off only half ("Category 2")
- Error history for finding the cause of sporadic errors

### 9.5 Switch-off history

The switch-off history, accessible from the menu DIAGNOSTICS->INT MONITOR->LAST DIAGNOSTIC, is intended to make reconstruction of the reason for switch-off easier for the user. The states of all safety-relevant AS-i slaves and all devices at the time the state change on the output device (change from green to another color) are stored.

---

1. For the sake of better diagnostics that procedure is being expanded using a Device/Device Color for adding diagnostics based on AS-i addresses (sub-devices) and their states.

9.6 Diagnostic values in the IDI



**IDI diagnostics can be optionally enabled for the following devices:**

- VBG-ENX-K30-DMD-S16-C1 ident. no.  $\geq$  15211
- VBG-ENX-K30-DMD-S16 ident. no.  $\geq$  15210
- VBG-ENX-K30-DMD-S16-EV ident. no.  $\geq$  15186

The input values for safety-relevant input slaves can be substituted in various ways. This makes the diagnostics information available directly in the cyclical I/O data. The default setting is the "substitution values" for the two input channels. Setting diagnostics values also sends 2 bits of color information for the associated safety-relevant component in addition to the input channels. The substitution possibilities are defined in the following tables:

Bit 3	Bit 2	Bit 1	Bit 0	Description
0	0	0	0	Both channels off
0	0	1	1	2nd channel off, 1st channel on
1	1	0	0	2nd channel on, 1st channel off
1	1	1	1	Both channels on

Tab. 9-6. Default status substitution values

Bit 3	Bit 2	Bit 1	Bit 0	Description
		0	0	Both channels off
		0	1	2nd channel off, 1st channel on
		1	0	2nd channel on, 1st channel off
		1	1	Both channels on
0	0			Device color: red, green or blue
0	1			Device color yellow: ("wait")
1	0			Device color: yellow flashing ("test")
1	1			Device color: red flashing ("error")

Tab. 9-7. Diagnostic values



**Information!**

The switching state of channel 1 and channel 2 (channel 1, channel 2 'on' or 'off', bit 0, bit 1) is sent at optimal speed. The device colors (bit 2, bit 3) have device-internal lower priority and can be sent slower.

The diagnostic values bit 0/1 and 2/3 are not synchronized. The states of the input channels and the resulting color can be sent at different times.



**Information!**

The color and thereby the status of the component do not always have to agree with the switching state of the input channels. In case of lost telegrams, untaught slaves or non-synchronous switching of the two channels, error and test states may result (red flashing and yellow flashing).

**9.7 Password protection**

All safety-related commands are password protected. These include:

- Loading configurations into the Monitor
- Stopping
- Learning code sequences
- Releasing
- Changing the password



**Information!**

No new release is necessary if when using safety-configured AS-i slaves code sequences have been newly learned using the ESC/Service key.

**9.7.1 Procedure for configuring and teaching code sequences**

The configuration is created using **ASIMON 3 G2** software, loaded into the safety unit and released. The name of the person releasing and the date are stored at this moment. If code sequences controlled through the display are newly taught, this is secured by a PIN to prevent unintended/unauthorized changing of the code sequences.



**Information!**

For additional information see section <Replacing a defective safety-configured AS-i slave>.

- A PIN is a 4-digit number and can only be changed from the display, not via the **ASIMON 3 G2** software.
- After entering the PIN, the display can be used to start a teaching procedure for the code sequences. The monitor stops immediately after entering the PIN. After teaching, the monitor starts after a prompt and acknowledgement on the display.

Action	ASIMON Software	On AS-i Safety Monitor
Configure and load into Safety Monitor	•	• (only from chip card)
Stopping	•	•
Releasing	•	–
Starting	•	•
Teaching code sequences	•	•
Changing the password	•	• (only from chip card)

Tab. 9-8.

Action	ASIMON Software	On AS-i Safety Monitor
Changing the PIN	–	•

Legend:

"•" = possible;

"–" = not possible

Tab. 9-8.

Code sequences for releasing a configuration do not necessarily have to have been successfully learned. It is also possible to release without code sequences, which must then be learned at a later time.

Teaching the code sequences is simple to perform:

- Using the ESC/Service key (See section <Replacing a defective safety-configured AS-i slave>)
- or
- Using the display (See section <Operation in advanced display mode>).

### 9.7.2 Function of the ESC/Service key

In traditional (classical) display mode, the ESC/Service key takes on two kinds of functions:

- Briefly pressing the ESC/Service key unlocks the Safety Monitor when red is flashing
- A longer press (3s) starts the teach procedure for a slave.



**Information!**

For additional information see section <Replacing a defective safety-configured AS-i slave>.

### 9.8 Safe coupling slaves on the AS-i circuits

The two AS-i circuits are capable of emulating a total of up to sixteen safe coupling slaves.

The assignment of the coupling slaves addresses to the release circuits is made using the ASIMON software.

### 9.9 Chip card

The chip card is divided into two areas. One area is reserved for unsafe data and administration, the other for safe data.

**Warning!**

Always turn off power before inserting or removing the card.



#### 9.9.1 Unsafe data

This section describes the system behavior of the unsafe system section when using the chip card.

### 9.9.1.1 Card unformatted

If an unformatted card is found when the device is started, the following is displayed:

```
NEW CHIPCARD  
WILL BE FORMATED  
AS-I DATA WILL  
BE SYNCHRONIZED
```

The chip card is formatted and then the data copied to the chip card.

### 9.9.1.2 Data not compatible

If a card is found whose data are incompatible with the device, the following error message is displayed:

```
CHIPCARD NOT  
COMPATIBLE
```

### 9.9.1.3 Card empty

The following message is displayed for an empty card:

```
CHIPCARD FOUND  
AS-I DATA WILL  
BE SYNCHRONIZED
```

From this time on all changes are made both in the device and on the chip card.

### 9.9.1.4 Data compatible

When starting with an empty device (e.g. after a factory reset) a non-empty card is found whose data are compatible with the device, the following message is displayed:

```
AS-I DATA FROM  
CHIPCARD TAKEN
```

The card configuration is written to the device. From this time on all changes are made both in the device and on the chip card.

### 9.9.1.5 Data in the device and on the chip card identical

If the card and device are not empty at start and the data are identical, no message is displayed.

### 9.9.1.6 Data in the device and on the chip card not identical

If the card and device are not empty at start and the data are not identical, an error message is displayed and the card is not synchronized with the device. The following menu is then automatically opened:

```
CHIPCARD AND  
AS-I DATA  
DIFFERENT  
CARD->MASTER  
MASTER->CARD  
CONTINUE
```

#### Description

CHIP CARD>MASTER: Chip card data are copied to the master

MASTER->CHIPCARD: Master data are copied to the chip card

NEXT: No change to the data

The menu can be exited by pressing the ESC/Service key without changing the data.

### 9.9.2 Safe data

This section describes the system behavior of the safe unit when using the chip card.

In general the safe part of the chip card has 4 memory banks (A...D). A bank is referred to as an active bank. Unless otherwise stated, the operations described in the following are always performed on the active bank.

#### 9.9.2.1 Data incompatible

If a card with incompatible data is found, the following error message is output:

```
CHIPCARD NOT  
COMPATIBLE
```

### 9.9.2.2 Data compatible

If a card with an empty active memory bank is found, the safety configuration including code sequences is written to the card and in future all changes are made in the card and in the device at the same time. The following message is displayed on the device:

```
CHIPCARD FOUND .
SAFETY DATA WILL
BE SYNCHRONIZED
```

### 9.9.2.3 Complete configuration

If when starting with an empty device a card with a released safety configuration including code sequences is found (Complete safety configuration) in the active memory bank, this configuration is written to the device, then the menu for releasing using Release Code is opened:

```
COPY BANK A
TO MONITOR
RELEASE DATE :
2006/06/17 18:43
BY: ROLF BECKER
CONFIG NAME :
L3040 MIT LADEVO
RRICHTUNG LINKU
ND PALETTENWECHS
LER V1.23
RELEASE CODE : 1BDF
- - - - -
- - - - -
TYPE CODE
0000
OK
```

If the active bank contains a Complete Configuration and if the data in the active bank on the memory card and the data in the device are identical (e.g. both empty), in future all changes are made in the card and in the device at the same time.

### 9.9.2.4 Data on the chip card and in the device are identical

If the card and device are not empty at start and the data are identical, no message is displayed.

### 9.9.2.5 Data not identical

If the active bank on the memory card and in the device are not empty at start and the data are not identical, the following message is displayed:

```
ERROR .  
CHIPCARD AND  
SAFETY DATA  
DIFFERENT .  
DELETE CHIPCARD  
OR SAFETY DATA
```

The safety unit will not operate in this case. You must either clear the device or the active bank via menu.

### 9.9.2.6 Operating the chip card from the menu

The data on the chip card can, as described in section <SAFE CHIPCARD>, be exchanged between the Monitor and the chip card. Note however the following:

In order to store a configuration on the chip card as a master configuration (i.e. without code sequences), proceed as follows:

- Write the released configuration into the Monitor without code sequences.
- Copy the configuration into a memory bank using the menu.

For additional information, see section <CARD →MONITOR (copy card data to the Monitor)>.

To convert a master configuration on the memory card to a Complete Configuration, this configuration must be overwritten by a Complete Configuration.

This is done as follows:

- Copy the card data to the Monitor.
- Teach the code sequences
- Write the data from the Monitor to the card.

### 9.9.3 Working with multiple memory banks

The chip card has four memory banks, each of which may contain a configuration (Complete or Master configuration). One of the banks is the active bank.

The AS-i 3.0 EtherNet/IP+Modbus TCP Gateway with integr. Safety Monitor always independently utilizes the active bank. Menu commands can however be used to copy the other memory banks to the AS-i Safety Monitor.

The corresponding memory bank thereby becomes the active bank.

If configurations from another memory bank are copied, a few safety rules need to be followed:



**Attention!**

*Safety advisory:*

*Ensure that the configuration intended for and released for the application is used!*

*This can be done by comparing the release codes on the display (See section <MONITOR CONFIG>):*

- The safety representative who generated and validated the configuration stores the release code for the configuration (Complete or Master) stores the release code for the configuration and approves use of the configuration for specific equipment.
- The person performing the startup reads out the release code on the display before starting the equipment or before teaching the code sequences in the case of master configurations and compares it with the release code released for the equipment.

*After the chip card has been used to load the configuration into the device, the safety functions of the device must be checked in the equipment.*

*Checking of the release code and testing the system must be documented in writing and is part of the system documentation.*

## 10. Operation in advanced display mode



### **Information!**

*You will find a description of the display menu in the separate document "Display\_Menue".*

## 11. Advanced Diagnostics for AS-i Masters

The advanced AS-i diagnostics is intended to localize occasionally occurring configuration errors and to determine the quality of data transmission on AS-i without using additional diagnostics tools.

AS-i Control Tools, a MS-Windows software designed to simplify AS-i installation and used to program AS-i Control, enables operation of the advanced diagnostics functions (LCS, error counters, and LOS).

### 11.1 List of corrupted AS-i Slaves (LCS)

The LCS contains the information from the Delta list. In addition to the list of configured slaves (LPS), the list of detected slaves (LDS), and the list of activated slaves (LAS), the AS-i master creates a fourth list, the list of corrupted slaves (LCS) containing advanced diagnostics data used to diagnose the causes for intermittently occurring configuration errors on AS-i. This list contains entries for all AS-i slaves that were responsible for at least one intermittent configuration error since the list was last read or since the AS-i master was turned on. Furthermore, intermittent AS-i power failures are listed in the LCS at the position of AS-i slave with address 0.



**Information!**

*Whenever the LCS is read it is deleted from memory.*

**Information!**

*The last intermittent configuration error can also be displayed on the AS-i master: Pressing the "Set" button on the AS-i master initiates the display of the AS-i slave responsible for the last intermittent configuration error. If a intermittent AS-i power failure occurred, the display shows 39 after pressing the "Set" button. This function is only available if the device is in normal operating mode of the protected mode (display empty) or in the off-line phase (Display: "40").*

### 11.2 Protocol analysis: Counters for corrupted data telegrams

The AS-i master with advanced diagnostics provides a counter for telegram repetitions for each AS-i slave. The counter counts up every time a corrupted data telegram has been found, making it possible to determine the quality of the transmission if only a few telegrams are corrupt and the AS-i slave never caused a configuration error.



**Information!**

*The counter values are read via the host interface and will be deleted after they were read. The highest possible counter value is 254. 255 indicates a counter overflow.*

Displaying the protocol analysis is possible through the AS-i Control Tools software by using the command "Master | AS-i Diagnostics".

### 11.3 Offline Phase for Configuration Errors

The AS-i masters with advanced diagnostics offer the possibility to set themselves into the offline phase when a configuration error occurs and thus are able to transition the AS-i network into a safe operational state. This ensures a quick reaction to a configuration error and the host can be relieved from this task. If any problems occur on the AS-i network, the AS-i masters can independently switch the AS-interface into a safe state.

There are two different ways to parameterize the AS-i master for this feature:

- Any configuration error occurring on AS-i switches the master from regular operation in protected mode into the offline phase.
- o . A list with the addresses of slaves that can potential initiate the off-line phase is defined (list of offline slaves LOS).

The user can decide how the system should react to a configuration error on AS-i. Thus, the AS-i master can be set to the offline phase for critical AS-i slaves, whereas for less critical slaves only the error message is sent to the host, but AS-i is still running.

Like the advanced diagnostics, the parameterization "offline phase on configuration error" is also supported by "AS-i-Control-Tools" (Command | Characteristics | Offline because of configuration error).

There are two options to reset the error message "OFFLINE BY LOS":

1. Deleting the complete LOS list on the affected AS-i network ("CLEAR ALL").
2. Power reset on the affected AS-i network.



**Attention!**

*If a power reset occurs on the AS-i network 1 the complete double gateway will be shut down.*

### 11.4 Functions of the AS-i Fault Detector

#### 11.4.1 Duplicate address detection

If two slaves on an AS-i network have the same address, a duplicate address exists. Since the master cannot communicate individually with these slaves any longer, this is considered an error. Because the two slave replies interfere, it is impossible for the master to recognize the slave responses. This results in extremely unstable network behavior.

The duplicate address detection function is used to safely recognize a duplicate address and to display it on the screen and in AS-i Control Tools.

A duplicate address causes a configuration error and is displayed on the screen.



**Information!**

*Duplicate addresses can be recognized only on an AS-i segment directly connected to the master.*

#### 11.4.2 Earth/Ground Fault Detector

An Earth/Ground Fault exists when the voltage  $U_{\text{GND}}$  (Nominal value of  $U_{\text{GND}}=0,5 U_{\text{AS-i}}$ ) is outside of the following range:

$$10\% U_{\text{AS-i}} \leq U_{\text{GND}} \leq 90\% U_{\text{AS-i}}$$

This error substantially limits the noise immunity of the AS-i communication.

Ground faults are indicated on the master's display as well as in AS-i Control Tools.



**Information!**

*To recognize ground faults the master must be grounded with its machine ground connection.*



**Information!**

*A ground fault in one of the two networks of a double master in a version 1 power supply for two AS-i networks causes a ground fault in the other network as well because of the the existing galvanic connection.*

#### 11.4.3 Noise Detector

The noise detector detects AC voltages on AS-i, that are not initiated by an AS-i master or AS-i slaves. These interference voltages can cause telegram disturbances.

A frequent cause are insufficiently shielded frequency inverters or improperly routed cables.

Noises is indicated on the master's display as well as in AS-i Control Tools.

#### 11.4.4 Over-voltage Detector

Over-voltages are present if the conductors of an AS-i network that normally are routed electrically symmetrical with respect to machine ground, are strongly electrically raised. A cause can for example be startup procedures of large consumers.

However, over-voltages do generally not interfere with the AS-i communication, but can under certain circumstances cause incorrect sensor signals.

Over-voltages are indicated on the master's display as well as in the AS-i Control Tools.

### 11.5 Functions of the new generation of AS-i Gateways

The new generation scores with further optimized diagnostics, several additional functions and even greater operating convenience.




**Information!**

*A listing of the individual devices and their features can be found in section <New Generation of AS-i Gateways with ethernet diagnostics interface>.*

#### 11.5.1 C-programmable Gateways

Main menu || SETUP || AS-I CONTROL || CONTROL FLAGS ||


The devices programmed in C are able themselves to take over a great number of control tasks. In smaller systems the user will even be able to do without a PLC altogether: if desired the C program can function as a full mini-PLC. In more complex applications the C-programmable Gateways make the work of the PLC easier - for example by pre-processing special functions.



#### 11.5.2 Interchangeable memory card

Main menu || SETUP || CHIPCARD || AS-I CHIPCARD ||


Interchangeable memory card: redundant memory for C program and device configuration.



#### 11.5.3 Earth fault monitor

Main menu || DIAGNOSE || ASI WATCHDOG ||

The new earth fault monitor allows the service technician to detect whether an earth fault has occurred directly on AS-i



or on a sensor line.

```
1.
Earth fault sen.
```

The menu **EFLT Ratio** shows the asymmetry of the AS-i network, referenced to ground (see sketch).



```
EFLT Ratio:           ↑
AS-i+ 2%
AS-i DC Voltage: 1
                   31,3V
                                     ↓
```

```
EFLT Ratio:           ↑
AS-i+ 100%
AS-i DC Voltage: 2
                   31,5V
                                     ↓
```

#### 11.5.4 Current can be read directly on the unit

Now the devices display both the maximum current and the current actually present in the respective AS-i circuit. Heavy consumers or a strong overload in an AS-i circuit are then easy to detect. Plus you can set the maximum current in the AS-i circuit on these devices. This ensures line protection even when using large 24V power supplies.

```
AS-i power
Reset
Maximal:             2
                   1,3A
                                     ↓
```

```
Maximal:      ↑
    1,3A
current:      2
    0,3A      ↓
```

```
Current:      ↑
    0,3A
Current limiting 2
    3,2A      ↓
```

### 11.5.5 Self-resetting fuses

Main menu || SETUP || CURRENT LIMIT ||

Thanks to self-resetting fuses in the "1 Gateway, 1 power supply for 2 AS-i circuits" Gateway version, when there is a short circuit in one of the two AS-i circuits the other circuit and the Gateway remain operational - the host controller keeps receiving diagnostic information from AS-i, which also provides meaningful assistance towards rapid troubleshooting.

The fuse resets itself periodically to check if the error is solved. The measured current value is available as diagnostic information at the field on the display and at the control level.

```
Current limiting
    3,2A
    2
```

### 11.5.6 AS-i Power24V capable

Main menu || SETUP || ASI POWER ||

Gateways for AS-i Power24V have been developed especially for use in small systems. They don't need any special AS-i power supply. With a standard 24V power supply a 50 m line length and with an AS-i power supply min. 100 m line length can be realised.

```
AS-i Power
24V geerdet
change
```

```
AS-i Power  
AS-i PWR Supply  
change
```

### 11.5.7 Ethernet diagnostics interface with web server

These devices allow diagnostics for both the Gateway and the AS-i networks (including Safety technology) over Ethernet without additional software. AS-i network can be thus a part of a remote maintenance concept. Moreover the configuration file are stored on the web server and so they are always within reach.

### 11.5.8 Transitionless operating mode changes

Main menu || SETUP || **MODE CHANGE** ||

These devices are able to change the operating mode from projecting mode to the protected operating mode without having to first go to the "offline phase".

This means the Slave outputs are not cleared and the safe Slaves not turned off.

Activation and deactivation is set using the Ethernet start parameterization.

This function must be explicitly activated; the default setting is "Deactivated."

The setting for activated and deactivated is saved, which means that it remains set after a "power cycle".

```
Mode Change
```

```
Offline Phase  
yes  
change
```

## 12. EtherNet/IP Interface

### Object modelling

The attributes of bus participants are mapped into objects in the CIP family (DeviceNet, ControlNet and EtherNet/IP) bus systems.

In addition to for all EtherNet/IP devices common objects, there are other objects in the AS-i gateways to access the data of the AS-i network:

- Identity
- Assembly
- AS-i master
- AS-i slave
- I/O data
- Advanced diagnostics
- Short command interface
- Long command interface
- Safety Control Status (internal)
- Safety Control Status (external)

Class code	Object name	Number of instances
1 (0x01)	Identity	1
2 (0x02)	Message router	1
4 (0x04)	Assembly	24 (single master (e.g.: "2447")) 86 (double master, (e.g.: "2761"))
6 (0x06)	Connection manager	1
71 (0x47)	Device level ring	1
72 (0x48)	Quality of service	1
100 (0x64)	AS-i master	1 for each AS-i circuit
101 (0x65)	AS-i slave	64 for each AS-i circuit
102 (0x66)	E/A data	1 for each AS-i circuit
103 (0x67)	Advanced diagnostics	1 for each AS-i circuit
104 (0x68)	Short command interface	1
105 (0x69)	Long command interface	1
106 (0x6A)	Safety Control Status internal Monitor	1
107 (0x6B)	Safety Control Status external Monitor	1 for each AS-i circuit

Tab. 12-9.

12.9.2013

## 12.1 Identity object

class code: 1 (0x01)  
number of instances: 1  
instance attributes

Attribute ID	Access Rule	Name	Value
1 (0x01)	get	vendor	5
2 (0x02)	get	device type	12
3 (0x03)	get	product code	e. g.: "2448" (double master) e. g.: "2447" (single master)
4 (0x04)	get	revision	1.1
5 (0x05)	get	status	see overview listed below
6 (0x06)	get	serial number	unique number, 32-bit
7 (0x07)	get	product name	e. g.: "VBG-ENX-K30-DMD-S16"

Tab. 12-10.

### Common services

Service Code	Class	Instance	Service name
5 (0x05)	no	yes	code 1 (class + instance)
16 (0x10)	yes	yes	get attributes all
14 (0x0E)	yes	yes	get attributes all

Tab. 12-11.

## 12.2 Device Level Ring Object

Class Code: 71 (0x47)  
number of instances: 1  
instance attributes

Attribute ID	Access Rule	Name	Value
1 (0x01)	get	network topology	0 (linear), 1 (ring)
2 (0x02)	get	network status	0 (normal), 1 (ring fault)
10 (0x0E)	get	active supervisor address	byte 0-3: ip-adress, byte 4-9: mac-adress
12 (0x0C)	get	capability flags	1 (announce-based ring node)

Tab. 12-12.

### Common Services

Service Code	Class	Instance	Service Name
1 (0x01)	yes	yes	get attributes all
14 (0x0E)	yes	yes	get attribute single

Tab. 12-13.

### 12.3 Quality of Service Object

Class Code: 72 (0x48)  
number of instances: 1  
instance attributes

Attribute ID	Access Rule	Name	Value
1 (0x01)	get/set	802.1q tag enable	0 (disabled), 1 (enabled)
4 (0x04)	get/set	dscp urgent	dscp after rfc 3168 for cip class 0/1 urgent (default 55)
5 (0x05)	get/set	dscp scheduled	dscp after rfc 3168 for cip class 0/1 scheduled (default 47)
6 (0x06)	get/set	dscp high	dscp after rfc 3168 for cip class 0/1 high (default 43)
7 (0x07)	get/set	dscp low	dscp after rfc 3168 for cip class 0/1 low (default 31)
8 (0x08)	get/set	dscp explicit	dscp after rfc 3168 for cip class 3/ucmm (default 27)

Tab. 12-14.

#### Common Services

Service Code	Class	Instance	Service Name
14 (0x0E)	no	yes	get attributes single
16 (0x10)	no	yes	get attribute single

Tab. 12-15.



**Information!**

The new settings take effect only after a device restart.



**Information!**

If "802.1Q Tag Enable" is turned on, the VLAN ID set in the device menu "Ethernet" -> "EtherNet/IP" -> "VLAN ID" is used.



**Information!**

The integrated switch uses four internal priority queues.



**Information!**

The VLAN ID is only used if in the EtherNet/IP Quality of Service Object (0x48) Attribute 1 (802.1Q Tag Enable) is set to 1 (= ON), so that Ethernet frames are sent in accordance with IEEE 802.1Q.

Mapping of the SDCP and 802.1D priorities to the queues is as follows:

Switch queue	DSCP	802.1D priority
4 (highest priority)	59	7
3	46, DSCP Urgent, DSCP Scheduled, DSCP High	4, 5, 6
2	24, DSCP Low, DSCP Explicit	2,3
1 (lowest priority)	other values	0,1

Tab. 12-16.

## 12.4 Assembly Object

class code 4 (0x04)  
 number of instances: 86

The Assembly Object handles data from the application objects.

The Assembly Object Instances consist of (in case of a double master):

- A-slaves and/or single slaves from circuit 1
- single, A- and B-slaves (all slaves) from circuit 1
- A-slaves and/or single slaves from both circuits
- single, A- and B-slaves (all slaves) from both circuits
- no 16-bit data
- no command interface
- short command interface
- long command interface
- no safety FB bits/status
- safety FB bits/status
- 16-bit data of slaves 10 ... 31 from circuit 1 (or from both circuits) sorted in ascending order
- 16-bit data of slaves 29 ... 31 from circuit 1 (or from both circuits) in the following format:

### 16-bit data of slaves 29 ... 31

byte	data item (attribute ID=3)
n	Slave 31 ch1 high byte
n+1	Slave 31 ch1 low byte
n+2	Slave 31 ch2 high byte
n+3	Slave 31 ch2 low byte
n+4	Slave 31 ch3 high byte
n+5	Slave 31 ch3 low byte
n+6	Slave 31 ch4 high byte
n+7	Slave 31 ch4 low byte
n+8	Slave 30 ch1 high byte
n+9	Slave 30 ch1 low byte
n+10	Slave 30 ch2 high byte
n+11	Slave 30 ch2 low byte
n+12	Slave 30 ch3 high byte
n+13	Slave 30 ch3 low byte
n+14	Slave 30 ch4 high byte

Tab. 12-17.

**16-bit data of slaves 29 ... 31**

n+15	Slave 30 ch4 low byte
n+16	Slave 29 ch1 high byte
n+17	Slave 29 ch1 low byte
n+18	Slave 29 ch2 high byte
n+19	Slave 29 ch2 low byte
n+20	Slave 29 ch3 high byte
n+21	Slave 29 ch3 low byte
n+22	Slave 29 ch4 high byte
n+23	Slave 29 ch4 low byte

Tab. 12-17.

Instances 100 (0x64) ... 135 (0x87), 172 (0xAC), 174 (0xAE), 176 (0xB0), 178 (0xB2), 180 (0xB4), 182 (0xB6) and 184 (0xB8) can only be read, while instances 136 (0x88) ... 171 (0xAB), 173 (0xAD), 175 (0xAF), 177 (0xB1), 179 (0xB3), 181 (0xB5), 183 (0xB7) und 185 (0xB9) can be read and written.



**Information!**

*The are only instances 100 (0x64) ... 105 (0x69), 109 (0x6D) ... 114 (0x72), 172 (0xAC) und 173 (0xAD) in case of a single master.*

12.4.1 Assembly Objects for VBG-ENX-K30-DMD-S16-C1, VBG-ENX-K30-DMD-S16

Assembly Instance			Data Item				
input	output	size (byte)	digital	analog	command interface		
100 (0x64)	136 (0x88)	16	AS-i circuit 1, single- and A-slaves	AS-i circuit 1, analog slaves 29 .. 31			
101 (0x65)	137 (0x89)	28			short		
102 (0x66)	138 (0x8A)	54			long		
103 (0x67)	139 (0x8B)	40					
104 (0x68)	140 (0x8C)	52			short		
105 (0x69)	141 (0x8D)	78			long		
106 (0x6A)	142 (0x8E)	64					
107 (0x6B)	143 (0x8F)	76			short		
108 (0x6C)	144 (0x90)	102			long		
109 (0x6D)	145 (0x91)	32					
110 (0x6E)	146 (0x92)	44	AS-i circuit 1, all slaves	AS-i circuit 1, analog slaves 29 .. 31	short		
111 (0x6F)	147 (0x93)	70			long		
112 (0x70)	148 (0x94)	56					
113 (0x71)	149 (0x95)	68			short		
114 (0x72)	150 (0x96)	94			long		
115 (0x73)	151 (0x97)	80					
116 (0x74)	152 (0x98)	92			short		
117 (0x75)	153 (0x99)	118			long		
118 (0x76)	154 (0x9A)	32			AS-i circuit 1+2, single- and A-slaves	AS-i circuit 1, analog slaves 29 .. 31	
119 (0x77)	155 (0x9B)	44					short
120 (0x78)	156 (0x9C)	70	long				
121 (0x79)	157 (0x9D)	56					
122 (0x7A)	158 (0x9E)	68	short				
123 (0x7B)	159 (0x9F)	94	long				
124 (0x7C)	160 (0xA0)	80					
125 (0x7D)	161 (0xA1)	92	short				
126 (0x7E)	162 (0xA2)	118	long				
127 (0x7F)	163 (0xA3)	64					
128 (0x80)	164 (0xA4)	76	AS-i circuit 1+2, all slaves	AS-i circuit 1, analog slaves 29 .. 31	short		
129 (0x81)	165 (0xA5)	102			long		
130 (0x82)	166 (0xA6)	88					
131 (0x83)	167 (0xA7)	100			short		
132 (0x84)	168 (0xA8)	126			long		
133 (0x85)	169 (0xA9)	112					
134 (0x86)	170 (0xAA)	124			short		
135 (0x87)	171 (0xAB)	150			long		

Tab. 12-18.

12.4.2 Assembly Objects for VBG-ENX-K30-DMD-S16-EV

Assembly Instance				Data Item								
Input	Size (Byte)	Output	Size (Byte)	Digital	Analog	Command interface	Safety FB Bits	Safety Status	min. RPI (ms)	min. RPI (ms) with DLR		
100 (0x64)	16	136 (0x88)	16	AS-i circuit 1, single- and A-slaves	AS-i circuit 1, analog slaves 29 .. 31				5	10		
101 (0x65)	28	137 (0x89)	28			short			5	10		
102 (0x66)	54	138 (0x8A)	54			long			6	14		
103 (0x67)	40	139 (0x8B)	40						6	14		
104 (0x68)	52	140 (0x8C)	52			short			6	14		
105 (0x69)	78	141 (0x8D)	78			long			8	18		
106 (0x6A)	64	142 (0x8E)	64			AS-i circuit 1+2, analog slaves 29 .. 31			8	16		
107 (0x6B)	76	143 (0x8F)	76				short			8	18	
108 (0x6C)	102	144 (0x90)	102	long				10	22			
109 (0x6D)	32	145 (0x91)	32					6	12			
110 (0x6E)	44	146 (0x92)	44	AS-i circuit 1, all slaves	AS-i circuit 1, analog slaves 29 .. 31	short			6	14		
111 (0x6F)	70	147 (0x93)	70			long			8	16		
112 (0x70)	56	148 (0x94)	56						7	15		
113 (0x71)	68	149 (0x95)	68			short			8	16		
114 (0x72)	94	150 (0x96)	94			long			9	18		
115 (0x73)	80	151 (0x97)	80			AS-i circuit 1+2, analog slaves 29 .. 31			9	18		
116 (0x74)	92	152 (0x98)	92				short			9	18	
117 (0x75)	118	153 (0x99)	118				long			11	24	
118 (0x76)	32	154 (0x9A)	32	AS-i circuit 1+2, single- and A-slaves	AS-i circuit 1, analog slaves 29 .. 31					6	12	
119 (0x77)	44	155 (0x9B)	44			short			6	14		
120 (0x78)	70	156 (0x9C)	70			long			8	16		
121 (0x79)	56	157 (0x9D)	56						7	15		
122 (0x7A)	68	158 (0x9E)	68			short			8	16		
123 (0x7B)	94	159 (0x9F)	94			long			9	18		
124 (0x7C)	80	160 (0xA0)	80			AS-i circuit 1+2, analog slaves 29 .. 31			9	18		
125 (0x7D)	92	161 (0xA1)	92				short			9	18	
126 (0x7E)	118	162 (0xA2)	118				long			11	24	
127 (0x7F)	64	163 (0xA3)	64							8	16	
128 (0x80)	76	164 (0xA4)	76			AS-i circuit 1+2, all slaves	AS-i circuit 1, analog slaves 29 .. 31	short			8	18
129 (0x81)	102	165 (0xA5)	102					long			10	22
130 (0x82)	88	166 (0xA6)	88						9	18		
131 (0x83)	100	167 (0xA7)	100	short					10	22		
132 (0x84)	126	168 (0xA8)	126	long					12	25		
133 (0x85)	112	169 (0xA9)	112	AS-i circuit 1+2, analog slaves 29 .. 31					11	24		
134 (0x86)	124	170 (0xAA)	124		short					12	25	
135 (0x87)	150	171 (0xAB)	150		long					13	26	

Tab. 12-19.

12.9.2013

Assembly Instance				Data Item									
Input	Size (Byte)	Output	Size (Byte)	Digital	Analog	Command interface	Safety FB Bits	Safety Status	min. RPI (ms)	min. RPI (ms) with DLR			
172 (0xAC)	246	173(0xAD)	246	AS-i circuit 1, all slaves	AS-i circuit 1, analog slaves 10 .. 31	long			17	32			
174 (0xAE)	454	175 (0xAF)	454	AS-i circuit 1 + 2, all slaves	AS-i circuit 1 + 2, analog slaves 10 .. 31						25	50	
176 (0xB0)	98	177(0xB1)	66				long		10	20			
178 (0xB2)	136	179(0xB3)	104								12	25	
180 (0xB4)	146	181(0xB5)	114			AS-i circuit 1+2, analog slaves 29 .. 31	long	2 bytes In / Out	32 byte In	13	26		
182 (0xB6)	184	183(0xB7)	152			AS-i circuit 1+2, analog slaves 29 .. 31						15	30
184 (0xB8)	488	185(0xB9)	456			AS-i circuit 1+2, analog slaves 10 .. 31						27	52

Tab. 12-19.

## 12.5 AS-i Master Object

class code: 100 (0x64)  
1 instance for each AS-i circuit

attribute ID	access rule	name	devicenet data type	default data value
100 (0x64)	get	ec-flags	UINT (16-bit)	
101 (0x65)	get/set	hi-flags	USINT	
102 (0x66)	get/set	operational mode	BOOL	
103 (0x67)	get	LDS (list of detected slaves)	ULINT	
104 (0x68)	get/set	LPS (list of projected slaves)	ULINT	
105 (0x69)	get	LAS (list of activated slaves)	ULINT	
106 (0x6A)	get	LPF (list of peripheral faults)	ULINT	
107 (0x6B)	get/set	Store_Actual_Configuration	BOOL	
108 (0x6C)	get/set	Store_Actual_Parameters	BOOL	
109 (0x6D)	get/set	Change_Slave_Address	UINT	
110 (0x6E)	get/set	Lock push-buttons	BOOL	

Tab. 12-20.

### EC-flags (16-bit)

2 <sup>15</sup>	2 <sup>14</sup>	2 <sup>13</sup>	2 <sup>12</sup>	2 <sup>11</sup>	2 <sup>10</sup>	2 <sup>9</sup>	2 <sup>8</sup>	2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>
DA	NSE	OV	EF	-	-	-	PoK	OR	APF	NA	CA	AAv	AAAs	S0	CoK

Tab. 12-21.

DA (double\_address): AS-i duplicate address detection  
0: no duplicate address  
1: duplicate address

NSE (noise): AS-i noise detection  
0: no noise  
1: noise fault

OV (overvoltage): AS-i overvoltage detection  
0: no overvoltage  
1: overvoltage fault

EF (earth\_fault): AS-i earth fault detection  
0: no earth fault  
1: earth fault

PoK (periphery\_ok): Periphery is OK  
0: Periphery is OK  
1: Periphery is not OK

OR (offline\_ready): The off-line phase is active

APF (ASi-power\_fail): An AS-i power fail is occurred

NA (normal\_operation\_active): The normal operation mode is active  
0: normal operation is active  
1: normal operation is not active

CA (configuration\_active): The configuration-mode is active

AAv (Auto_Address_Available):	Automatic programming is possible 0: Auto-address is possible 1: Auto-address is not possible
AAs (Auto_Address_Assign):	Automatic programming is allowed
S0 (LDS.0):	There is an AS-i slave with address '0'
Cok (config_ok):	Configuration error: 0: no error 1: error

**Hi-flags (8-bit)**

	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>
AAe	OL	DX	

Tab. 12-22.

AAe:	Auto_Address_Enable
OL:	Off-line
DX:	Data_Exchange_Active

**Operational mode (8-bit):**

1:	configuration mode
0:	protected mode

**LDS, LAS, LPS, LPF (64-bit)**

Byte	2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>
0	7A	6A	5A	4A	3A	2A	1A	0A
...	...							
7	31B	30B	29B	28B	27B	26B	25B	24B

Tab. 12-23.

LDS:	list of detected slaves
LAS:	list of activated slaves
LPS:	list of activated slaves
LPF:	list of peripheral faults

**Store actual parameter/store actual configuration/lock push-buttons**

True: proceed the action

**Change slave address (16-bit)**

Byte	2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>
0	-		B	source address				
1	-		B	target address				

Tab. 12-24.

**Meaning of the bit B**

B = 0:	Single AS-i Slave or A-slave
B = 1:	B-slave

## 12.6 AS-i slave Object

class code: 101 (0x65)

64 instances for each AS-i circuit, 1 for each AS-i slave

instance ID	AS-i slave
1 (0x01)	slave 0, circuit 1
2 (0x02)	slave 1A, circuit 1
...	...
32 (0x20)	slave 31A circuit 1
33 (0x21)	empty, circuit 1
34 (0x22)	slave 1B, circuit 1
...	...
64 (0x40)	slave 31B, circuit 1
65 (0x41)	slave 0, circuit 2
...	...
96 (0x60)	slave 31A, circuit 2
97 (0x61)	empty, circuit 2
...	...
98 (0x62)	slave 1B, circuit 2
...	...
128 (0x80)	slave 31B, circuit 2

Tab. 12-25.

attribute ID	access rule	name	devicenet data type	remark
100 (0x64)	get	actual configuration	UINT	
101 (0x65)	get/set	permanent configuration	UINT	slave 0, 32: not read-/writeable
102 (0x66)	get/set	actual parameters	USINT	
103 (0x67)	get/set	permanent parameters	USINT	
104 (0x68)	get/set	xID1	USINT	slave 0: writeable only, slave 0 - 32: readable

Tab. 12-26.

### actual configuration/permanent configuration (16-bit)

2 <sup>15</sup>	2 <sup>14</sup>	2 <sup>13</sup>	2 <sup>12</sup>	2 <sup>11</sup>	2 <sup>10</sup>	2 <sup>9</sup>	2 <sup>8</sup>	2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>
ID				IO				xID2				XID1			

Tab. 12-27.

### parameter xID1 (8-bit)

2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>
-				data			

Tab. 12-28.

## 12.7 I/O Data Object

class code: 102 (0x66)  
 Input and output data  
 1 instance for each AS-i circuit  
 Instance 1 equates to AS-i circuit 1  
 Instance 2 equates to AS-i circuit 2

attribute ID	access rule	name	devicenet data type	default data value
100 (0x64)	get	input data image, single and A-slaves	ARRAY[16] of USINT	
101 (0x65)	get	input data image, B-slaves	ARRAY[16] of USINT	
102 (0x66)	get/set	output data image single and A-slaves	ARRAY[16] of USINT	
103 (0x67)	get/set	output data image, B-slaves	ARRAY[16] of USINT	
104 (0x68)	get	16-bit input data slave 1	ARRAY[4] of INT	
...	...	...	...	...
134 (0x86)	get	16-bit input data slave 31	ARRAY[4] of INT	
135 (0x87)	get/set	16-bit output data slave 1	ARRAY[4] of INT	
...	...	...	...	...
165 (0xA5)	get/set	16-bit output data slave 31	ARRAY[4] of INT	

Tab. 12-29.

**Input and Output Data Image**

Byte	2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>
	F3	F2	F1	F0				
0	flags				slave 1/1A			
1	slave 2/2A				slave 3/3A			
2	slave 4/4A				slave 5/5A			
3	slave 6/6A				slave 7/7A			
4	slave 8/8A				slave 9/9A			
5	slave 10/10A				slave 11/11A			
6	slave 12/12A				slave 13/13A			
7	slave 14/14A				slave 15/15A			
8	slave 16/16A				slave 17/17A			
9	slave 18/18A				slave 19/19A			
10	slave 20/20A				slave 21/21A			
11	slave 22/22A				slave 23/23A			
12	slave 24/24A				slave 25/25A			
13	slave 26/26A				slave 27/27A			
14	slave 28/28A				slave 29/29A			
15	slave 30/30A				slave 31/31A			
16	reserved				slave 1B			
17	slave 2B				slave 3B			
18	slave 4B				slave 5B			
19	slave 6B				slave 7B			
20	slave 8B				slave 9B			
21	slave 10B				slave 11B			
22	slave 12B				slave 13B			
23	slave 14B				slave 15B			
24	slave 16B				slave 17B			
25	slave 18B				slave 19B			
26	slave 20B				slave 21B			
27	slave 22B				slave 23B			
28	slave 24B				slave 25B			
29	slave 26B				slave 27B			
30	slave 28B				slave 29B			
31	slave 30B				slave 31B			

Tab. 12-30.

### Flags

	Input data	Output data
F0	ConfigError	Off-line
F1	APF	LOS-master-bit
F2	PeripheryFault	→ ConfigurationMode
F3	ConfigurationActive	→ ProtectedMode

Tab. 12-31.

ConfigError:	0=ConfigOK	1=ConfigError
APF:	0=AS-i-Power OK	1=AS-i-Power Fail
PeripheryFault:	0=PeripheryOK	1=PeripheryFault
ConfigurationActive:	0=ProtectedOperationMode	1=ProjectingMode
Off-Line:	0=On-Line	1=Off-Line
LOS-master-bit	0=Off-Line by ConfigError deactivated	1=Off-Line by ConfigError activated.

### 16-bit data



#### Information!

A-slaves map the data on channels 1 and 2.

B-slaves map the data on channels 3 and 4.

In addition to the access via the command interfaces, the 16-bit data for or by the slaves with 16-bit value can be exchanged cyclically (profile 7.3., S-7.4, S-6.0, S-7.5, S-7.A.8, S-7.A.9, S-7.A.A). Competing writing access attempts on 16-bit output data will not be blocked by every other. If 16-bit output data for a particular slave are being transmitted both cyclically and acyclically with the command interface, the acyclically transmitted values will be overwritten by the cyclically transmitted values.

Data of all channels of a slave can be transmitted in a reserved data area. Therefore accessing 16-bit data is as easy as accessing digital data.

### 16-bit value

Word	2 <sup>15</sup>	2 <sup>14</sup>	2 <sup>13</sup>	2 <sup>12</sup>	2 <sup>11</sup>	2 <sup>10</sup>	2 <sup>9</sup>	2 <sup>8</sup>	2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>
	D15	D14	D13	D12	D11	D10	D9	D8	D7	D6	D5	D4	D3	D2	D1	D0
1	slave X, channel 1															
2	slave X, channel 2															
3	slave X, channel 3															
4	slave X, channel 4															

Tab. 12-32.

## 12.8 Advanced Diagnostics Object

class code: 103 (0x67)

1 instance for each AS-i circuit  
 Instance 1 equates to AS-i circuit 1  
 Instance 2 equates to AS-i circuit 2

attribute ID	access rule	name	devicenet data type	default data value
100 (0x64)	Get/Set	LOS (List of offline slaves)	ULINT	
101 (0x65)	Get	error counter A	ARRAY[32] of USINT	
102 (0x66)	Get	error counter B	ARRAY[32] of USINT	

Tab. 12-33.

**Slave error counter:**

**single and A slaves**

Index	error counter
1	slave 1/1A
2	slave 2/2A
3	slave 3/3A
...	...
31	slave 31/31A

Tab. 12-34.

**B slaves**

index	error counter
1	slave 1B
2	slave 2B
3	slave 3B
...	...
31	slave 31B

Tab. 12-35.

### 12.9 Short Command Interface Object

class code: 104 (0x68)

1 instance

attribute ID	access rule	name	devicenet data type	default data value
100 (0x64)	get/set	content	ARRAY[12] of USINT	
		command	[0]	
		toggle-bit and AS-i circuit	[1]	
		data	[2 ... 11]	

Tab. 12-36.

### 12.10 Long Command Interface Object

class code: 105 (0x69)

1 instance

attribute ID	access rule	name	devicenet data type	default data value
100 (0x64)	get/set	content	ARRAY [38] of USINT	
		command	[0]	
		toggle-bit and AS-i circuit	[1]	
		data	[2 ... 37]	

Tab. 12-37.

For special details acc. the command interface commands see the separat manual "AS-i 3.0 Command Interface".

## 12.11 Safety Control/Status

### 12.11.1 Internal monitor

#### 12.11.1.1 Safety Control Status internal monitor for VBG-ENX-K30-DMD-S16-C1, VBG-ENX-K30-DMD-S16

class code: 106 (0x6A)  
 1 instance

attribute ID	access rule	name	devicenet data type	default data value
100 (0x64)	get		ARRAY [16] of USINT	
		safety status release circuit 1	[0]	
		safety status release circuit 2	[1]	
		...	[2 ... 14]	
		safety status relais circuit 16	[15]	
101 (0x65)	get/set	safety control	USINT	

Tab. 12-38.

Coding of states and colors see tab. <Coding of status bytes per OSSD>.

#### Safety control

byte	description
1	byte from the EtherNet/IP
	bit 0: 1.Y1
	bit 1: 1.Y2
	bit 2: 2.Y1
	bit 3: 2.Y2
	bit 4 ... 7: reserved



#### Set (data write access)

The bits of the output bytes which have been set via the host interface are ORed with the real and the homonymous hardware inputs of the device.

#### GET (data read access)

The information-bits of the outputs 1.Y1, 1.Y2, 1.Y2 and 2.Y2 which have been read back only reflect the data bits set via the host interface.

**Coding of status bytes per OSSD**

Bit [0 ... 3]	State or. color
00 <sub>16</sub>	green permanent lighting
01 <sub>16</sub>	green flashing
02 <sub>16</sub>	yellow permanent lighting
03 <sub>16</sub>	yellow flashing
04 <sub>16</sub>	red permanent lighting
05 <sub>16</sub>	red flashing
06 <sub>16</sub>	grey or off
07 <sub>16</sub>	reserved
Bit [6]	status or color
0	no device flashing yellow
1	at least one device flashing yellow
Bit [7]	status or color
0	no device flashing red
1	at least one device flashing red

Tab. 12-39.

12.11.1.2 Feldbus bits internal monitor for VBG-ENX-K30-DMD-S16-EV

Class Code: 106 (0x6A)

1 Instance

Attribute ID	Access Rule	Name	DeviceNet Data Type	Default Data Value
100 (0x64)	get		ARRAY [32] of USINT	
		safety status OSSD 1	[0]	
		safety status OSSD 2	[1]	
		...	[2 ... 30]	
		safety status OSSD 32	[31]	
101 (0x65)	get/set	fieldbus bits	ARRAY [2] of USINT	

Tab. 12-40.

**Fieldbus bits**

Bit	15	...	3	2	1	0
meaning	Bits from EtherNet/IP					

## 12.11.2 External Monitor

### 12.11.2.1 Safety Control Status external Monitor

class code: 107 (0x6B)  
1 instance per AS-i circuit

attribute ID	access rule	name	devicenet data type	default data value
100 (0x64)	get	slave 1:	ARRAY [8] of USINT	
		safety status release circuit 1	[0]	
		safety status release circuit 2	[1]	
		...	[2 ... 6]	
		safety status, release circuit 8	[7]	
...	...	...	...	...
130 (0x82)	get	slave 31:	ARRAY [8] of USINT	
		safety status release circuit 1	[0]	
		safety status release circuit 2	[1]	
		...	[2 ... 6]	
		safety status release circuit 8	[7]	
...	...	...	...	...
131 (0x83)	get/set	safety control slave 1	USINT	
...	...	...	...	...
161 (0xA1)	get/set	safety control slave 31	USINT	

Tab. 12-41.

Coding of states and colors see tab. <Coding of status bytes per OSSD>.

#### Safety control

Byte	description
1	byte from the EtherNet/IP
	bit 0: 1.Y1
	bit 1: 1.Y2
	bit 2: 2.Y1
	bit 3: 2.Y2
	bit 4 ... 7: reserved



#### Set (data write access)

The bits of the output bytes which have been set via the host interface are ORed with the real and the homonymous hardware inputs of the device.

#### GET (data read access)

The information-bits of the outputs 1.Y1, 1.Y2, 1.Y2 and 2.Y2 which have been read back only reflect the data bits set via the host interface.

**Coding of status bytes per OSSD**

Bit [0 ... 3]	State or. color
00 <sub>16</sub>	green permanent lighting
01 <sub>16</sub>	green flashing
02 <sub>16</sub>	yellow permanent lighting
03 <sub>16</sub>	yellow flashing
04 <sub>16</sub>	red permanent lighting
05 <sub>16</sub>	red flashing
06 <sub>16</sub>	grey or off
07 <sub>16</sub>	reserved
Bit [6]	status or color
0	no device flashing yellow
1	at least one device flashing yellow
Bit [7]	status or color
0	no device flashing red
1	at least one device flashing red

Tab. 12-42.



**Information!**

*For further codes indicated by the display, see section <Status indication, faults and fault elimination>.*

### 13. The Modbus Address Table

Cyclic data exchange similar to the Momentum Ethernet Adapter  
**AS-i circuit 1: Input Data Image IDI**

4x reference	contact	read access															
bit value		2 <sup>15</sup>	2 <sup>14</sup>	2 <sup>13</sup>	2 <sup>12</sup>	2 <sup>11</sup>	2 <sup>10</sup>	2 <sup>9</sup>	2 <sup>8</sup>	2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>
„bit“		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
1	1 - 16	F1	F2	F3	F4	F5	F6	F7	F8	F9	F10	F11	F12	F13	F14	F15	F16
2	17 - 32	slave 0/0A				slave 1/1A				slave 2/2A				slave 3/3A			
		D0	D1	D2	D3	D0	D1	D2	D3	D0	D1	D2	D3	D0	D1	D2	D3
3	33 - 48	slave 4/4A				slave 5/5A				slave 6/6A				slave 7/7A			
4	49 - 66	slave 8/8A				slave 9/9A				slave 10/10A				slave 11/11A			
5	65 - 80	slave 12/12A				slave 13/13A				slave 14/14A				slave 15/15A			
6	81 - 96	slave 16/16A				slave 17/17A				slave 18/18A				slave 19/19A			
7	97 - 112	slave 20/20A				slave 21/21A				slave 22/22A				slave 23/23A			
8	113 - 128	slave 24/24A				slave 25/25A				slave 26/26A				slave 27/27A			
9	129 - 144	slave 28/28A				slave 29/29A				slave 30/30A				slave 31/31A			
10	145 - 160	not used				slave 1B				slave 2B				slave 3B			
11	161 - 176	slave 4B				slave 5B				slave 6B				slave 7B			
12	177 - 192	slave 8B				slave 9B				slave 10B				slave 11B			
13	193 - 208	slave 12B				slave 13B				slave 14B				slave 15B			
14	209 - 224	slave 16B				slave 17B				slave 18B				slave 19B			
15	225 - 240	slave 20B				slave 21B				slave 22B				slave 23B			
16	241 - 256	slave 24B				slave 25B				slave 26B				slave 27B			
17	257 - 272	slave 28B				slave 29B				slave 30B				slave 31B			

Tab. 13-43.

F1 - F16: flags, see tab. <Reference 1>.

Cyclic data exchange similar to the Momentum Ethernet Adapter  
**AS-i circuit 2: Input Data Image IDI**

4x reference	contact	read access															
bit value		2 <sup>15</sup>	2 <sup>14</sup>	2 <sup>13</sup>	2 <sup>12</sup>	2 <sup>11</sup>	2 <sup>10</sup>	2 <sup>9</sup>	2 <sup>8</sup>	2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>
„Bit“		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
18	273 - 288	F1	F2	F3	F4	F5	F6	F7	F8	F9	F10	F11	F12	F13	F14	F15	F16
19	289 - 304	slave 0/0A				slave 1/1A				slave 2/2A				slave 3/3A			
		D0	D1	D2	D3	D0	D1	D2	D3	D0	D1	D2	D3	D0	D1	D2	D3
20	305 - 320	slave 4/4A				slave 5/5A				slave 6/6A				slave 7/7A			
21	321 - 336	slave 8/8A				slave 9/9A				slave 10/10A				slave 11/11A			
22	337 - 352	slave 12/12A				slave 13/13A				slave 14/14A				slave 15/15A			
23	353 - 368	slave 16/16A				slave 17/17A				slave 18/18A				slave 19/19A			
24	369 - 384	slave 20/20A				slave 21/21A				slave 22/22A				slave 23/23A			
25	385 - 400	slave 24/24A				slave 25/25A				slave 26/26A				slave 27/27A			
26	401 - 416	slave 28/28A				slave 29/29A				slave 30/30A				slave 31/31A			
27	417 - 432	not used				slave 1B				slave 2B				slave 3B			
28	433 - 448	slave 4B				slave 5B				slave 6B				slave 7B			
29	449 - 464	slave 8B				slave 9B				slave 10B				slave 11B			
30	465 - 480	slave 12B				slave 13B				slave 14B				slave 15B			
31	481 - 496	slave 16B				slave 17B				slave 18B				slave 19B			
32	497 - 512	slave 20B				slave 21B				slave 22B				slave 23B			
33	513 - 528	slave 24B				slave 25B				slave 26B				slave 27B			
34	529 - 544	slave 28B				slave 29B				slave 30B				slave 31B			

Tab. 13-44.

F1 - F16: flags, see tab. <Reference 1>.

Cyclic data exchange similar to the Momentum Ethernet Adapter  
**AS-i circuit 1: Output Data Image ODI**

4x reference	contact	write access															
		2 <sup>15</sup>	2 <sup>14</sup>	2 <sup>13</sup>	2 <sup>12</sup>	2 <sup>11</sup>	2 <sup>10</sup>	2 <sup>9</sup>	2 <sup>8</sup>	2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>
„Bit“		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
1	1 - 16	F1	F2	F3	F4	F5	F6	F7	F8	F9	F10	F11	F12	F13	F14	F15	F16
2	17 - 32	slave 0/0A				slave 1/1A				slave 2/2A				slave 3/3A			
		D0	D1	D2	D3	D0	D1	D2	D3	D0	D1	D2	D3	D0	D1	D2	D3
3	33 - 48	slave 4/4A				slave 5/5A				slave 6/6A				slave 7/7A			
4	49 - 66	slave 8/8A				slave 9/9A				slave 10/10A				slave 11/11A			
5	65 - 80	slave 12/12A				slave 13/13A				slave 14/14A				slave 15/15A			
6	81 - 96	slave 16/16A				slave 17/17A				slave 18/18A				slave 19/19A			
7	97 - 112	slave 20/20A				slave 21/21A				slave 22/22A				slave 23/23A			
8	113 - 128	slave 24/24A				slave 25/25A				slave 26/26A				slave 27/27A			
9	129 - 144	slave 28/28A				slave 29/29A				slave 30/30A				slave 31/31A			
10	145 - 160	not used				slave 1B				slave 2B				slave 3B			
11	161 - 176	slave 4B				slave 5B				slave 6B				slave 7B			
12	177 - 192	slave 8B				slave 9B				slave 10B				slave 11B			
13	193 - 208	slave 12B				slave 13B				slave 14B				slave 15B			
14	209 - 224	slave 16B				slave 17B				slave 18B				slave 19B			
15	225 - 240	slave 20B				slave 21B				slave 22B				slave 23B			
16	241 - 256	slave 24B				slave 25B				slave 26B				slave 27B			
17	257 - 272	slave 28B				slave 29B				slave 30B				slave 31B			

Tab. 13-45.

F1 - F16: flags, see tab. <Reference 1>.

Cyclic data exchange similar to the Momentum Ethernet Adapter  
**AS-i circuit 2: Output Data Image ODI**

4x reference	contact	write access															
bit value		2 <sup>15</sup>	2 <sup>14</sup>	2 <sup>13</sup>	2 <sup>12</sup>	2 <sup>11</sup>	2 <sup>10</sup>	2 <sup>9</sup>	2 <sup>8</sup>	2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>
„bit“		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
18	273 - 288	F1	F2	F3	F4	F5	F6	F7	F8	F9	F10	F11	F12	F13	F14	F15	F16
19	289 - 304	slave 0/0A				slave 1/1A				slave 2/2A				slave 3/3A			
		D0	D1	D2	D3	D0	D1	D2	D3	D0	D1	D2	D3	D0	D1	D2	D3
20	305 - 320	slave 4/4A				slave 5/5A				slave 6/6A				slave 7/7A			
21	321 - 336	slave 8/8A				slave 9/9A				slave 10/10A				slave 11/11A			
22	337 - 352	slave 12/12A				slave 13/13A				slave 14/14A				slave 15/15A			
23	353 - 368	slave 16/16A				slave 17/17A				slave 18/18A				slave 19/19A			
24	369 - 384	slave 20/20A				slave 21/21A				slave 22/22A				slave 23/23A			
25	385 - 400	slave 24/24A				slave 25/25A				slave 26/26A				slave 27/27A			
26	401 - 416	slave 28/28A				slave 29/29A				slave 30/30A				slave 31/31A			
27	417 - 432	not used				slave 1B				slave 2B				slave 3B			
28	433 - 448	slave 4B				slave 5B				slave 6B				slave 7B			
29	449 - 464	slave 8B				slave 9B				slave 10B				slave 11B			
30	465 - 480	slave 12B				slave 13B				slave 14B				slave 15B			
31	481 - 496	slave 16B				slave 17B				slave 18B				slave 19B			
32	497 - 512	slave 20B				slave 21B				slave 22B				slave 23B			
33	513 - 528	slave 24B				slave 25B				slave 26B				slave 27B			
34	529 - 544	slave 28B				slave 29B				slave 30B				slave 31B			

Tab. 13-46.

F1 - F16: flags, see tab. <Reference 1>.

The bits within the words of this block are arranged appropriate for the BLKM (Block Move) function in Modicon's 984 Ladder Language (as proposed in the Open Modbus Specification, Release 1.0). The bits are numbered from most significant bit to least significant bit:

**Reference 1**

Flag	bit	bit value	write	read
F1	1	8000 <sub>h</sub>	Data_Exchange_Active	Config_OK
F2	2	4000 <sub>h</sub>	Off-Line	LDS.0
F3	3	2000 <sub>h</sub>	Auto_Address_Enable	Auto_Address_Assign
F4	4	1000 <sub>h</sub>	Configuration Mode on	Auto_Address_Available
F5	5	800 <sub>h</sub>	Configuration Mode off	Conguration_Active
F6	6	400 <sub>h</sub>		Normal_Operation_Active
F7	7	200 <sub>h</sub>		APF/not APO
F8	8	100 <sub>h</sub>		Offline_Ready
F9	9	80 <sub>h</sub>		Periphery_OK
F10	10	40 <sub>h</sub>		
F11	11	20 <sub>h</sub>		
F12	12	10 <sub>h</sub>		
F13	13	8 <sub>h</sub>		Earth Fault
F14	14	4 <sub>h</sub>		Overvoltage
F15	15	2 <sub>h</sub>		Noise
F16	16	1 <sub>h</sub>		Duplicate Address

Tab. 13-47. Reference 1

Data_Exchange_Active:	If this output is set, no data transmission between the AS-i/Gateway and the AS-i slaves is possible. <i>0: Data exchange is active</i> <i>1: Data exchange is not active</i>
Off-line:	This output sets the master into the off-line phase
Auto_Address_Enable:	This output blocks the automatic slave-address programming. <i>0: Auto-address is enabled</i> <i>1: Auto-address is disabled</i>
Configuration_Mode_on:	Configuration mode is on
Configuration_Mode_off:	Configuration mode is off
Config_OK:	Configuration error: <i>0: no error</i> <i>1: error</i>
LDS.0:	An AS-i slave with address zero exists
Auto_Address_Assign:	Automatic programming is allowed
Auto_Address_Available:	Automatic programming is possible <i>0: Auto-address is possible</i> <i>1: Auto-address is not possible</i>
Configuration_Active:	The configuration-mode is active
Normal_Operation_Active:	The normal operation mode is active <i>0: normal operation is active</i> <i>1: normal operation is not active</i>
APF/not APO:	An AS-i power fail occurred
Offline_Ready:	The off-line phase is active
Periphery_OK:	Periphery is OK <i>0: Periphery is OK</i> <i>1: Periphery is not OK</i>
Earth Fault:	AS-i earth fault detection <i>0: no earth fault</i> <i>1: earth fault</i>
Overvoltage:	AS-i overvoltage detection <i>0: no overvoltage</i> <i>1: overvoltage fault</i>
Noise:	AS-i noise detection <i>0: no noise</i> <i>1: noise fault</i>
Duplicate Address:	AS-i duplicate address detection <i>0: no duplicate address</i> <i>1: duplicate address</i>

**Reference 2**

Bit	bit value	write	read
1	8000 <sub>h</sub>	ODI slave 0, D0	IDI slave 0, D0
2	4000 <sub>h</sub>	ODI slave 0, D1	IDI slave 0, D1
3	2000 <sub>h</sub>	ODI slave 0, D2	IDI slave 0, D2
4	1000 <sub>h</sub>	ODI slave 0, D3	IDI slave 0, D3
5	800 <sub>h</sub>	ODI slave 1, D0	IDI slave 1, D0
6	400 <sub>h</sub>	ODI slave 1, D1	IDI slave 1, D1
7	200 <sub>h</sub>	ODI slave 1, D2	IDI slave 1, D2
8	100 <sub>h</sub>	ODI slave 1, D3	IDI slave 1, D3
9	80 <sub>h</sub>	ODI slave 2, D0	IDI slave 2, D0
10	40 <sub>h</sub>	ODI slave 2, D1	IDI slave 2, D1
...	...	...	...

Tab. 13-48. Reference 2

Some of the flags are inverted in order to have zero values in protected mode during normal operation without any configuration errors.

The bits within the words of all other blocks contain input or output data.

They have the following arrangement:

Bit	bit value	slave	input or output port
1	8000 <sub>h</sub>	1	D3
2	4000 <sub>h</sub>	1	D2
3	2000 <sub>h</sub>	1	D1
4	1000 <sub>h</sub>	1	D0
5	800 <sub>h</sub>	0	D3
6	400 <sub>h</sub>	0	D2
7	200 <sub>h</sub>	0	D1
8	100 <sub>h</sub>	0	D0
9	80 <sub>h</sub>	3	D3
10	40 <sub>h</sub>	3	D2
11	20 <sub>h</sub>	3	D1
12	10 <sub>h</sub>	3	D0
13	8 <sub>h</sub>	2	D3
14	4 <sub>h</sub>	2	D2
15	2 <sub>h</sub>	2	D1
16	1 <sub>h</sub>	2	D0

Tab. 13-49.

The configuration mode can be switched on or off with a rising edge in reference 0, bit 4 or 5, respectively.

**Device-relevant references**

4x referece	access	data
2049 ... 2064	r/-	AS-i/ENIP Gateway
2065 ... 2072	r/-	device version
2073 ... 2080	r/-	firmware feature (without hi-flags)
2081 ... 2084	r/-	firmware data code
2085	r/w	Front_Panel_Operation (0 enabled, else disabled)
2086	r/-	return value of most recently called <i>Execution Control</i> function: 0: success 1: failure 2: slave with 1st address not detected 3: slave with zero address detected 4: slave with 2nd address detected 5: delete error 6: set error 7: address stored temporarily 8: <i>extended ID1</i> stored temporarily 9: error reading <i>extended ID1</i>
2304	r/w	AS-i control status bits
2305 ... 2368	r/w	AS-i control flag memory
3073 ... 3091	r/w	command interface

Tab. 13-50.

The device-relevant references 2305 ... 2368 have the following arrangement:

4x reference	high byte	low byte
2305	flag byte 0	flag byte 1
2306	flag byte 2	flag byte 3
...	...	...
2368	flag byte 126	flag byte 127

Tab. 13-51.

**Device-relevant references (similar to the Momentum Ethernet Adapter)**

4x reference	access	data
2087	r/w	default value for watchdog timeout in 10 ms units range 1 to 999 (this value overwrites the value written in the reference 61441)
61441	r/w	timeout in 10 msec units default 100 (= 1 sec) range 3 to 65536
62465 ... 62476	r/w	list of "allowed master" (not used)
62481	-/w	authorize IP address record Set to 1 allow IP address assignment to be retained in FLASH. Default of 0 to require BOOTP.
63489	r/-	size of status block (63488 ... 63500)
63490	r/-	number of word of input (in cyclic data block, 34)
63491	r/-	number of word of output (in cyclic data block, 34)
63492	r/-	module ID code
63493	r/-	module revision number
63494	r/-	ASCII header size in words. ASCII header is (largely!) printable and starts at 64512
63495	r/-	internal diagnostic (not used)
63496	r/-	reservation time remaining (not used)
63497	r/-	watchdog holdup time remaining (resets to value in reference 61441 at each output operation)
63498	r/-	<i>module health</i> (32768 is <i>good health</i> )
63499 ... 63501	r/-	internal diagnostic (not used)
64513 ... 64522	r/-	ASCII text description of device e.g. : "VBG-ENX-K30-DMD-S16"

Tab. 13-52.

**AS-i circuit 1  
process data and actual configuration data**

4x reference	access	data
4097 ... 4112	r/-	input data image IDI
4113 ... 4128	r/w	output data image ODI
4129 ... 4144	r/w	parameter image PI <sup>1</sup>
4145 ... 4208	r/-	configuration data image CDI
4209 ... 4212	r/-	list of activated slaves LAS
4213 ... 4216	r/-	list of detected slaves LDS
4217 ... 4220	r/-	list of periphery faults LFP
4225	r/-	EC-flags
4226	r/w	hi-flags

Tab. 13-53.

1. Writing to the references 4129 to 4144 invokes the Execution Control function. Write\_Parameter () rather than writing the PI.

**4x reference 4225**

<b>Bit value</b>	<b>execution control flags</b>
1 <sub>h</sub>	Config_OK!
2 <sub>h</sub>	LDS.0
4	Auto_Address_Assign
8 <sub>h</sub>	Auto_Address_Available!
10 <sub>h</sub>	Configuration_Active
20 <sub>h</sub>	Normal_Operation_Active!
40 <sub>h</sub>	APF/not APO
80 <sub>h</sub>	Offline_Ready
100 <sub>h</sub>	Periphery_OK!
1000 <sub>h</sub>	Earth Fault
2000 <sub>h</sub>	Overvoltage
4000 <sub>h</sub>	Noise
8000 <sub>h</sub>	Duplicate Address

Tab. 13-54.

Config_OK!	Configuration error 0: <i>error</i> 1: <i>no error</i>
LDS.0:	An AS-i slave with address zero is existing
Auto_Address_Assign:	Automatic programming is allowed
Auto_Address_Available!:	Automatic programming is possible 0: <i>Auto-address is not possible</i> 1: <i>Auto-address is possible</i>
Configuration_Active:	The configuration-mode is active
Normal_Operation_Active!:	The normal operation mode is active 0: <i>normal operation is not active</i> 1: <i>normal operation is active</i>
APF/not APO:	An AS-i power fail occurred
Offline_Ready:	The off-line phase is active
Periphery_OK!:	Periphery is OK 0: <i>Periphery is not OK</i> 1: <i>Periphery is OK</i>
Earth Fault:	AS-i earth fault detection 0: <i>no earth fault</i> 1: <i>earth fault</i>
Overvoltage:	AS-i overvoltage detection 0: <i>no overvoltage</i> 1: <i>overvoltage fault</i>
Noise:	AS-i noise detection 0: <i>no noise</i> 1: <i>noise fault</i>
Duplicate Address:	AS-i duplicate address detection 0: <i>no duplicate address</i> 1: <i>duplicate address</i>

**4x reference 4226**

Bit value	Host Interface-Flags
1	Data_Exchange_Active!
2	Off_Line
4	Auto_Address_Enable!

Tab. 13-55.

Data\_Exchange\_Active!: If this output is set, no data transmission between the AS-i/Gateway and the AS-i slaves is possible.  
0: Data exchange is not active  
1: Data exchange is active

Off-line: This output sets the master into the off-line phase.

Auto\_Address\_Enable!: This output blocks automatic slave-address programming.  
0: Auto-address is disabled  
1: Auto-address is enabled

**4x reference 4145 ... 4208**

Bit mask	data
000F <sub>h</sub>	I/O configuration
00F0 <sub>h</sub>	ID-code
0F00 <sub>h</sub>	extended ID 1-code
F000 <sub>h</sub>	extended ID 2-code

Tab. 13-56.

**Arrangement of lists LAS, LOS, LPS, LCS, DELTA and LPF**

The lists LAS, LOS, LPS, LCS, DELTA und LPF are arrangement bit by bit, see the table below:

**LAS, LOS, LPS, LCS, DELTA, LPF (16-bit)**

2 <sup>15</sup>	2 <sup>14</sup>	2 <sup>13</sup>	2 <sup>12</sup>	2 <sup>11</sup>	2 <sup>10</sup>	2 <sup>9</sup>	2 <sup>8</sup>	2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>
7	6	5	4	3	2	1	0	15	14	13	12	11	10	9	8
23	22	21	20	19	18	17	16	31	30	29	28	27	26	25	24

Tab. 13-57.

- LAS: list of activated slaves
- LOS: list of offline slaves
- LPS: list of projekted slaves
- LCS: list of corrupted slaves
- DELTA: list of slaves with configuration error
- LPF: list of periphery faults

### 13.1 Safety Control/Status

#### 13.1.1 Internal Monitor for VBG-ENX-K30-DMD-S16-C1, VBG-ENX-K30-DMD-S16

**Safety Control Status internal monitor (data for read access)**

4x reference	contact	read access															
bit value		2 <sup>15</sup>	2 <sup>14</sup>	2 <sup>13</sup>	2 <sup>12</sup>	2 <sup>11</sup>	2 <sup>10</sup>	2 <sup>9</sup>	2 <sup>8</sup>	2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>
„Bit“		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
35	545 - 560	safety status OSSD 1								safety status OSSD 2							
36	561 - 576	safety status OSSD 3								safety status OSSD 4							
37	577 - 592	safety status OSSD 5								safety status OSSD 6							
38	593 - 608	safety status OSSD 7								safety status OSSD 8							
39	609 - 624	safety status OSSD 9								safety status OSSD 10							
40	625 - 640	safety status OSSD 11								safety status OSSD 12							
41	641 - 656	safety status OSSD 13								safety status OSSD 14							
42	657 - 672	safety status OSSD 15								safety status OSSD 16							

Tab. 13-58.

#### Coding of status bytes per OSSD

Bit [0 ... 3]	State or. color
00 <sub>16</sub>	green permanent lighting
01 <sub>16</sub>	green flashing
02 <sub>16</sub>	yellow permanent lighting
03 <sub>16</sub>	yellow flashing
04 <sub>16</sub>	red permanent lighting
05 <sub>16</sub>	red flashing
06 <sub>16</sub>	grey or off
07 <sub>16</sub>	reserved
Bit [6]	status or color
0	no device flashing yellow
1	at least one device flashing yellow
Bit [7]	status or color
0	no device flashing red
1	at least one device flashing red

Tab. 13-59.

12.9.2013

The cyclical output identifier contains the 4 Safety Monitor bits 1.Y1, 1.Y2, 2.Y1 and 2.Y2. The monitoring element "Monitor input" and the start elements "Monitor Start-Monitor Input" and "Activation using Monitor Input" access these data. In contrast, the "Feedback circuit" element always accesses the EDM input. The bits of the output bytes are ORed with the real and the homonymous hardware inputs of the device.

**Safety Control internal monitor (data for write access)**

Safety Control internal monitor (data for write access)																	
4x refer- ence	contact	write access															
bit value		2 <sup>15</sup>	2 <sup>14</sup>	2 <sup>13</sup>	2 <sup>12</sup>	2 <sup>11</sup>	2 <sup>10</sup>	2 <sup>9</sup>	2 <sup>8</sup>	2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>
35	545 - 560	reserved												2.Y2	2.Y1	1.Y2	1.Y1

Tab. 13-60.

### 13.1.2 Internal Monitor for VBG-ENX-K30-DMD-S16-EV

#### Safety status internal monitor (data for read access)

4x refer-ence	contact	read access															
		bit value		2 <sup>15</sup>	2 <sup>14</sup>	2 <sup>13</sup>	2 <sup>12</sup>	2 <sup>11</sup>	2 <sup>10</sup>	2 <sup>9</sup>	2 <sup>8</sup>	2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>
„bit“		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
35	545 - 560	safety status OSSD 1								safety status OSSD 2							
36	561 - 576	safety status OSSD 3								safety status OSSD 4							
37	577 - 592	safety status OSSD 5								safety status OSSD 6							
38	593 - 608	safety status OSSD 7								safety status OSSD 8							
39	609 - 624	safety status OSSD 9								safety status OSSD 10							
40	625 - 640	safety status OSSD 11								safety status OSSD 12							
41	641 - 656	safety status OSSD 13								safety status OSSD 14							
42	657 - 672	safety status OSSD 15								safety status OSSD 16							
43	673 - 688	safety status OSSD 17								safety status OSSD 18							
44	689 - 704	safety status OSSD 19								safety status OSSD 20							
45	705 - 720	safety status OSSD 21								safety status OSSD 22							
46	721 - 736	safety status OSSD 23								safety status OSSD 24							
47	737 - 752	safety status OSSD 25								safety status OSSD 26							
48	753 - 768	safety status OSSD 27								safety status OSSD 28							
49	769 - 784	safety status OSSD 29								safety status OSSD 30							
50	785 - 800	safety status OSSD 31								safety status OSSD 32							

Tab. 13-61.

### 13.1.3 Safety fieldbus bits for VBG-ENX-K30-DMD-S16-EV

#### Safety fieldbus bits (data for read/write access)

4x reference	contact	read/write access															
bit value		2 <sup>15</sup>	2 <sup>14</sup>	2 <sup>13</sup>	2 <sup>12</sup>	2 <sup>11</sup>	2 <sup>10</sup>	2 <sup>9</sup>	2 <sup>8</sup>	2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>
„bit“		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
51	801 - 816	feldbus bits															

Tab. 13-62.

### 13.1.4 External monitor, AS-i circuit 1/2

#### Safety status external monitor (data for read access)

4x reference	access	data read access															
bit value		2 <sup>15</sup>	2 <sup>14</sup>	2 <sup>13</sup>	2 <sup>12</sup>	2 <sup>11</sup>	2 <sup>10</sup>	2 <sup>9</sup>	2 <sup>8</sup>	2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>
„bit“		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
5641	r / -	slave 1: OSSD 1								slave 1: OSSD 2							
...	...	...								...							
5648	r / -	slave 1: OSSD 15								slave 1: OSSD 16							
5649	r / -	slave 2: OSSD 1								slave 2: OSSD 2							
...	...	...								...							
5887	r / -	slave 31: OSSD 15								slave 31: OSSD 16							

Tab. 13-63.

**Coding of status bytes per OSSD**

Bit [0 ... 3]	State or. color
00 <sub>16</sub>	green permanent lighting
01 <sub>16</sub>	green flashing
02 <sub>16</sub>	yellow permanent lighting
03 <sub>16</sub>	yellow flashing
04 <sub>16</sub>	red permanent lighting
05 <sub>16</sub>	red flashing
06 <sub>16</sub>	grey or off
07 <sub>16</sub>	reserved
Bit [6]	status or color
0	no device flashing yellow
1	at least one device flashing yellow
Bit [7]	status or color
0	no device flashing red
1	at least one device flashing red

Tab. 13-64.

The cyclical output identifier contains the 4 Safety Monitor bits 1.Y1, 1.Y2, 2.Y1 and 2.Y2. The monitoring element "Monitor input" and the start elements "Monitor Start-Monitor Input" and "Activation using Monitor Input" access these data. In contrast, the "Feedback circuit" element always accesses the EDM input. The bits of the output bytes are ORed with the real and the homonymous hardware inputs of the device.

**Safety status external monitor (data for write access)**

4x refer-ence	acc-ess	data write access															
bit value		2 <sup>15</sup>	2 <sup>14</sup>	2 <sup>13</sup>	2 <sup>12</sup>	2 <sup>11</sup>	2 <sup>10</sup>	2 <sup>9</sup>	2 <sup>8</sup>	2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>
„bit“		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
5889	r/w	reserved												Slave 1 2.Y2	Slave 1 2.Y1	Slave 1 1.Y2	Slave 1 1.Y1
5890	r/w	reserved												Slave 2 2.Y2	Slave 2 2.Y1	Slave 2 1.Y2	Slave 2 1.Y1
...	...	...												...	...	...	...
5919	r/w	reserved												Slave 31 2.Y2	Slave 31 2.Y1	Slave 31 1.Y2	Slave 31 1.Y1

Tab. 13-65.

## 13.2 AS-i circuit 1 data

### 13.2.1 Permanent configuration data

**AS-i circuit 1  
 permanent configuration data**

4x reference	access	data
4385 ... 4400	r/w	permanent parameter ( <i>PP</i> )
4401 ... 4464	r/w	permanent configuration data ( <i>PCD</i> )
4465 ... 4468	r/w	list of projected slaves ( <i>LPS</i> )

Tab. 13-66.

### 13.2.2 Enhanced diagnostic

**AS-i circuit 1  
 enhanced diagnostic**

4x reference	access	data
4609 ... 4672	r/-	transmission error counters <sup>1</sup>
4673 ... 4676	r/-	list of corrupted slaves <i>LCS</i> <sup>1</sup>
4677 ... 4680	r/w	list of offline slaves <i>LOS</i>
4681 ... 4684	r/-	delta list

Tab. 13-67.

1. The transmission error counters and the *LCS* are reset each time they are read.

### 13.2.3 Function invocation

**AS-i circuit 1**

**function invocation**

4x reference	access	data
4865	-/w	function: opcode 1: Set_Operation_Mode 2: Change_Slave_Address 3: Store_Actual_Parameters 4: Store_Actual_Configuration 5: Execute_Command 6: Send_Parameter
4865	r/-	function: result 0: success 32769: failure 32770: slave with 1st addr not detected 32771: slave with zero addr detected 32772: slave with 2nd addr detected 32773: delete error 32774: set error 32775: address stored temporarily 32776: extended ID1 stored temporarily 32777: error reading extended ID1 32778: parameter out of range 32779: invalid opcode
4866	r/w	function: parameter 1 (old slave address)
4867	r/w	function: parameter 2 (new slave address)

Tab. 13-68.

**Set\_Operation\_Mode:** A zero in the 4x reference 4865 activates the protected mode. All other values switch on the configuration mode.

**Change\_Slave\_Address:** This function will be executed, if the value 2 is written to the 4x reference 4865. The value written in the 4x reference 4867 will be the new address of the slave. The old address has to be written to the 4x reference 4866 before.

**Store\_Actual\_Parameters:** If the value 3 is written to the 4x reference 4865, the actual parameters (PI) will be stored as parameters projected (PP).

**Store\_Actual\_Configuration:** If the value 4 is written to the 4x reference 4865, the actual AS-i configuration will be stored as projected parameters (PCD, LPS).

**Execute\_command:** If the value 5 is written to the 4x reference 4865, this function will be executed. The value written in the 4x reference 4867 will be sent as the information-part to a slave, which the 4x reference has been written before to the 4x reference 4866.



**Information!**

*B* addresses are located behind *A* addresses.

Addresses **0 ... 31** correspond to **0A ... 31A**, addresses **32 ... 64** correspond to **0B ... 31B**.

**13.3 AS-i circuit 1 analog data**

**13.3.1 16 bit output data of AS-i slaves according to slave profile 7.3 or 7.4**

**AS-i circuit 1**

**16 bit output data of AS-i slaves according to slave profile 7.3 or 7.4**

4x reference	word	data															
		2 <sup>15</sup>	2 <sup>14</sup>	2 <sup>13</sup>	2 <sup>12</sup>	2 <sup>11</sup>	2 <sup>10</sup>	2 <sup>9</sup>	2 <sup>8</sup>	2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>
5125	1	slave at address 1, channel 1															
5126	2	slave at address 1, channel 2															
...		...															
5248	124	slave at address 31, channel 4															

Tab. 13-69.

**13.3.2 16 bit input data of AS-i slaves according to slave profile 7.3 or 7.4**

**AS-i circuit 1**

**16 bit input data of AS-i slaves according to slave profile 7.3 or 7.4**

4x reference	word	data															
		2 <sup>15</sup>	2 <sup>14</sup>	2 <sup>13</sup>	2 <sup>12</sup>	2 <sup>11</sup>	2 <sup>10</sup>	2 <sup>9</sup>	2 <sup>8</sup>	2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>
5253	1	slave at address 1, channel 1															
5254	2	slave at address 1, channel 2															
...		...															
5376	124	slave at address 31, channel 4															

Tab. 13-70.

### 13.4 AS-i circuit 2 data

#### 13.4.1 Process data and actual configuration data

**AS-i circuit 2  
process data and actual configuration data**

4x reference	access	data
8193 ... 8208	r/-	input data image IDI
8209 ... 8224	r/w	output data image ODI
8225 ... 8234	r/w	parameter image PI <sup>1</sup>
8241 ... 8304	r/-	configuration data image CDI
8305 ... 8308	r/-	list of activated slaves LAS
8309 ... 8312	r/-	list of detected slaves LDS
8313 ... 8316	r/-	list of periphery faults LPF
8321	r/-	ec-flags
8322	r/w	hi-flags

Tab. 13-71.

1. Writing to the references 8225 to 8234 invokes the Execution Control function. Write\_Parameter() rather than writing the PI.

#### 13.4.2 Permanent configuration data

**AS-i circuit 2  
permanent configuration data**

4x reference	access	data
8481 ... 8496	r/w	permanent parameter (PP)
8497 ... 8560	r/w	permanent configuration data (PCD)
8561 ... 8564	r/w	list of projected slaves (LPS)

Tab. 13-72.

#### 13.4.3 Enhanced diagnostic

**AS-i circuit 2  
enhanced diagnostic**

4x reference	access	data
8705 ... 8768	r/-	transmission error counters <sup>1</sup>
8769 ... 8772	r/-	list of corrupted slaves (LCS) <sup>1</sup>
8773 ... 8776	r/w	list of offline slaves (LOS)
8777 ... 8780	r/-	delta list

Tab. 13-73.

1. The transmission error counters and the LCS are reset each time they are read.

### 13.4.4 Function invocation

**AS-i circuit 2**

**Function invocation**

4x reference	access	data
8961	-/w	function: opcode 1: Set_Operation_Mode 2: Change_Slave_Address 3: Store_Actual_Parameters 4: Store_Actual_Configuration 5: Execute_Command 6: Send_Parameter
8961	r/-	function: result 0: success 32769: failure 32770: slave with 1st addr not detected 32771: slave with zero addr detected 32772: slave with 2nd addr detected 32773: delete error 32774: set error 32775: address stored temporarily 32776: extended ID1 stored temporarily 32777: error reading extended ID1 32778: parameter out of range 32779: invalid opcode
8962	r/w	function: parameter 1
8963	r/w	function: parameter 2

Tab. 13-74.

### 13.5 AS-i circuit 2 analog data

#### 13.5.1 16 bit output data of AS-i slaves according to slave profile 7.3 or 7.4

**AS-i circuit 2**

**16 bit output data of as-i slaves according to slave profile 7.3 or 7.4**

4x reference	word	data															
		2 <sup>15</sup>	2 <sup>14</sup>	2 <sup>13</sup>	2 <sup>12</sup>	2 <sup>11</sup>	2 <sup>10</sup>	2 <sup>9</sup>	2 <sup>8</sup>	2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>
9221	1	slave at address 1, channel 1															
9222	2	slave at address 1, channel 2															
...		...															
9344	124	slave at address 31, channel 4															

Tab. 13-75.

#### 13.5.2 16 bit input data of as-i slaves according to slave profile 7.3 or 7.4

**AS-i circuit 2**

**16-bit input data of AS-i slaves according to slave profile 7.3 or 7.4**

4x reference	word	data															
		2 <sup>15</sup>	2 <sup>14</sup>	2 <sup>13</sup>	2 <sup>12</sup>	2 <sup>11</sup>	2 <sup>10</sup>	2 <sup>9</sup>	2 <sup>8</sup>	2 <sup>7</sup>	2 <sup>6</sup>	2 <sup>5</sup>	2 <sup>4</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>
9349	1	slave at address 1, channel 1															
9350	2	slave at address 1, channel 2															
...		...															
9472	124	slave at address 31, channel 4															

Tab. 13-76.

### 13.6 Modbus watchdog

The watchdog is set by default to 1000 msec (=100 in register 61441). This value will be automatically set after POWER ON of the gateway. Every write access on any Modbus registers reloads the watchdog timer. If no values are written before the watchdog timer is counted to zero the gateway will automatically put all AS-i circuits that are not in *configuration mode* in a safe state by clearing the outputs. This means they are reseted.

The timeout period can be adjusted if necessary at the address 61441 (in 10 ms units, range 1 to 65536) but it will return to the default value on power cycle.

If zero is written to the address 61441, the watchdog is disabled.

The reference 2087 holds the default value for the watchdog timeout. This value is set in the register 61441 after power on of the gateway. This period can be adjusted from 0 to 999 (0=watchdog disabled). Writing to this register also writes to the register 61441.

Reading the address 61441 returns the watchdog holdup time remaining (reset to value written at each output operation).

## 14. Operation via Ethernet IP (Modbus/TCP)

The AS-i/Gateway acts as a 1 or 2 complete Master for the AS-i and as a 256 bit digital I/O module for Ethernet. All possibilities offered by AS-i can be used via Ethernet TCP/IP.

The used Modbus/TCP protocol is similar to the Modbus protocol. Specifically, it covers the use of Modbus messaging in an Intranet or Internet environment using TCP/IP protocols. The only differences to the Modbus protocol are the form of any "framing" sequence, error check pattern and address interpretation.

All requests are sent via TCP on registered port 502.



### Data addresses in Modbus messages

All data addresses in Modbus messages are referenced to zero. The first occurrence of a data item is addressed as item number zero.

For example:

The coil known as "coil 1" in a programmable controller is addressed as coil 0000 in the data address field of a Modbus message.

Coil 127 decimal is addressed as coil 007E hex (126 decimal).

Holding register 40001 is addressed as register 0000 in the data address field of the message. The function code field already specifies a "holding register" operation. Therefore the "4XXXX reference is implicit.

Holding register 40108 is addressed as register 006B hex (107 decimal).

### 14.1 Message Structure

Telegrams from the Modbus-Master (query-messages) and answers of the Modbus slaves have the same structure:

The request and response are prefixed by 6 bytes as follows:

T1	T2	P1	P2	B1	B2	UI	F	D1	D2	...	Dn
high	low	high	low	high	low			high	low		low

Transaction identifier  $T_1, T_2$ : usually 0 - copied by server.

protocol identifier  $P_1, P_2$ : 0

length field  $B_1$ : upper byte of the length field = 0 (since all messages are smaller than 256)

length field  $B_2$ : lower byte of the length field = number of bytes following

unit identifier UI: value to indentifying the client

function code F: Code of Modbus-function to be executed by the slave. Under certain circumstances the slave could answer with an error-telegram. In this case the function-code in the response-message is increased by 128.

data bytes  $D_1 \dots D_n$ : Field to hold user-data.  
 The number of bytes is variable



**Information!**

Checksum fields are not needed, because the TCP/IP and link layer (eg. Ethernet) instead are used to verify accurate delivery of the packet.

**Example transaction:**

Read 1 register at offset 4 from UI 9. Return value is 5

request	00	00	00	00	00	06	09	03	00	04	00	01
response	00	00	00	00	00	05	09	03	02	00	05	

**14.2 Ethernet TCP/IP functions**

In the following chapter are shown the support functions. Please note, that only the related bytes are shown (bytes 0 - 3 are let away, because the values are 0).

**14.2.1 Function 3 (3hex): "Read multiple registers"**

This function allows to read the value of read/write-registers.

request:	3	R1 high	R2 low	N1 high	N2 low							
response:	3	B	D1 high	D1 low	...	Dn high	Dn low					

R1/R2: reference number (high byte / low byte)

N1/N2: word count (range 1 - 125) (high byte / low byte)

response:

B: byte count of response (b = 2 x word count)

D: register values

**14.2.2 Function 16 (10hex): "Write multiple registers"**

This function allows the setting of several read/write-registers:

request:	10	R1 high	R2 low	N1 high	N2 low	B	D1 high	D1 low	...	Dn high	Dn low
response:	10	R1 high	R2 low	N1 high	N2 low						

R1/R2: reference number (2 byte hex-value of register  
 e.g. 8192 = 0x2000)

N1/N2: Word count (1 - 100) (2 byte)

B: byte count of response (B = 2 x word count / 1 byte)  
 (redundant information to word count but necessary).

D1 ... Dn: register values

### 14.2.3 Function 23 (17hex): "Read/Write multiple registers"

This function allows to read the value of read/write-registers and the setting of several read/write-registers:

request:	17	RR high	RR low	NR high	NR low	RW high	RW low					
		NW high	NW low	B	D1 high	D1 low	...	Dn low				

response:	17	B	D1 high	D1 low	...	Dn high	Dn low
-----------	----	---	------------	-----------	-----	------------	-----------

RR: reference number for read (2 byte hex-value of register)

NR: word count for read (1 - 125) (2 byte)

RW: reference number for write (2 byte hex-value of register)

NW: word count for write (1 - 100) (2 Byte)

B: byte count (B = 2 x word count for write / 1 byte)

(redundant information to Word count but necessary)

D1 ... Dn: register value

#### Example:

Read 2 registers at reference 0 and write 1 register at reference 3 of value 4660 returning values 4 and 4951.

request:	17	RR high	RR low	NR high	NR low	RW high	RW low	NW high	NW low	B	D1 high	D1 low
----------	----	------------	-----------	------------	-----------	------------	-----------	------------	-----------	---	------------	-----------

request:	17	00	00	00	02	00	03	00	01	02	46	60
----------	----	----	----	----	----	----	----	----	----	----	----	----

response:	17	B	D1 high	D1 low	D2 high	D2 low
-----------	----	---	------------	-----------	------------	-----------

response:	17	04	00	04	49	51
-----------	----	----	----	----	----	----

### 14.2.4 Exception codes

There is a defined set of exception codes to be returned by slaves in the event of problems. Note that masters may send out commands "speculatively", and use the success or exception codes received to determine which MODBUS commands the device is willing to respond to and to determine the size of the various data regions available on the slave.

All exceptions are signaled by adding 128 to the function code of the request, and following this byte by a single reason byte for example as follows:

**For instance:**

03 46 60 00 01 ⇒ 128 02

request: read 1 Register at index 4660

response: exception type 2 - „illegal data address“

**List of exceptions:**

- **01 ILLEGAL FUNCTION**  
 The function code received in the query is not an allowable action for the slave. This may be because the function code is only applicable to newer controllers, and was not implemented in the unit selected. It could also indicate that the slave is in the wrong state to process a request of this type, for example because it is unconfigured and is being asked to return register values.
- **02 ILLEGAL DATA ADDRESS**  
 The data address received in the query is not an allowable address for the slave. More specifically, the combination of reference number and transfer length is invalid. For a controller with 100 registers, a request with offset 96 and length 4 would succeed, a request with offset 96 and length 5 will generate exception 02.
- **03 ILLEGAL DATA VALUE**  
 A value contained in the query data field is not an allowable value for the slave. This indicates a fault in the structure of the remainder of a complex request, such as that the implied length is incorrect. It specifically does NOT mean that a data item submitted for storage in a register has a value outside the expectation of the application program, since the MODBUS protocol is unaware of the significance of any particular value of any particular register.
- **04 ILLEGAL RESPONSE LENGTH**  
 Indicates that the request as framed would generate a response whose size exceeds the available MODBUS data size. Used only by functions generating a multi-part response, such as functions 20 and 21.
- **05 ACKNOWLEDGE**  
 Specialized use in conjunction with programming commands
- **06 SLAVE DEVICE BUSY**  
 Specialized use in conjunction with programming commands
- **07 NEGATIVE ACKNOWLEDGE**  
 Specialized use in conjunction with programming commands
- **08 MEMORY PARITY ERROR**  
 Specialized use in conjunction with function codes 20 and 21, to indicate that the extended file area failed to pass a consistency check.
- **0A GATEWAY PATH UNAVAILABLE**  
 Specialized use in conjunction with Modbus Plus gateways, indicates that the gateway was unable to allocate a Modbus Plus PATH to use to process the request. Usually means that the gateway is misconfigured.


- **0B GATEWAY TARGET DEVICE FAILED TO RESPOND**  
Specialized use in conjunction with Modbus Plus gateways, indicates that no response was obtained from the target device. Usually means that the device is not present on the network.

## 15. Data Transfer using CIP Messages in RSLogix5000


This chapter explains the data transfer of AS-i 3.0 EtherNet/IP Gateways using CIP Messages in RSLogix5000.

### 15.1 MSG instruction and Message Type Tag


- Include a MSG instruction.
- Create a new MESSAGE-type tag as control tag for the instruction.



- Select "Configure" on the "New Tag" window or "... " next to the tag name to open the "Message Configuration" window.




- Select the "Communication" tab.
- Browse to the "AS-i Ethernet IP" module
- Check the "Connected" check box.



### 15.2 Example 1: read LAS

- Select the "Configuration" tab in the "Message Configuration" window
- Select:
  - Message Type: CIP generic
  - Service Type: Get attribute single
- Map:
  - For "Class": "64"
  - For "Instance": "1" (for AS-i circuit 1)
  - For "Attribute": "69"
- As "Destination", create a new tag or select an existing tag to hold the incoming data.



**15.3 Example 2: read/write 16-bit (analog) data**


- Select the "Configuration" tab in the "Message Configuration" window
- Select:
  - Message type: CIP generic

**Read 16-bit data from slave address 7**

- Select:
  - Service type: Get attribute single
- Map:
  - For "Class": "66"
  - For "Instance": "1" (for AS-i circuit 1)
  - For "Attribute": "6E" (16-bit input data slave 7)
- As "Destination", create a new tag or select an existing tag to hold the incoming data.

**Write 16-bit data to slave address 7**

- Select:
  - Service type: Set attribute single
- Map:
  - For "Class": "66"
  - For "Instance": "1" (for AS-i circuit 1)
  - For "Attribute": "8D" (16-bit output data slave 7)
- As "Source element", create a new tag or select an existing tag to hold the outgoing data
- As "Source length": "4" (16-bit data = 8 bytes)



## 16. System startup using AS-i Control Tools

The Windows based software AS-i Control Tools enables an easy and clear configuration of the AS-i network.




### Information!


*AS-i Control Tools must be installed first!*

*This way, the device driver is copied into the previous designed folder in AS-i Control Tools and should be recognized automatically.*

1. Connect the device to the PC via its serial interface and the diagnostic interface.
2. Start AS-i Control Tools.
3. Select Master | New.



4. Choose RS232 diagnostic interface as the protocol.




5. Select the appropriate settings (for example serial interface COM 2, station address <auto>).
6. Select Master | AS-i configuration.
7. The AS-i configuration editor will be started. All detected and configured AS-i slaves are displayed in this window.

- Click on a slave to open the dialog window 'slave configuration'.



This window enables the user to edit a slave address and to set AS-i parameters or AS-i configuration data. Additionally, inputs and outputs can be tested.

- Click the second button on the right side of the tool bar to get a graphical display of "AS-i Control Tools".



Configuring the AS-i network is easily accomplished by first connecting each AS-i slave separately to the AS-i line and setting its address, followed by pressing the button “Store configuration” to store the existing AS-i network in the AS-i master as configuration data.

Furthermore, an **AS-i Address Assistant** is available, allowing to perform an address change of a new AS-i slave to the desired address as soon as it is connected to the AS-i network. The desired AS-i configuration can be created offline ahead of time and can be stored to a file. When setting up the system the AS-i slaves are then simply connected, one at a time, to the AS-i network. Further descriptions to all additional features of this software can be obtained from the integrated help file.

## 17. Configuration with Windows Software ASIMON 3 G2



### ***Information!***

*Please note further information in the configuration software **ASIMON 3 G2** for Windows.*

## 18. Safe Link


### 18.1 General introduction

Safe Link represents the most efficient and cost-effective way to link safe signals from multiple AS-i networks.

As for an AS-i linking network, safe linking using potential-free contacts or safe electronic in- and outputs eliminates expensive and cumbersome wiring. Safe Link also offers the same system range as a PROFINET controller based on the PROFIsafe standard without being restricted to a particular system controller.

Safe Link allows up to 1922 safe inputs to be processed in a full configuration of 31 gateways with 62 safe slaves. 31 safe bits per Gateway are provided for coupling, resulting in a total of 961 signals that can be safely coupled.

#### Safe coupling via standard Ethernet



For Safe Link the Gateways are connected over the Ethernet diagnostics interface (10 Mbit/s, half-duplex) and a switch. In the case of PROFINET and EtherNet/IP+Modbus TCP, instead the fieldbus interface can be used for Safe Link.

If the Ethernet interface is used for coupling, devices having different controller systems (such as PROFIBUS, PROFINET, EtherNet/IP, Modbus, sercos, etc.) can exchange signals with each other without any additional effort using the switch.


Since data transmission is based on the sending of multicasts, it must be ensured that the switch used can process and pass along the corresponding broadcasts.

## 18.2 Configuration

<b>Safe Link</b>	
Ethernet diagnostics interface	10Mbits, half-duplex
Ports	Depends on the Multicast group Port 1024 to 1038
Protocol	UDP
Data packets	72 bytes per packet Average 286 packets per second
<b>Group organization</b>	
Number	max. 15 groups (Group addresses 1 to 15)
No. of devices	max. 31 devices per group
<b>System size</b>	
max. system size	31 Gateways x 62 safe input slaves = 1922 safe inputs in full configuration
<b>Kopplung</b>	
max. no. of coupled signals	31 GW x 31 signal bits = 961 safe coupled signals in full configuration
<b>Switch</b>	
Requirements	<ul style="list-style-type: none"> <li>• Multicast-capable</li> <li>• If not all connected devices receive all signals, an IGMP-capable lean managed switch is required</li> </ul>

### 18.2.1 Configuration using ASIMON

Complete configuration of Safe Link is done using the ASIMON software, in the "Monitor/Bus information" section [1] on the "Safe Link" tab [2].



Here the group and device addresses are assigned and the safe programs for the individual Gateways managed. Information about the IP addresses of the participating devices are also stored in the project structure.

In organizational terms all Gateways that need to communicate with each other are combined in one group (Group addresses 1 to 15) [3].

Each device in a group is given a unique device address (Device addresses 1 to 31) [4].

One of the devices is assigned as the manager of the group [5], which means it monitors whether all the participating devices are present in the network.

31 bits are available in each Gateway which can be used by the other group members as safe signals.

In a full configuration with 31 Gateways this means a total of 961 safe coupled signals are available.



**Information!**

*Before setting up Safe Link, be sure you have read the information on configuring Safe Link in the ASIMON documentation in the section <Safe Link Tab>*

## 18.3 Diagnostics

### *Directly on the device*

If a group member does not receive the expected messages from another member, it displays the device address of the missing Gateway together with the message "not active".


e.g. missing data telegrams from Devicer 4:

```
X.4 not active
```

### *About ASIMON*


The ASIMON software can be used at any time to perform diagnostics for the Safe Link by invoking "Safe Link diagnostics" from the "Start diagnostics" menu in the "Applications" section. This opens a window with a graphical detailed view of the state of communication for all group members.

If an error occurs in Safe Link, the corresponding signals are shown in gray in the ASIMON configuration, and at the same time a popup window opens automatically with a reference to missing devices.



Clicking on the "Safe Link diagnostics" button [1] on the bottom edge of the popup window also opens the diagnostics window for Safe Link.

Here you are shown the status and direction of communication between the individual group members in graphical format. Based on the arrow colors you can see which sections of communication may be associated with telegram errors.



**Information!**

Please refer here to the information in the ASIMON documentation in the <Safe Link diagnostics> section.

## 19. Appendix, examples

### 19.1 Commissioning with RSLogix5000 V20 or higher

This document describes how to install and use an EDS file and an Add On Instruction for AS-i Ethernet IP Gateways in RSLogix5000 V20 or higher.


1. Start the EDS Wizard: "Tools" -> "EDS Hardware Installation Tool".




2. Select "Register an EDS file(s)".




3. Select your EDS file.




4. Select **"Next"** until the installation is completed.




5. Create a new Module in the RSLogix I/O Configuration.




6. Select the Pepperl+Fuchs AS-i Gateway.



7. Assign Name and IP Address and select “**Change**” to change the kind of data being transferred.




8. Use the Drop Down Menu to select the kind of data.




abbreviation	meaning
I/O	input and output data
I	only input data
C1[2] A[B] slaves	circuit 1 [and 2] A [and B] AS-i slaves
C1[2] analog	circuit 1 [and 2] analog slaves 29 ... 31
C1[2] slaves 10 ... 31 analog	circuit 1 [und 2] analog slaves 10 ... 31
CI	command interface
Safety (from SV 4.3)	Safety Control/Status (from Safety Version 4.3)


9. The AS-i Gateway data can now be found in the Controller Tags.




10. Optionally the example AOI (**Add-On Instructions**) can be used to copy the raw data into structured data. Free AOI examples are available:
  - **AOI-COP\_ASi.L5X** copies digital data (A/B slaves, circuit 1 und 2, three analog slaves and the command interface).
  - **AOI-COP\_ASi\_Safety.L5X** copies additionally Safety Control/Status.
  - **AOI-COP\_ASi\_Safety\_Long\_Analog.L5X** copies additionally up to 22 analog slaves
- Right click on **"Add-On Instructions"** and select **"Import Add-On Instruction"**.



11. Select the file "AOI-COP\_ASi.L5X" (as an example).




12. Confirm the Import Configuration.







- Open the AOIs "Logic" and adapt the length of the actually configured data. See comments in the routine



- Call the AOI in your program.



16. The AS-i Gateway data can now be found in data structures.




## 19.2 The first commissioning with CompactLogix


This chapter shows exemplarily the start-up of the AS i 3.0 EtherNet/IP Gateways with the software RSLogix 5000 CompactLogix, version 13.00.

- Start the software RSLogix 5000.
- Select *New* from the menu *File*.


- Now select your controller, register its name and confirm with **OK**.



- Click in the tree view control window with the right mouse button on your controller
- Click in the PopUp window with the left mouse button on *New Module*.



- Select the entry *Generic Ethernet Module* and confirm with *OK*.



- Now register all necessary characteristics of the module:
  - Controller name
  - Comm. format
  - IP-Address
  - Connection parameters
  - Assembly Instance - Input/Output
  - Assembly Instance - Configuration (Register here a number between 1...255)
  - Assembly Instance - Size



### Assembly Instances

A so-called *Assembly Object* specifies the structure of objects for the data communication. The data (e.g.: I/O data) can be combined into blocks with the *Assembly Object Data* and sent over only one communication link.

Thus less access to the network are necessary.

It is differentiated between *Input Assemblies* and *Output Assemblies*:

-*Input Assembly* reads application data over the net and/or produces data on the network.

-*Output Assembly* writes data on the application and/or processes data of the network.


In this example the *Input Instance 114* and the *Output Instance 150* is used (94 bytes for in and output data).

### Allocation of the data


32 bytes for digital data (A/B slaves)

24 bytes for analog data (slave address 29 .. 31)


38 bytes für command interface



- Click the button *Next*
- Please enter in the data field *Request Packet Interval (RPI)* a time (see chap. <Assembly Object>).
- Please click on the *Finish* button.




- Now you can begin programming.
- For the first downloading of the software the transmission path must be indicated. Select for this purpose from the menu *Communications* the entry: *Who Active*.



- With a double click on the pictogram *Processor* you can begin with the download.

### 19.2.1 Working with sample files

- Please unzip your "[AS-i/Ethernet IP gateway with AS-i Scanner for Allen-Braley CompactLogix](#)" sample file.
- Please start the software RSLogix 5000.
- Please open the file "F01\_Module.ACD". This sample file contains a program that shows you, how to use the command interface (mailbox).
- If it is needed, please adjust your controller and the ip of your gateway.
- Please look at the description of the controller tags, where you can find the tag *Mailbox1*.



Here you can edit the command interface instructions. You can find an appropriate description in the *Mbx0Main* routine in the *Mailbox*.

#### Further sample files:

- F02\_RD\_RW.ACD, F03\_Get\_LAS.ACD, F04\_READ\_IDI.ACD,
- F05\_GET\_DELTA.ACD, F06\_GET\_TECA.ACD,
- F07\_SET\_LOS.ACD, F08\_GET\_LOS.ACD,
- F09\_GET\_LCS.ACD, F10\_GET\_LPF.ACD,
- F11\_SafeDiagSort.ACD, F12\_ACYCLIC\_TRANS.

The task *MainProgram* of these examples shows, how to use some instructions of the *Command Interface* with help of the task *Mbx0Main*.

#### DataExchange.ACD

This sample file contains a very simple program that shows you how to read and write digital AS-interface inputs and outputs.

### 19.3 Safety diagnostics in the input data image (IDI)



**Information!**

*This functionality is available only in certain models. For additional information see section <Diagnostic values in the IDI>.*

#### 19.3.1 Representation of the diagnostic information

Diagnostics in the IDI is a way to get the most important diagnostics information into the controller without using a command interface (mailbox) and without additional effort. The diagnostics information is sent in the input data image, encoded to the input bits of the safety input slave address.

Bits 0 and 1 represent the switching state of Channels 1 and 2 of the safety input, thereby making the state directly accessible very quickly.

Bit 3	Bit 2	Bit 1	Bit 0	Description
X	X	0	0	Both channels open
X	X	0	1	2 <sup>nd</sup> channel open, 1 <sup>st</sup> channel closed
X	X	1	0	2 <sup>nd</sup> channel closed, 1 <sup>st</sup> channel open
X	X	1	1	Both channels closed

Tab. 19-77.

Bits 2 and 3 contain the state of the safety input (the device color of the ASIMON):

Bit 3	Bit 2	Bit 1	Bit 0	Description
0	0	X	X	Device color: red, green or gray
0	1	X	X	Device color: yellow ("wait")
1	0	X	X	Device color: yellow flashing ("test")
1	1	X	X	Device color: red flashing ("error")

Tab. 19-78.



**Attention!**

Note the following points when performing an evaluation:

- The information for switching state and error status are not processed synchronously
- When there is a configuration error all bits having a value of 0 are sent; this must be noted when evaluating the data.
- When the monitor is stopped the device color is "gray".
- The state "yellow flashing" can be recognized as a transition state with regular switching. This depends on the set module type. This state should be understood as a test request only if it is stably reported.

### 19.3.2 Other representation variants

In addition to the above, there are also the following variants for representing the diagnostics:

- Safety code sequence:  
 Sending of the code sequence, with no evaluation of the data; the current state is sent for each bit. Sending of a code sequence for safety input slaves results in a continuous changing between states "1" and "0".
- Substitution values:  
 Substitution of the code sequences by the state of the input (Safe Subst Val), where the following values are sent:


Bit 3	Bit 2	Bit 1	Bit 0	Description
0	0	0	0	Both channels off
0	0	1	1	2 <sup>nd</sup> channel off, 1 <sup>st</sup> channel on
1	1	0	0	2 <sup>nd</sup> channel on, 1 <sup>st</sup> channel off
1	1	1	1	Both channels on

Tab. 19-79.


### 19.3.3 Changing the default setting

The diagnostics type is set or changed using the device display (Safety -> AS-i Safety -> Safe subst Val)

Another method for setting the diagnostics type is by using the GSD/GSDML parameters:



Old GSD files do not affect the setting; new GSDs do not change the mode by default (default setting: "no change"):





## 20. Status indication, faults and fault elimination

### 20.1 Spontaneous display of faults from the safety unit

Spontaneous messages are displayed on Pepperl+Fuchs GmbH AS-i monitors as follows:

- When both networks are operating without error, a smiley is displayed.
- When field bus communication fails, this is indicated by a text message.
- When there is a fault on an AS-i slave, this is displayed until the fault is no longer present.
- When there are no faults present, the states of the safety unit are displayed in text beneath the smiley.
- When four local release circuits are present, a line is displayed with their status.

```

    ☺Press OK for Menu
      Output Circuit
      1:ON      2:ON
      3:ON      4:ON
    
```

#### Coding:

Display in protecting mode:

1, 2, 3 and 4 for the release circuits

display	status of the safety unit	meaning
ON	green	relais circuit turned on
OFF	red	relais circuit turned off
WAIT	flashing green	wait time Stop 1 running
START	yellow	waiting for Start signal

Display in error status:

SAFETY FAULT: flashing red  
 TEST: flashing yellow

*Red* and *flashing yellow* are fault messages and are treated separately.

If the safety unit is in configuration mode, this is indicated by the CONFIG-OPERATION display.

*Yellow flashing* and *red flashing* means the AS-i slave address of the faulted device is displayed. If there are other faults present at the same time, all faults are displayed alternately.

If the safety unit is in the *red flashing* state and no menu is open, the safety unit can be unlocked by pressing the ESC/Service key (Section <Function of the ESC/Service key>).

- If the message “Fatal Error” is reported from the safety unit, only this error message will be displayed in normal mode (not the menu). The non-safe unit continues to operate normally in this case and the menus can also be opened.

```
FATAL ERROR
000 255 222 111
```

- All other messages are not shown spontaneously.

If the safety unit is in the *yellow flashing* state, depending on the status of the configuration an external test may be required, an acknowledgement of the status may need to be made, or the turn-on delay active.

## 20.2 Replacing a defective safety-configured AS-i slave

If a safety-configured AS-i slave is defective, it can be replaced even without a PC or reconfiguration of the AS-i Safety Monitor by pressing the ESC/Service key on the AS-i Safety Monitor.



### **Information!**

*Pressing the ESC/Service key changes the safety monitor from protecting mode to configuration mode. The output circuits are therefore not turned off.*

*Code tables for replaced AS-i slaves can be taught without the PIN.*

Proceed as follows:

1. Disconnect the AS-i slave from the AS-i cable.
2. Press the ESC/Service key on the AS-i Safety Monitor and on all other safety monitors for approx. 3 seconds.

```
CONNECT NEW
SLAVE 17
THEN PRESS
SERVICE
```

3. Connect the new safety-configured AS-i slave, which has already been programmed to the corresponding address, to the AS-i cable.
4. Press the ESC/Service key again on the AS-i Safety Monitor and on all other Safety Monitors which use the replacement safe AS-i slave for approx. 3 seconds. The code table for the new slave is taught and checked for correctness.  
 If this is OK, the AS-i Safety Monitor changes to protecting mode. Otherwise you are prompted again to teach.



### **Information!**

*Inputs on the new slave must be turned on.*



**Attention!**

*After replacing a defective safe AS-i slave, always check the correct function of the new slave.*

### 20.3 Replacing a defective AS-i Safety Monitor

If an AS-i Safety Monitor is defective and needs to be replaced, the replacement unit does not necessarily have to be newly configured using the **ASIMON 3 G2** software, rather it is possible to copy the configuration of the defective device using a chip card.

Requirement:

The replacement unit has an empty configuration in its configuration memory.



**Information!**

*After replacing a defective safe AS-i Safety Monitor, always check the correct function of the new AS-i Safety Monitor.*

### 20.4 Forget the password? What do I do now?



**Attention!**

*Only the responsible safety representative is permitted to retrieve a lost password as follows!*

If the password is lost for your configuration, proceed as follows:

1. Find the valid configuration protocol for the AS-i Safety Monitor whose password you have lost (printout or file). In the configuration protocol in line 10 (Monitor Section, Validated) you will find a 4-digit code.
  - If you do not have the configuration protocol and do not want to place the AS-i safety monitor in configuration mode, connect the AS-i safety monitor whose password you have lost to the PC and start the **ASIMON 3 G2** software.
  - Select a neutral configuration and start the diagnostics function in **ASIMON 3 G2** using MONITOR -> DIAGNOSTICS. Wait until the current configuration appears on the screen. This may take up to 1 minute.
  - Open the window MONITOR/BUS INFORMATION (EDIT MENU -> MONITOR/BUS INFORMATION...). On the Title tab you will also find the 4-digit code in the Download time window area.
2. Contact technical support at your supplier and enter the 4-digit code.
3. From this code a master password can be generated which can be used to access the stored configuration.
4. Use this master password to stop the AS-i Safety Monitor and enter a new user password. In the Monitor menu of the **ASIMON 3 G2** configuration software select the menu item Password changing.



**Attention!**

*Please note that accessing the configuration stored in the AS-i Safety Monitor can affect the safe function of the system. Changes to released configurations are to be made only by authorized personnel. Any change must be made according to the instructions in the User's Manual for the **ASIMON 3 G2** configuration software.*



**Information!**

*The default password (factory setting) of the AS-i safety monitor is "SIMON". If you would like to reconfigure the AS-i safety monitor, you must first change this default password to a new one known only to you as safety officer.*

## 21. Codes indicated by the display

In the basic state of the configuration mode, the addresses of all detected slaves are displayed in two-second intervals. A blank display indicates that the LDS (List of Detected Slaves) is empty, no slaves were detected.

In the basic state of the protected operating mode, the display is either blank or displays the address of a faulty assignment.

During manual address programming, the slave address display has a different meaning (see also chapter "Operating in advanced display mode").

All displayed numbers bigger than 31 which can not be interpreted as a slave address are status or error messages of the master. They have the following meanings:

39	Advanced AS-i diagnostics: After pressing the 'set'-button a short-time AS-i power failure occurred.
40	The AS-i master is in offline phase.
41	The AS-i master is in detection phase.
42	The AS-i master is in activation phase.
43	The AS-i master starts the normal operating mode.
68	Hardware error: disturbed internal communication.
69	Hardware error: disturbed internal communication.
70	Hardware error: The AS-i master's EEPROM cannot be written.
71	Wrong PIC-type.
72	Hardware error: wrong PIC-processor.
73	Hardware error: wrong PIC-processor.
74	Checksum error in the EEPROM.
75	Error in the internal RAM.
76	Error in the external RAM.
77	AS-i control software error: Stack overflow (AS-i control II)
78	AS-i control software error: checksum error in the control program. <u>"control checksum"</u> : checksumm in Control III C program (bin.file) not correct. The file is possibly damaged. <u>"control exec err"</u> : error in Control III C program. <u>"control watchdog"</u> : watchdog predetermined in Control III C program has expired . <u>"control incomp"</u> : Control III C program from another gateway type loaded (e.g. Ethernet IP in Profibus gateway).

12.9.2013

79	Checksum error in the data menu. <u>"breakpoint"</u> : Control III C program in break point.
80	Error while attempting to exit the configuration mode: A slave with address zero exists.
81	General error while changing a slave address
82	The front panel operation is blocked. Until repowering-up the device can only be accessed from the host via the interface.
83	Program reset of the AS-i Control program: The AS-i Control program is being read from the EEPROM and copied into the RAM.
88	Display test while starting up the AS-i master
90	Error while changing a slave address in protected operating mode: No slave with address 0 existing.
91	Error while changing slave address: Target address is already used.
92	Error while changing slave address: New address could not be set.
93	Error while changing slave address: New address could only be stored volatile in the slave.
94	Error while changing the slave address in protected operating mode: Slave has wrong configuration data.
95	The error 95 is caused by a superfluous slave and not by a missing slave. That is why the slave address is occupied by this superfluous slave. (In the protected mode the slave addresses which caused any configuration error can be displayed by pressing the SET button. AS-i master without graphical display are not able to differentiate between a missing slave, an incorrect slave or a redundant slave. All incorrect addresses are displayed. By pressing the SET button 5 sec. the displayed address starts to flash. Pressing the SET button again the master attempts to program the slave at the address 0 to the incorrect address.)

## 22. Reference List

### 22.1 Manual: "ASIMON 3 G2 Configuration Software"

This Manual contains a detailed description of the configuration software for the AS-i Safety Monitor. The manual is an important component of the documentation for the AS-i Safety Monitor. It is not possible to configure and start up the AS-i Safety Monitor without the **ASIMON 3 G2** software.

### 22.2 Sources

1. Kriesel, Werner R.; Madelung, Otto W. (editors): AS-interface. Das Aktuator-Sensor-Interface für die Automation. Auflage, Carl Hanser Verlag; München, Wien, 1999, ISBN 3-446-21064-4
2. Spezifikation des AS-interface, ComSpec V3.0 AS-international Association (available from AS-international Association, <http://www.as-interface.net>).
3. Vorschlag eines Grundsatzes für die Prüfung und Zertifizierung von „Bussystemen für die Übertragung sicherheitsrelevanter Nachrichten“, Stand 29.2.2000.
4. AS-interface - Die Lösung in der Automation, Ein Kompendium über Technik, Funktion, Applikation (erhältlich, auch in englischer Sprache, bei AS-international Association, <http://www.as-interface.net>).

## 23. Glossary

### **A/B slave**

An AS-i slave with extended addressing. The address range of an A/B slave extends from 1A to 31A and 1B to 31B.

### **AS-i Power Fail**

Voltage below the threshold on the AS-i cable.

### **I/O code**

The first digit of the slave profile, which indicates how many in- and outputs the slave has. A 4I/4O slave has for example a "7", and a slave with 4 digital inputs a "0".

### **EDM (External Device Monitoring, feedback circuit)**

Used for monitoring the switching function of the contactors connected to the Safety Monitor, whereby the normally closed contacts (forced-opening when possible) are fed back to the start circuit of the Safety Monitor. A restart is then only possible if the normally closed contacts are closed (in the quiescent state).

### **ID code**

The ID code is set by the slave manufacturer and cannot be changed. The AS-i Association determines the ID codes which are assigned for a particular class of slaves. For example, all  $\Rightarrow$  A/B slaves have ID code "A".

### **ID1 Code, extended ID1 code**

The ID1 code is set by the slave manufacturer. In contrast to the other codes, which determine the profile, it can be changed from the master or using an addressing device. The user should however only use this feature in exceptional circumstances, since otherwise *configuration errors* may occur.

In the case of A/B slaves, the MSB of the ID1 code is used for distinguishing between the A and the B address. Therefore, only the lowest 3 bits are relevant for these slaves.

Since this code was not introduced until AS-i Specification 2.1, it is also referred to as extended ID1 code.

### **ID2 Code, extended ID2 code**

The ID2 code is set by the slave manufacturer and cannot be changed. The AS-i Association determines the ID2 codes, which are assigned for a particular class of slaves. For example, all 2-channel 16 bit input slaves having an S-7-3 bit code use ID2 code "D". Since this code was not introduced until AS-i Specification 2.1, it is also referred to as extended ID2 code.

**Inclusion phase**

The AS-i master sends a command to an available slave address to detect new slaves. If no reply is received, it immediately begins with the next data exchange phase.

**LPF - List of Peripheral Faults**

The list of peripheral faults was introduced with specification 2.1. This list includes an entry for each slave that signals a  $\Rightarrow$  peripheral fault.

**Offline phase**

In offline phase there is no communication on AS-i.

**OSSD (release circuit)**

The safe AS-i components and functional devices assigned to an output circuit of the AS-i safety monitor. They are responsible for releasing the machine element which generates the hazardous movement.

**Password**

Security code for a (security) configuration, is required for releasing a configuration or activating a changed configuration. The password is a string of 4 ... 8 alphanumeric characters. It is stored in the configuration.

**Peripheral fault**

Depending on the slave, an overflow, an overload on the sensor supply, or some other fault affecting the slave peripheral can be displayed.

**PIN**

A security code is required for teaching code sequences. The PIN is a 4-digit decimal number.

The PIN does not authorize for activating a safety configuration.

The PIN is stored in the EEPROM of the unprotected device section as well as in the unprotected area of the chip card, and is therefore sent to a new device when the chip card is replaced. When resetting to factory defaults, the PIN is set to 0000.

**Release Code**

Security code for a safety configuration on the chip card. A 4-character hexadecimal number generated by the **ASIMON 3 G 2** software. The release code is displayed before copying a configuration from the memory card to the Monitor and must be repeated by the operator.

This provides a technical safeguard against errors in the unprotected display and keyboard software.

### Single Slave

A single slave can in contrast to a  $\Rightarrow$  *A/B slave* only be addressed from range 1 to 31; the fourth output data bit can be used. All slaves as defined by the older AS-i Specification 2.0 are single slaves.

There are however also single slaves as defined by Specification 2.1, for example the new 16 bit slaves.

### Slave profile

Configuration data for a slave, consisting of:

$\Rightarrow$  *I/O configuration* and  $\Rightarrow$  *ID-Code*, as well as  $\Rightarrow$  *extended ID1-Code* and  $\Rightarrow$  *extended ID2-Code*.

The slave profile is used to distinguish between various slave classes. It is specified by the AS-i Association and set by the slave manufacturer.

AS-i 2.0 slaves do not have extended ID1 and ID2 codes. A 2.1 or 3.0 AS-interface master enters in this case an "F" for each of the extended ID1 and ID2 codes.

### Master configuration

Released configuration, without code sequences. The safety unit cannot turn on the outputs, but as soon as the code sequences are learned, the device is usable.

Such a master configuration can for example be used in serial production machine building for loading the safety program, whereby the configuration is created in the design and the code sequences taught on the physical machine.

### Complete configuration

Counterpart to  $\Rightarrow$  *master configuration*. Release configuration including code sequences. The device is always usable.

# FACTORY AUTOMATION – SENSING YOUR NEEDS



## Worldwide Headquarters

Pepperl+Fuchs GmbH  
68307 Mannheim · Germany  
Tel. +49 621 776-0  
E-mail: [info@de.pepperl-fuchs.com](mailto:info@de.pepperl-fuchs.com)

## USA Headquarters

Pepperl+Fuchs Inc.  
Twinsburg, Ohio 44087 · USA  
Tel. +1 330 4253555  
E-mail: [sales@us.pepperl-fuchs.com](mailto:sales@us.pepperl-fuchs.com)

## Asia Pacific Headquarters

Pepperl+Fuchs Pte Ltd.  
Company Registration No. 199003130E  
Singapore 139942  
Tel. +65 67799091  
E-mail: [sales@sg.pepperl-fuchs.com](mailto:sales@sg.pepperl-fuchs.com)

[www.pepperl-fuchs.com](http://www.pepperl-fuchs.com)

 **PEPPERL+FUCHS**  
SENSING YOUR NEEDS

Subject to modifications  
Copyright PEPPERL+FUCHS • Printed in Germany