


MANUAL

**OHV200-F22\*-B15**

**Handheld reader**



CE

With regard to the supply of products, the current issue of the following document is applicable: The General Terms of Delivery for Products and Services of the Electrical Industry, published by the Central Association of the Electrical Industry (Zentralverband Elektrotechnik und Elektroindustrie (ZVEI) e.V.) in its most recent version as well as the supplementary clause: "Expanded reservation of proprietorship"

<b>1</b>	<b>Introduction.....</b>	<b>5</b>
1.1	Content of this Document .....	5
1.2	Target Group, Personnel.....	5
1.3	Symbols Used .....	6
<b>2</b>	<b>Product Description .....</b>	<b>7</b>
2.1	Use and Application.....	7
2.2	Indicators and Operating Controls.....	8
2.3	Feedback .....	8
2.4	Scope of Delivery .....	9
2.5	Accessories .....	9
2.6	Storage and Disposal .....	9
<b>3</b>	<b>Installation.....</b>	<b>10</b>
3.1	Inserting and Removing the Battery .....	10
3.2	Mounting the Charger and Charging the Handheld Reader .....	10
3.3	Installing Vision Configurator .....	11
3.4	Installing Device Drivers .....	12
<b>4</b>	<b>Configuration .....</b>	<b>13</b>
4.1	Switching On the Handheld Reader .....	13
4.2	Selecting the Operating Mode .....	13
4.2.1	Docking Mode.....	13
4.2.2	Bluetooth Mode .....	14
4.2.3	Tablet Mode .....	14
4.2.4	Configuration Mode .....	15
4.2.5	Keyboard Layout.....	16
4.3	Configuring the Handheld Reader.....	17

<b>4.4</b>	<b>Configuration Process Using Vision Configurator.....</b>	<b>17</b>
4.4.1	Layout of Application Window .....	18
4.4.2	Image Display.....	19
4.4.3	Sensor Data .....	19
4.4.4	Test Statistics.....	20
4.4.5	Image Transmission .....	21
4.4.6	File Transmission.....	22
4.4.7	1-D Codes.....	23
4.4.8	2-D Codes.....	24
4.4.9	Sensor Settings.....	24
4.4.10	Decoding Options .....	26
4.4.11	Read Result .....	27
4.4.12	Script.....	28
4.4.13	Edited Parameters .....	33
<b>4.5</b>	<b>Configuration with Control Codes .....</b>	<b>34</b>
4.5.1	Operation .....	34
4.5.2	Read Operation .....	35
4.5.3	Data Processing .....	38
4.5.4	Data Transfer .....	40
4.5.5	Restarting and Clearing.....	42
4.5.6	Code Types .....	43
<b>4.6</b>	<b>Reading Firmware Version and Serial Number .....</b>	<b>50</b>
<b>5</b>	<b>Operation.....</b>	<b>51</b>
5.1	Reading Codes .....	51
<b>6</b>	<b>Maintenance.....</b>	<b>52</b>
<b>7</b>	<b>Troubleshooting.....</b>	<b>53</b>

# 1 Introduction

## 1.1 Content of this Document

This document contains information required to use the product in the relevant phases of the product life cycle. This may include the following:

- Product identification
- Delivery, transport, and storage
- Assembly and installation
- Commissioning and operation
- Maintenance and repair
- Troubleshooting
- Dismounting
- Disposal

The documentation comprises the following parts:

- Present document
- Datasheet

In addition, the documentation may comprise the following parts, if applicable:

- EC-Type Examination Certificate
- EC Declaration of Conformity
- Attestation of conformity
- Certificates
- Control drawings
- Other documents

## 1.2 Target Group, Personnel

Responsibility for planning, assembly, commissioning, operation, maintenance, and dismounting lies with the plant operator.

Only appropriately trained and qualified personnel may carry out mounting, installation, commissioning, operation, maintenance, and dismounting of the product. The personnel must have read and understood the instruction manual and the further documentation.

Prior to using the product make yourself familiar with it. Read the document carefully.



## 1.3 Symbols Used

This document contains symbols for the identification of warning messages and of informative messages.

### Warning Messages

You will find warning messages in instances, whenever dangers may arise from your actions. It is mandatory that you observe these warning messages for your personal safety and in order to avoid property damages.

Depending on the risk level, the warning messages are displayed in descending order as follows:



#### ***Danger!***

This symbol indicates an imminent danger.

Non-observance will result in personal injury or death.



#### ***Warning!***

This symbol indicates a possible fault or danger.

Non-observance may cause personal injury or serious property damage.



#### ***Caution!***

This symbol indicates a possible fault.

Non-observance could interrupt the device and any connected systems and plants, or result in their complete failure.

### Informative Symbols



#### ***Note!***

This symbol brings important information to your attention.



#### **Action**

This symbol indicates a paragraph with instructions. You are prompted to perform an action or a sequence of actions.

## 2 Product Description

### 2.1 Use and Application



**Caution!**

Irritation caused by optical radiation

The optical unit on the handheld reader is equipped with very bright LEDs that can cause irritation in dark environments.

Do not point the handheld reader at people.

Do not look directly into the optical unit on the handheld reader.

The OHV200 handheld is a compact handheld reader for all common 1-D and 2-D codes. Special technology to prevent glare allows the device to accurately read codes on highly reflective surfaces. With its patented dual lens and a resolution of 1.2 million pixels, it can read both small and large codes from a wide range of distances. A different-colored target projection makes it easier to see the relevant code. Feedback comes in the form of a visual or audible signal or a vibration.

Using the Vision Configurator software, rule sets can be created for formatting read results without the need for extensive programming work. This facilitates integration into ERP systems. The read data is transferred via the Bluetooth interface or by plugging the handheld reader into the charger. Thanks to its robust housing and IP65 protection, the handheld reader is also suitable for outdoor use.

Type designations:

- Version without handle: **OHV200-F220**.
- Version with handle: **OHV200-F221**.



The device is only approved for appropriate and intended use. Ignoring these instructions will void any warranty and absolve the manufacturer from any liability.

Use the device only within the specified ambient and operating conditions.

Protection of the personnel and the plant is not ensured if the device is not being used according to its intended use.


## 2.2 Indicators and Operating Controls

### OHV200-F220



- 1 Memory
- 2 Bluetooth connection
- 3 Function indicator
- 4 Trigger buttons

### OHV200-F221



- 1 Memory
- 2 Bluetooth connection
- 3 Function indicator
- 4 Trigger buttons

## 2.3 Feedback

Action	LED	Audible signal	Vibration
Handheld reader successfully switched on	The function indicator on the handheld reader briefly lights up red then briefly lights up green.	Single audible signal	Vibrates once
Handheld reader ready	LEDs are off.	No audible signal	No vibration
Code reading successful	The function indicator on the handheld reader briefly lights up green. If a Bluetooth connection is activated, the Bluetooth connection on the charger flashes blue during data transfer.	Single audible signal	Vibrates once
Code reading failed	Bluetooth connection flashes green four times.	Four audible signals	Vibrates four times
Configuration code reading successful	The function indicator on the handheld reader briefly lights up green.	Two audible signals	Vibrates twice
Configuration code reading failed Configuration code not permitted	The function indicator on the handheld reader lights up twice.	Five audible signals	Vibrates five times



Action	LED	Audible signal	Vibration
The handheld reader memory is full	Memory flashes five times per second. See chapter 4.5.5	No audible signal	No vibration
Connection between charger and PC successfully established No Bluetooth connection between charger and handheld reader	The Bluetooth connection on the charger flashes blue.	No audible signal	No vibration
Connection between charger and PC successfully established Bluetooth connection between charger and handheld reader successfully established	The Bluetooth connection on the charger lights up blue. The Bluetooth connection on the handheld reader lights up green.	Single audible signal	Vibrates once

## 2.4 Scope of Delivery

Check the packaging and contents for damage.

Check if you have received every item and if the items received are the ones you ordered.

- Handheld reader  
OHV200-F22\*-B15
- Lithium-ion battery, 1300 mAh  
OHV-BAT
- Brief instructions

## 2.5 Accessories

Designation	Description
OHV-CHARGER-B15	Charging station for OHV200 handheld readers with integrated Bluetooth modem incl. USB-G-1M-PVC-ABG-USBB-G connection cable The connection cable can also be ordered separately later on.
OHV-BAT	1300 mAh lithium-ion battery for OHV200 handheld readers
OHV-BAT-CHARGER	Charger for lithium-ion batteries
Vision Configurator	Configuration software for camera-based sensors When using OHV handheld readers, you can download the software free of charge from <a href="http://www.pepperl-fuchs.com">www.pepperl-fuchs.com</a> .

## 2.6 Storage and Disposal

Keep the original packaging. Always store and transport the device in the original packaging.

Store the device in a clean and dry environment. The permitted ambient conditions (see datasheet) must be considered.

Disposing of device, packaging, and possibly contained batteries must be in compliance with the applicable laws and guidelines of the respective country.


### 3 Installation

#### 3.1 Inserting and Removing the Battery



##### Inserting the Battery

1. Insert the battery into the handheld reader.




2. Make sure that the battery audibly snaps into place.



##### Removing the Battery

1. Move the locking device on the bottom of the handheld reader in the direction of the arrow.




2. Remove the battery.

#### 3.2 Mounting the Charger and Charging the Handheld Reader



##### Mounting the Charger

1. Insert the USB cable or the plug of the plug-in power supply into the socket provided on the bottom of the charger.



2. Place the charger in the position you wish to mount it.
3. Screw the charger into place using the mounting holes provided.



##### Charging the Handheld Reader

1. Ensure that the charger is connected to the USB cable or the plug of the plug-in power supply.
2. Place the handheld reader in the charger.
3. When the handheld reader's battery is charging, the battery's charge status display flashes.

## Charge Status Display

To check the charge status of the lithium-ion battery, press the button on the back of the battery.

Charge status	LED 1	LED 2	LED 3	LED 4
75 % ... 100 %	ON	ON	ON	ON
50 % ... 75 %	ON	ON	ON	
25 % ... 50 %	ON	ON		
10 % ... 25 %	ON			
0 % ... 10 %	Flashing			

### 3.3 Installing Vision Configurator

Vision Configurator is a piece of configuration software for camera-based sensors. The software allows you to perform advanced configuration of the sensor using a clearly arranged user interface. Standard tasks include parameterization of the handheld reader, saving data sets, as well as the transfer and display of data and error diagnostics.



#### Note!

As an alternative to configuration using Vision Configurator, you can configure the handheld reader using control codes.



#### Installing Vision Configurator

1. Download the current version of Vision Configurator from <http://www.pepperl-fuchs.com>.
2. Open the installation file.
3. Select a language.
4. Follow the instructions on the setup wizard.
5. Before exiting the setup wizard, select **Install OHV USB driver**. A virtual COM port is installed that Vision Configurator uses to communicate with OHV handheld readers.



### Completing the Vision Configurator Setup Wizard

Setup has finished installing Vision Configurator.

NOTE: To use one of the devices listed below, please first connect your device with your PC and install the corresponding driver.

- Install PCV Profibus, Profinet, Ethernet/IP, CANopen driver
- Install PCV/PGV RS485, SSI-USB driver
- Install OHV USB driver
- Launch Vision Configurator

**PEPPERL+FUCHS**  
SENSING YOUR NEEDS



## 3.4 Installing Device Drivers

The handheld reader registers itself as an input device or keyboard. Special device drivers are not needed.

- **USB connection:** The operating system automatically installs the drivers for input devices (Human Interface Device). An active internet connection is required, depending on the operating system.
- **Bluetooth connection:** The handheld reader identifies itself as an external input device during coupling.

## 4 Configuration

### 4.1 Switching On the Handheld Reader

To switch on the handheld reader, hold down any trigger button for approx. two seconds. The function indicator on the handheld reader briefly lights up red then briefly lights up green. An audible signal is emitted and the handheld reader vibrates.

### 4.2 Selecting the Operating Mode

The handheld reader has four different operating modes.

Mode	Description
<b>Docking Mode</b>	The charger is connected to a PC and the Bluetooth connection is deactivated. Read codes are saved on the handheld reader. As soon as the handheld reader is plugged into the charger, the codes are transferred to the PC and the handheld reader's memory is cleared.
<b>Bluetooth Mode</b>	The charger is connected to a PC and the Bluetooth connection is activated. Read codes are transferred to the charger via Bluetooth immediately after they are read. The charging tray then automatically transfers the codes to the PC.
<b>Tablet Mode</b>	The handheld reader is connected to a tablet PC or a smartphone (Android version 4.1 or higher, iOS version 5.1 or higher) via Bluetooth. Read codes are transferred to a tablet PC or smartphone via Bluetooth immediately after they are read.
<b>Configuration Mode</b>	The charger is connected to a PC and the Bluetooth connection is deactivated. Configuration mode is exclusively used for communication with Vision Configurator. See chapter 4.4 Read codes are saved on the handheld reader. As soon as the handheld reader is inserted into the charger, the codes are transferred to Vision Configurator. Once configuration has been completed, switch back to the original operating mode.

#### 4.2.1 Docking Mode



##### Activating Docking Mode

1. Deactivate the charger's Bluetooth function. Move the slider on the back/underside of the charger in the opposite direction to the arrow.
2. Read the following code using the handheld reader.



CC002940\_3

↳ Docking mode is activated. Read codes are saved on the handheld reader. As soon as the handheld reader is plugged into the charger, the codes are transferred to the PC and the handheld reader's memory is cleared.



**Note!**

In docking mode, data is transferred as ASCII characters by default.

If data is not transferred correctly in docking mode, modify the keyboard layout. See chapter 4.2.5



## 4.2.2 Bluetooth Mode



### Activating Bluetooth Mode

1. Activate the charger's Bluetooth function. Move the slider on the back/bottom of the charger in the direction of the arrow.
2. If you switch to Bluetooth mode from some other operating mode, read the following code using the handheld reader.  
If the handheld reader was already in Bluetooth mode, you can skip this step.



CC002942\_Reader\_step1\_2

3. Read the **Quick Connect** code on the front of the charger or the modem.  
↳ Bluetooth mode is activated. Read codes are transferred to the charger via Bluetooth immediately after they are read. The charging tray then automatically transfers the codes to the PC.



#### **Note!**

In Bluetooth mode, data is transferred using a US English keyboard layout by default. If data is not transferred correctly in Bluetooth mode, modify the keyboard layout. See chapter 4.2.5

## 4.2.3 Tablet Mode




### Activating Tablet Mode

1. Activate the Bluetooth function on the tablet PC or smartphone.
2. Read the following code using the handheld reader.



CC002941\_3

3. Then read the following code using the handheld reader.



M10257\_01

4. On the tablet PC or smartphone, search for Bluetooth devices within the detection range.
5. Select **OHV200** or **CR2600**, depending on the firmware version, from the list of available devices.  
Devices are visible in the list for a limited period of time only. If the handheld reader is no longer displayed, read the second code again.  
↳ A confirmation code will appear on the tablet PC or smartphone.

6. Input the digits for the confirmation code by using the handheld reader to read in the codes for each digit. Confirm the input by entering the code for **Enter**.



↳ The handheld reader is paired with the tablet PC or smartphone. Read codes are transferred to a tablet PC or smartphone via Bluetooth immediately after they are read.



**Note!**

In tablet mode, data is transferred using a US English keyboard layout by default. If data is not transferred correctly in tablet mode, modify the keyboard layout. See chapter 4.2.5

## 4.2.4 Configuration Mode



### Activating Configuration Mode

1. Deactivate the charger's Bluetooth function. Move the slider on the back/underside of the charger in the opposite direction to the arrow.
2. Read the following code using the handheld reader.



3. Insert the handheld reader into the charger to establish a connection with the PC.

↳ Configuration mode is activated. This mode is exclusively used for communication with Vision Configurator.














**Note!**

In configuration mode, data is transferred as ASCII characters by default.  
To select a different keyboard layout, see the **Device Settings** area in Vision Configurator.

## 4.2.5 Keyboard Layout

You can use the following control codes to modify the keyboard layout for the current operating mode.

### Microsoft Windows

English (US)  M10460_02	English (US International)  M10469_01	English (GB)  M10471_01
German (Germany)  M10463_02	German (Switzerland)  M10466_02	French (France)  M10462_02
French (Belgium)  M10461_02	Spanish (Spain)  M10472_01	Spanish (Latin America)  M10465_02
Russian  M10418_02	Japanese  M10464_02	



### Apple OS X and iOS



## 4.3 Configuring the Handheld Reader

There are two different ways to configure the handheld reader.

- **Vision Configurator:** The software allows you to perform advanced configuration on a PC using a clearly arranged user interface. Standard tasks include parameterization of the handheld reader, saving data sets, as well as the transfer and display of data and error diagnostics. See chapter 4.4
- **Control codes:** Control codes allow direct configuration without using a PC. To adjust a parameter, scan the appropriate control code using the handheld reader. See chapter 4.5

## 4.4 Configuration Process Using Vision Configurator

To configure the handheld reader using Vision Configurator, you must activate configuration mode. This mode is exclusively used for communication with Vision Configurator. If you are configuring the handheld reader using control codes, you do not need to switch to configuration mode.



### **Note!**

Once configuration has been completed, switch back to an operating mode. See chapter 4.2



### Starting Vision Configurator

Before working with Vision Configurator, ensure that the handheld reader is in configuration mode. See chapter 4.2.4

1. Start Vision Configurator.
2. Select the user name **Default** in the **User** area. There are no different user rights for OHV handheld readers.
3. Select **Handheld readers** in the **Sensor family** area.
4. Select the relevant model, the type of connection **USB**, and **USB to Virtual COM Port**.
5. Select a language in the **Language** area.
6. Click on **OK**.

### 4.4.1 Layout of Application Window




Figure 4.1 Application screen

1. The display area shows the read images and offers basic editing tools.
2. The **Sensor data** area shows information about the connected sensor.
3. The **Test statistics** area shows information on the read codes.
4. The status bar shows information about the user who is logged in as well as the sensor connection status.
5. The parameter area is split into several subareas and contains sensor-specific parameters.
6. The toolbar allows direct access to selected menu items.

#### 4.4.2 Image Display

Image display is not supported on OHV handheld readers in the OHV200 and OHV300 series. However, any images captured using the handheld reader in the near field and far field can be analyzed and edited on your PC using a program of your choice.



#### Retrieving Images

1. Call up the **Image transmission** configuration window.
2. Select **Save all images** in the **Image saving mode on sensor** area.
3. Read a code.
4. Call up the **File transmission** configuration window.
5. Select the corresponding image file in the **On sensor saved files** area and click **Download selected file(s) from sensor**.  
 ↳ The image is downloaded to your PC, where you can analyze or edit it using a program of your choice.
6. Once you have finished analyzing the images, select **Save no image** in the **Image saving mode on sensor** area to increase the reading speed of the handheld reader and use less memory.

#### 4.4.3 Sensor Data


This area shows information about the connected sensor.

Sensor data	
<b>Sensor type</b>	OHV200 0020143196
<b>Firmware version</b>	v0820
<b>Bootloader version</b>	v0820
<b>Sensor illumination</b>	Red
<b>Decoder version</b>	cd(13.2.21)



#### 4.4.4 Test Statistics

This area shows information about the read code.



Show ASCII value	Activate this option to display the read result in ASCII characters.
Save reader results	Activate this option to save read results locally. If you have activated this option, you can select a location to save the results.
Single trigger	Triggers a read operation.
Reset counter	Clears the contents of the <b>Test statistics</b> area.

### 4.4.5 Image Transmission

This is where you can define the settings for saving read codes.



**Note!**

Saving images when decoding increases the decoding time.



#### Image Saving Mode on Sensor


<b>Save mode when sensor triggers</b>	<ul style="list-style-type: none"> <li><input type="checkbox"/> Save no image</li> <li><input type="checkbox"/> Save all images</li> <li><input type="checkbox"/> Save non decoded images</li> <li><input type="checkbox"/> Save decoded images</li> </ul>
---------------------------------------	--

#### Frame Quality on Sensor

<b>Save frames uncompressed on sensor</b>	The recorded image is saved uncompressed in portable graymap format on the sensor.
<b>Save frames compressed on sensor</b>	The recorded image is saved compressed in JPEG format on the sensor.
<b>Image quality</b>	<p>If the image is to be saved in JPEG format, you can define the image quality here.</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> 0 %: maximum compression, lowest image quality</li> <li><input type="checkbox"/> ...</li> <li><input type="checkbox"/> 100 %: minimum compression, highest image quality</li> </ul>

## 4.4.6 File Transmission

This is where you can manage files saved on the sensor.



### Listed File Types

<b>Instruction files</b>	Displays the command files on the sensor with file extension <b>crb</b>
<b>Java script files</b>	Displays the JavaScript files on the sensor with file extension <b>js</b>
<b>Image files</b>	Displays the graphics files on the sensor with file extension <b>jpg</b> or <b>pgm</b>
<b>Initialization file</b>	Displays the initialization files on the sensor with file extension <b>ini</b>
<b>Show all</b>	Displays all the files on the sensor
<b>Show none</b>	Displays no files on the sensor

### On sensor saved files

<b>Select no file</b>	Cancels selection on all files
<b>Refresh</b>	Updates the display of files
<b>Select all files</b>	Selects all the files on the sensor
<b>Delete files</b>	Deletes the selected files
<b>Delete after transmitting</b>	The selected files on the sensor are deleted following transfer from the sensor to the PC
<b>Download selected file(s) from sensor</b>	Loads the selected files from the sensor to the PC
<b>Upload new file to sensor</b>	Loads the file to the sensor
<b>Save and restart sensor</b>	Saves the current sensor settings and restarts the sensor



## Updating Firmware

1. Click on **Upload new file to sensor** or select **Sensor > Update Firmware** in the menu bar.
2. Select a firmware file with the extension crz.
3. The firmware file is transferred to the handheld reader. Uploading the firmware takes a few minutes.
4. Once the file has been transferred, the handheld reader automatically restarts.
  - ↳ The firmware is now updated. You can check the firmware version in the **Device data** area.

### 4.4.7


## 1-D Codes

This is where you can define which 1-D code types the handheld reader should read. Different code types are shown depending on the sensor used and the firmware version.



### Tip

Deactivate all code types that are not required and activate only the code types that you wish to read. This increases the evaluation speed and prevents a code type such as Codablock being mistakenly interpreted as another code type, such as Code 128.



## Activating 1-D Codes

1. To activate a code type, check the check box in front of the code type designation.
  - ↳ Advanced options for the selected code type are shown in the area on the right.
2. Activate or deactivate the advanced options.
3. To save the settings, select **Sensor > Save settings** in the menu bar.



## Deactivating 1-D Codes

1. To deactivate a code type, uncheck the check box in front of the code type designation.
2. To save the settings, select **Sensor > Save settings** in the menu bar.


#### 4.4.8 2-D Codes

This is where you can define which 2-D code types the handheld reader should read. Different code types are shown depending on the sensor used and the firmware version.



**Tip**

Deactivate all code types that are not required and activate only the code types that you wish to read. This increases the evaluation speed and prevents a code type such as Codablock being mistakenly interpreted as another code type, such as Code 128.



#### Activating 2-D Codes

1. To activate a code type, check the check box in front of the code type designation.  
↳ Advanced options for the selected code type are shown in the area on the right.
2. Activate or deactivate the advanced options.
3. To save the settings, select **Sensor > Save settings** in the menu bar.



#### Deactivating 2-D Codes

1. To deactivate a code type, uncheck the check box in front of the code type designation.
2. To save the settings, select **Sensor > Save settings** in the menu bar.

#### 4.4.9 Sensor Settings

This is where you can configure the feedback. Since the sensor registers itself with other devices as an input device or keyboard, you can configure which keyboard layout the sensor should use for data transfer.



**Note!**

To ensure the correct transfer of data, it is important to select the right keyboard layout. Depending on the keyboard selected, individual characters, e.g., special symbols, are output differently.



The screenshot shows a configuration window with the following sections:

- Volume and vibration:** A slider for 'Beep volume' is set to 3. A checkbox for 'Vibration' is checked.
- Target LEDs:** A checkbox for 'Enable' is checked.
- Keyboard support:** A dropdown menu for 'Supported keyboard' is set to 'ASCII universal'.
- Bluetooth:** Two checkboxes, 'Vibrate if out of range' and 'Beep if out of range', are both unchecked.

### Volume and Vibration

<b>Beep volume</b>	You can adjust the volume of the audible signal here. <ul style="list-style-type: none"> <li>■ 0: silent</li> <li>■ ...</li> <li>■ 3: maximum volume</li> </ul>
<b>Vibration</b>	You can activate or deactivate vibration here.

### Target LEDs

<b>Enable</b>	You can activate or deactivate the blue bars that indicate the reading field here.
---------------	--

### Keyboard Support

<b>Supported keyboard</b>	<ul style="list-style-type: none"> <li>■ US keyboard without leading zero</li> <li>■ ASCII general</li> <li>■ User-defined keyboard</li> <li>■ French keyboard</li> <li>■ German keyboard</li> <li>■ Japanese keyboard</li> <li>■ Swiss keyboard</li> <li>■ Belgian keyboard</li> <li>■ UK keyboard</li> <li>■ Latin American keyboard</li> <li>■ Spanish keyboard</li> <li>■ Russian keyboard</li> </ul>
---------------------------	---

### Bluetooth

<b>Vibrate if out of range</b>	The handheld reader vibrates as soon as it leaves the base station's maximum detection range.
<b>Beep if out of range</b>	The handheld reader emits an audible signal as soon as it leaves the base station's maximum detection range.



## 4.4.10 Decoding Options

You can change settings for the read operation here.

<b>Display</b>	
<input type="checkbox"/>	Enhanced display reading
<b>Continuous reading</b>	
<input type="checkbox"/>	Continuous reading
<b>Duplicate codes</b>	
Duplicate code scan delay	None
<b>Reading field</b>	
<input checked="" type="radio"/>	Near and far field
<input type="radio"/>	Near field
<input type="radio"/>	Far field

### Display

<b>Optimized reading of displays</b>	Optimizes the optical unit on the handheld reader to read reflective surfaces such as displays.
--------------------------------------	---

### Continuous Reading

<b>Continuous Reading</b>	You can activate or deactivate continuous reading here. If this option is activated, the sensor continuously attempts to read a code, without the user having to activate a trigger button.
---------------------------	---

### Code Duplicates

<b>Scan delay on the same code</b>	<p>This option prevents the same code from being read twice in direct succession within a selected time frame. After the time frame has elapsed or if another code has been read in the interim, the same code can be read again. This option is particularly useful in conjunction with continuous reading, since it can prevent the same code from being read multiple times.</p> <ul style="list-style-type: none"> <li>■ None</li> <li>■ ...</li> <li>■ 1 day</li> </ul>
------------------------------------	--

### Reading Field

<b>Selection</b>	With this option, you can select whether the near field, far field, or both together are used for reading. If you deactivate a field, the evaluation speed increases, but codes in the deactivated field can no longer be read.
------------------	---

### 4.4.11 Read Result

You can process the read result and assign a prefix or suffix to the result here. The prefix is placed in front of the read result and the suffix is placed at the end of the read result.

If the read result is additionally processed by a script, the prefixes or suffixes are assigned immediately following script processing.

#### Prefix/Suffix

<b>Prefix</b>	You can input a value for the prefix here. To delete the prefix, click on <b>Delete prefix</b> .
<b>Suffix</b>	You can input a value for the suffix here. To delete a suffix, click on <b>Delete suffix</b> .

#### Inserting Special Symbols for Keyboard Mode

<b>Prefix TAB</b>	Click on <b>Prefix TAB</b> to insert a tab character into the prefix field.
<b>Suffix TAB</b>	Click on <b>Suffix TAB</b> to insert a tab character into the suffix field.
<b>Suffix ENTER</b>	Click on <b>Suffix ENTER</b> to insert an input character into the suffix field.
<b>more ...</b>	Click on <b>more ...</b> to call up a list of additional special characters. To insert a special character from the list, click on the + icon in the corresponding line. Different special characters are available depending on whether the handheld reader is connected to Vision Configurator via USB or via RS-232.

#### Additional Outputs

<b>Output the code type of the read code</b>	If you activate this option, the code type of the read code will be output between the prefix and the read result. If the sensor is connected to Vision Configurator, the code type is displayed in the <b>Test statistics</b> area.
--	--



### 4.4.12 Script

Here you can process the read result using JavaScript. You can input your own source code or assemble a script from predefined blocks.

If a prefix or a suffix is additionally assigned to the read result, the prefixes or suffixes are assigned immediately following the script processing.

**Key layout**

Upper button	Read in both fields		Insert special characters
Lower button	Read in both fields		
Both buttons simultaneously	No action		...

**Input codes**

Insert	Command	Description	Codomain
+	<b>SUBSTRING_FROM_POSITION_x_O...</b>	<i>Output y chars from position x, zero based</i>	x: int, y: int
+	<b>SUBSTRING_FROM_POSITION_x_O...</b>	<i>Output all chars from position x, zero based</i>	x: int
+	<b>OUTPUT_LAST_x_CHARS</b>	<i>Output last x chars</i>	x: int

**Source code**

	Codesymbology	Prefix read code	Prefix current code	Command
*	none			

Insert special characters  
...

**Example**

Read code: 123456789	Output: 123456789
----------------------	-------------------

**Script transmission**

Send script to device

Remove script from device

Save and restart device

Reset with code

Create reader programming code

Create control code from file

### Button Assignment

In this area, you can assign defined functions to the trigger buttons on the top of the handheld reader. You can also use the **Insert special characters** button to assign function keys **F1** ... **F12** or key combinations to the trigger buttons.



Figure 4.2 Trigger buttons

1. Upper button
2. Lower button

## Input Codes

The following predefined components are available:

`SUBSTRING_FROM_POSITION_x_ON_y_CHARS`

Only returns one part of the code. x denotes the position from which the characters are output, where x = 0 represents the first character of the code. y denotes the number of characters that are output after position x.

Example: `SUBSTRING_FROM_POSITION_6_ON_3_CHARS` returns characters 7 to 9.

`SUBSTRING_FROM_POSITION_x_ON_ALL_CHARS`

Only returns one part of the code. x refers to the position from which all subsequent characters are returned, where x = 0 represents the first character of the code.

`OUTPUT_LAST_x_CHARS`

Returns the last x characters of the code.

Example: `OUTPUT_LAST_3_CHARS` returns the last 3 characters.

`OUTPUT_ALL_CHARS_BETWEEN_abc_AND_def`

Returns the characters of the code that are between an abc and def data string. If there are multiple occurrences of the data strings abc and def, only the characters between the first occurrence are returned. If the data string abc does not appear, no characters are returned.

`OUTPUT_ALL_CHARS_BEFORE_abc`

Returns the characters of the code that appear before an abc data string. If there are multiple occurrences of the data string abc, all characters before the first occurrence are returned. If the data string abc does not appear, no characters are returned.

`OUTPUT_ALL_CHARS_AFTER_abc`

Returns the relevant characters of the code that follow the data string abc. If the data string abc appears several times, all characters from the first occurrence are returned and subsequent occurrences of the data string abc are deleted. If the data string abc does not appear, no characters are returned.

`OUTPUT_x_CHARS_AFTER_abc`

Returns x relevant characters of the code that follow the data string abc. If the data string abc appears several times, x characters from the first occurrence are returned and subsequent occurrences of the data string abc are deleted. If the data string abc does not appear, no characters are returned.

`DELETE_FROM_POSITION_x_ON_y_CHARS`

Deletes part of the code. x refers to the position from which the y characters are removed, where x = 0 represents the first character of the code.

Example: `DELETE_FROM_POSITION_0_ON_5_CHARS` deletes characters 1 to 5.

`DELETE_SUBSTRING_abc`

Deletes the data string abc from the code. If the data string occurs several times, only the first occurrence of the data string is deleted.

`DELETE_LAST_x_CHARS`

Deletes the last x characters of the code.

Example: `DELETE_LAST_4_CHARS` deletes the last 4 characters.

`DELETE_ALL_CHARS_BEFORE_abc`

Deletes all characters of the code that appear before an abc data string. If there are multiple occurrences of the data string abc, only the characters that appear before the first occurrence are deleted.

`DELETE_ALL_CHARS_AFTER_abc`

Deletes all characters of the code that follow the data string abc. If there are multiple occurrences of the data string, all characters after the first occurrence are deleted.

`INSERT_abc_AT_POSITION_x`

Adds the data string abc at position x, where x = 0 represents the position before the first character of the code.

`INSERT_abc_AFTER_def`

Adds the data string abc to the data string def. If the data string def appears several times, the data string abc is appended to the first occurrence. If the data string def does not appear, no characters are appended.

`APPEND_STRING_abc`

Appends the data string abc to the code.

`IF_GOODREAD_OUTPUT_abc`

Returns the data string abc if a code has been read successfully.

`REPLACE_STRING_abc_WITH_def`

Replaces the data string abc with the data string def. If the data string abc occurs multiple times, only the first occurrence is replaced.

`REPLACE_ALL_abc_AFTER_POSITION_x_WITH_def`

Replaces the data string abc with data string def after position x. If the data string abc appears after position x several times, all occurrences are replaced.

`IF_CODE_CONTAINS_abc_OUTPUT_def`

Returns the data string def if the data string abc appears in the code. If the data string abc appears several times, the data string def is returned only once.

`APPEND_FROM_ORIGINAL_ALL_CHARS_AFTER_abc`

Appends all of the characters that follow the data string abc in the read code to the output. This rule applies directly to the read code and is independent of other rules already applied to the code. If the data string abc appears several times, all characters from the first occurrence are appended and subsequent occurrences of the data string abc are deleted. If the data string abc does not appear, no characters are appended.

`APPEND_FROM_ORIGINAL_x_CHARS_AFTER_abc`

Appends x characters that follow the data string abc in the read code to the output. This rule applies directly to the read code and is independent of other rules already applied to the code. If the data string abc appears several times, x characters from the first occurrence are appended and subsequent occurrences of the data string abc are deleted. If the data string abc does not appear, no characters are appended.

## Source Code

You can edit the source code for the script in the source code area. You can also use the **Insert special characters** button to insert certain special characters.

## Example

In this area, you can test the result by using an example.

## Script Transfer

Button	Description
Open	Opens a locally stored script file.
Save	Saves the current script to a local file.
Send script to sensor	Saves the script on the sensor.
Delete script from sensor	Deletes the script from the sensor.
Save and restart	Saves the script on the sensor. The sensor then restarts and the script is activated.
Reset with code	Creates a control code that can be used to reset the sensor. After reading the control code, the sensor restarts.

Button	Description
Create control code	Generates a control code for the script. After reading the control code, the sensor restarts and the script is activated if the script has already been saved on the sensor.
Create control code from file	Generates a control code for the script from a file. After reading the control code, the sensor restarts and the script is activated if the script has already been saved on the sensor.



### Creating a Script

1. In the **Source code** area, click on a cell in the first column to edit the associated line.
2. Click on **+** to insert a predefined module in the selected line. You can also insert multiple commands and combine these with one another.

↳ The command appears in the selected line. If the source code is shaded red, the source code is incomplete or contains errors. If the source code is green, the source code is OK.

- Complete the variables so that the command can be executed.  
 If a command is to be executed only for a specific code type, select the relevant code type in the **Code symbology** column.  
 If a command is to be executed only when the read code begins with a certain data string, input the data string in the **Prefix of read code** column.  
 If a command is to be executed only when the current processing result begins with a certain data string, input the data string in **Prefix of current code** column.  
 To insert special characters, click on **Insert special characters**.
- If the source code is green, you can test the source code in the **Example** area. To do this, enter a sample value in the **Read code** field.

The screenshot displays a software configuration window with several sections:

- Key layout:** Three rows of dropdown menus for 'Upper button', 'Lower button', and 'Both buttons simultaneously', each with an 'Insert special characters' button to its right.
- Input codes:** A table with columns for 'Insert', 'Command', 'Description', and 'Codomain'. It lists three commands: 'SUBSTRING\_FROM\_POSITION\_x\_ON\_y\_CHA...', 'SUBSTRING\_FROM\_POSITION\_x\_ON\_ALL\_C...', and 'OUTPUT\_LAST\_x\_CHARS'.
- Source code:** A table with columns for 'Codesymbology', 'Prefix read code', 'Prefix current code', and 'Command'. The 'Command' column contains 'SUBSTRING\_FROM\_POSITION\_3\_ON\_4\_...'. A red arrow points from this command to the 'Example' section.
- Example:** A section with a 'Read code' field containing '123abc456xyz789' and an 'Output' field containing 'abc4'. This section is highlighted with a red box.
- Script transmission:** A row of buttons including 'Send script to device', 'Remove script from device', 'Save and restart device', 'Reset with code', 'Create reader programming code', and 'Create control code from file'.

↳ The commands from the **Source text** area are applied to the sample value in the **Read code** field and the result is displayed in the **Output** field.



### 4.4.13 Edited Parameters

Here you can find an overview of all settings you have changed that now deviate from the factory settings.

To generate a control code that contains all affected settings, click on **Create control code for own settings**.

If you check the **First completely reset sensor** check box, a reset command is integrated in the control code. When the control code is read, all settings are first reset to factory defaults before the new settings are applied.



**Note!**

Scripts for processing the read result are not included in this overview.



**Tip**

This function allows your configured settings to be transferred to multiple sensors by scanning the control code.

Parameters not on default value			
Parametername	Tab	Default value	Current value
Supported keyboard	Sensor settings	US keyboard without leading zero	ASCII universal

**Custom settings**

Reset sensor first

Create control code for custom settings



## 4.5 Configuration with Control Codes

As an alternative to configuration using Vision Configurator, you can configure the handheld reader using control codes. Control codes allow direct configuration without using a PC. To adjust a parameter, scan the appropriate control code using the handheld reader.



### 4.5.1 Operation

The following codes can be used to adjust the settings for operation.




#### Paging Function










Code	Description
<b>Enable Reader Paging</b>  M10155_01	Activates the paging function. The paging function works only in Bluetooth mode. If you hold down the Bluetooth button on the charger for around two seconds, the handheld reader emits visual and audible signals and vibrates, depending on its settings. To switch the signals off, hold down the Bluetooth button on the charger for around two seconds or press the trigger on the handheld reader.
<b>Disable Reader Paging</b>  M10156_01	Deactivates the paging function.

#### Target Detection

Code	Description
<b>Targeting On</b>  M10153_01	Activates the blue bars for indicating the read range.
<b>Targeting Off</b>  M10154_01	Deactivates the blue bars for indicating the read range.

#### Feedback



Code	Description
<b>Beep On / Vibrate On</b>  M10140_01	Switches audible signals and vibration on.
<b>Beep Off / Vibrate On</b>  M10141_01	Switches audible signals off and vibration on.
<b>Beep On / Vibrate Off</b>  M10142_01	Switches audible signals on and vibration off.

Code	Description
<b>Beep Off / Vibrate Off</b>  M10143_01	Switches audible signals and vibration off.
<b>Beep volume 0 %</b>  M10194_01	Sets the volume of the audible signal to 0 %.
<b>Beep volume 33 %</b>  M10195_01	Sets the volume of the audible signal to 33 %.
<b>Beep volume 67 %</b>  M10196_01	Sets the volume of the audible signal to 67 %.
<b>Beep volume 100 %</b>  M10197_01	Sets the volume of the audible signal to 100 %.
<b>Bluetooth Radio Out of Range Beep On</b>  M10173_01	Activates an audible alarm if the handheld reader loses the Bluetooth connection.
<b>Bluetooth Radio Out of Range Vibrate On</b>  M10174_01	Activates a vibration alarm if the handheld reader loses the Bluetooth connection.
<b>Bluetooth Radio Out of Range Beep and Vibrate On</b>  M10175_01	Activates an audible alarm and a vibration alarm if the handheld reader loses the Bluetooth connection.
<b>Bluetooth Radio Out of Range Beep and Vibrate Off</b>  M10176_01	Deactivates the audible alarm and the vibration alarm if the handheld reader loses the Bluetooth connection.




## 4.5.2 Read Operation



The following codes can be used to adjust the settings for the read operation.

### Reading Displays







Code	Description
<b>Enable Cell Phone Reading Enhancement</b>  M10163_01	Optimizes the optical unit on the handheld reader to read reflective surfaces such as displays.
<b>Disable Cell Phone Reading Enhancement</b>  M10162_01	Deactivates optimization for reading reflective surfaces.






### Motion detection

Code	Description
<b>Motion Detection On Start Delay 0 ms</b>  M0161_03	Activates motion detection with a start delay of 0 ms. If motion detection is activated, the handheld reader automatically attempts to read a code as soon as motion is detected in the read range. It is not necessary to activate the trigger button.
<b>Motion Detection On Start Delay 500 ms</b>  M0162_03	Activates motion detection with a start delay of 500 ms. If motion detection is activated, the handheld reader automatically attempts to read a code as soon as motion is detected in the read range. It is not necessary to activate the trigger button.
<b>Motion Detection On Start Delay 0 ms Dark Environment</b>  M0163_03	Activates motion detection with dimmer readiness lighting and a start delay of 0 ms. If motion detection is activated, the handheld reader automatically attempts to read a code as soon as motion is detected in the read range. It is not necessary to activate the trigger button.

Code	Description
<b>Motion Detection On Start Delay 500 ms Dark Environment</b>  M0164_03	Activates motion detection with dimmer readiness lighting and a start delay of 500 ms. If motion detection is activated, the handheld reader automatically attempts to read a code as soon as motion is detected in the read range. It is not necessary to activate the trigger button.
<b>Motion Detection Off</b>  M0129_08	Deactivates motion detection.

### Continuous Reading




Code	Description
<b>Continuous Scan On</b>  M10012_01	Activates continuous reading. If this option is activated, the sensor continuously attempts to read a code, without the user having to activate a trigger button.
<b>Continuous Scan Off</b>  M10011_01	Deactivates continuous reading.
<b>Duplicate Scan Disabled</b>  M10144_01	Prevents the same code from being read twice in direct succession.
<b>1 sec Duplicate Scan Delay</b>  M10145_01	Prevents the same code from being read twice in direct succession for a period of one second. After the time frame has elapsed or if another code has been read in the interim, the same code can be read again.
<b>2 sec Duplicate Scan Delay</b>  M10146_01	Prevents the same code from being read twice in direct succession for a period of two seconds. After the time frame has elapsed or if another code has been read in the interim, the same code can be read again.
<b>3 sec Duplicate Scan Delay</b>  M10147_01	Prevents the same code from being read twice in direct succession for a period of three seconds. After the time frame has elapsed or if another code has been read in the interim, the same code can be read again.




Code	Description
<b>5 sec Duplicate Scan Delay</b>  M10148_01	Prevents the same code from being read twice in direct succession for a period of five seconds. After the time frame has elapsed or if another code has been read in the interim, the same code can be read again.
<b>10 sec Duplicate Scan Delay</b>  M10149_01	Prevents the same code from being read twice in direct succession for a period of ten seconds. After the time frame has elapsed or if another code has been read in the interim, the same code can be read again.
<b>30 sec Duplicate Scan Delay</b>  M10150_01	Prevents the same code from being read twice in direct succession for a period of 30 seconds. After the time frame has elapsed or if another code has been read in the interim, the same code can be read again.
<b>1 hour Duplicate Scan Delay</b>  M10151_01	Prevents the same code from being read twice in direct succession for a period of 1 hour. After the time frame has elapsed or if another code has been read in the interim, the same code can be read again.
<b>1 day Duplicate Scan Delay</b>  M10152_01	Prevents the same code from being read twice in direct succession for a period of one day. After the time frame has elapsed or if another code has been read in the interim, the same code can be read again.

### 4.5.3 Data Processing






The following codes can be used to add prefixes and suffixes to read results.

#### Prefixes


Code	Description
<b>Prefix AIM IDs on</b>  M10199_01	Activates code type output immediately before the read result. If an additional prefix is applied, the code type will be written between the prefix and the read result.
<b>Prefix AIM IDs off</b>  M10198_01	Deactivates code type output.
<b>Prefix comma</b>  M10127_01	Places a comma in front of the read result.

Code	Description
<b>Prefix space</b>  M10128_01	Places a space in front of the read result.
<b>Prefix tab</b>  M10129_01	Places a tab character in front of the read result.
<b>Prefix erase/none</b>  M10126_01	Removes all prefixes.

### Suffixes

Code	Description
<b>Suffix comma</b>  M10131_01	Adds a comma to the end of the read result.
<b>Suffix space</b>  M10132_01	Adds a space to the end of the read result.
<b>Suffix enter</b>  M10134_01	Adds an input character to the end of the read result.
<b>Suffix tab</b>  M10133_01	Adds a tab to the end of the read result.
<b>Suffix erase/none</b>  M10130_01	Removes all suffixes.






### Clearing Prefixes and Suffixes

Code	Description
<p><b>Erase all prefix and suffix data</b></p>  <p>M10135_01</p>	<p>Clears all prefixes and suffixes.</p>

## 4.5.4 Data Transfer



The following codes can be used to adjust the settings for data transfer.

### Saving Read Results



Code	Description
<p><b>Log Only</b></p>  <p>M10188_04</p>	<p>Activates saving of read results in the handheld reader. The results are not automatically transferred; instead they must be read out. The results remain in the memory after reading and can be retrieved again. To remove the results, the memory must be explicitly cleared. See chapter 4.5.5</p>
<p><b>Send and Log</b></p>  <p>M10186_04</p>	<p>Activates saving of read results in the handheld reader. The results are automatically transferred as soon as a connection to another device is established. The results remain in the memory after transfer and can be retrieved again. To remove the results, the memory must be explicitly cleared. See chapter 4.5.5</p>
<p><b>Disable Log</b></p>  <p>M10187_04</p>	<p>Deactivates saving of read results in the handheld reader. This setting is not supported in dock mode or configuration mode as the read results must remain stored until the handheld reader is inserted into the charger. This setting is configured by default at the factory for Bluetooth mode and tablet mode.</p>
<p><b>Transfer All Data in Memory</b></p>  <p>M10297_01</p>	<p>Reads out the handheld reader's memory. If saving of read results has been activated (<b>Log Only</b> or <b>Send and Log</b>), the results will remain stored in the memory after read-out. If saving of read results has been deactivated (<b>Disable log</b>), the memory will be empty following read-out.</p>
<p><b>Clear All Stored Data and Images</b></p>  <p>M10138_02</p>	<p>Deletes all read results and recordings stored on the handheld reader.</p>







### Bidirectional Connection



Code	Description
<b>Reader Text Commands On</b>  M10137_01	Facilitates a bidirectional connection to the handheld reader, which allows commands to be sent to the handheld reader via the serial interface. For example, this allows a signal indicating that a value has been successfully recorded by an ERP system to be transferred to the handheld reader.
<b>Reader Text Commands Off</b>  M10136_01	Deactivates the bidirectional connection via the serial interface.

### USB Connection

Code	Description
<b>Full Speed</b>  M10161_01	Activates the USB interface's full speed mode. Suitable from USB 1.1
<b>High Speed</b>  M10160_01	Activates the USB interface's high speed mode. Suitable from USB 2.0

### RS-232 Connection


Code	Description
<b>RS-232 Communication Mode</b>  M661_01	This code switches the ODZ-MAH-B15-M3 Bluetooth modem from a USB connection to an RS-232 connection.
<b>RS-232 9600 Baud Rate</b>  M316_01	Sets the baud rate for the RS-232 connection to 9600
<b>RS-232 19200 Baud Rate</b>  M317_01	Sets the baud rate for the RS-232 connection to 19200
<b>RS-232 38400 Baud Rate</b>  M318_01	Sets the baud rate for the RS-232 connection to 38400

Code	Description
<b>RS-232 57600 Baud Rate</b>  M319_01	Sets the baud rate for the RS-232 connection to 57600
<b>RS-232 115200 Baud Rate</b>  M320_01	Sets the baud rate for the RS-232 connection to 115200 This setting is preset at the factory.


#### 4.5.5 Restarting and Clearing

The following codes can be used to configure the device and the device memory.


##### Restarting the Device

Code	Description
<b>Reboot reader</b>  M10296_01	Restarts the handheld reader.



##### Resetting the Device to Factory Settings

Code	Description
<b>Reset reader to RF factory defaults</b>  M10001_03	Resets the handheld reader to factory settings and then activates Bluetooth mode. To establish the Bluetooth connection, scan the <b>Quick Connect</b> code on the front of the charger or modem. Read results already saved on the device will not be lost as a result of doing this. Once the Bluetooth connection is established, the codes in the handheld reader's memory will be transferred via Bluetooth.

##### Reading the Memory

Code	Description
<b>Transfer All Data in Memory</b>  M10297_01	Reads out the handheld reader's memory. If saving of read results has been activated ( <b>Log Only</b> or <b>Send and Log</b> ), the results will remain stored in the memory after read-out. If saving of read results has been deactivated ( <b>Disable log</b> ), the memory will be empty following read-out.

### Deleting the Memory and Scripts

Code	Description
<b>Clear All Stored Data and Images</b>  M10138_02	Deletes all read results and recordings stored on the handheld reader.
<b>Clear all JavaScript Rules</b>  M10139_01	Deletes all scripts saved on the handheld reader.

### 4.5.6 Code Types







The following codes can be used to define which code types the handheld reader should read. Different code types are supported depending on the handheld reader and firmware version. Settings marked with a \* are preset at the factory.



**Tip**

Deactivate all code types that are not required and activate only the code types that you wish to read. This increases the evaluation speed and prevents a code type such as Codablock being mistakenly interpreted as another code type, such as Code 128.

**A**



















Australian Post			
On  M10288_02	Off *  M10289_02		
Aztec			
On *  M10018_01	Off  M10019_01	Inverted (light on a dark background) On  M10020_01	Inverted (light on a dark background) and normal On  M10021_01



**C**

Codabar			
On *  M10022_01	Off  M10023_01		
Codablock F			
On  M10027_01	Off *  M10026_01		



2015-11













<b>Code 11</b>			
<p>On</p>  <p>M10029_01</p>	<p>Off *</p>  <p>M10028_01</p>	<p>Without output of checksum</p> <p>On</p>  <p>M10031_01</p>	
<b>Code 32 (Italian Pharmacode)</b>			
<p>On</p>  <p>M10239_02</p>	<p>Off *</p>  <p>M10238_02</p>		
<b>Code 39</b>			
<p>On *</p>  <p>M10033_02</p>	<p>Off</p>  <p>M10034_02</p>	<p>Only codes with checksum</p> <p>On</p>  <p>M10036_01</p>	<p>Only codes with checksum</p> <p>Off *</p>  <p>M10035_01</p>
<p>Without output of checksum</p> <p>On</p>  <p>M10037_01</p>			
<b>Code 39 Extended</b>			
<p>Decoding with full ASCII character set</p> <p>On</p>  <p>M10039_01</p>	<p>Decoding with full ASCII character set</p> <p>Off *</p>  <p>M10038_01</p>		
<b>Code 49</b>			
<p>On</p>  <p>M10458_01</p>	<p>Off *</p>  <p>M10459_01</p>		
<b>Code 93</b>			
<p>On *</p>  <p>M10042_01</p>	<p>Off</p>  <p>M10043_01</p>		
<b>Code 128</b>			
<p>On *</p>  <p>M10044_01</p>	<p>Off</p>  <p>M10045_01</p>		

Composite			
<p>On</p>  <p>M10047_01</p>	<p>Off *</p>  <p>M10046_01</p>		





D

Data Matrix			
<p>Reading of standard Data Matrix codes is always enabled and cannot be disabled.</p>	<p>Inverted (light on a dark background)</p> <p>On *</p>  <p>M10051_03</p>	<p>Inverted (light on a dark background)</p> <p>Off</p>  <p>M10050_03</p>	









E

EAN-8			
<p>Check digit output</p> <p>On *</p>  <p>M10485_01</p>	<p>Check digit output</p> <p>Off</p>  <p>M10486_01</p>	<p>Convert EAN-8 to EAN-13</p> <p>On</p>  <p>M10488_01</p>	<p>Convert EAN-8 to EAN-13</p> <p>Off *</p>  <p>M10487_01</p>
EAN-13			
<p>Check digit output</p> <p>On *</p>  <p>M10483_01</p>	<p>Check digit output</p> <p>Off</p>  <p>M10484_01</p>	<p>Convert Bookland EAN-13 to ISBN</p> <p>On</p>  <p>M10492_01</p>	<p>Convert Bookland EAN-13 to ISBN</p> <p>Off *</p>  <p>M10491_01</p>
<p>Convert Bookland EAN-13 to ISSN</p> <p>On</p>  <p>M10494_01</p>	<p>Convert Bookland EAN-13 to ISSN</p> <p>Off *</p>  <p>M10493_01</p>		
<p>For other settings, see <b>UPC (Universal Product Code)</b>.</p>			





G

GS1 DataBar			
<p>All</p> <p>On *</p>  <p>M10054_01</p>	<p>All</p> <p>Off</p>  <p>M10055_01</p>	<p>Omnidirectional and truncated</p> <p>On</p>  <p>M10057_03</p>	<p>Omnidirectional and truncated</p> <p>Off</p>  <p>M10355_02</p>








<p>Stacked and omnidirectional On</p>  <p>M10058_03</p>	<p>Stacked and omnidirectional Off</p>  <p>M10353_03</p>		
<b>GS1 DataBar Expanded</b>			
<p>On</p>  <p>M10059_03</p>	<p>Off</p>  <p>M10417_02</p>	<p>Stacked On</p>  <p>M10357_02</p>	<p>Stacked Off</p>  <p>M10356_02</p>
<b>GS1 DataBar Limited</b>			
<p>On</p>  <p>M10056_03</p>	<p>Off</p>  <p>M10354_02</p>		



**H**

<b>Han Xin</b>			
<p>On</p>  <p>M10248_01</p>	<p>Off *</p>  <p>M10249_01</p>		
<b>Hong Kong 2 of 5</b>			
<p>On</p>  <p>M10079_01</p>	<p>Off *</p>  <p>M10078_02</p>		





**I**

<b>Int 2 of 5</b>			
<p>On *</p>  <p>M10060_01</p>	<p>Off</p>  <p>M10061_01</p>	<p>Only codes with checksum On</p>  <p>M10235_01</p>	<p>Only codes with checksum Off *</p>  <p>M10234_01</p>
<p>Without output of checksum On</p>  <p>M10065_01</p>			









**J**

Japan Post			
On  M10292_02	Off *  M10293_02		



**K**

KIX Code (Dutch Post)			
On  M10290_02	Off *  M10291_02		
Korean Post			
On  M10358_01	Off *  M10359_01		

**M**

Maxicode			
On  M10067_02	Off *  M10066_01		
Matrix 2 of 5			
On  M10069_01	Off *  M10068_01		
Micro PDF417			
On  M10073_01	Off *  M10072_01		
MSI Plessey			
On  M10076_01	Off *  M10077_01		

**N**

NEC 2 of 5			
On  M10082_01	Off *  M10083_01		



**P**

<b>PDF417</b>			
On *  M10070_01	Off  M10071_01		
<b>Pharmacode</b>			
On  M10275_02	Off *  M10274_03	Reading from left to right  M10281_02	Reading from right to left  M10280_02
<b>Plessey</b>			
On  M10237_02	Off *  M10236_02		

**Q**

<b>QR Code</b>			
On *  M10095_03	Off  M10096_02	Normal, inverted (light on a dark background), mirrored, model 1 On  M10101_02	Normal, inverted (light on a dark background), mirrored, model 1 Off  M10351_03

**R**

<b>RM4SCC (Royal Mail)</b>			
On  M10294_02	Off *  M10295_02		





**S**

<b>Straight 2 of 5</b>			
On  M10241_01	Off *  M10240_01		

















**T**

<b>Telepen</b>			
On  M10103_01	Off *  M10104_01		











<b>Trioptic</b>			
On  M10041_01	Off *  M10040_01	Reverse order of code halves On  M10446_01	Reverse order of code halves Off  M10445_01

**U**

<b>UPC (Universal Product Code)</b>			
UPC-A, UPC-E, EAN-8, EAN-13 On *  M10105_01	UPC-A, UPC-E, EAN-8, EAN-13 Off  M10106_01	Convert UPC-E to UPC-A On  M10108_01	Convert UPC-E to UPC-A Off *  M10107_01
UPC-A numbering system output On *  M10477_01	UPC-A numbering system output Off  M10478_01	UPC-A check digit output On *  M10475_01	UPC-A check digit output Off  M10476_01
UPC-E numbering system output On *  M10481_01	UPC-E numbering system output Off  M10482_01	UPC-E check digit output On *  M10479_01	UPC-E check digit output Off  M10480_01
Convert UPC-A to EAN-13 On  M10490_01	Convert UPC-A to EAN-13 Off *  M10489_01	Output of UPC-2- and UPC-5- additional codes On  M10110_01	Output of UPC-2- and UPC-5- additional codes Off *  M10109_01

For other settings, see **EAN-8** and **EAN-13**.

<b>UPU ID tag (Universal Postal Union)</b>			
On  M10360_02	Off  M10361_02		
<b>USPS Intelligent Mail</b>			
On  M10286_02	Off  M10287_02		
<b>USPS Planet</b>			
On  M10284_02	Off  M10285_02		

USPS Postnet			
On  M10282_02	Off  M10283_02		

#### 4.6 Reading Firmware Version and Serial Number

To read the handheld reader's firmware version and serial number, scan the following code using the handheld reader.



To read the firmware version and serial number for the charger or modem, scan the following code using the handheld reader.



The read result is in the following format:

iVVVVWWWXXXXSSSSSSSSSAOODYYYHHIIIIJJJKKKLLLL<TAB>Z...Z

Abbreviation	Description
i	Internal ID
VVVV	Version number of application firmware
WWW	Version number of bootloader firmware
XXXX	Version number of Bluetooth firmware
SSSSSSSS	Serial number of the handheld reader
A	Current execution state A: processor is running B: undefined state C: undefined state
OO	OEM designation
D	Display type 0 or N: no display D: standard display
YYYY	Version number of the flash file system
HH	Version number of the hardware revision
IIII	Hardware type designation 0008 indicates OHV100-F222
JJJJ	Version number of the boot application
KKKK	Version number of the operating system kernel
LLLL	Version number of the root file system
<TAB>	ASCII TAB character
Z...Z	Version number of the OEM decoder

## 5 Operation

### 5.1 Reading Codes

The handheld reader reads both very small 2-D codes (e.g., Data Matrix codes) and larger 1-D codes (e.g., barcodes). The handheld reader offers a field of vision comprising two areas that can be read at the same time. This covers a read range between 4 cm and 31 cm. The optimal read range is 10 cm.

By default, the read range is indicated by two blue bars. However, you can deactivate the display of the blue bars.



#### **Tip**

If several codes are located right next to each other, we recommend you cover the codes that you do not wish to read. This prevents you from inadvertently reading another code.



#### **Reading Codes**

The handheld reader registers itself with other devices as an input device or keyboard. Before you read a code, start or activate the application to which the read result is to be transferred.

1. To read the code, hold the trigger button down.
2. Position the blue bars in the center of the code that you wish to read. Move the handheld reader closer to or farther away from the code until the height of the blue bars roughly corresponds to the height of the code.

↳ If the reading process is successful, the function indicator on the handheld reader briefly lights up green. When activated, an audible signal is emitted and the handheld reader vibrates.

## 6 Maintenance

To get the best possible performance out of your device, keep the optical unit on the device clean and clean it when necessary.

Observe the following instructions when cleaning:

- Do not touch the optical unit with your fingers.
- Do not immerse the device in water. Do not spray the device with water or other fluids.
- Do not use a scouring agent to clean the surface of the device.
- Use a cotton or paper cloth moistened with water or isopropyl alcohol (not soaked).
- Remove any residual alcohol using a cotton or paper cloth moistened with distilled water (not soaked).
- Wipe the device surfaces dry using a lint-free cloth.

7

## Troubleshooting





**Note!**

The device must not be repaired, changed or manipulated.

If there is a defect, the device must be repaired by Pepperl+Fuchs.

**Fault Repair**

Fault	Possible Cause	Remedy
Codes could not be read.	The optical unit on the handheld reader is dirty.	Clean the optical unit. See chapter 6
	The reading distance is too large or too small.	Move the handheld reader closer to or farther away from the code, until the height of the blue bars roughly corresponds to the height of the code. See chapter 5.1
	The code is positioned on a reflective surface.	Activate the option for better display reading. See chapter 4.5.2 Change the reading angle by holding the handheld reader in an inclined position in relation to the surface.
	Reading of the code type is deactivated.	Activate the code type using Vision Configurator (see chapter 4.4.7, see chapter 4.4.8) or the relevant control code (see chapter 4.5.6).
The read result is not being transferred.	The handheld reader is not in the correct operating mode.	Activate a suitable operating mode. <ul style="list-style-type: none"> <li>■ Docking mode: see chapter 4.2.1</li> <li>■ Bluetooth mode: see chapter 4.2.2</li> <li>■ Tablet mode: see chapter 4.2.3</li> <li>■ Configuration mode: see chapter 4.2.4</li> </ul>
The read result is incorrect.	The handheld reader is using the wrong keyboard layout.	Change the keyboard layout for the current operating mode. See chapter 4.2.5
	The code type is incorrectly interpreted as another code type.	Use the <b>Test statistics</b> area in Vision Configurator to determine which code type the code is being read as (see chapter 4.4.4). Deactivate all code types that are not needed using Vision Configurator (see chapter 4.4.7, see chapter 4.4.8) or the relevant control code (see chapter 4.5.6).
	The read result is altered by a script, code type details, a prefix, or a suffix.	Use the <b>Parameter</b> area in Vision Configurator to check the settings for <b>Read result</b> (see chapter 4.4.11) and <b>Script</b> (see chapter 4.4.12).
The connection to Vision Configurator cannot be established.	The handheld reader is not in configuration mode.	Activate configuration mode. See chapter 4.2.4
	The charger's Bluetooth function is activated.	To deactivate the charger's Bluetooth function, move the slider on the back/underside of the charger in the opposite direction to the arrow. See chapter 4.2.4
No data is transferred in docking mode.	The charger's Bluetooth function is activated.	To deactivate the charger's Bluetooth function, move the slider on the back/underside of the charger in the opposite direction to the arrow. See chapter 4.2.1

Fault	Possible Cause	Remedy
No data is transferred in Bluetooth mode.	The charger's Bluetooth function is deactivated.	To activate the charger's Bluetooth function, move the slider on the back/underside of the charger in the direction of the arrow and then activate Bluetooth mode again. See chapter 4.2.2
	The handheld reader is outside the detection range of the Bluetooth receiver.	Move the handheld closer to the charger or Bluetooth modem. If the connection is not automatically reestablished, scan the <b>Quick Connect</b> code on the front of the charger or the modem.  To be able to read codes outside of the detection range of the Bluetooth receiver when in Bluetooth mode, scan the following code.  <small>M10186_04</small>  Codes that you read while outside the detection range of the Bluetooth receiver will then be saved on the handheld reader. As soon as the connection to the Bluetooth receiver is reestablished, the codes from the handheld reader's memory will be transferred via Bluetooth. If the connection is not automatically reestablished, scan the <b>Quick Connect</b> code on the front of the charger or the modem.
Some settings will be lost when the device is switched off and on again.	The altered settings have not been saved.	Change the settings again and then read the following code to save the settings manually.  <small>M10159_01</small>

## Performing a Hardware Reset Using a Control Code

To reset the handheld reader, scan the following code.



CC002943\_2



### Hardware Reset

As an alternative to reading the control code, you can reset the handheld reader using the trigger buttons.

1. Move the locking device on the bottom of the handheld reader in the direction of the arrow and remove the battery.
2. Press and hold both trigger buttons on the top of the handheld reader.
3. Insert the battery into the handheld reader and continue to hold down the trigger buttons. After approx. ten seconds, five audible signals will sound.
4. Then release the trigger buttons.
  - ↳ The function indicator on the handheld reader will flash green.
5. Press and hold both trigger buttons on the top of the handheld reader again. After around five seconds, one audible signal will sound.
6. Then release the trigger buttons.
  - ↳ The handheld reader has now been restored to its default settings.

# FACTORY AUTOMATION – SENSING YOUR NEEDS



## Worldwide Headquarters

Pepperl+Fuchs GmbH  
68307 Mannheim · Germany  
Tel. +49 621 776-0  
E-mail: [info@de.pepperl-fuchs.com](mailto:info@de.pepperl-fuchs.com)

## USA Headquarters

Pepperl+Fuchs Inc.  
Twinsburg, Ohio 44087 · USA  
Tel. +1 330 4253555  
E-mail: [sales@us.pepperl-fuchs.com](mailto:sales@us.pepperl-fuchs.com)

## Asia Pacific Headquarters

Pepperl+Fuchs Pte Ltd.  
Company Registration No. 199003130E  
Singapore 139942  
Tel. +65 67799091  
E-mail: [sales@sg.pepperl-fuchs.com](mailto:sales@sg.pepperl-fuchs.com)

[www.pepperl-fuchs.com](http://www.pepperl-fuchs.com)

 **PEPPERL+FUCHS**  
SENSING YOUR NEEDS

Subject to modifications  
Copyright PEPPERL+FUCHS • Printed in Germany

/ TDOCT-2958FENG

11/2015