

MANUAL

OHV100-F222-R2

Handheld reader



CE

With regard to the supply of products, the current issue of the following document is applicable: The General Terms of Delivery for Products and Services of the Electrical Industry, published by the Central Association of the Electrical Industry (Zentralverband Elektrotechnik und Elektroindustrie (ZVEI) e.V.) in its most recent version as well as the supplementary clause: "Expanded reservation of proprietorship"

1	Introduction.....	5
1.1	Content of this Document	5
1.2	Target Group, Personnel.....	5
1.3	Symbols Used	5
2	Product Description	7
2.1	Use and Application.....	7
2.2	Indicators and Operating Controls.....	8
2.3	Feedback	8
2.4	Scope of Delivery	8
2.5	Accessories	9
2.6	Storage and Disposal	9
3	Installation.....	10
3.1	Connection	10
3.1.1	Installing/Removing the Cable	10
3.1.2	Establishing a USB Connection	10
3.1.3	Establishing an RS-232 Connection	11
3.2	Installing Vision Configurator	11
3.3	Installing Device Drivers	12
4	Configuration	13
4.1	Selecting Operating Mode.....	13
4.1.1	Keyboard Mode	13
4.1.2	Configuration Mode	13
4.1.3	Keyboard Layout.....	14
4.2	Configuring the Handheld Reader.....	15

4.3	Configuration Process Using Vision Configurator.....	15
4.3.1	Layout of Application Window	16
4.3.2	Image display	16
4.3.3	Sensor Data	17
4.3.4	Test Statistics.....	18
4.3.5	Image Transmission	18
4.3.6	File Transmission.....	19
4.3.7	1-D Codes.....	21
4.3.8	2-D Codes.....	21
4.3.9	Device Settings	22
4.3.10	Decoding Options	23
4.3.11	Read Result	24
4.3.12	Script.....	25
4.3.13	Edited Parameters	29
4.4	Configuration with Control Codes	29
4.4.1	Operation	29
4.4.2	Read Operation	31
4.4.3	Data Processing	32
4.4.4	Data Transfer	35
4.4.5	Restarting and Clearing.....	37
4.4.6	Code Types	38
4.5	Reading Firmware Version and Serial Number	45
5	Operation.....	46
5.1	Reading Codes	46
5.2	Operation Using a Bracket.....	46
6	Maintenance.....	49
7	Troubleshooting.....	50

1 Introduction

1.1 Content of this Document

This document contains information required to use the product in the relevant phases of the product life cycle. This may include the following:

- Product identification
- Delivery, transport, and storage
- Assembly and installation
- Commissioning and operation
- Maintenance and repair
- Troubleshooting
- Dismounting
- Disposal

The documentation comprises the following parts:

- Present document
- Datasheet

In addition, the documentation may comprise the following parts, if applicable:

- EC-Type Examination Certificate
- EC Declaration of Conformity
- Attestation of conformity
- Certificates
- Control drawings
- Other documents

1.2 Target Group, Personnel

Responsibility for planning, assembly, commissioning, operation, maintenance, and dismounting lies with the plant operator.

Only appropriately trained and qualified personnel may carry out mounting, installation, commissioning, operation, maintenance, and dismounting of the product. The personnel must have read and understood the instruction manual and the further documentation.

Prior to using the product make yourself familiar with it. Read the document carefully.



1.3 Symbols Used

This document contains symbols for the identification of warning messages and of informative messages.

Warning Messages

You will find warning messages in instances, whenever dangers may arise from your actions. It is mandatory that you observe these warning messages for your personal safety and in order to avoid property damages.

Depending on the risk level, the warning messages are displayed in descending order as follows:



Danger!

This symbol indicates an imminent danger.

Non-observance will result in personal injury or death.



Warning!

This symbol indicates a possible fault or danger.

Non-observance may cause personal injury or serious property damage.



Caution!

This symbol indicates a possible fault.

Non-observance could interrupt the device and any connected systems and plants, or result in their complete failure.

Informative Symbols



Note!

This symbol brings important information to your attention.



Action

This symbol indicates a paragraph with instructions. You are prompted to perform an action or a sequence of actions.

2 Product Description

2.1 Use and Application



Caution!

Irritation caused by optical radiation

The optical unit on the handheld reader is equipped with very bright LEDs that can cause irritation in dark environments.

Do not point the handheld reader at people.

Do not look directly into the optical unit on the handheld reader.

The OHV100 handheld is a compact handheld reader for all common 1-D and 2-D codes. Special technology to prevent glare allows the device to accurately read codes on highly reflective surfaces. With its patented dual lens and a resolution of 1.2 million pixels, it can read both small and large codes from a wide range of distances. A different-colored target projection makes it easier to see the relevant code. Feedback comes in the form of a visual or audible signal or a vibration.

Using the Vision Configurator software, rule sets can be created for formatting read results without the need for extensive programming work. This facilitates integration into ERP systems. Data is transferred via USB or RS-232, depending on which connection cable is selected. With its robust housing and IP54 protection, the handheld reader is ideally suited to heavy-duty industrial use.




The device is only approved for appropriate and intended use. Ignoring these instructions will void any warranty and absolve the manufacturer from any liability.

Use the device only within the specified ambient and operating conditions.

Protection of the personnel and the plant is not ensured if the device is not being used according to its intended use.

2.2 Indicators and Operating Controls



- 1 Function indicator
- 2 10-pin connector socket
- 3 Trigger button
- 4 Optical unit

2.3 Feedback

Action	Function indicator	Audible signal	Vibration
Handheld reader successfully switched on	Off	Two audible signals	Vibrates twice
Handheld reader ready	Off	No audible signal	No vibration
Code reading successful	Function indicator briefly lights up green.	Single audible signal	Vibrates once
Configuration code reading successful	Function indicator briefly lights up green.	Two audible signals	Vibrates twice

2.4 Scope of Delivery

Check the packaging and contents for damage.

Check if you have received every item and if the items received are the ones you ordered.

- Handheld reader
OHV100-F222-R2
- Brief instructions

2.5 Accessories

Designation	Description
V45-G-2M-PVC-ABG-USB-G	Connection cable for USB connection, approx. 1.8 meters
V45-G-2M-PVC-SUBD9	Connection cable for RS-232 connection, approx. 2.4 meters (extended) Data connection: Sub-D socket, 9-pin Power supply: DC connector socket, 5.5 mm
ODZ-MAH-SUPPLY	Power supply for RS-232 connection 5 VDC, 1.2 A, short-circuit protected
OHV-BRACKET	Table mounting bracket
Vision Configurator	Configuration software for camera-based sensors When using OHV handheld readers, you can download the software free of charge from www.pepperl-fuchs.com .

2.6 Storage and Disposal

Keep the original packaging. Always store and transport the device in the original packaging.

Store the device in a clean and dry environment. The permitted ambient conditions (see datasheet) must be considered.

Disposing of device, packaging, and possibly contained batteries must be in compliance with the applicable laws and guidelines of the respective country.



3 Installation

3.1 Connection

You can connect the handheld reader to the following interfaces.


- USB
- RS-232

3.1.1 Installing/Removing the Cable



Installing the Cable

1. Hold the end of the cable with the RJ50 plug and insert the plug into the RJ50 socket underneath the handle.




2. Make sure that the cable audibly snaps into place.



Removing the Cable

1. Insert a thin object such as a straightened paper clip into the hole at the bottom of the handle at the side.



2. Carefully pull the cable complete with RJ50 plug out of the handle.

3.1.2 Establishing a USB Connection



Establishing a USB Connection

1. Insert the USB plug on the connection cable into a free USB port on the PC. This step can be carried out even during operation.
2. To switch on the handheld reader, hold down the trigger button for approx. two seconds.
3. When the handheld reader is successfully connected, an audible signal will be emitted and the handheld reader will vibrate.

↳ The handheld reader is now ready.

3.1.3 Establishing an RS-232 Connection



Establishing an RS-232 Connection

1. Switch off the PC.
2. Insert the RS-232 plug on the connection cable into the RS-232 port on the PC.
3. Insert the low-voltage plug on the power supply unit into the low-voltage socket on the RS-232 connection cable.
4. Connect the mains power plug on the power supply unit to the mains.
5. Switch on the PC.

↳ Once you have switched on the PC, the handheld reader will switch itself on automatically.

6. When the handheld reader is successfully connected, an audible signal will be emitted and the handheld reader will vibrate.

↳ The handheld reader is now ready.

The handheld reader uses the following RS-232 factory settings:

- 115,200 baud
- 8 data bits
- No parity

3.2 Installing Vision Configurator

Vision Configurator is a piece of configuration software for camera-based sensors. The software allows you to perform advanced configuration of the sensor using a clearly arranged user interface. Standard tasks include parameterization of the handheld reader, saving data sets, as well as the transfer and display of data and error diagnostics.



Note!

As an alternative to configuration using Vision Configurator, you can configure the handheld reader using control codes.



Installing Vision Configurator

1. Download the current version of Vision Configurator from <http://www.pepperl-fuchs.com>.
2. Open the installation file.
3. Select a language.
4. Follow the instructions on the setup wizard.

5. Before exiting the setup wizard, select **Install OHV USB driver**. A virtual COM port is installed that Vision Configurator uses to communicate with OHV handheld readers.



3.3 Installing Device Drivers

The handheld reader registers itself as an input device or keyboard. Special device drivers are not needed.

The operating system automatically installs the drivers for input devices (Human Interface Device). An active internet connection is required, depending on the operating system.

4 Configuration

4.1 Selecting Operating Mode

The handheld reader has two different operating modes.

Mode	Description
Keyboard Mode	When in keyboard mode, the handheld reader acts like a keyboard. The read codes are transferred to the PC as a combination of letters and digits.
Configuration Mode	Configuration mode is used exclusively for communication with Vision Configurator. See chapter 4.3 After configuration has been completed, switch back to operating mode.

4.1.1 Keyboard Mode



Activating Keyboard Mode

Read the following code using the handheld reader.



↳ The function indicator on the handheld reader briefly lights up green.

Data is transferred using a US English keyboard layout by default.

If data is not transferred correctly in keyboard mode, modify the keyboard layout. See chapter 4.1.3

4.1.2 Configuration Mode



Activating Configuration Mode (USB Connection)

Read the following code using the handheld reader.



↳ The function indicator on the handheld reader briefly lights up green.



Activating Configuration Mode (RS-232 connection)

1. Read the following code to activate raw mode for the data transfer.



2. Read a code to define the baud rate. See chapter 4.4.4
You can use the following code, for example, which sets the baud rate of the RS-232 connection to 115,200.



M10399_01

↳ The function indicator on the handheld reader briefly lights up green.

Data is transferred using a US English keyboard layout by default.

To select a different keyboard layout, see the **Device Settings** area in Vision Configurator. See chapter 4.3.9

4.1.3 Keyboard Layout

You can use the following control codes to modify the keyboard layout for the current operating mode.


Microsoft Windows

English (US)



M10460_02

English (US International)



M10469_01

English (GB)



M10471_01

German (Germany)



M10463_02

German (Switzerland)



M10466_02

French (France)



M10462_02

French (Belgium)



M10461_02

Spanish (Spain)



M10472_01

Spanish (Latin America)



M10465_02

Russian




M10418_02

Japanese



M10464_02

Apple OS X and iOS



4.2 Configuring the Handheld Reader

There are two different ways to configure the handheld reader.

- **Vision Configurator:** The software allows you to perform advanced configuration on a PC using a clearly arranged user interface. Standard tasks include parameterization of the handheld reader, saving data sets, as well as the transfer and display of data and error diagnostics. See chapter 4.3
- **Control codes:** Control codes allow direct configuration without using a PC. To adjust a parameter, scan the appropriate control code using the handheld reader. See chapter 4.4

4.3 Configuration Process Using Vision Configurator

To configure the handheld reader using Vision Configurator, you must activate configuration mode. This mode is used exclusively for communication with Vision Configurator. If you are configuring the handheld reader using control codes, you do not need to switch to configuration mode.



Note!

After configuration has been completed, switch back to keyboard mode. See chapter 4.1.1



Starting Vision Configurator

Before working with Vision Configurator, ensure that the handheld reader is in configuration mode. See chapter 4.1.2

1. Start Vision Configurator.
2. Select the user name **Default** in the **User** area. There are no different user rights for OHV handheld readers.
3. Select **OHV sensor** in the **Sensor family** area.
4. Select the handheld reader, the connection type, and the connection port from the list, where necessary.
5. Select a language in the **Language** area.
6. Click **OK**.

↳ The connection between the handheld reader and the software has now been created.

4.3.1 Layout of Application Window





Figure 4.1 Application screen

1. The display area shows the read images and offers basic editing tools.
2. The **Sensor data** area shows information about the connected sensor.
3. The **Test statistics** area shows information on the read codes.
4. The status bar shows information about the user who is logged in as well as the sensor connection status.
5. The parameter area is split into several subareas and contains sensor-specific parameters.
6. The toolbar allows direct access to selected menu items.

4.3.2 Image display

The image display shows the recording taken by the handheld reader in the near field and far field.

The toolbar offers basic editing functions.



1. Zoom into the image.
2. Zoom out of the image.
3. Display image in original size.
4. Length x width in pixels
5. Current zoom factor as a percentage
6. Position of the cursor within the image
7. Grayscale value of the pixel over which the cursor is located.
8. If you have activated **Save image**, you can select a location to save the image here.
9. Triggers a new recording in the near field and far field.
The image is immediately transferred to the image display area.
10. Triggers a new recording in the far field.
The image is immediately transferred to the image display area.
11. Triggers a new recording in the near field.
The image is immediately transferred to the image display area.
12. Tick **Save images** if you wish to save the recording locally.
13. Adjusts the image display in relation to the size of the image display area.




4.3.3 Sensor Data

This area shows information about the connected sensor.



4.3.4 Test Statistics

This area shows information about the read code.



Show ASCII value	Activate this option to display the read result in ASCII characters.
Save reader results	Activate this option to save read results locally. If you have activated this option, you can select a location to save the results.
Single trigger	Triggers a read operation.
Reset counter	Clears the contents of the Test statistics area.

4.3.5 Image Transmission

This is where you can define the settings for saving read codes.



Note!

Saving images when decoding increases the decoding time.




Image Saving Mode on Sensor

Save mode when sensor triggers	<ul style="list-style-type: none"> <input type="checkbox"/> Save no image <input type="checkbox"/> Save all images <input type="checkbox"/> Save non decoded images <input type="checkbox"/> Save decoded images
---------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------


Frame Quality on Sensor

Save frames uncompressed on sensor	The recorded image is saved uncompressed in portable graymap format on the sensor.
Save frames compressed on sensor	The recorded image is saved compressed in JPEG format on the sensor.
Image quality	<p>If the image is to be saved in JPEG format, you can define the image quality here.</p> <ul style="list-style-type: none"> <input type="checkbox"/> 0 %: maximum compression, lowest image quality <input type="checkbox"/> ... <input type="checkbox"/> 100 %: minimum compression, highest image quality



4.3.6 File Transmission

This is where you can manage files saved on the sensor.



Listed File Types

Instruction files	Displays the command files on the sensor with file extension crb
Java script files	Displays the JavaScript files on the sensor with file extension js
Image files	Displays the graphics files on the sensor with file extension jpg or pgm
Initialization file	Displays the initialization files on the sensor with file extension ini
Show all	Displays all the files on the sensor
Show none	Displays no files on the sensor

On sensor saved files

Select no file	Cancels selection on all files
Refresh	Updates the display of files
Select all files	Selects all the files on the sensor
Delete files	Deletes the selected files
Delete after transmitting	The selected files on the sensor are deleted following transfer from the sensor to the PC
Download selected file(s) from sensor	Loads the selected files from the sensor to the PC
Upload new file to sensor	Loads the file to the sensor
Save and restart sensor	Saves the current sensor settings and restarts the sensor



Updating Firmware

1. Click on **Upload new file to sensor** or select **Sensor > Update Firmware** in the menu bar.
2. Select a firmware file with the extension crz.
3. The firmware file is transferred to the handheld reader. Uploading the firmware takes a few minutes.
4. Once the file has been transferred, the handheld reader automatically restarts.
 - ↳ The firmware is now updated. You can check the firmware version in the **Device data** area. See chapter 4.3.3

4.3.7

1-D Codes

This is where you can define which 1-D code types the handheld reader should read. Different code types are shown depending on the sensor used and the firmware version.



Tip

Deactivate all code types that are not required and activate only the code types that you wish to read. This increases the evaluation speed and prevents a code type such as Codablock being mistakenly interpreted as another code type, such as Code 128.

<input checked="" type="checkbox"/>	Codabar	Advanced code settings Code off Optimization on low contrast <input type="checkbox"/> For linear barcodes <input type="checkbox"/> For Interleaved 2 of 5
<input type="checkbox"/>	Code 11	
<input type="checkbox"/>	Code 32	
<input checked="" type="checkbox"/>	Code 39	
<input checked="" type="checkbox"/>	Code 93	
<input checked="" type="checkbox"/>	Code 128	
<input checked="" type="checkbox"/>	GS1 (RSS)	
<input checked="" type="checkbox"/>	Interleaved 2 of 5	
<input type="checkbox"/>	Matrix 2 of 5	
<input type="checkbox"/>	MSI Plessey	
<input type="checkbox"/>	NEC 2 of 5	
<input type="checkbox"/>	Pharmacode	
<input type="checkbox"/>	Plessey	
<input type="checkbox"/>	Postcode	
<input type="checkbox"/>	Straight 2 of 5 (IATA)	
<input type="checkbox"/>	Telepen	
<input type="checkbox"/>	Trioptic	
<input checked="" type="checkbox"/>	UPC/EAN/JAN	



Activating 1-D Codes

1. To activate a code type, check the check box in front of the code type designation.
 - ↳ Advanced options for the selected code type are shown in the area on the right.
2. Activate or deactivate the advanced options.
3. To save the settings, select **Sensor > Save settings** in the menu bar.



Deactivating 1-D Codes

1. To deactivate a code type, uncheck the check box in front of the code type designation.
2. To save the settings, select **Sensor > Save settings** in the menu bar.




4.3.8 2-D Codes

This is where you can define which 2-D code types the handheld reader should read. Different code types are shown depending on the sensor used and the firmware version.



Tip

Deactivate all code types that are not required and activate only the code types that you wish to read. This increases the evaluation speed and prevents a code type such as Codablock being mistakenly interpreted as another code type, such as Code 128.



Activating 2-D Codes

1. To activate a code type, check the check box in front of the code type designation.
↳ Advanced options for the selected code type are shown in the area on the right.
2. Activate or deactivate the advanced options.
3. To save the settings, select **Sensor > Save settings** in the menu bar.



Deactivating 2-D Codes

1. To deactivate a code type, uncheck the check box in front of the code type designation.
2. To save the settings, select **Sensor > Save settings** in the menu bar.




4.3.9 Device Settings

This is where you can configure the feedback. Since the sensor registers itself with other devices as an input device or keyboard, you can configure which keyboard layout the sensor should use for data transfer.



Note!

To ensure the correct transfer of data, it is important to select the right keyboard layout. Depending on the keyboard selected, individual characters, such as special symbols, are output differently.



Volume and Vibration

Audible signal volume	Here you can adjust the volume of the audible signal. <ul style="list-style-type: none"> ■ 0: silent ■ ... ■ 3: maximum volume
Vibration	Here you can activate or deactivate vibration.

Target LEDs

Switched on	Here you can activate or deactivate the blue bars that indicate the read range.
--------------------	---------------------------------------------------------------------------------

Keyboard Support

Supported keyboards	<ul style="list-style-type: none"> ■ US keyboard without leading zero ■ ASCII general ■ User-defined keyboard ■ French keyboard ■ German keyboard ■ Japanese keyboard ■ Swiss keyboard ■ Belgian keyboard ■ UK keyboard ■ Latin American keyboard ■ Spanish keyboard ■ Russian keyboard
----------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------



4.3.10 Decoding Options

You can change settings for the read operation here.

Display	
<input type="checkbox"/>	Enhanced display reading
Continuous reading	
<input type="checkbox"/>	Continuous reading
Motion detection	
Motion detection	Switched off
Duplicate codes	
Duplicate code scan delay	None
Reading field	
<input checked="" type="radio"/>	Near and far field
<input type="radio"/>	Near field
<input type="radio"/>	Far field

Display

Optimized reading of displays	Optimizes the optical unit on the handheld reader to read from reflective surfaces such as displays.
--------------------------------------	------------------------------------------------------------------------------------------------------

Continuous Reading

Continuous Reading	You can activate or deactivate continuous reading here. If this option is activated, the sensor continuously attempts to read a code without the user having to activate a trigger button.
---------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Motion Detection

Motion Detection	<p>If motion detection is enabled, the sensor automatically attempts to read a code as soon as motion is detected in the read range. See chapter 5.2</p> <ul style="list-style-type: none"> ■ Switched off ■ On, no start delay ■ On, start delay 500 ms ■ On, no start delay, dark surroundings ■ On, start delay 500 ms, dark surroundings
-------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Code Duplicates

Scan delay on the same code	<p>This option prevents the same code from being read twice directly in succession within a selected time frame. After the time frame has elapsed, or if another code has been read in the interim, the same code can be read again. This option is particularly useful in conjunction with continuous reading, since it can prevent the same code from being read multiple times.</p> <ul style="list-style-type: none"> ■ None ■ ... ■ 1 day
------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Read Range

Selection	With this option, you can select whether only the near range, the long range, or both together are used for reading. If you deactivate an area, the evaluation speed increases, but codes in the deactivated area can no longer be read.
------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

4.3.11 Read Result

You can process the read result and assign a prefix or suffix to the result here. The prefix is placed in front of the read result and the suffix is placed at the end of the read result.

If the read result is additionally processed by a script, the prefixes or suffixes are assigned immediately following script processing.

Prefix/Suffix

Prefix	You can input a value for the prefix here. To delete the prefix, click on Delete prefix .
Suffix	You can input a value for the suffix here. To delete a suffix, click on Delete suffix .

Inserting Special Symbols for Keyboard Mode

Prefix TAB	Click on Prefix TAB to insert a tab character into the prefix field.
Suffix TAB	Click on Suffix TAB to insert a tab character into the suffix field.
Suffix ENTER	Click on Suffix ENTER to insert an input character into the suffix field.
more ...	Click on more ... to call up a list of additional special characters. To insert a special character from the list, click on the + icon in the corresponding line. Different special characters are available depending on whether the handheld reader is connected to Vision Configurator via USB or via RS-232.

Additional Outputs

Output the code type of the read code	If you activate this option, the code type of the read code will be output between the prefix and the read result. If the sensor is connected to Vision Configurator, the code type is displayed in the Test statistics area.
----------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

4.3.12 Script

Here you can process the read result using JavaScript. You can input your own source code or assemble a script from predefined blocks.

If a prefix or a suffix is additionally assigned to the read result, the prefixes or suffixes are assigned immediately following the script processing.

Input Codes

The following predefined components are available:

`SUBSTRING_FROM_POSITION_x_ON_y_CHARS`

Only returns one part of the code. *x* denotes the position from which the characters are output, where *x* = 0 represents the first character of the code. *y* denotes the number of characters that are output after position *x*.

Example: `SUBSTRING_FROM_POSITION_6_ON_3_CHARS` returns characters 7 to 9.

`SUBSTRING_FROM_POSITION_x_ON_ALL_CHARS`

Only returns one part of the code. *x* refers to the position from which all subsequent characters are returned, where *x* = 0 represents the first character of the code.

`OUTPUT_LAST_x_CHARS`

Returns the last *x* characters of the code.

Example: `OUTPUT_LAST_3_CHARS` returns the last 3 characters.

`OUTPUT_ALL_CHARS_BETWEEN_abc_AND_def`

Returns the characters of the code that are between an *abc* and *def* data string. If there are multiple occurrences of the data strings *abc* and *def*, only the characters between the first occurrence are returned. If the data string *abc* does not appear, no characters are returned.

`OUTPUT_ALL_CHARS_BEFORE_abc`

Returns the characters of the code that appear before an *abc* data string. If there are multiple occurrences of the data string *abc*, all characters before the first occurrence are returned. If the data string *abc* does not appear, no characters are returned.

`OUTPUT_ALL_CHARS_AFTER_abc`

Returns the relevant characters of the code that follow the data string *abc*. If the data string *abc* appears several times, all characters from the first occurrence are returned and subsequent occurrences of the data string *abc* are deleted. If the data string *abc* does not appear, no characters are returned.

`OUTPUT_x_CHARS_AFTER_abc`

Returns x relevant characters of the code that follow the data string abc. If the data string abc appears several times, x characters from the first occurrence are returned and subsequent occurrences of the data string abc are deleted. If the data string abc does not appear, no characters are returned.

`DELETE_FROM_POSITION_x_ON_y_CHARS`

Deletes part of the code. x refers to the position from which the y characters are removed, where x = 0 represents the first character of the code.

Example: `DELETE_FROM_POSITION_0_ON_5_CHARS` deletes characters 1 to 5.

`DELETE_SUBSTRING_abc`

Deletes the data string abc from the code. If the data string occurs several times, only the first occurrence of the data string is deleted.

`DELETE_LAST_x_CHARS`

Deletes the last x characters of the code.

Example: `DELETE_LAST_4_CHARS` deletes the last 4 characters.

`DELETE_ALL_CHARS_BEFORE_abc`

Deletes all characters of the code that appear before an abc data string. If there are multiple occurrences of the data string abc, only the characters that appear before the first occurrence are deleted.

`DELETE_ALL_CHARS_AFTER_abc`

Deletes all characters of the code that follow the data string abc. If there are multiple occurrences of the data string, all characters after the first occurrence are deleted.

`INSERT_abc_AT_POSITION_x`

Adds the data string abc at position x, where x = 0 represents the position before the first character of the code.

`INSERT_abc_AFTER_def`

Adds the data string abc to the data string def. If the data string def appears several times, the data string abc is appended to the first occurrence. If the data string def does not appear, no characters are appended.

`APPEND_STRING_abc`

Appends the data string abc to the code.

`IF_GOODREAD_OUTPUT_abc`

Returns the data string abc if a code has been read successfully.

`REPLACE_STRING_abc_WITH_def`

Replaces the data string abc with the data string def. If the data string abc occurs multiple times, only the first occurrence is replaced.

`REPLACE_ALL_abc_AFTER_POSITION_x_WITH_def`

Replaces the data string abc with data string def after position x. If the data string abc appears after position x several times, all occurrences are replaced.

`IF_CODE_CONTAINS_abc_OUTPUT_def`

Returns the data string def if the data string abc appears in the code. If the data string abc appears several times, the data string def is returned only once.

`APPEND_FROM_ORIGINAL_ALL_CHARS_AFTER_abc`

Appends all of the characters that follow the data string abc in the read code to the output. This rule applies directly to the read code and is independent of other rules already applied to the code. If the data string abc appears several times, all characters from the first occurrence are appended and subsequent occurrences of the data string abc are deleted. If the data string abc does not appear, no characters are appended.

`APPEND_FROM_ORIGINAL_x_CHARS_AFTER_abc`

Appends x characters that follow the data string abc in the read code to the output. This rule applies directly to the read code and is independent of other rules already applied to the code. If the data string abc appears several times, x characters from the first occurrence are appended and subsequent occurrences of the data string abc are deleted. If the data string abc does not appear, no characters are appended.

Source Code

You can edit the source code for the script in the source code area. You can also use the **Insert special characters** button to insert certain special characters.

Example

In this area, you can test the result by using an example.

Script Transfer

Button	Description
Open	Opens a locally stored script file.
Save	Saves the current script to a local file.
Send script to sensor	Saves the script on the sensor.
Delete script from sensor	Deletes the script from the sensor.
Save and restart	Saves the script on the sensor. The sensor then restarts and the script is activated.
Reset with code	Creates a control code that can be used to reset the sensor. After reading the control code, the sensor restarts.
Create control code	Generates a control code for the script. After reading the control code, the sensor restarts and the script is activated if the script has already been saved on the sensor.



Creating a Script

1. In the **Source code** area, click on a cell in the first column to edit the associated line.
2. Click on **+** to insert a predefined module in the selected line. You can also insert multiple commands and combine these with one another.

Input codes

Insert	Command	Description	Codomain
+	SUBSTRING_FROM_POSI...	Output y chars from position x, zero based	x: int, y: int
+	SUBSTRING_FROM_POSI...	Output all chars from position x, zero based	x: int
+	OUTPUT_LAST_x_CHARS	Output last x chars	x: int

Source code

	Codesymbology	Prefix read code	Prefix current code	Command
	none			SUBSTRING_FROM_POSITION_x_ON_y...
*	none			

Example

Read code: 123abc456xyz789 Output: 123abc456xyz789

Script transmission

Buttons: Send script to sensor, Remove script from sensor, Save and restart sensor, Reset with code, Create reader programming code

↳ The command appears in the selected line. If the source code is shaded red, the source code is incomplete or contains errors. If the source code is green, the source code is OK.

- Complete the variables so that the command can be executed.
If a command is to be executed only for a specific code type, select the relevant code type in the **Code symbology** column.
If a command is to be executed only when the read code begins with a certain data string, input the data string in the **Prefix of read code** column.
If a command is to be executed only when the current processing result begins with a certain data string, input the data string in **Prefix of current code** column.
To insert special characters, click on **Insert special characters**.
- If the source code is green, you can test the source code in the **Example** area. To do this, enter a sample value in the **Read code** field.

Source code

	Codesymbology	Prefix read code	Prefix current code	Command
	none			SUBSTRING_FROM_POSITION_3_ON_4...
*	none			

Example

Read code: 123abc456xyz789 Output: abc4

↳ The commands from the **Source text** area are applied to the sample value in the **Read code** field and the result is displayed in the **Output** field.



4.3.13 Edited Parameters

Here you can find an overview of all settings you have changed that now deviate from the factory settings.

To generate a control code that contains all affected settings, click on **Create control code for own settings**.

If you check the **First completely reset sensor** check box, a reset command is integrated in the control code. When the control code is read, all settings are first reset to factory defaults before the new settings are applied.



Note!

Scripts for processing the read result are not included in this overview.



Tip

This function allows your configured settings to be transferred to multiple sensors by scanning the control code.

Parametername	Tab	Default value	Current value
Supported keyboard	Sensor settings	US keyboard without leading zero	ASCII universal

Custom settings

Reset sensor first

Create control code for custom settings

4.4 Configuration with Control Codes

As an alternative to configuration using Vision Configurator, you can configure the handheld reader using control codes. Control codes allow direct configuration without using a PC. To adjust a parameter, scan the appropriate control code using the handheld reader.

4.4.1 Operation

The following codes can be used to adjust the settings for operation.

Target Detection

Code	Description
Targeting on  M10153_01	Activates the blue bars for indicating the read range.
Targeting off  M10154_01	Deactivates the blue bars for indicating the read range.

Feedback

Code	Description
Beep on/vibrate on  M10140_01	Switches audible signals and vibration on.
Beep off/vibrate on  M10141_01	Switches audible signals off and vibration on.
Beep on/vibrate off  M10142_01	Switches audible signals on and vibration off.
Beep off/vibrate off  M10143_01	Switches audible signals and vibration off.
Beep volume 0 %  M10194_01	Sets the volume of the audible signal to 0 %.
Beep volume 33 %  M10195_01	Sets the volume of the audible signal to 33 %.

Code	Description
Beep volume 67 % M10196_01	Sets the volume of the audible signal to 67 %.
Beep volume 100 % M10197_01	Sets the volume of the audible signal to 100 %.

4.4.2 Read Operation

The following codes can be used to adjust the settings for the read operation.

Reading Displays

Code	Description
Enable cell phone reading enhancement M10163_01	Optimizes the optical unit on the handheld reader to read from reflective surfaces such as displays.
Disable cell phone reading enhancement M10162_01	Deactivates optimization for reading reflective surfaces.

Read Mirrored Codes

Code	Description
Mirroring on M10125_01	Enables mirrored codes to be read.
Mirroring off M10124_02	Prevents mirrored codes from being read.

Continuous Reading

Code	Description
Continuous scan on M10012_01	Activates continuous reading. If this option is activated, the sensor continuously attempts to read a code without the user having to activate a trigger button.
Continuous scan off M10011_01	Deactivates continuous reading.

Code	Description
Duplicate scan disabled  M10144_01	Prevents the same code from being read twice directly in succession.
1 sec duplicate scan delay  M10145_01	Prevents the same code from being read twice directly in succession for a period of one second. After the time frame has elapsed, or if another code has been read in the interim, the same code can be read again.
2 sec duplicate scan delay  M10146_01	Prevents the same code from being read twice directly in succession for a period of two seconds. After the time frame has elapsed, or if another code has been read in the interim, the same code can be read again.
3 sec duplicate scan delay  M10147_01	Prevents the same code from being read twice directly in succession for a period of three seconds. After the time frame has elapsed, or if another code has been read in the interim, the same code can be read again.
5 sec duplicate scan delay  M10148_01	Prevents the same code from being read twice directly in succession for a period of five seconds. After the time frame has elapsed, or if another code has been read in the interim, the same code can be read again.
10 sec duplicate scan delay  M10149_01	Prevents the same code from being read twice directly in succession for a period of ten seconds. After the time frame has elapsed, or if another code has been read in the interim, the same code can be read again.
30 sec duplicate scan delay  M10150_01	Prevents the same code from being read twice directly in succession for a period of 30 seconds. After the time frame has elapsed, or if another code has been read in the interim, the same code can be read again.
1 hour duplicate scan delay  M10151_01	Prevents the same code from being read twice directly in succession for a period of one hour. After the time frame has elapsed, or if another code has been read in the interim, the same code can be read again.
1 day duplicate scan delay  M10152_01	Prevents the same code from being read twice directly in succession for a period of one day. After the time frame has elapsed, or if another code has been read in the interim, the same code can be read again.

4.4.3 Data Processing

The following codes can be used to add prefixes or suffixes to read results, or to change all characters to upper case.

Prefixes

Code	Description
Prefix AIM IDs on  M10199_01	Activates code type output immediately before the read result. If an additional prefix is applied, the code type will be written between the prefix and the read result.
Prefix AIM IDs off  M10198_01	Deactivates code type output.
Prefix comma  M10127_01	Places a comma in front of the read result.
Prefix space  M10128_01	Places a space in front of the read result.
Prefix TAB (USB connection)  M10129_01	Places a tab character in front of the read result. Use this code when the handheld reader is connected to the PC via the USB interface.
Prefix TAB (RS-232 connection)  M10319_01	Places a tab character in front of the read result. Use this code when the handheld reader is connected to the PC via the RS-232 interface.
Prefix erase/none  M10126_01	Removes all prefixes.

Suffixes

Code	Description
Suffix comma  M10131_01	Adds a comma to the end of the read result.
Suffix space  M10132_01	Adds a space to the end of the read result.
Suffix enter (USB connection)  M10134_01	Adds an input character to the end of the read result. Use this code when the handheld reader is connected to the PC via the USB interface.
Suffix ENTER (RS-232 connection)  M10322_01	Adds an input character to the end of the read result. Use this code when the handheld reader is connected to the PC via the RS-232 interface.
Suffix TAB (USB connection)  M10133_01	Adds a tab character to the end of the read result. Use this code when the handheld reader is connected to the PC via the USB interface.
Suffix TAB (RS-232 connection)  M10323_01	Adds a tab character to the end of the read result. Use this code when the handheld reader is connected to the PC via the RS-232 interface.
Suffix erase/none  M10130_01	Removes all suffixes.

Clearing Prefixes and Suffixes

Code	Description
Erase all prefix and suffix data  M10135_01	Clears all prefixes and suffixes.

Changing Read Results to Upper Case

Code	Description
Enable translate all characters to uppercase  M10220_03	Changes all characters to uppercase.
Disable translate all characters to uppercase  M10426_02	Outputs the characters exactly as they appear in the code.

4.4.4 Data Transfer

The following codes can be used to adjust the settings for data transfer.

Bidirectional Connection

Code	Description
Reader text commands on  M10137_01	Facilitates a bidirectional connection to the handheld reader, which allows commands to be sent to the handheld reader via the serial interface. For example, this allows a signal indicating that a value has been successfully recorded by an ERP system to be transferred to the handheld reader.
Reader text commands off  M10136_01	Deactivates the bidirectional connection via the serial interface.

RS-232 Connection

Code	Description
RS-232 raw mode  M10387_01	Activates raw mode for data transfer.
RS-232 packet mode  M10388_01	Activates packet mode for data transfer.
RS-232 interface, 7 data bits  M10390_01	Activates the use of 7 data bits.

Code	Description
RS-232 interface, 8 data bits  M10391_01	Activates the use of 8 data bits.
RS-232 interface, baud rate: 1200  M10392_01	Sets the baud rate for the RS-232 connection to 1200.
RS-232 interface, baud rate: 2400  M10393_01	Sets the baud rate for the RS-232 connection to 2400.
RS-232 interface, baud rate: 4800  M10394_01	Sets the baud rate for the RS-232 connection to 4800.
RS-232 interface, baud rate: 9600  M10395_01	Sets the baud rate for the RS-232 connection to 9600.
RS-232 interface, baud rate: 19,200  M10396_01	Sets the baud rate for the RS-232 connection to 19,200.
RS-232 interface, baud rate: 38,400  M10397_01	Sets the baud rate for the RS-232 connection to 38,400.
RS-232 interface, baud rate: 57,600  M10398_01	Sets the baud rate for the RS-232 connection to 57,600.
RS-232 interface, baud rate: 115,200  M10399_01	Sets the baud rate for the RS-232 connection to 115,200.

Code	Description
RS-232 interface, even parity  M10400_01	Activates the transfer of an even parity count.
RS-232 interface, odd parity  M10401_01	Activates the transfer of an odd parity count.
RS-232 interface, no parity  M10402_01	Activates the transfer without a parity count.



4.4.5 Restarting and Clearing

The following codes can be used to configure the device and the device memory.

Restarting the Device

Code	Description
Reboot reader  M10296_01	Restarts the handheld reader.

Resetting the Device to Factory Settings

Code	Description
Reset to USB factory defaults  M10002_02	Resets the handheld reader to factory settings and restarts the handheld reader. Use this code when the handheld reader is connected to the PC via the USB interface.
Reset to RS-232 factory defaults  M10389_02	Resets the handheld reader to factory settings and restarts the handheld reader. Use this code when the handheld reader is connected to the PC via the RS-232 interface.

Deleting the Memory and Scripts

Code	Description
Clear all stored data and images  M10138_02	Deletes all read results and recordings stored on the handheld reader.
Clear all JavaScript rules  M10139_01	Deletes all scripts saved on the handheld reader.

4.4.6 Code Types

The following codes can be used to define which code types the handheld reader should read. Different code types are supported depending on the handheld reader and firmware version. Settings marked with a * are preset at the factory.



Tip

Deactivate all code types that are not required and activate only the code types that you wish to read. This increases the evaluation speed and prevents a code type such as Codablock being mistakenly interpreted as another code type, such as Code 128.

A

Australian Post			
On  M10288_02	Off *  M10289_02		
Aztec			
On *  M10018_01	Off  M10019_01	Inverted (light on a dark background) On  M10020_01	Inverted (light on a dark background) and normal On  M10021_01

C

Codabar			
On *  M10022_01	Off  M10023_01		
Codablock F			
On  M10027_01	Off *  M10026_01		
Code 11			

2015-11



<p>On</p>  <p>M10029_01</p>	<p>Off *</p>  <p>M10028_01</p>	<p>Without output of checksum</p> <p>On</p>  <p>M10031_01</p>	
Code 32 (Italian Pharmacode)			
<p>On</p>  <p>M10239_02</p>	<p>Off *</p>  <p>M10238_02</p>		
Code 39			
<p>On *</p>  <p>M10033_02</p>	<p>Off</p>  <p>M10034_02</p>	<p>Only codes with checksum</p> <p>On</p>  <p>M10036_01</p>	<p>Only codes with checksum</p> <p>Off *</p>  <p>M10035_01</p>
<p>Without output of checksum</p> <p>On</p>  <p>M10037_01</p>			
Code 39 Extended			
<p>Decoding with full ASCII character set</p> <p>On</p>  <p>M10039_01</p>	<p>Decoding with full ASCII character set</p> <p>Off *</p>  <p>M10038_01</p>		
Code 49			
<p>On</p>  <p>M10458_01</p>	<p>Off *</p>  <p>M10459_01</p>		
Code 93			
<p>On *</p>  <p>M10042_01</p>	<p>Off</p>  <p>M10043_01</p>		
Code 128			
<p>On *</p>  <p>M10044_01</p>	<p>Off</p>  <p>M10045_01</p>		

Composite			
<p>On</p>  <p>M10047_01</p>	<p>Off *</p>  <p>M10046_01</p>		

D

Data Matrix			
<p>Reading of standard Data Matrix codes is always enabled and cannot be disabled.</p>	<p>Inverted (light on a dark background)</p> <p>On *</p>  <p>M10051_03</p>	<p>Inverted (light on a dark background)</p> <p>Off</p>  <p>M10050_03</p>	

E

EAN-8			
<p>Check digit output</p> <p>On *</p>  <p>M10485_01</p>	<p>Check digit output</p> <p>Off</p>  <p>M10486_01</p>	<p>Convert EAN-8 to EAN-13</p> <p>On</p>  <p>M10488_01</p>	<p>Convert EAN-8 to EAN-13</p> <p>Off *</p>  <p>M10487_01</p>
EAN-13			
<p>Check digit output</p> <p>On *</p>  <p>M10483_01</p>	<p>Check digit output</p> <p>Off</p>  <p>M10484_01</p>	<p>Convert Bookland EAN-13 to ISBN</p> <p>On</p>  <p>M10492_01</p>	<p>Convert Bookland EAN-13 to ISBN</p> <p>Off *</p>  <p>M10491_01</p>
<p>Convert Bookland EAN-13 to ISSN</p> <p>On</p>  <p>M10494_01</p>	<p>Convert Bookland EAN-13 to ISSN</p> <p>Off *</p>  <p>M10493_01</p>		
<p>For other settings, see UPC (Universal Product Code).</p>			

G

GS1 DataBar			
<p>All</p> <p>On *</p>  <p>M10054_01</p>	<p>All</p> <p>Off</p>  <p>M10055_01</p>	<p>Omnidirectional and truncated</p> <p>On</p>  <p>M10057_03</p>	<p>Omnidirectional and truncated</p> <p>Off</p>  <p>M10355_02</p>



Stacked and omnidirectional On  M10058_03	Stacked and omnidirectional Off  M10353_03		
GS1 DataBar Expanded			
On  M10059_03	Off  M10417_02	Stacked On  M10357_02	Stacked Off  M10356_02
GS1 DataBar Limited			
On  M10056_03	Off  M10354_02		

H

Han Xin			
On  M10248_01	Off *  M10249_01		
Hong Kong 2 of 5			
On  M10079_01	Off *  M10078_02		

I

Int 2 of 5			
On *  M10060_01	Off  M10061_01	Only codes with checksum On  M10235_01	Only codes with checksum Off *  M10234_01
Without output of checksum On  M10065_01			



J

Japan Post			
On M10292_02	Off * M10293_02		

K

KIX Code (Dutch Post)			
On M10290_02	Off * M10291_02		
Korean Post			
On M10358_01	Off * M10359_01		

M

Maxicode			
On M10067_02	Off * M10066_01		
Matrix 2 of 5			
On M10069_01	Off * M10068_01		
Micro PDF417			
On M10073_01	Off * M10072_01		
MSI Plessey			
On M10076_01	Off * M10077_01		

N

NEC 2 of 5			
On M10082_01	Off * M10083_01		

2015-11



P

PDF417			
On * M10070_01	Off M10071_01		
Pharmacode			
On M10275_02	Off * M10274_03	Reading from left to right M10281_02	Reading from right to left M10280_02
Plessey			
On M10237_02	Off * M10236_02		

Q

QR Code			
On * M10095_03	Off M10096_02	Normal, inverted (light on a dark background), mirrored, model 1 On M10101_02	Normal, inverted (light on a dark background), mirrored, model 1 Off M10351_03

R

RM4SCC (Royal Mail)			
On M10294_02	Off * M10295_02		

S

Straight 2 of 5			
On M10241_01	Off * M10240_01		

T

Telepen			
On M10103_01	Off * M10104_01		

Trioptic			
On  M10041_01	Off *  M10040_01	Reverse order of code halves On  M10446_01	Reverse order of code halves Off  M10445_01

U

UPC (Universal Product Code)			
UPC-A, UPC-E, EAN-8, EAN-13 On *  M10105_01	UPC-A, UPC-E, EAN-8, EAN-13 Off  M10106_01	Convert UPC-E to UPC-A On  M10108_01	Convert UPC-E to UPC-A Off *  M10107_01
UPC-A numbering system output On *  M10477_01	UPC-A numbering system output Off  M10478_01	UPC-A check digit output On *  M10475_01	UPC-A check digit output Off  M10476_01
UPC-E numbering system output On *  M10481_01	UPC-E numbering system output Off  M10482_01	UPC-E check digit output On *  M10479_01	UPC-E check digit output Off  M10480_01
Convert UPC-A to EAN-13 On  M10490_01	Convert UPC-A to EAN-13 Off *  M10489_01	Output of UPC-2- and UPC-5- additional codes On  M10110_01	Output of UPC-2- and UPC-5- additional codes Off *  M10109_01

For other settings, see **EAN-8** and **EAN-13**.

UPU ID tag (Universal Postal Union)			
On  M10360_02	Off  M10361_02		
USPS Intelligent Mail			
On  M10286_02	Off  M10287_02		
USPS Planet			
On  M10284_02	Off  M10285_02		

USPS Postnet			
On  M10282_02	Off  M10283_02		

4.5 Reading Firmware Version and Serial Number

To read the handheld reader's firmware version and serial number, scan the following code using the handheld reader.



The read result is in the following format:

Xap/iVVVVVWWWWWXXXXSSSSSSSSSSAOODYYYYHHIIIJJJKKKKLLLL<TAB>Z...Z

Abbreviation	Description
i	Internal ID
VVVV	Version number of application firmware
WWWW	Version number of bootloader firmware
XXXX	Version number of Bluetooth firmware
SSSSSSSSSS	Serial number of the handheld reader
A	Current execution state A: processor is running B: undefined state C: undefined state
OO	OEM name
D	Display type 0 or N: no display D: standard display
YYYY	Version number of the flash memory
HH	Version number of the hardware revision
IIII	Hardware type designation
JJJJ	Version number of the boot application
KKKK	Version number of the operating system kernel
LLLL	Version number of the root file system
<TAB>	Tab characters
Z...Z	Version number of the OEM decoder

5 Operation

5.1 Reading Codes

The handheld reader reads both very small 2-D codes (e.g., Data Matrix codes) and larger 1-D codes (e.g., barcodes). The handheld reader offers a field of vision comprising two areas that can be read at the same time. This covers a read range between 4 cm and 31 cm. The optimal read range is 10 cm.

By default, the read range is indicated by two blue bars. However, you can deactivate the display of the blue bars.



Tip

If several codes are located right next to each other, we recommend you cover the codes that you do not wish to read. This prevents you from inadvertently reading another code.



Reading Codes

The handheld reader registers itself with other devices as an input device or keyboard. Before you read a code, start or activate the application to which the read result is to be transferred.

1. To read the code, hold the trigger button down.
2. Position the blue bars in the center of the code that you wish to read. Move the handheld reader closer to or farther away from the code until the height of the blue bars roughly corresponds to the height of the code.
 - ↳ If the reading process is successful, the function indicator on the handheld reader briefly lights up green. When activated, an audible signal is emitted and the handheld reader vibrates.

5.2 Operation Using a Bracket

The handheld reader features a motion detection system. If motion detection is activated, the handheld reader automatically attempts to read a code as soon as motion is detected in the read range. It is not necessary to activate the trigger button.

If using the OHV-BRACKET, the handheld reader is set ex works in such a way that motion detection is automatically activated when the handheld reader is inserted into the bracket, and automatically deactivated when the handheld reader is removed from the bracket. However, you are able to change this setting.





<p>Motion detection on when in bracket Motion detection off when out of bracket</p>  <p>M10403_02</p>	<p>Activates automatic activation of motion detection when the handheld reader is inserted into the OHV-BRACKET.</p>
<p>Motion detection on</p>  <p>M10404_02</p>	<p>Activates motion detection regardless of whether the handheld reader is in the OHV-BRACKET fixture or not.</p>
<p>Motion detection off</p>  <p>M10013_02</p>	<p>Disables motion detection regardless of whether the handheld reader is in the OHV-BRACKET fixture or not.</p>
<p>Optimize motion detection for bright environments</p>  <p>M10014_03</p>	<p>Optimizes motion detection for bright environments.</p>
<p>Optimize motion detection for dark environments</p>  <p>M10015_03</p>	<p>Optimizes motion detection for dark environments.</p>
<p>No motion detection delay</p>  <p>M10016_03</p>	<p>Sets the start delay for motion detection to 0 ms.</p>
<p>500 ms motion detection delay</p>  <p>M10017_03</p>	<p>Sets the start delay for motion detection to 500 ms.</p>



6 Maintenance

To get the best possible performance out of your device, keep the optical unit on the device clean and clean it when necessary.

Observe the following instructions when cleaning:

- Do not touch the optical unit with your fingers.
- Do not immerse the device in water. Do not spray the device with water or other fluids.
- Do not use a scouring agent to clean the surface of the device.
- Use a cotton or paper cloth moistened with water or isopropyl alcohol (not soaked).
- Remove any residual alcohol using a cotton or paper cloth moistened with distilled water (not soaked).
- Wipe the device surfaces dry using a lint-free cloth.

7 Troubleshooting



Note!

The device must not be repaired, changed or manipulated.

If there is a defect, the device must be repaired by Pepperl+Fuchs.

Fault Repair

Fault	Possible Cause	Remedy
Codes could not be read.	The optical unit on the handheld reader is dirty.	Clean the optical unit. See chapter 6
	The reading distance is too large or too small.	Move the handheld reader closer to or farther away from the code, until the height of the blue bars roughly corresponds to the height of the code. See chapter 5.1
	The code is positioned on a reflective surface.	Activate the option for enhanced display reading. See chapter 4.4.2
		Change the reading angle by holding the handheld reader in an inclined position in relation to the surface.
	Reading of the code type is deactivated.	Activate the code type using Vision Configurator (see chapter 4.3.7, see chapter 4.3.8) or the relevant control code (see chapter 4.4.6).
The read result is not being transferred.	The handheld reader is not in keyboard mode.	Activate keyboard mode. See chapter 4.1.1
The read result is incorrect.	The handheld reader is using the wrong keyboard layout.	Change the keyboard layout for the current operating mode. See chapter 4.1.3
	The code type is incorrectly interpreted as another code type.	Use the Test statistics area in Vision Configurator to determine which code type the code is being read as (see chapter 4.3.4). Deactivate all code types that are not needed using Vision Configurator (see chapter 4.3.7, see chapter 4.3.8) or the relevant control code (see chapter 4.4.6).
	The read result is altered by a script, code type details, a prefix, or a suffix.	Use the Parameter area in Vision Configurator to check the settings for Read result (see chapter 4.3.11) and Script (see chapter 4.3.12).

Fault	Possible Cause	Remedy
The connection to Vision Configurator cannot be established.	The handheld reader is not in configuration mode.	Activate configuration mode. See chapter 4.1.2
Some settings will be lost when the device is switched off and on again.	The altered settings have not been saved.	Change the settings again and then read the following code to save the settings manually.  M10159_01



Hardware Reset

As an alternative to reading the control code, you can reset the handheld reader using the trigger button.

1. Disconnect the handheld reader from the PC.
2. Press and hold the trigger button on the handheld reader.
3. Connect the handheld reader to the PC.
4. After approx. ten seconds, five audible signals will sound. Then release the trigger button.
 - ↳ The function indicator on the handheld reader will flash green.
5. Press and hold the trigger button on the handheld reader again.
6. After around five seconds, one audible signal will sound. Then release the trigger button.
 - ↳ The handheld reader has now been restored to its default settings.

FACTORY AUTOMATION – SENSING YOUR NEEDS



Worldwide Headquarters

Pepperl+Fuchs GmbH
68307 Mannheim · Germany
Tel. +49 621 776-0
E-mail: info@de.pepperl-fuchs.com

USA Headquarters

Pepperl+Fuchs Inc.
Twinsburg, Ohio 44087 · USA
Tel. +1 330 4253555
E-mail: sales@us.pepperl-fuchs.com

Asia Pacific Headquarters

Pepperl+Fuchs Pte Ltd.
Company Registration No. 199003130E
Singapore 139942
Tel. +65 67799091
E-mail: sales@sg.pepperl-fuchs.com

www.pepperl-fuchs.com

 **PEPPERL+FUCHS**
SENSING YOUR NEEDS

Subject to modifications
Copyright PEPPERL+FUCHS • Printed in Germany

/ TDOCT-3029EENG
11/2015