Position Encoding System WCS* Read Head

Electrical Data

Manual





Your automation, our passion.

With regard to the supply of products, the current issue of the following document is applicable: The General Terms of Delivery for Products and Services of the Electrical Industry, published by the Central Association of the Electrical Industry (Zentralverband Elektrotechnik und Elektroindustrie (ZVEI) e.V.) in its most recent version as well as the supplementary clause: "Expanded reservation of proprietorship"

Worldwide

Pepperl+Fuchs Group Lilienthalstr. 200 68307 Mannheim Germany Phone: +49 621 776 - 0 E-mail: info@de.pepperl-fuchs.com **North American Headquarters** Pepperl+Fuchs Inc. 1600 Enterprise Parkway Twinsburg, Ohio 44087 USA Phone: +1 330 425-3555 E-mail: sales@us.pepperl-fuchs.com Asia Headquarters Pepperl+Fuchs Pte. Ltd. P+F Building 18 Ayer Rajah Crescent Singapore 139942 Phone: +65 6779-9091 E-mail: sales@sg.pepperl-fuchs.com https://www.pepperl-fuchs.com

1	Introduction6				
	1.1	Content of this Document6			
	1.2	Target Group, Personnel6			
	1.3	Symbols Used6			
2	Produ	uct Description			
	2.1	Functional Description8			
	2.2	Areas of Use			
3	Data	Cables and Mounting/Dismounting the Read Head13			
	3.1	Data Cable13			
	3.2	Mounting/Dismounting the Read Head Enclosure14			
4	RS-48	85 Interface (LS1xx*, LS2xx*)16			
	4.1	Electrical Connection and Data Cables16			
	4.2	Hardware Configuration18			
	4.3	Data Protocols20			
	4.4	Status and Error Messages26			
	4.5	LED Status Indication27			
5	SSI Ir	nterface (LS3xx*)			
	5.1	Electrical Connection and Data Cables29			
	5.2	Hardware Configuration			
	5.3	Data Protocols			
	5.4	Status and Error Messages33			
	5.5	LED Status Indication33			
6	CANo	open Interface (LS4xx*)35			
	6.1	Electrical Connection35			
	6.2	Hardware Configuration36			
	6.3	Software Configuration			
	6.4	Data Protocols			
	6.5	LED Status Indication			
7	Ether	Net/IP Interface (LS5xx*)40			
	7.1	Electrical Connection40			
	7.2	Hardware Configuration41			

	7.3	Software Configuration42
	7.4	Data Protocols46
	7.5	LED Status Indication
8	PROF	NET Interface (LS6xx*)51
	8.1	Electrical Connection51
	8.2	Hardware Configuration41
	8.3	Software Configuration53
	8.4	Data Protocols55
	8.5	LED Status Indication58
9	Ether	CAT® Interface (LS7xx*)
	9.1	Power Source
	9.2	Hardware Configuration60
	9.3	EtherCAT® Communication Methods62
	9.4	Software Configuration62
	9.5	Data Protocols71
	9.6	Process Data Objects (PDOs)76
	9.7	Firmware Update via the "File access over EtherCAT®" (FoE) Protocol82 $$
	9.8	LED Status Indication84
	9.9	Trademarks
10	IO-Lin	k interface (LS8xx*)87
	10.1	Electrical Connection90
	10.2 10.2.1 10.2.2	IO-Link Offline Parameterization Using PACTware
	10.3 10.3.1 10.3.2	Data Log 101 Process data structure - input data 102 Process data structure - output data 107
	10.4	LED Status Indicator108
	10.5	Display110
	10.6	Read Head Versions110

11	Optio	Options and Special Functions					
	11.1	Option D—Integrated Display in the Read Head, Type LSD					
	11.2	Option-E—Extended, Type WCS3B-LS*E*, RS-485113					
	11.3	Option-H—Heating in Read Head, Type LSH					
	11.4	Option-S—Velocity Output, Type LSS					
12	Mode	I Overview for WCS Read Heads118					
13	Dispo	osal121					
14	Арре	ndix122					
	14.1	Cable Overview					

1 Introduction

1.1 Content of this Document

This document contains information required to use the product in the relevant phases of the product life cycle. This may include information on the following:

- Product identification
- Delivery, transport, and storage
- Mounting and installation
- Commissioning and operation
- Maintenance and repair
- Troubleshooting
- Dismounting
- Disposal



Note

For full information on the product, refer to the further documentation on the Internet at www.pepperl-fuchs.com.



Note

For specific device information such as the year of construction, scan the QR code on the device. As an alternative, enter the serial number in the serial number search at www.pepperl-fuchs.com.

The documentation comprises the following parts:

- This document
- Datasheet

In addition, the documentation may comprise the following parts, if applicable:

- EU-type examination certificate
- EU declaration of conformity
- Attestation of conformity
- Certificates
- Control drawings
- Instruction manual
- Functional safety manual
- Other documents

1.2 Target Group, Personnel

Responsibility for planning, assembly, commissioning, operation, maintenance, and dismounting lies with the plant operator.

Only appropriately trained and qualified personnel may carry out mounting, installation, commissioning, operation, maintenance, and dismounting of the product. The personnel must have read and understood the instruction manual and the further documentation.

Prior to using the product make yourself familiar with it. Read the document carefully.



1.3 Symbols Used

This document contains symbols for the identification of warning messages and of informative messages.

Warning Messages

You will find warning messages, whenever dangers may arise from your actions. It is mandatory that you observe these warning messages for your personal safety and in order to avoid property damage.

Depending on the risk level, the warning messages are displayed in descending order as follows:



Danger!

This symbol indicates an imminent danger.

Non-observance will result in personal injury or death.



Warning!

This symbol indicates a possible fault or danger.

Non-observance may cause personal injury or serious property damage.



Caution!

This symbol indicates a possible fault.

Non-observance could interrupt the device and any connected systems and plants, or result in their complete failure.

Informative Symbols

-		
-		

Note

This symbol brings important information to your attention.



Action

This symbol indicates a paragraph with instructions. You are prompted to perform an action or a sequence of actions.

2 Product Description

2.1 Functional Description

The WCS position encoding system consists of two main components:

Code Rail

The code rail carries information for the absolute code. The code rail is routed parallel to the track for the material handling equipment and thus assigns a unique position to every point on the track. It is possible to route the code rail at points only where positioning is required. The system allows the code rail to be routed along curves and allows branches to be created. The code rail is built to order and delivered in a bundle. Unless otherwise ordered, the code rail always starts with position value 0 and ends with a maximum position according to the ordered length in meters. The length of a code rail segment ranges from 0 to a maximum total length of 314.573 m (WCS3) or from 0 to a maximum total length of 327 m (WCS2).

Spacers can also be ordered for repair purposes or specific applications, stating the start or end position of the desired section and the desired length in meters.

For identification applications ID-pads are available as short code rail sections, with a length of between 250 mm and 264 mm and a unique identification number.

Read Head

The U-shaped read head scans the code rail photoelectronically without touching it. The read head detects a new position value every 0.8 mm (WCS3) or 0.833 mm (WCS2).

This results in the following data:

	WCS2B	WCS3B
Resolution	± 0.42 mm 1200 pos./m	± 0.40 mm 1250 pos./m
Movement speed [v _{max}]	12.5 m/s	12.5 m/s
Y axis (tolerance)	± 5 mm	± 15.5 mm
X axis (tolerance)	± 5 mm	± 14 mm

After insertion into the code rail, the read head determines a highly accurate position value without reference or delay. The code rail can be scanned at very high speeds. The scanning can be reproduced, is reliable, and is independent of temperature fluctuations.

The position value, movement speed, and error codes such as the contamination detection or the "OUT" message can be transmitted directly from the read head to the control panel via a communication interface. There are a number of types of interfaces available in the WCS3 read head to achieve this, such as RS-485, SSI, CANopen, PROFINET, and EtherNet/IP.

There is a wide range of interface modules available for connecting to other interfaces:

- PROFINET
- PROFIBUS DP
- EtherNet/IP
- EtherCAT
- DeviceNet
- CANopen

Each interface module can simultaneously accommodate up to four read heads with an RS-485 interface and address each separately. This makes it easy to extend your plant at a later stage.

In addition to automatic contamination detection, there are other optional extensions for the WCS read head. The options are indicated in the type code with the corresponding letter:

2024-07



WCS2B and WCS3B						
Н	Integrated heating element for an extended outside temperature range as low as - 40 °C.					

WCS3B	
D	Integrated display with a seven-segment display for position and diagnostic information.
E	Read head with Extended option for long distances of up to 629.146 meters.
0	Outdoor protective enclosure with degree of protection IP69 for outdoor use.
S	Switching output for signaling when a limit speed is exceeded

The variants available can be found in the product selector at https://www.pepperl-fuchs.com, as well as in the model overview for read heads, see chapter 12.

Mounting System

There are three different mounting systems available for mounting the code rail. The bracket system, the WCS3 aluminum profile system, and the WCS2 aluminum profile system with fix-ture for a guide trolley. The three mounting systems can be screwed directly to the surface or mounted on standard C profiles.

The bracket system is the easiest to mount as it features mounting brackets for straight section elements and curved sections (vertical, horizontal). The brackets are screwed directly to the code rail and to the surface and C profile.

As an alternative to the mounting brackets, the WCS3 aluminum profile system provides better stabilization of the code rail and simplified mounting for long, straight sections. In this case, the code rail is inserted into an extruded aluminum profile developed for the WCS and fixed in place with a fixing cord. The aluminum profile rail is clipped to plastic brackets and attached to the surface with a C profile.

The WCS2 aluminum profile rail system with guide trolley is intended for applications with high running tolerances. The aluminum profile accommodates the code rail and the guide trolley. The guide trolley is connected to the vehicle via a free-running tappet and guarantees that the read head is always in the optimal position in relation to the code rail. At the same time, the read head is decoupled from vehicle vibrations. Use of the guide trolley is generally recommended with the WCS2 read head due to the low read head gap. For the WCS3 read head with outdoor protective enclosure, an optional guide trolley can be used in combination with the WCS2 profile rail.

2024-07

Properties of the WCS

- Absolute position encoding system
- Photoelectric principle (infrared range)
- Proven and robust
- Easy to maintain
- No reference points required
- No calibration and adjustment work necessary
- Resistant to power failure
- Millimeter-precise positioning with absolute repeat accuracy
- Determination of position value in real time and regardless of temperature fluctuations
- Guaranteed reading up to a speed of 12.5 m/s
- High resolution = ±0.4 mm
- Variable route length:
 - Up to 327 m (WCS2)
 - Up to 314.573 m (WCS3)
 - Up to 629.146 m (WCS Extended)
- The coding system is also suitable for curves with a radius of up to 0.5 m (does not apply to systems with guide trolleys)
- A wide range of areas of application, e.g., automated storage and retrieval systems, moving carriages, monorail conveyors, galvanic plants, automatic and slewing cranes, elevators, as well as outdoors such as in harbors, offshore installations, and ships
- · Various mounting systems available for installing the code rail
- · Connection to any control panel possible, either directly or via interface module
- Connectivity to many fieldbus systems available
- Support during commissioning and maintenance due to extensive system diagnostics options
- High functional reliability as a result of permanent self-diagnostics
- Contamination warning
- Optional heating for ambient temperatures down to -40 °C
- Digital output of an adjustable limit speed (optional)
- The WCS3-Outdoor has an IP69-compliant protective enclosure



2.2 Areas of Use

The WCS can be used anywhere where material handling equipment has to be positioned precisely. The operating principle of the WCS enables it to be used in a diverse range of applications, including:

- Interruptions in the code rail
- Applications with curves and circular paths
- Use of multiple vehicles in a row

Due to the large tolerance between the read head and code rail, the WCS can be used for most applications. In some cases, however, it is advantageous to use the WCS with a special protective enclosure or a guide trolley in conjunction with the aluminum profile system. Here are some examples from the variety of application options:

Automated Storage and Retrieval Systems (High-Bay Warehouses)

Moving carriages, lifting gear, and transversing carriages are each positioned with one read head. The positioning is independent of the length of the code rail and always absolutely reproducible. For new high-bay warehouses we recommend the WCS3 system. For retrofits in older warehouses, it may be beneficial to use the WCS2 in conjunction with the aluminum profile system:

- · Easy to retrofit
- High mechanical tolerances between the measuring system and moving carriages possible
- Decoupling of vehicle vibrations



Figure 2.1

Automated storage and retrieval system (high-bay warehouse)

Automatic Cranes

Automatic cranes are a typical application for the WCS2 in conjunction with the aluminum profile system. The crane is positioned using one read head each for the crane and the trolley movement. At each point, the guide trolley ensures the optimal position of the read head in relation to the code rail and decouples any vibrations from the crane track. Optional cleaning brushes for the code rail can be attached to the guide trolley. This means that the WCS can be used in a very dusty environment, such as in cement works or foundries. If the cranes are used outdoors, the WCS3 is used with a special protective enclosure.



Figure 2.2 Automatic crane

Galvanic Plants

One or more vehicles in succession moving along a straight route. The vehicles automatically bring the material to be galvanized into the corresponding bath. The high and adaptable light output of the read heads has enabled the WCS position encoding system to perform extremely well even under these difficult conditions. The WCS3 with protective enclosure is ideal for galvanic plants. In addition to degree of protection IP69, the enclosure is resistant to acids and alkalis.



Figure 2.3

Galvanic plant



Overhead Conveyors

Many vehicles have to be positioned on a circular track—the WCS offers the optimal solution for this. Branches (track switches) and curves can be created. The WCS3 is particularly well-suited for this task. After a power failure, the current position of the vehicle is transferred to the control panel immediately; the vehicle does not have to be moved. The WCS can also be used for distances longer than 314.573 m.



Figure 2.4 Overhead conveyor

Harbor Applications

The WCS with protective enclosure is used for conveyor systems in particularly demanding areas such as harbors, offshore, and on ships. To meet the requirements of these areas, the WCS includes an IP69-compliant protective enclosure that, in addition to protecting against dust and humidity, has been specifically designed for resistance to aggressive substances such as salt water, salty air, acids, and alkalis. It offers increased resistance to impact compared to typical outdoor sources of interference such as falling branches and hailstorms. In combination with built-in heating, the WCS can even be used in snow and temperatures as low as -40 °C. The indicator LEDs and the display are always visible through the translucent enclosure material.



Figure 2.5 Power rail of a gantry crane

3 Data Cables and Mounting/Dismounting the Read Head

3.1 Data Cable

A shielded data cable with twisted-pair wires is used for the electrical connection. Pepperl and Fuchs can supply suitable preassembled M12 single-ended female cordsets (see chapter 14.1) or field-attachable M12 single-ended female cordsets and data cables.

Data cable WCS-DC*

There are 2 types of data cable available:

- WCS-DCS for stationary cable routing
- WCS-DCF for trailing cable and drag chain installations.

The data cables are twisted pairs and have a tinned copper braided shield. The braided shield surrounds all wire pairs. The parameters of the data cables that are suitable for RS-485, SSI, and CANopen data transfer are listed in the table below.

	WCS-DCS	WCS-DCF
Capacitance (core-core)	120 pF/m	60 pF/m
Cross section	0.14 mm ²	0.25 mm ²
Number of wires	6 (3 x 2)	6 (3 x 2)
External diameter	5.8 mm	7.5 mm
Temperature range	-40 80 °C	-40 70 °C

Cable routing

The basic prerequisite for uninterrupted data transfer is that the data cables are routed in such a way that any coupling of electromagnetic fields and interference is excluded. For EMC-compliant cable routing, it is necessary to divide the cables into cable groups and route these groups separately.

Group A

- Shielded data cable (including analog)
- Unshielded cable for DC and AC voltages 0 ... 60 V
- Shielded cable for DC and AC voltages 0 ... 230 V
- Coaxial cables for monitors

Group B

Unshielded cable for DC and AC voltages 60 ... 400 V

Group C

• Unshielded cable for DC and AC voltages greater than 400 V

Shielding Cables

The shielding of cables is required to suppress electromagnetic interference. Establishing a low resistance or low impedance connection with the protective conductor is a particularly important factor in ensuring that these interference currents do not become a source of interference themselves.

The WCSB2B and WCS3B read heads have no connection option for the cable shield. The cable shield is connected to the plant potential in the switch cabinet with low resistance (large area). In the case of high electromagnetic interference, it is advisable to connect the shield of the data cable to the plant potential in the immediate vicinity of the read head with low resistance using a grounding clip.

3.2 Mounting/Dismounting the Read Head Enclosure

If required, the factory default setting of the read head can be changed using the respective DIP switches. The DIP switches are located inside the housing on the PCB of the read head. To access the DIP switches, open the enclosure cover of the read head. Proceed as follows:



Mounting/Dismounting

1. Disconnect the device from the power supply.



2. Open the read head by removing the four screws (4) on the bottom of the read head.



Warning!

Property damage caused by electrostatic discharge (ESD) If the housing is opened, the electronics may be damaged by electrostatic dis-



• Use a wrist grounding strap or other ESD protective measures.







Figure 3.2 Removing the enclosure cover

3. Remove the enclosure cover (1) from the read head. To do this, carefully pull the enclosure cover upward.





4. After making all adjustments, carefully slide the enclosure cover onto the read head and screw it into place with the four screws.



Note

The settings of the DIP switches for the respective interfaces can be found in the following chapters, under the menu item Hardware Configuration.



4 RS-485 Interface (LS1xx*, LS2xx*)

The serial interface of the read head allows the position values and other defined operating data to be read out.

Up to four WCS2B and/or WCS3B read heads can be interconnected in one RS-485 bus line. In this case, the read heads must have different addresses. The read head address must be configured in the read head if it has not already been set. If the read head address is already preset, this is indicated by the type designation of the read head. In the section "Type Overview of WCS Read Head," you will find a detailed breakdown of the read head types, see chapter 12.

Note

Information on security

From a security perspective, the following precautions must be taken for the product by the responsible application operator:

- Physically secure the device against unauthorized access
- Ensure that the device communicates only in an isolated bus with a higher-level controller and with a defined, trusted circuit of bus nodes

4.1

Electrical Connection and Data Cables



Π

Caution!

Property damage and system malfunctions due to incorrect pinout

Incorrect assignment of the wire pairs to the respective pins can result in property damage and system malfunctions.

• Note the assignment of the wire pairs to the pins as shown in the respective wiring diagrams.

Connection diagram for WCS2B read head

The WCS2B read head is connected via a 5-pin M12 plug.



Figure 4.1

WCS2B, RS-485 interface



Connection diagram for WCS3B read head

The WCS3B read head is connected via a 5-pin M12 plug.



Figure 4.2 WCS3B, RS-485 interface

The counterpart of the plug connections, the 5-pin M12 socket, is not included in the scope of delivery for the read head. You can obtain suitable connectors and cables from Pepperl+Fuchs, see chapter 14.1.

Data cable

For the RS-485 data transfer path, a four-wire, shielded, twisted pair data cable must be used. One wire pair is used for the supply voltage, and one pair for the RS-485 data connection. The maximum length of the cable depends on the capacitance of the data cable—core-core—for data transfer, and on the cross section of the cables for power supply to the read heads. For data transfer, a small core cross section and thus a small cable capacitance is an advantage, whereas for the power supply, the largest possible cross section is required. The table below shows the possible cable lengths depending on the cable cross section.

Cable cross		Number of read heads without heater			Number of read heads with heater				
section	AWG ¹	1	2	3	4	1	2	3	4
0.14 mm ²	~ 26	200 m	110 m	70 m	50 m	15 m	10 m	7 m	5 m
0.22 mm ²	~ 24	320 m	170 m	110 m	80 m	30 m	15 m	10 m	7 m
0.25 mm ²	-	350 m	190 m	130 m	90 m	35 m	17 m	12 m	8 m
0.28 mm ²	-	400 m	220 m	150 m	110 m	40 m	20 m	15 m	10 m
0.34 mm ²	~ 22	500 m	250 m	180 m	140 m	50 m	25 m	17 m	12 m
0.50 mm ²	~ 20	500 m	400 m	270 m	200 m	70 m	35 m	25 m	17 m

Cable length

1. American Wire Gauge, a system commonly used in North America for the specification of wire diameters in electrical engineering.

In the calculations, the worst-case scenario was assumed: All read heads are located at the end of the data line. In the case of large cable lengths, and when connecting multiple WCS2 read heads with a heater, 6-wire data cables (3×2) can be used. These data cables use two pairs for the power supply (doubling the cable cross section), and one pair for the RS-485 data line. The table below shows the possible cable lengths depending on the cable capacitance (core-core). The number of connected read heads is of no significance.

Capacitance	RS-485 interface					
(core-core)	19.2 kb	62.5 kb	187.5 kb			
60 pF	500 m	500 m	300 m			
90 pF	500 m	450 m	275 m			
120 pF	500 m	400 m	250 m			



4.2 Hardware Configuration

You can change the hardware and software configuration of the read head in the read head. The changes to the read head type are made with two DIP switches or with three if you have a read head with the "Display" option: S1 (1) is a DIP switch with four switch positions, S2 (2) and S1D (3) are switches with two switch positions each.



Figure 4.3 Positions of the DIP switches

- 1. Configuration switch S1, 4-way (address, baud rate)
- 2. Configuration switch S2, 2-way (terminator)
- 3. Configuration switch S1D, 2-way (display)

Changing the read head address

	Configuration switch "S1"				
Read head type	1	2	3	4	Address
WCS2B-LS***-0 WCS3B-LS***-0	OFF	OFF	Х	Х	0
WCS2B-LS***-1 WCS3B-LS***-1	ON	OFF	Х	Х	1
WCS2B-LS***-2 WCS3B-LS***-2	OFF	ON	Х	Х	2
WCS2B-LS***-3 WCS3B-LS***-3	ON	ON	Х	Х	3
WCS3B-LS***S-0	OFF	Х	Х	Х	0
WCS3B-LS***S-1	ON	Х	Х	Х	1

Changing the terminator

WCS2B and WCS3B					
	Configuration switch "S2"				
Terminator	1	2			
ON	ON	ON			
OFF	OFF	OFF			

Changing the baud rate

Base types LS*11/LS*21:

Read head type	Configu	ration sv	vitch "S1	н	
(* = 1 or 2)	1	2	3	4	Baud rate
WCS2B-LS*11 WCS3B-LS*11	Х	Х	OFF	Х	187.5 kBaud
WCS2B-LS*21 WCS3B-LS*21	Х	Х	ON	Х	62.5 kBaud

Base types LS231/LS261

Read head type	Configu	ration sv	vitch "S1	"	
(* = 1 or 2)	1	2	3	4	Baud rate
WCS2B-LS*61 WCS3B-LS*61	Х	Х	OFF	Х	38.4 kBaud
WCS2B-LS*31 WCS3B-LS*31	Х	Х	ON	Х	31.25 kBaud

Base types LS246/LS256

Read head type	Configu	ration sv	vitch "S1	11	
(* = 1 or 2)	1	2	3	4	Baud rate
WCS2B-LS*46 WCS3B-LS*46	Х	Х	OFF	OFF	19.2 kBaud even parity
WCS2B-LS*47 WCS3B-LS*47	Х	Х	OFF	ON	19.2 kBaud no parity

2024-07



Read head type	Confi	iguration	switch "S	61"	
(* = 1 or 2)	1	2	3	4	Baud rate
WCS2B-LS*56 WCS3B-LS*56	Х	Х	ON	OFF	9.6 kBaud even parity
WCS2B-LS*57 WCS3B-LS*57	Х	Х	ON	ON	9.6 kBaud no parity

Base types LS*1xS/LS*2xS

Read head type (* = 1 or 2, x = 1, 6, or 7)	Configu	ration sv	vitch "S1		
	1	2	3	4	Baud rate
WCS3B-LS*1xS	Х	OFF	Х	Х	187.5 kBaud
WCS3B-LS*2xS	Х	ON	Х	Х	62.5 kBaud

Base types LS*3xS/LS*6xS

	Read head type (* = 1 or 2, x = 1, 6, or 7)	Configu	ration sv	vitch "S1		
		1	2	3	4	Baud rate
	WCS3B-LS*6xS	Х	OFF	Х	Х	38.4 kBaud
	WCS3B-LS*3xS	Х	ON	Х	Х	31.25 kBaud

Base types LS*3xS/LS*6xS

Read head type (* = 1 or 2, x = 1, 6, or 7)	Configu	ration sv	vitch "S1		
	1	2	3	4	Baud rate
WCS3B-LS*4xS	Х	OFF	Х	Х	19.2 kBaud
WCS3B-LS*5xS	Х	OFF	Х	Х	9.6 kBaud

Adjusting the Display

You can rotate the character position on the display 180° using the S1D DIP switch. This allows you to read the displayed values easily regardless of the installation position of the read head.

WCS3B	WCS3B									
	Configuration switc	h "S1D"								
Display position	1	2	Comment							
0°	OFF	OFF	The displayed value can be read on a code rail mounted upright.							
180°	ON	ON	The displayed value can be read on a code rail mounted sus- pended.							

4.3 Data Protocols

Various data protocols and data transmission speeds are available for direct connection of the read head to the higher-level control panel via a serial communication channel. The data protocols and baud rates are identical for the respective types in the WCS2B and WCS3B read heads.

A byte has the following format:



Figure 4.4 Data structure

For data protocols 1 and 2, the eighth data bit is used to distinguish between request bytes and response bytes. For control panels that do not support direction control via the eighth data bit, data protocol 3 is available. Read heads with an RS-485 interface and data protocol 3 can be delivered as type:

LSxx6 = data protocol 3 with parity (even parity), 9 bits/byte

LSxx7 = data protocol 3 without parity, 8 bits/byte

Response Time

The minimum response time of the read head (to start sending the first data bytes from the response telegram) depends on the internal time sequence of the read head and is $10 \dots 180 \mu$ sec for data protocol 1 and 2.

For data protocol 3, the response time is a byte time + 10 ... 100 μ sec. The byte time depends on the baud rate and is calculated from **1/baud rate** * **11,000 in** μ sec.

For example: 38.4 kBaud

Byte time = 1/38.4 * 11,000 = **286.5** µsec.

i

Note

Note the different data protocols for extended read head, see chapter 11.2.

Data protocol 1

Request byte for read head										
Byte	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
	1	0	0	0	F0	0	0	A1	A0	

Respon	Response telegram from the read head													
Byte	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0					
Byte 1	0	OUT	ERR	A1	A0	DB	P18	P17	P16					
Byte 2	0	P15	P14	P13	P12	P11	P10	P09	P08					
Byte 3	0	P07	P06	P05	P04	P03	P02	P01	P00					
Byte 4	0	OUT	ERR	A1	A0	DB	P18	P17	P16					
Byte 5	0	P15	P14	P13	P12	P11	P10	P09	P08					
Byte 6	0	P07	P06	P05	P04	P03	P02	P01	P00					



Data protocol 1 with position and velocity output

Request byte for read head											
Byte	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0		
	1	1	0	0	0	0	0	A1	A0		

Response telegram from the read head

	Ŭ								
Byte	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	0	OUT	ERR	A1	A0	DB	P18	P17	P16
Byte 2	0	P15	P14	P13	P12	P11	P10	P09	P08
Byte 3	0	P07	P06	P05	P04	P03	P02	P01	P00
Byte 4	0	SST	SP6	SP5	SP4	SP3	SP2	SP1	SP0
Byte 5	0	OUT	ERR	A1	A0	DB	P18	P17	P16
Byte 6	0	P15	P14	P13	P12	P11	P10	P09	P08
Byte 7	0	P07	P06	P05	P04	P03	P02	P01	P00
Byte 8	0	SST	SP6	SP5	SP4	SP3	SP2	SP1	SP0

Data protocol 2

Request byte for read head									
Byte	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
	1	0	1	1	F0	0	0	A1	A0

Response telegram from the read head									
Byte	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	0	OUT	ERR	A1	A0	DB	P18	P17	P16
Byte 2	0	P15	P14	P13	P12	P11	P10	P09	P08
Byte 3	0	P07	P06	P05	P04	P03	P02	P01	P00
Byte 4	0	XOR By	te 1 Byt	ie 3					

Data protocol 2 with position and velocity output

Reques	Request byte for read head								
Byte	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
	1	1	1	1	0	0	0	A1	A0

Respon	Response telegram from the read head									
Byte	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
Byte 1	0	OUT	ERR	A1	A0	DB	P18	P17	P16	
Byte 2	0	P15	P14	P13	P12	P11	P10	P09	P08	
Byte 3	0	P07	P06	P05	P04	P03	P02	P01	P00	
Byte 4	0	SST	SP6	SP5	SP4	SP3	SP2	SP1	SP0	
Byte 5	0	XOR Byte 1 Byte 4								

Data protocol 3

Request byte for read head									
Byte	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
	PAR	1	0	0	F0	0	0	A1	A0

Respon	Response telegram from the read head								
Byte	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	PAR	0	0	A1	A0	0	DB	OUT	ERR
Byte 2	PAR	0	0	0	P18	P17	P16	P15	P14
Byte 3	PAR	0	P13	P12	P11	P10	P09	P08	P07
Byte 4	PAR	0	P06	P05	P04	P03	P02	P01	P00
Byte 5	PAR	XOR Byt	te 1 Byt	ie 4					

Data protocol 3 with position and velocity output

Request byte for read head									
Byte	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
	PAR	1	1	1	0	0	0	A1	A0

Respon	Response telegram from the read head								
Byte	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	PAR	0	SST	A1	A0	0	DB	OUT	ERR
Byte 2	PAR	0	0	0	P18	P17	P16	P15	P14
Byte 3	PAR	0	P13	P12	P11	P10	P09	P08	P07
Byte 4	PAR	0	P06	P05	P04	P03	P02	P01	P00
Byte 5	PAR	0	SP6	SP5	SP4	SP3	SP2	SP1	SP0
Byte 6	PAR	XOR Byte 1 Byte 5							

Description of the protocol data

Activation of the read head

F0	A1	A0	Read head address
х	0	0	Read head address 0
х	0	1	Read head address 1
х	1	0	Read head address 2
х	1	1	Read head address 3
0	х	х	Send position value
1	х	х	Send diagnostic result



Data	from	read	head
------	------	------	------

Funct	Function number for read head F0=0 (send position value)								
ERR	DB	Ουτ	SST	Description	State of the read head lens				
0	0	0	х	Current position value in P00 P18, binary coded	Good				
0	0	1	х	Read head outside the code rail, no position value (see OUT message)	Good				
0	1	0	х	Current position value in P00 P18, binary coded	Poor				
0	1	1	х	No position value, read head outside the code rail (see OUT message)	Poor				
1	x	x	x	No position value, error message from read head, error number in P00 P04, binary coded	-				
х	х	х	1	Current speed unknown, last speed in SP0 SP6 *)	-				
х	х	х	0	Current speed in SP0 SP6 *)	-				

*) Speed information

The speed is binary coded in bits SP0 to SP6.

SP0SP6	Speed in	n 0.1 m/s, binary coded
	0:	Speed less than 0.1 m/s
	126:	Speed more than 12.5 m/s
	127:	Speed unknown
For example:		
SP0SP6	1:	Speed 0.1 m/s
	37:	Speed 3.7 m/s
	112:	Speed 11.2 m/s

Diagnostic function F0=1

The read head can be requested to perform a diagnosis of the photoelectrics via the request byte to the read head. For this purpose, the read head must be located outside of the code rail. On the WCS2B and WCS3B read heads, the degree of dirt accumulation on the photoelectrics is monitored automatically during operation and the diagnostic bit (DB) set if dirt accumulation is too high. Thus the request for diagnosis to the read head via F0 in the request byte is no longer necessary. However, for reasons of downward compatibility, this function is also supported by the new read heads.

2024-07

Diagnostic bit (DB)

Diagnostic bit (DB) displays the result of the integrated diagnostics of the read head.

Function	Function number for read head F0 = 1 (send diagnosis result)						
ERR	DB	Ουτ	Description	State of the read head lens			
0	1	0	Diagnosis invalid, read head not outside of the code rail	-			
0	1	1	Diagnosis result in P16 P18	-			
			P16 P18 = 0	Good			
			P16 P18 > 0	Poor			
1	x	x	Error message from read head, error message in P00 P04, binary coded	-			

Contamination detection

Read heads WCS2B and WCS3B continually monitor the condition of the lenses. If a drop in light output is detected on the infrared transmitter, e.g., as a result of contamination of the clear protective lenses, the read head automatically increases the light intensity. If the level of contamination is too high, a warning message is sent to the higher-level control panel (diagnostic bit DB=1). The automatic light adjustment in the read head allows you sufficient time to clean the read head as part of the next servicing procedure. The WCS3B read head emits a visual signal for the "contamination detected" state: the yellow and red LEDs on the front of the read head flash alternately. To clean the lenses, the read head must be removed from the code rail (removed from the mounting base). After cleaning the transparent protective lenses, the contamination message is automatically deleted from the read head. If the message is not reset despite careful cleaning or replacement of the plastic protective lenses, there may be an error. In this case, the read head must be sent for inspection.

OUT message

Function number for read head F0 = 0 (send position value)							
ERR	DB	OUT	SST	Description	State		
0	х	1	х	P00P18 = 0 -> read head is par- tially outside the code rail	OUT		
				P00 = 1, P02P18 = 0 -> read head is completely outside the code rail	OUT A		

OUT means that the position value cannot be determined because the position of the code rail in the read head gap is incorrect.

OUT A (A=AII) means that there is no code rail in the read head gap; all light barriers of the read head report a signal.

The "OUT" message may be desirable and correct, e.g., if the code rail is interrupted and the read head sends this information between the individual rail pieces to the control panel. If the "OUT" message must not occur, the following test steps must be performed:

Result of the check	Remedy
The upper edge of the code rail is outside the	Align the code rail precisely
tolerance range of the read head	Aligning the read head
	 Use the guide system for the read head



Result of the check	Remedy
The plastic protective lenses on the optical	Clean optical unit
unit are dirty or scratched	Ensure the read head is cleaned
	Change the protective lenses
Incidence of extraneous light	 Protect the read head against any incidence of extraneous light

If these measures do not solve the problem, the read head must be sent for inspection.

4.4 Status and Error Messages

Error number	Cause	Remedy
1 2	WCS read head cannot calculate position value because:	
	Optical unit is dirty	Clean optical unit
	Plastic protective lenses are scratched	Align WCS read head and code rail correctly; replace scratched plastic protective lenses
	Position of the read head in relation to the code rail is incorrect	Check the position of the WCS read head in relation to the code rail; install WCS read head correctly
	Light barriers have failed	Check light barriers; if necessary send for repair
3	RAM error, WCS read head	Send WCS read head for repair
4	EPROM error, WCS read head	Send WCS read head for repair
5	ROM error, WCS read head	Send WCS read head for repair
6	Reserved	
7	No position value available	Message only after switching on the WCS read head and/or after a RESET
8 9 10 11 12	Data transfer error between WCS read head and interface module, data transfer disrupted	Check the cable connection from the WCS read head to the interface module; check the shielding, protec- tive earth, cable routing (EMC)
13	WCS read head cannot be addressed by the interface module	Check the cable connection from the WCS read head to the interface module; check the operating voltage of the read head
14	Read head is located in the initialize or diagnostic routine	Wait for initialization; exit diagnostics (set the selector switch on the interface module to 0 7)
15	Interface module is not set for com- munication with multiple WCS read heads	Send interface module for correct configuration setting
19	RAM error in interface module	Send interface module for repair
20	EPROM error in interface module	Send interface module for repair

PEPPERL+FUCHS

4.5 LED Status Indication

WCS3B-LS1xx*/ WCS3B-LS2xx*





Description of the LED Indicators

ltem	Display	Designation	Color	Display	Meaning
1	PWR	Operating Indicator	green	On	Power on
2 (left)	СОМ	Data flow indicator	Yellow	On	Data transfer active
2 (right)	SPD	Velocity display	Yellow	On	When the limit speed is exceeded
3	STS	Fault indicator	red	On	System error
			red	Flashing	Read head out- side the code rail
2 and 3	STS and SPD, or COM	Contamination indi- cator	yellow and red	Flash alter- nately (f=1.5 Hz)	The read head optics are dirty
		Function indicator	yellow and red	for 2 secs	After switching on or a reset



WCS3B-LS*E* (Option—Extended)



Description of the LED Indicators

Item	Display	Designation	Color	Display	Meaning
1	СОМ	Data flow indicator	Yellow	Flashing	Data transfer active
			Yellow	Off	Data transfer indicator
2	SPD	Velocity display	Yellow	On	Supply voltage on
			Yellow	Off	Limit speed exceeded
3 S	STS	Status indicator	green	On	Code rail detected, nor- mal function
			green	Flashing	Position invalid; code rail area is not unique after the supply voltage has been connected
			red	On	Internal diagnostic error
			red	Flashing	Read head partially or completely outside the code rail

5 SSI Interface (LS3xx*)

The read head with SSI interface supports data formats in Gray code (LS311) or binary code (LS310). Data transfer is carried out on the SSI read head at the request of the control panel.

Note



Information on security

From a security perspective, the following precautions must be taken for the product by the responsible application operator:

- Physically secure the device against unauthorized access
- Make sure there is a point-to-point connection between the device and the higher-level controller

5.1 Electrical Connection and Data Cables



Caution!

Property damage and system malfunctions due to incorrect pinout

Incorrect assignment of the wire pairs to the respective pins can result in property damage and system malfunctions.

 Note the assignment of the wire pairs to the pins as shown in the respective wiring diagrams.

Connection diagram for WCS2B read head

The WCS2B read head with SSI interface is electrically connected via an 8-pin M12 plug.



Figure 5.1 WCS2B, SSI interface

Connection diagram for WCS3B read head

The WCS3B read head with SSI interface is electrically connected via an 8-pin M12 plug.



Figure 5.2

WCS3B, SSI interface

The counterpart of the plug connections, the 8-pin M12 socket, is not included in the scope of delivery for the respective read head. You can obtain suitable connectors and cables from Pepperl+Fuchs, see chapter 14.1.

Data Cable

For SSI data transfer, a 6-wire, shielded, twisted pair data cable (3 x 2) is used. One wire pair is used for the supply voltage, one pair for the CLK line, and one pair for the DATA line. The cable lengths that are technically possible can be determined from the tables. For large cable lengths (longer than 12 m) between the SSI read head and control panel, we recommend using the SSI interface module. In this case, the data is transferred asynchronously from the read head to the interface module via the RS-485 interface. The data is converted to SSI protocol immediately next to the control panel. The table below shows the possible cable lengths depending on the cable capacitance (core-core). The number of connected read heads is of no significance.

Capacitance	SSI Interface					
(core-core)	125 kHz	250 kHz	500 kHz			
60 pF	200 m	100 m	30 m			
90 pF	150 m	80 m	25 m			
120 pF	100 m	60 m	20 m			



5.2 Hardware Configuration

You can change the hardware and software configuration of the read head in the read head. The changes to the read head type are made with a DIP switch or with two if you have a read head with the "Display" option: S1 (1) is a DIP switch with four switch positions and S1D (2) is a DIP switch with two switch positions.



Figure 5.3 Configuration switch positions

- 1. Configuration switch S1, 4-way (data format, contamination detection)
- 2. Configuration switch S1D, 2-way (display)

Changing the data format

	Configu	ration sv	vitch "S1		
Read head type	1	2	3	4	Code
WCS2B-LS310 WCS3B-LS310	ON	OFF	Х	Х	Binary
WCS2B-LS311 WCS3B-LS311	OFF	OFF	Х	Х	Gray

	Configu	ration sv	vitch "S1		
Read head type	1	2	3	4	Code
WCS2B-LS31* WCS3B-LS31*	Х	OFF	Х	OFF	ON
WCS2B-LS31* WCS3B-LS31*	Х	OFF	Х	ON	OFF

Output of a warning if the lenses are contaminated

Adjusting the Display

You can rotate the character position on the display 180° using the S1D DIP switch. This allows you to read the displayed values easily regardless of the installation position of the read head.

WCS3B							
	Configuration s	switch "S1D"					
Display position	1	2	Comment				
0°	OFF	OFF	The displayed value can be read on a code rail mounted upright.				
180°	ON	ON	The displayed value can be read on a code rail mounted suspended.				

5.3 Data Protocols

The read head with SSI interface supports data formats in gray code (LS311) or binary code (LS310). Data transfer for the SSI read head is carried out on request from the control panel.

SSI interface

The clock signal (CLK) generated by the control panel is used for the transfer. If no data transfer begins, the serial data output of the read head remains at 1. The data transfer begins with a falling edge of the clock signal. With each rising edge of the clock signal, the read head transmits one bit of the current position. The transfer begins with the most significant bit (MSB) and ends with the least significant bit (LSB).



Figure 5.4 SSI data format

The read head with SSI interface corresponds to a 19-bit absolute encoder in the data format. Effectively, the WCS read head delivers up to 512 revolutions and 1024 increments/revolution. The clock rate between the control panel and the read head may be 100 ... 1000 kHz. The recommended value is 250 kHz.

Bit 1 ... 3

The first three bits are always 0.

Bit 4 ... 22 (2¹⁸ ... 2⁰ position values)

The position values are transferred to bits 4 to 22 of the SSI protocol. For LS311 read heads the position values are gray encoded, and for LS310 read heads the position values are binary encoded.



Bit 23 (OA read head outside the code rail)

A distinction is made between two different states:

1. The code rail is located in the read head gap, but outside the possible tolerances. In this case, the control panel receives the following bit pattern:

KB = 0OA = 0

4 = 0

POS $2^0 \dots 2^{18} = 1$ (position value 524287)

2. There is no code rail in the read head gap. In this case, bit OA = 1 (Out All) is set in addition to the above bit pattern.

Note

Position data (bit 4 ... 22) are output for LS311 read heads in gray code. Status and error bits (bit 23 ... 25) are not output in gray code.

Bit 24 (DB output of a prewarning if the lenses are contaminated)

The contamination warning is transferred in bit 24 of the SSI protocol and can be evaluated. The diagnostic bit DB is always switched on by default.

Read heads WCS2B and WCS3B continually monitor the condition of the lenses. If a drop in light output is detected on the infrared transmitter, e.g., as a result of contamination of the clear protective lenses, the read head automatically increases the light intensity. If the level of contamination is too high, a warning message is sent to the higher-level control panel (diagnostic bit DB=1). The automatic light adjustment in the read head allows you sufficient time to clean the read head as part of the next servicing procedure. The WCS3B read head emits a visual signal for the "contamination detected" state: the yellow and red LEDs on the front of the read head flash alternately. To clean the lenses, the read head must be removed from the code rail (removed from the mounting base). After cleaning the transparent protective lenses, the contamination message is automatically deleted from the read head. If the message is not reset despite careful cleaning or replacement of the plastic protective lenses, there may be an error. In this case, the read head must be sent for inspection.

Read head type	S1		Diagnostic bit		
(* = 0 or 1)	1	2	3	4	
WCS2B-LS31*	Х	OFF	Х	OFF	ON
WCS2B-LS31*	Х	OFF	Х	ON	OFF
WCS3B-LS31*	Х	OFF	Х	OFF	ON
WCS3B-LS31*	Х	OFF	Х	ON	OFF

Bit 25 (KB error message)

If the read head detects an error, the KB error bit is set and the error code is output to the control panel:

KB = 1

POS $2^0 \dots 2^2$ = error number

POS $2^3 \dots 2^{18} = 0$

Information on the error messages see chapter 5.4.

5.4 Status and Error Messages

Error number	Cause	Remedy
1 2	WCS read head cannot calculate position value because:	
	Optical unit is dirty	Clean optical unit
	Plastic protective lenses are scratched	Align WCS read head and code rail cor- rectly; replace scratched plastic protective lenses
	Position of the read head in relation to the code rail is incorrect	Check the position of the WCS read head in relation to the code rail; install WCS read head correctly
	Light barriers have failed	Check light barriers; if necessary send for repair
3	RAM error, WCS read head	Send WCS read head for repair
4	EPROM error, WCS read head	Send WCS read head for repair
5	ROM error, WCS read head	Send WCS read head for repair
6	Reserved	
7	No position value available	Message only after switching on the WCS read head and/or after a RESET




5.5 LED Status Indication

WCS3B-LS3xx*





Description of the LED Indicators

Item	Display	Designation	Color	Display	Meaning
1	PWR	Operating Indicator	green	On	Power on
2 (left)	COM	Data flow indi- cator	Yellow	On	Data transfer active
2 (right)	SPD	Velocity dis- play	Yellow	On	When the limit speed is exceeded
3	STS	Fault indicator	red	On	System error
			red	Flashing	Read head outside the code rail
2 and 3	STS and SPD, or COM	Contamina- tion indicator	yellow and red	Flash alter- nately (f=1.5 Hz)	The read head optics are dirty
		Function indi- cator	yellow and red	for 2 secs	After switching on or a reset

6 CANopen Interface (LS4xx*)

The WCS3B read head with CANopen interface can be connected directly to a CANopen bus after configuration. The configuration is carried out via DIP switches in the read head in a deenergized state.

The CAN interface is galvanically isolated. The read head works as a CANopen node in the "Predefined Connection Set" and sends the data in the TxPDO1.



6.1

Note

Information on security

From a security perspective, the following precautions must be taken for the product by the responsible application operator:

- Physically secure the device against unauthorized access
- Ensure that the device communicates only in an isolated bus with a higher-level controller and with a defined, trusted circuit of bus nodes

Electrical Connection

Caution!

Property damage and system malfunctions due to incorrect pinout

Incorrect assignment of the wire pairs to the respective pins can result in property damage and system malfunctions.

 Note the assignment of the wire pairs to the pins as shown in the respective wiring diagrams.

Connection diagram for WCS3B read head

The connection is made via a 5-pin M12 plug. The counterpart to the connector is not included in the scope of delivery for the read head.



Figure 6.1 WCS3B, CANopen interface

You can obtain suitable connectors and cables from Pepperl+Fuchs, see chapter 14.1.

Data Cable

For CANopen data transfer, a four-wire, shielded, twisted pair data cable must be used. One wire pair is used for the supply voltage, and one wire pair is used for the CANopen data transfer.

The maximum length of the cable depends on the speed of the data transfer. The table below shows the possible cable lengths depending on the bit rate.

Maximum cable length

Bit rate	Cable length
125 kbits/s	500 m
250 kbits/s	250 m
500 kbits/s	100 m
1 Mbits/s	30 m



6.2 Hardware Configuration

You can change the hardware and software configuration of the read head in the read head. The read head type is changed using three DIP switches.



Figure 6.2 Configuration switch positions

- 1. 4-way configuration switch (transfer mode, data protocols)
- 2. 1-way configuration switch (CAN terminator)
- 3. 8-way configuration switch (baud rate, node ID)

CAN Terminator

On the middle PCB in the read head there is a 1-way DIP switch (2). This switch can be used to switch the CAN terminator, 120 ohms, off or on. The terminator is switched on by default.

Baud Rate

The baud rate can be changed using two switches of the 8-way DIP switch (3) on the central PCB in the read head. The baud rate is 250 kBaud by default.

DIP 8-8	DIP 8-7	Baud rate
OFF	OFF	125 kBaud
OFF	ON	250 kBaud
ON	OFF	500 kBaud
ON	ON	1 MBaud

Node ID

The address in the CANopen bus, the node ID, can be changed using switches 1 to 6 of the 8way DIP switch (3) on the central PCB in the read head. The node ID is encoded in binary form. The smallest possible node ID is 1, the highest possible node ID is 63. Node ID 0 is not permitted. Node ID 1 is applied by default.

Transfer mode in the CANopen bus

The transfer mode and the "inhibit time" can be configured using switches 1 to 3 of the 4-way DIP switch (1) on the PCB on the side of the read head.

Asynchronous

Switch position 0 ... 3, see table below.

The read head automatically sends the data to the CAN bus as soon as this has changed in the read head. However, a wait time of at least x ms must have passed since the last data packet. This can prevent bus overload. If x = 0 ms, no waiting time is taken into account. In this case, the maximum data rate to the CAN bus is approx. 1.5 ... 2 ms.

If the data in the read head does not change, it is sent to the CAN bus every y ms. Thus the control panel receives data even if the vehicle is stationary.

Synchronous

Switch position 7, see table below.

The read head sends data after the SYNC command from the control panel. The typical delay time after SYNC is 2 ms; the maximum delay time is 5 ms. By default, switch 1 - 3 = OFF, i.e., asynchronous data transfer 0 ms/10 ms.

Switch setting	DIP4-3	DIP4-2	DIP4-1	x ms/y ms
0	OFF	OFF	OFF	0 ms/10 ms
1	OFF	OFF	ON	5 ms/20 ms
2	OFF	ON	OFF	10 ms/50 ms
3	OFF	ON	ON	20 ms/50 ms
4	ON	OFF	OFF	Reserved
5	ON	OFF	ON	Reserved
6	ON	ON	OFF	Reserved
7	ON	ON	ON	SYNC mode

Data Protocols

Two data protocols are supported: CAN data protocol 1 and CAN data protocol 2.

The data protocols always have a length of 8 bytes. The data protocol is selected via the fourth switch of the 4-way DIP switch (1) on the PCB on the side of the read head.

DIP4-4 = OFF ... Can data protocol 1 DIP4-4 = ON ... CAN data protocol 2

6.3 Software Configuration

The read head is integrated into the network via an EDS file (electronic datasheet) with a project planning tool such as RSLogix 5000. The EDS file contains all information about device-specific parameters and operating modes.

Note

Downloading the EDS file

You can find the relevant EDS file in the **Software** section of the product detail page for the device.

To access the product detail page for the device, go to http://www.pepperl-fuchs.com and type e.g., the product description or the item number into the search function.

6.4 Data Protocols

Two data protocols are supported: data protocol 1 and data protocol 2.

The data protocols always have a length of 8 bytes. The data protocol is selected via the fourth switch of the 4-way DIP switch on the PCB on the side of the read head (see chapter 6.2).

- DIP4-4 = OFF ... CAN data protocol 1
- DIP4-4 = ON ... CAN data protocol 2

Data protocol 1

Bit	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 0	0	0	0	0	0	P18	P17	P16
Byte 1	P15	P14	P13	P12	P11	P10	P09	P08
Byte 2	P07	P06	P05	P04	P03	P02	P01	P00
Byte 3	0	0	SST	DB	ERR	OUT	0	0
Byte 4	0	SP6	SP5	SP4	SP3	SP2	SP1	SP0
Byte 5	0	0	0	0	0	0	0	0
Byte 6	0	0	0	0	0	0	0	0
Byte 7	0	0	0	0	0	0	0	0

Data protocol 2

Bit	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 0	0	0	SST	DB	ERR	OUT	0	0
Byte 1	P07	P06	P05	P04	P03	P02	P01	P00
Byte 2	P15	P14	P13	P12	P11	P10	P09	P08
Byte 3	0	0	0	0	0	P18	P17	P16
Byte 4	0	SP6	SP5	SP4	SP3	SP2	SP1	SP0
Byte 5	0	0	0	0	0	0	0	0
Byte 6	0	0	0	0	0	0	0	0
Byte 7	0	0	0	0	0	0	0	0



6.5 LED Status Indication

WCS3B-LS4xx*





Description of the LED Indicators

Item	Display	Designation	Color	Display	Meaning
1	PWR	Operating Indicator	green	On	Power on
2 (left)	COM	Data flow indicator	Yellow	On	Data transfer active
2 (right)	SPD	Velocity display	Yellow	On	When the limit speed is exceeded
3	STS	Fault indicator	red	On	System error
			red	Flashing	Read head out- side the code rail
2 and 3	2 and 3 STS and SPD, or COM Contamination		yellow and red	Flash alter- nately (f=1.5 Hz)	The read head optics are dirty
		Function indicator	yellow and red	for 2 secs	After switching on or a reset

7

EtherNet/IP Interface (LS5xx*)

The read head communicates with the controller (e.g., PLC) via EtherNet/IP. An object-oriented fieldbus system for exchanging data between nodes based on Ethernet communications.

The basic properties of the interface are:

- Transfer rate 10 Mbit/s or 100 Mbit/s, half or full duplex operation
- Automatic negotiation of the transfer rate and the duplex method (auto negotiation)
- Automatic setting for crossed lines (auto crossover)

EtherNet/IP protocol works according to the CIP protocol (Common Industrial Protocol) and is used to control, configure, monitor, and collect data. Time-sensitive data exchange (implicit messaging) takes place using the UDP/IP protocol and non-time-sensitive data exchange (explicit messaging) using the TCP/IP protocol.

The read head supports the following features:

- "Listen only," "Input only," and "Exclusive Owner" connection types
- Message transmission as "Multipoint data transfer" (Multicast) and "Point-to-point data transfer" (Unicast)
- Cycle time (request packet interval) ≥ 2 ms
- Dynamic Host Configuration Protocol (DHCP)
- Address Conflict Detection (ACD)

Note

Information on security

From a security perspective, the following precautions must be taken for the product by the responsible application operator:

- Physically secure the device against unauthorized access
- Ensure that the device is only operated on an isolated network without connection to the corporate network, internet, or cloud services;
 - there the device may only communicate with a higher-level controller, or with a defined, trusted circle of network participants
- Protect the power supply from unauthorized access:
 - The device has a recovery mode in which the firmware can be changed. The recovery mode is activated by lowering the input voltage to below 9 V!
 - Ensure an input voltage of at least 10 V in normal operation.





Caution!

7.1

Electrical Connection

Λ

Property damage and system malfunctions due to incorrect pinout

Incorrect assignment of the wire pairs to the respective pins can result in property damage and system malfunctions.

 Note the assignment of the wire pairs to the pins as shown in the respective wiring diagrams.

Connection diagram for WCS3B read head

The WCS3B-LS5* read head is connected to EtherNet/IP and the power supply via an 8-pin M12 socket with Y encryption.





Pins 6 and 8 are reserved for an internal interface and are connected to ground (-UB).



Note

A shielded twisted pair cable that meets at least the CAT 5e/CAT 6 specification is used to connect the read head to the control panel. The maximum recommended cable length is 75 m for CAT 5e and 55 m for CAT 6. Longer distances are possible provided that the respective specifications are observed. The connection can be implemented with various cable types available from Pepperl+Fuchs.

Y-Splitter

There are various options available for the electrical connection. A hybrid cable (see chapter 14.1) with a common data and supply line can be connected directly to the read head. Alternatively, data and supply lines can be routed separately with the Y-splitter.



Figure 7.2 V19SY-Y-V1D/V1: Y-splitter, M12 plug Y-encoded to M12 plug A-encoded and M12 socket D-encoded

You can obtain the appropriate connectors and cables from Pepperl+Fuchs, see chapter 14.1.



7.2 Hardware Configuration

If you have a read head with the "Display" option, a DIP switch with two switches S1D (2) is installed. This DIP switch allows you to change the display. The 4-way DIP switch (1) in the figure below does not work. The firmware parameters of the read head are set via the corresponding project planning software.



Figure 7.3 Configuration switch positions

- 1. Configuration switch S1, 4-way (no function)
- 2. Configuration switch S1D, 2-way (display)

Adjusting the Display

You can rotate the character position on the display 180° using the S1D DIP switch. This allows you to read the displayed values easily regardless of the installation position of the read head.

WCS3B									
Display	Configuration	switch "S1D"							
position	1 2		Comment						
0°	OFF	OFF	The displayed value can be read on a code rail mounted upright.						
180°	ON	ON	The displayed value can be read on a code rail mounted suspended.						

7.3 Software Configuration

The read head communicates with the control panel (e.g., PLC) via EtherNet/IP, an object-oriented fieldbus system for exchanging data between nodes based on Ethernet communications.

The read head is integrated into the network via an EDS file (electronic datasheet) with a project planning tool such as RSLOGIX5000. The EDS file contains all information about device-specific parameters and operating modes.



Downloading the EDS file

You can find the relevant EDS file in the **Software** section of the product detail page for the device.

To access the product detail page for the device, go to http://www.pepperl-fuchs.com and type e.g., the product description or the item number into the search function.



Setting the IP address

The read head is delivered in DHCP mode and waits for an address assignment from the control panel.

The following section describes the process of assigning an address via the **BOOT/DHCP Server** from Rockwell Automation as an example.

- 1. Connect the read head with the DHCP server.
- 2. Start the BOOT/DHCP server software.
- 3. Enter the following data in the Network Settings menu:
 - Subnet Mask "255.255.255.0"
 - Gateway "192.168.1.1"
 - The remaining fields are not filled in.

etwork Sett	ngs							
Defaults								
Subnet Ma	sk: 25	55	•	255		255	•	0
Gatew	ay: 19	92		168		1	ł,	1
Primary DI	s: 0)	•	0		0	•	0
Secondary DI	S: 0)	•	0		0	÷	0
Domain Nar	ne:	_	_		_		_	
	,	-	_	OK	_	1	C.	mool
	[1	ОК			Ca	ancel

4. Switch on the supply voltage to the read head.



5	BOOTP/DHCP Serve	er 2.3									
File	e Tools Help										
F	lequest History										
	Clear History Add to Relation List										
	(hr:min:sec) Type Ethernet Address (MAC) IP Address Hostname										
	15:33:51 DHCP 15:33:43 DHCP	00:0D:81:02:29:A1 00:0D:81:02:29:A1									
	1940 - 1976 - 1976 - 1976 - 1976 - 1976 - 1976 - 1976 - 1976 - 1976 - 1976 - 1976 - 1976 - 1976 - 1976 - 1976 -	24423677454367777757843									
F	lelation List										
	New Delete Ena	able BOOTP Enable DHCP Dis	sable BOOTP/DHCP								
	Ethernet Address (MAC	C) Type IP Address	Hostname	Description							
-9	tatus				Entries						
L	Inable to service DHCP	request from 00:0D:81:02:29:A1.			0 of 256						
					191 - 191 - 191 - 191 - 191 - 191 - 191 - 191 - 191 - 191 - 191 - 191 - 191 - 191 - 191 - 191 - 191 - 191 - 191						

→ The read head cyclically carries out DHCP requests. The MAC address of the read head is entered in the list in the **Request History** field.

- 5. Enter the desired IP address in the New Entry menu.
 - The software automatically adopts the MAC address of the read head.
 - The "hostname" function is not supported.
 - You may enter text under "Description."

New Entry	
Ethernet Address (MAC):	00:0D:81:02:29:A1
IP Address:	192.168.1.2
Hostname:	
Description:	
	OK Cancel

- 6. Confirm the entries of the address data using **OK**.
 - → The IP address is assigned to the read head on the next DHCP request. The new address data will be displayed in the **Relation List** field.

BOOTP/DHCP Server 2.3	
File Tools Help	
Request History	
Clear History Add to Relation List	
(hr:min:sec) Type Ethernet Address (MAC) IP Address Hostname	
15:35:15 DHCP 00:0D:81:02:29:A1 192.168.1.2	
15:36:15 DHCP 00:0D:81:02:29:A1 15:34:59 DHCP 00:0D:81:02:29:A1	
15:34:51 DHCP 00:0D:81:02:29:A1	
15:34:47 DHLP 00:0D:81:02:29:A1 15:34:39 DHCP 00:0D:81:02:29:A1	_
15:34:07 DHCP 00:0D:81:02:29:A1	~
Ethernet Address (MAC) Type IP Address Hostname Description	
00:00:81:02:29:A1 DHCP 192:168.1.2	
Status	Entries
Sent 192.168.1.2 to Ethernet address 00:0D:81:02:29:A1	1 of 256

7. Press the Disable BOOTP/DHCP key in the Relation List field.

 \mapsto In this way, the assigned IP address is saved permanently in the read head.

BOOTP/DHCP Server 2.3			
File Tools Help			
Request History			
Clear History Add to Relation List			
(hr:min:sec) Type Ethernet Address (MAC)	IP Address	Hostname	<u> </u>
15:35:15 DHCP 00:0D:81:02:29:A1 15:35:15 DHCP 00:0D:81:02:29:A1	192.168.1.2		
15:34:59 DHCP 00:0D:81:02:29:A1			
15:34:51 DHCP 00:0D:81:02:29:A1 15:34:47 DHCP 00:0D:81:02:29:A1			
15:34:39 DHCP 00:0D:81:02:29:A1			
15:34:07 DHCP 00:0D:81:02:29:A1			×
New Delete Enable BOOTP Enable DHCP D	isable BOOTP/DHCP		
Ethernet Address (MAC) Type IP Address	Hostname	Description	
00:0D:81:02:29:A1 DHCP 192.168.1.2			
Status			Entries
[Disable DHCP] Command successful			1 of 256
·			

2024-07

7.4 Data Protocols

EtherNet/IP Objects

All the data and functions of the read head are defined via objects in accordance with the EtherNet/IP standards. The read head corresponds to the "Encoder Device Type 0x22" device profile.

The read head supports the following listed standard and product-specific classes.

Standard Classes

Class ID	Class name
0x01	Identity Object
0x02	Message Router Object
0x04	Assembly Object
0x06	Connection manager object
0xF5	TCP/IP Interface Object
0xF6	Ethernet Link Object
0x48	Quality of service

Product-specific class

Class ID	Class name
0x23	Position Sensor Object

The parameters are not directly addressable from the network with the "Set" or "Get" attribute services. Access is via assembly objects (class code 0x04)

Cyclic Data Communication with Assembly Objects (Class Code 0x04)

Assemblies are special CIP objects used for cyclic data communication (implicit messaging). Assemblies are composed of one or more attributes of various objects. These objects allow you to send or receive data from multiple objects via a connection. The composition of the assemblies is fixed in the read head and cannot be modified by the user.

Instance no.	Description	Size [byte]	Attribute	Attribute ID	Data Type
1	ltem	4	Position Value Signed	10	DINT 4 bytes
100	Status, position, velocity, faults	7	Status word	100	USINT 1 byte
			Position Value Signed	10	DINT 4 bytes
			Velocity Value	101	USINT 1 byte
			Error Value	102	USINT 1 byte

Input Assemblies

Addresses required for the various connection types

The connection type defines the connection between the control system (originator), in this case the controls, and the target device (target), in this case the read head. The following options are available for data traffic.

Data from the control system to the target device

Instance no. (dec.)	Size [byte]	Connection Type
192	0	Listen only
193	0	Input only

Data from the target device to the control system

Instance no. (dec.)	Size [byte]	Assemblies	
1	4	Item	
100	7	Status, position, velocity, faults	

Attributes of the Position Sensor Object (Class ID 0x23)

Class attributes

ID	Name	Access	Data Type	Size [byte]	Description
1	Revision	-	UINT	2	Object inspec- tion

Standard instance attributes for object 0x23

ID	Attribute	Access	Data Type	Size [byte]	Description
10	Position Value Signed	-	DINT	4	Position value signed

The parameters are not directly addressable from the network with the "Set" or "Get" attribute services. You can change the parameters by using assemblies.

Specific read head attributes

ID	Attribute	Access	Data Type	Size [byte]	Description
100	Status word	-	USINT	1	Status information
101	Velocity	-	USINT	1	Velocity in dm/s
102	Error	-	USINT	1	Fault if content $\neq 0$

Basic data structure

1 byte = 8 bit value

Byte 4	Byte 3	Byte 2	Byte 1
For example: XP31 XP24 MSB (most significant byte)	For example: XP23 XP16	For example: XP15 XP08	For example: XP07 XP00 LSB (least significant byte)



Position data X: Position Value Signed (ID 10)

Size	Туре	
4 byte consistent	Input Data	

32 bit X data LSB first LSB = least significant byte with resolution 0.8 mm: $L_{max} = 314.5 \text{ m} = 314500 \text{ mm}$

Data for attribute 10

	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	XP07	XP06	XP05	XP04	XP03	XP02	XP01	XP00
Byte 2	XP15	XP14	XP13	XP12	XP11	XP10	XP09	XP08
Byte 3	XP23	XP22	XP21	XP20	XP19	XP18	XP17	XP16
Byte 4	XP31	XP30	XP29	XP28	XP27	XP26	XP25	XP24

Content

Status: Status word (ID 100)

Size	Туре	Content
1 byte	Input Data	8 bit status

If the ERR bit is set, there is an error. The error number is transmitted to the "Error value (ID 102)" attribute.

Data for attribute 100

	Content	
Bit no.	Byte 1 Status	Function
1	ERR	Error message, error code in ERR00 – ERR07
2	OUT	Read head partially outside the code rail No valid position avail- able.
3	OUTALL	Read head completely outside the code rail.
4	DB	Diagnostic bit. Read head dirty.
5	SST	Speed status. If the speed status = 1 then the current velocity is unknown. The specified velocity value is invalid.
6	Reserved	-
7	Reserved	-
8	Reserved	-

Speed: Velocity Value (ID 101)

Size	Туре
1 byte consistent	Input Data

Content

8 bit speed data LSB first Information in dm/s

Data for attribute 101

	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	SP07	SP06	SP05	SP04	SP03	SP02	SP01	SP00



Faults: Error Value (ID 102)

Size	Туре	Content
1 byte consistent	Input Data	8 bit fault data

Data for Attribute 102

		-						
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	ERR7	ERR6	ERR5	ERR4	ERR3	ERR2	ERR1	ERR0

A binary encoded value in attribute 100 means that the corresponding fault is active.

	Content	
Value	Byte 1 Status	Function
0	Error 0	-
1	Error 1	Current position cannot be determined.
2	Error 2	Current position cannot be determined.
3	Error 3	Fault in the RAM working memory.
4	Error 4	Fault in the EPROM memory or in the decoder.
5	Error 5	Fault in the ROM memory.
6	Error 6	-
7	Error 7	-





7.5 LED Status Indication

WCS3B-LS5xx*



Description of the LED Indicators

Item	Display	Designation	Color	Display	Meaning
1	STS	Status indicator	green	On	Code rail detected, normal function
			red	On	System error
			red	Flashing	No code rail detected
2	LINK	Ethernet link	green	On	Fieldbus connection exists
3	ACT	Ethernet RX/TX	Yellow	Flashing	Data transfer
4	FB ST	Ethernet commu- nication	red	On	Communication errors

2024-07

8 **PROFINET Interface (LS6xx*)**

The WCS3B-LS6xx* read heads are PROFINET I/O devices that communicate cyclically with the assigned PROFINET I/O controller during operation.

The PROFINET interface of the WCS3B-LS6xx* read heads supports:

- A transfer rate of 100 Mbit/s
- The real-time category RT
- The range of functions in accordance with Conformance Class B
- The identification and maintenance functions (I&M) IM0 IM4

Note

Information on security

From a security perspective, the following precautions must be taken for the product by the responsible application operator:

- Physically secure the device against unauthorized access
- Ensure that the device is only operated on an isolated network without connection to the corporate network, internet, or cloud services;
 - there the device may only communicate with a higher-level controller, or with a defined, trusted circle of network participants
- Protect the power supply from unauthorized access:
 - The device has a recovery mode in which the firmware can be changed. The recovery mode is activated by lowering the input voltage to below 9 V!
 - Ensure an input voltage of at least 10 V in normal operation.

8.1 Electrical Connection



Caution!

Property damage and system malfunctions due to incorrect pinout

Incorrect assignment of the wire pairs to the respective pins can result in property damage and system malfunctions.

 Note the assignment of the wire pairs to the pins as shown in the respective wiring diagrams.

Connection diagram for WCS3B read head

The WCS3B-LS6* read head is connected to PROFINET and the power supply via an 8-pin M12 socket with Y encryption.



Figure 8.1 WCS3B, PROFINET interface

Pins 6 and 8 are reserved for an internal interface and are connected to ground (-UB).



Note

A shielded twisted pair cable that meets at least the CAT 5e/CAT 6 specification is used to connect the read head to the control panel. The maximum recommended cable length is 75 m for CAT 5e and 55 m for CAT 6. Longer distances are possible provided that the respective specifications are observed. The connection can be implemented with various cable connections available from Pepperl+Fuchs.

Y-splitter

There are various options available for the electrical connection. A hybrid cable (see chapter 14.1) with a common data and supply line can be connected directly to the read head. Alternatively, data and supply lines can be routed separately with the Y-splitter.



Figure 8.2 V19SY-Y-V1D/V1: Y-splitter, M12 plug Y-encoded to M12 plug A-encoded and M12 socket D-encoded

You can obtain the appropriate connectors and cables from Pepperl+Fuchs, see chapter 14.1.



8.2 Hardware Configuration

If you have a read head with the "Display" option, a DIP switch with two switches S1D (2) is installed. This DIP switch allows you to change the display. The 4-way DIP switch (1) in the figure below does not work. The firmware parameters of the read head are set via the corresponding project planning software.



Figure 8.3 Configuration switch positions

- 1. Configuration switch S1, 4-way (no function)
- 2. Configuration switch S1D, 2-way (display)

Adjusting the Display

You can rotate the character position on the display 180° using the S1D DIP switch. This allows you to read the displayed values easily regardless of the installation position of the read head.

WCS3B			
Display	Configuration "S1D"	on switch	
position	1	2	Comment
0°	OFF	OFF	The displayed value can be read on a code rail mounted upright.
180°	ON	ON	The displayed value can be read on a code rail mounted suspended.

8.3 Software Configuration

PROFINET is an open standard for industrial automation based on industrial Ethernet. PROF-INET integrates information technology with established standards such as TCP/IP and XML in automation technology.

Within PROFINET, PROFINET IO is the communication concept for the construction of decentralized applications. This means that read heads are integrated through PROFINET IO. The familiar IO view of PROFIBUS DP is used where the usable data of the read heads is transferred to the process image of the control panel in cycles. PROFINET IO is a device model consisting of slots and channels, which is based on the main features of PROFIBUS DP. The properties of the read heads are written in a Generic Station Description Markup Language (GSDML) based on XML. PROFINET IO is engineered in such a way that the read heads are assigned to a control panel in project planning.

PROFINET IO distinguishes between the following three device types:

- IO controller: Controller that executes the automation program.
- IO device: Decentrally assigned field device that is assigned to an IO controller.
- IO supervisor: Programming unit/PC with commissioning and diagnostic functions.

The read head functions as a PROFINET I/O device that communicates cyclically with the assigned PROFINET I/O controller during operation.

Project planning using device description

The read head is integrated into the project planning tool by way of a device description. The field device properties are described in the GSDML file. The GSDML file contains the data of the field device that you need to operate the device in a PROFINET network. You import the GSDML file into a project planning tool that you use to configure the read head settings. Once project planning is complete, the control panel receives the project planning data and configuration data.

Downloading the GSDML file

You can find the relevant GSDML file in the **Software** section of the product detail page for the device.

To access the product detail page for the device, go to http://www.pepperl-fuchs.com and type e.g., the product description or the item number into the search function.

PROFINET address and identifying a device

Every read head has a unique device identification. This device identification consists of the following:

- A unique MAC address. This MAC address is printed on the back of the device.
- A device name. The default device name is wcs3b-ls610.
- An IP address. The default IP address is 192.168.2.2.





Identification & maintenance—calling up and editing data

Identification & maintenance data (I&M data) is information stored in a device. I&M data uniquely identifies a device within a plant. The identification data (I data) includes information about the device, for example the item number and device name. Identification data cannot be changed.

Maintenance data (M data) includes information about the device within the plant, for example the installation location and installation date. Maintenance data is initially stored in the device during installation. Maintenance data can be changed.

The Step7 software from Siemens can be used to display and change the I&M data.

- 1. To do so, open the hardware configuration **HW Config** and call up the "Target system" menu.
- 2. Open one of the following functions:
 - "Download module identification"
 - "Download module identification in PG"

	Offline	Include	ONLINE	
Plant designation:	plant 1	\gg \square \gg	plant 5	
Location designation:	position 1	»г»	position 1	
nstallation date:	09/22/2011	» ┌ »	09/22/2011	
Additional information:	RFID evaluation unit 1 💻	» F »	RFID evaluation unit 1	

Figure 8.4

- 3. Depending on the requirement, read or edit the following I&M data:
 - I&M data 1: plant designation, location designation
 - I&M data 2: installation date
 - I&M data 3: additional information

8.4 Data Protocols

The WCS3B-LS6xx* read heads are PROFINET I/O devices that communicate cyclically with the assigned PROFINET I/O controller during operation.

The PROFINET interface of the WCS3B-LS6xx* read heads supports:

- A transfer rate of 100 Mbit/s
- The real-time category RT
- The range of functions in accordance with Conformance Class B
- The identification and maintenance functions (I&M) IM0 IM4

Modules with response telegram

The following modules enable read head data to be retrieved using PROFINET.

Position Data X Module

Size	Туре	Content
2 words, consistent	Input data	32-bit X data MSB first MSB = \mathbf{m} ost \mathbf{s} ignificant \mathbf{b} yte Resolution: 0.8 mm, binary coded L _{max =} 314.5 m = 314500 mm

Response

	Content			
Bit no.	Word 1 X data	Word 2 X data		
1	XP16	XP00		
2	XP17	XP01		
3	XP18	XP02		
4	0	XP03		
5	0	XP04		
6	0	XP05		
7	0	XP06		
8	0	XP07		
9	0	XP08		
10	0	XP09		
11	0	XP10		
12	0	XP11		
13	0	XP12		
14	0	XP13		
15	0	XP14		
16	0	XP15		



Speed data module

Size	Туре	Content
1 byte	Input data	8 bit speed data Resolution: 0.1 m/s, binary coded Speed of 0 12.5 m/s Example: Speed = 4.7 m/s> speed output = 47 with resolu- tion 0.1 m/s 126 for speed > 12.5 m/s 127 for unknown speed

Response

	Content
Bit no.	Word 1 Speed
1	SP00
2	SP01
3	SP02
4	SP03
5	SP04
6	SP05
7	SP06
8	SP07

Error message module

Size	Туре	Content
1 byte	Input data	8 bit numerical value ERR message from 0 7 Example: ERR message = 00000001 = Error 1 Error 1 corresponds to "Current position cannot be deter- mined"

ERR messages

	Content	
Error	Byte 1 Status	Function
0	ERR00	-
1	ERR01	Current position cannot be determined
2	ERR02	Current position cannot be determined
3	ERR03	Fault in the working memory (RAM)
4	ERR04	Fault in the EPROM memory or in the decoder
5	ERR05	Fault in the ROM memory
6	ERR06	-
7	ERR07	-

Status module

Size	Туре	Content
1 byte	Input data	8 bit status

Response

	Content	
Bit no.	Byte 1 Status	Function
1	ERR	Error message, see error codes ERR00 – ERR07
2	OUT	Read head partially outside the code rail. No valid position available.
3	OUTALL	Read head completely outside the code rail.
4	DB	Diagnostic bit. Read head dirty.
5	SST	Speed status
6	Reserved	-
7	Reserved	-
8	Reserved	-



8.5 LED Status Indication

WCS3B-LS6xx*



Description of the LED Indicators

Item	Display	Designation	Color	Display	Meaning
1	STS	Status indicator	green	On	Code rail detected, normal function
			red	On	System error
			red	Flashing	No code rail detected
2	LINK	Ethernet link	green	On	Fieldbus connec- tion exists
3	ACT	Ethernet RX/TX	Yellow	Flashing	Data transfer
4	FB ST	Ethernet communication	red	On	Communication errors

9 EtherCAT® Interface (LS7xx*)

The WCS3B-LS7xx* read heads provide an EtherCAT 1 The device communicates cyclically with the assigned EtherCAT® controller during operation.

The EtherCAT® interface of the WCS3B-LS6xx* read heads supports:

- A transfer rate of 100 Mbit/s
- Data transfer via "CANopen over EtherCAT®" (CoE)
- Firmware update via "File access over EtherCAT®" (FoE)
- Selectable modules with data structure
 - Standard
 - Backward-compatible with older WCS gateways WCS-ECG110
- End node in the line structure. Combined Y-plug with data port and accessory cable, Tadapter for separation on two standardized M12-connections 4-pin

Note

Information on security

From a security perspective, the following precautions must be taken for the product by the responsible application operator:

- · Physically secure the device against unauthorized access
- Ensure that the device is only operated on an isolated network without connection to the corporate network, internet, or cloud services;
 - there, the device may only communicate with a higher-level controller, or with a defined, trusted circle of network participants
- Protect the power supply from unauthorized access:
 - The device has a recovery mode in which the firmware can be changed. The recovery mode is activated by lowering the input voltage to below 9 V!
 - Ensure an input voltage of at least 10 V in normal operation
 - Ensure that only authorized users have access to the FoE feature on the network
 - The device supports file access over EtherCAT® (FoE). Firmware changes are always possible with the FoE function!

The EtherCAT® controller can be used to query the firmware version during initialization to detect firmware changes.

9.1

Power Source



Caution!

Property damage and system malfunctions due to incorrect pinout

Incorrect assignment of the wire pairs to the respective pins can result in property damage and system malfunctions.

• Note the assignment of the wire pairs to the pins as shown in the respective wiring diagrams.

Connection diagram for WCS3B read head

The WCS3B-LS7* read head is connected to EtherCAT and the voltage supply via an 8-pin M12 socket with Y encryption.





Figure 9.1 EtherCAT Interface

Note

A shielded twisted-pair cable that meets at least the CAT 5e/CAT 6 specification is used to connect the read head to the control panel. The maximum recommended cable length is 75 m for CAT 5e and 55 m for CAT 6. Longer distances are possible provided that the respective specifications are observed. The connection can be implemented with various cable connections available from Pepperl+Fuchs.





Y-Splitter

There are various options available for the electrical connection. A hybrid cable (see chapter 14.1) with a common data and supply line can be connected directly to the read head. Alternatively, data and supply lines can be routed separately with the Y-splitter.



Figure 9.2 V19SY-Y-V1D/V1: Y-splitter, M12 plug Y-coded to M12 plug A-coded and M12 socket Dcoded

You can obtain the appropriate connectors and cables from Pepperl+Fuchs, see chapter 14.1.

9.2 Hardware Configuration

The WCS3B read head with velocity output features an additional 24 VDC output, which transmits a signal in the event that a limit speed is exceeded. The limit speed can be configured on the 4-way DIP switch in the read head. The limit speed is set to 0.7 m/s on delivery.



Figure 9.3 Configuration switch positions

- 1. Configuration switch S1, 4-way (limit speed)
- 2. Configuration switch S1D, 2-way (display)

Set the Limit Speed

	S1			
Limit speed v _{limit}	1	2	3	4
0.7 m/s	Х	Х	OFF	OFF
2.0 m/s	Х	Х	OFF	ON
3.0 m/s	Х	Х	ON	OFF
4.0 m/s	Х	Х	ON	ON

The limit speed is output digitally via pin 8 of the 8-pin M12 socket with Y-coding:

 U_v (pin 8) = operating voltage $U_B \rightarrow v_{current} < v_{limit}$

 U_v (pin 8) = floating (high impedance) --> $v_{current} \ge v_{limit}$



i

Note

LED limit speed status display

Yellow LED off: Limit speed exceeded

Note

The set limit speed is not noted on the nameplate of the read head.

Adjusting the Display

You can rotate the character position on the display 180° using the S1D DIP switch. This allows you to read the displayed values easily regardless of the mounting position of the read head.

WCS3B					
Display posi-	Configuration switch "S1D"				
tion	1	2	Comment		
0°	OFF	OFF	The displayed value can be read on a code rail mounted upright.		
180°	ON	ON	The displayed value can be read on a code rail mounted suspended.		

9.3 EtherCAT® Communication Methods

For the CANopen over EtherCAT® (CoE) protocol supported by the read head, most objects are supported for the communication layer according to the CIA's DS301 CANopen standard by EtherCAT®. These are mostly objects for setting up communication between the control unit and the bus node.

The EtherCAT® protocol uses two different types of transfer to transfer the device and user protocols, such as the CoE protocol. These two transfer types are the mailbox telegram protocol for transmitting acyclic data and the process data telegram protocol for transmitting cyclic data.

For the CoE protocol, these two transfer types are used for the different types of CANopen transfer. They are used as follows:

• Mailbox Telegram Protocol:

This transfer type is used to transfer the service data objects (SDO) defined under CANopen. Service data objects control the parameter data exchange, e.g., the acyclic execution of the preset function. They are transmitted in EtherCAT® in SDO frames.

• Process Data Telegram Protocol:

This transfer type is used to transfer the process data objects (PDO) defined under CANopen. Process data objects manage the process data exchange, e.g., the cyclic transfer of the position value. They are transmitted in EtherCAT® in PDO frames.

PEPPERL+FUCHS

9.4 Software Configuration

The following pages provide an example of how to configure a read head using the "TwinCAT®" project planning and development environment from Beckhoff Automation GmbH.

Configuration with TwinCAT® 3

There are two possibilities for the configuration of the EtherCAT® readhead:

- **Offline configuration**, if configuration is to take place before the plant creation, e.g., on a laptop as a programming system
- Online configuration via a scan of the existing network (preferred), if the control panel is already connected to the EtherCAT® system and all components of the EtherCAT® network are ready for operation.

Sample online configuration

The following describes the online configuration.

Here, all available nodes are automatically integrated into the EtherCAT® network by the master.

Device Description File—ESI File

With EtherCAT®, all process data and the parameters are described in objects. The compilation of all the process data and parameters (the object directory) is stored in an EtherCAT® description file (ESI file, EtherCAT® slave information file).

This ESI file contains all objects with index, subindex, name, data type, data access, and the value range with minima, maxima, and default value. The ESI file describes the complete functionality of the device. It is possible to adapt the communication between the device and the control via these objects.

Downloading and Installing the ESI File

You can find the relevant ESI file in the **Commissioning** section of the product detail page for the device. To access the product detail page for the device, go to http://www.pepperl-fuchs.com and use the search function to search by the product description or the item number.

Install the ESI file using your controller manufacturer's configuration software. For TwinCAT®, the ESI file must normally be copied into the installation folder. After installation, the object data of the ESI file is available in the hardware catalog.





Creating a New Project in TwinCAT® 3

To connect your read head to the controller, you must create a new project in TwinCAT® 3.

- 1. Start TwinCAT® 3 on your PC.
- 2. On the start page, select the option "New TwinCAT Project..."
- 3. Select "TwinCAT XAE Project (XML format)," enter a project name, and confirm your selection with "OK."

New Project						? ×
▶ Recent		Sort by: Default	• # E		Search (Ctrl+E)	، م
 Installed TwinCAT Measurement 		TwinCAT XAE P	roject (XML format)	TwinCAT Projects	Type: TwinCAT Projects TwinCAT XAE System Manager	
Bode Plot FilterDesigner					Configuration	
Scope TwinCAT Projects						
TwinCAT PLC						
Not finding what you are Open Visual Studio	looking for? Installer					
<u>N</u> ame: Twi	nCAT Project1					
Location: C:\	Jsers\User\Docun	nents\TcXaeShell		•	Browse	
Solution name: Twi	nCAT Project1				 Create <u>directory</u> for solution 	
					 Create new <u>Git</u> repository 	
					ОК	Cancel

Figure 9.4 Creating a New Project



It is generally possible to use the TwinCAT locally or remotely. If the TwinCAT system including user interface is installed on the relevant controller (locally), TwinCAT can be used locally. In this example, TwinCAT is used locally.


Integrate the controller in TwinCAT® 3

1. Install the ESI file of the module family in TwinCat®. In TwinCAT® 3, the ESI file is normally inserted in the installation folder C:\TwinCAT\3.1\Config\Io\EtherCAT®.

→ After you restart TwinCAT®, the modules will be available in the hardware catalog.

2. Start TwinCat and open a new project.



After creating the project, you must first take the following steps to establish communication with the controller.

- 3. In the left-hand working area of "Solution Explorer", switch to the option "I/O."
- 4. Right-click on "Devices" and select the "Add New Item..." option.



Figure 9.5

 \mapsto The "Insert Device" selection window opens.

5. Select "EtherCAT® Master" and confirm with "OK."



Profibus DP Profinet CANopen	maaon	
DeviceNet Second Strength Second Strengt Second Strength Second Strength Second S	ice us are	Target Type PC only CX only BX only All

Figure 9.6

→ The EtherCAT® controller is created in the "Solution Explorer" project tree with the designation "Device 1 (EtherCAT®)."

6. In the "Solution Explorer" project tree, select the controller with the designation "Device 1 (EtherCAT®)" with a left mouse click.

 \mapsto The properties page opens on the right side of the window.

7. Click the "Adapter" tab, followed by "Search..." to select the port for your controller.

TwinCAT Project1 - TcXaeShell				
File Edit View Project Build De	bug TwinCAT TwinSA	AFE PLC Team	Scope T	ools Window Help
◎ - ○ 🎨 - 🎦 - 😩 🗎 🗳 ১	日白ッ・ペー	Release 🔹	TwinCAT RT (x6	i4) ▼ ► Attach ▼
Build 4024.11 (Loaded) 🔻 🚽 🔛 🎑	🔳 🌮 🔨 🎯 🛃	🖌 🖌 TwinCAT Pro	oject1 •	<pre><local></local></pre>
Solution Explorer 🝷 🖡	K TwinCAT Project1 😐	×		
○ ○ ☆ # · · · · · · · · · · · · · · · · · ·	General Adapter Et	nerCAT Online CoE	Online	
Search Solution Explorer (Ctrl+ü)	Network Adap	ter		
Solution 'TwinCAT Project1' (1 project)		OS (NDIS)	O PCI	ODPRAM
TwinCAT Project1	Description:	Ethernet (TwinCA	T-Intel PCI Ether	net Adapter (Gigabit))
SYSTEM	Device Name		780-1403-4740-	897E-BE65014D0EE8
	PCI Buc/Slot	1221102.(01021		Soarch
SAFETY	T CF Dua/Siot			Search
90. C++	MAC Address:	8c ec 4b f / e0 9b		Compatible Devices
ANALYTICS	IP Address:	192.168.3.10 (255	5.255.255.0)	
		Promiscuous M	lode (use with W	ireshark only)
 Devices Device 1 (EtherCAT) 		Virtual Device I	Names	
a a a a a a a a a a a a a a	Adapter Refer	ence		
🕏 SyncUnits	Adanter			\vee

- Figure 9.7
- 8. In the "Device Found At" dialog, select the port for your controller; in this example, the "Ethernet (TwinCAT-Intel PCI Ethernet adapter (Gigabit))" is used.



Figure 9.8

9. Click on the "OK" button to confirm the selection.





Adding the Read Head to the Project

1. To add the read head to the controller, right-click on "Device 1 (EtherCAT®)" in the project tree. Activate the "Scan" function with the right mouse button.

Solution Explorer	џ ×	TwinCAT Project1	+ X
◎ ◎ 🏠 🛱 ▾ 💿 ▾ 🗗 🎾 🗖	•	General Adapter	EtherCAT Online CoE - Online
Search Solution Explorer (Ctrl+ü)	P	Name:	Device 1 (EtherCAT)
Solution 'TwinCAT Project1' (1 project	ct)	Object Id:	0x03010010
 WillCAT HOJECT SYSTEM 		Туре:	EtherCAT Master
		Comment:	
SAFETY			
ANALYTICS			
Devices			Disabled
Device 1 (EtherCAT)	*כ	Add New Item	Ins
∎ + Image Image-Info	t o	Add Existing Item	Shift+Alt+A
SyncUnits	×	Remove	Del
 Inputs Outputs 		Change NetId	
InfoData		Save Device 1 (EtherC	CAT) As
🍟 Mappings		Append EtherCAT Cm	nd
		Append Dynamic Co	ntainer
		Online Reset	
		Online Reload	
	***.	Online Delete	
		Scan	
		Change Id	

Figure 9.9

→ All EtherCAT® nodes are read in and automatically added to the I/O configuration. The WCS3B-LS710x read head appears in the project tree below the EtherCAT® controller as Box 1 (WCS3B-LS710x).



Figure 9.10

2. Click on the entry "Box 1 (WCS3B-LS710x)" using the left mouse button.

 \mapsto The menu "TwinCAT Project 1" is displayed.

3. To configure the process data, go to the "Process Data" tab.



Tv	vinCAT Pr	roject1	+ ×													
	General	EtherCA	T DC	Process D	Data Plc		ts Startu	p CoE -	Onlin	e Online						
	Sync Ma	anager:			PDO	List:										
	SM	Size	Type	Flags	Inde	x	Size	Name				Flags		SM	SU	
	0	128	MbxOut	9	0x1/	10	1.0	Status				MF		3	0	
	1	128	MbxIn		0x1/	A11	4.0	Position	bina	y coded		F		3	0	
	2	0	Outputs	\bigcirc	0x1/	12	4.0	Position	gray	code		F			0	
	3	6	Inputs-	-2	0x1/	A13	1.0	Speed				F		3	0	
					0x1/	A14	1.0	Error Co	ode			F			0	
	<			>												
	PDO As	signmen	t (0x1C13):	PDO	Conten	t (0x1A10)									
	✓0x1A	10			Inde	X	Size	Offs	Na	ime			Туре		Default (ł	hex)
		12	-(3)		0x60	010:01	0.1	0.0	en	or			BIT			
	✓ 0x1A	13	\bigcirc		0x60	010:02	0.1	0.1	ou	t			BIT			
	0x1A	14			0x60	010:03	0.1	0.2	ou	tali			BIT			
					0x0	10:04	0.1	0.3	ab	•			BIT			
	Doumle	ad			Decid	- 6 1										
	Downic				Pred	ennea i	PDO Assigi	nment: (n	ione)							
		JO Assig	nment		Load	PDO ir	nfo from de	vice								
		DO Confi	guration		Sync	Unit A	ssignment.									
	amo			Onlino		Т	-	Sizo		>Addro	In/Out	Lisor ID	Linkod	to		
				onnine		נין	ит П	0.1		20.0	Involut	o sei iD	Linkeu	10		
	enor			0		D	н т	0.1		39.0	input	0				
	out			0		В	н т	0.1		39.1	Input	0				
	outAll			0		В		0.1		39.2	Input	0				
1	db			0		В	IT	0.1		39.3	Input	0				
1	sst			0		В	IT	0.1		39.4	Input	0				
1	Position	n (binary	/)	278082		U	DINT	4.0		40.0	Input	0				
-	Speed			0		U	SINT	1.0		44.0	Input	0				
-	WcState	е		0		В	IT	0.1		1522.1	Input	0				
-		oggle		0		В	IT	0.1		1524.1	Input	0				
-	State			8		U	INT	2.0		1548.0	Input	0				
,	AdsAd	dr		192.168.2	40.99.2.	1: A	MSADDR	8.0		1550.0	Input	0				
1								-								

- 4. In the "Sync Manager" section, click on the "Inputs" option and select your input PDOs in the "PDO Assignment" area.
- 5. For example, clear the "0x1A12" check box if position data in gray code should not be transferred to the EtherCAT® controller.
- 6. To set the TwinCAT system manager to "Config Mode", restart TwinCAT. To do this, click the "Restart TwinCAT (Config Mode)" button (1). Click "OK" to confirm the dialog (2).



Figure 9.11

- Confirm the message "Load I/O Devices" with "OK."
 → The message "Activate Free Run" appears.
- 8. Confirm the dialog with "Yes" to allow the processing of input data within the "Config Mode."





Figure 9.12

2024-07

9.5 Data Protocols

For the CANopen over EtherCAT® (CoE) protocol supported by the read head, most objects are supported for the communication according to the CIA's DS301 CANopen standard by EtherCAT®.

The EtherCAT® protocol uses two different types of transfer to transmit the device and user protocols, such as the CoE protocol. These two transfer types are the mailbox telegram protocol for transmitting acyclic data and the process data telegram protocol for transmitting cyclic data.

For the CoE protocol, these two transfer types are used for the different types of CANopen transfer. They are used as follows:

• Mailbox Telegram Protocol:

This transfer type is used to transfer the service data objects (SDO) defined under CANopen. Service data objects control the parameter data exchange, e.g., the acyclic execution of the preset function. They are transmitted in EtherCAT® in SDO frames.

• Process Data Telegram Protocol:

This transfer type is used to transfer the process data objects (PDO) defined under CANopen. Process data objects manage the process data exchange, e.g., the cyclic transfer of the position value. They are transmitted in EtherCAT® in PDO frames.

In the case of CANopen over EtherCAT® (CoE), all parameters are located in what is known as the object directory. They can be changed or read there using the SDO (service data object) telegram, specifying their index and subindex.

The following table shows an overview of the supported indexes in the communication profile area:

Index (hex) box	Object name	Link
Default objects		
0x1000	Device type	See "Object 0x1000—Device Type" on page 72
0x1008	Device name	See "Object 0x1008: Manufacturer Device Name" on page 72
0x1009	Hardware version	See "Object 0x1009: Hardware ver- sion" on page 72
0x100A	Software version	See "Object 0x100A: Software Ver- sion" on page 73
0x1018	Identify object	See "Object 1018: Identify Object" on page 73
0x1C00	Sync manager Communication type (sync manager type)	See "Object 1C00: Sync Manager Communication Type" on page 73
0x1C12	RxPDO assign	See "Object 1C12: RxPDO Assign- ment" on page 74
0x1C13	TxPDO assign	See "Object 1C13: TxPDO assign- ment" on page 74
Profile-specific objects		
0xF000	Modular device profile	See "Object F000: Modular Device Profile" on page 75
Manufacturer-specific ob	jects	
0x3000	Pepperl+Fuchs serial num- ber	See "Object 3000: Pepperl+Fuchs Serial Number" on page 76

Object directory



For the tables below, the following applies:

ro (= read only) means read-only access

rw (= \mathbf{r} ead \mathbf{w} rite) means reading and writing permitted

Object 0x1000—Device Type

This object specifies which device type it relates to.

Index	Subindex	Object name	Data type	Default	Access
0x1000	0x00	Device type	unsigned32	0x1389(5001)	ro

Object 0x1008: Manufacturer Device Name

This object specifies the manufacturer-specific device name.

Index	Subindex	Object name	Data type	Default	Access
0x1008	0x00	Manufacturer Device Name	string	-	ro

Object 0x1009: Hardware version

This object specifies the status of the hardware version of the read head.

Index	Subindex	Object name	Data type	Default	Access
0x1009	0x00	Hardware ver- sion	string	-	ro

Object 0x100A: Software Version

This object specifies the status of the software version.

Index	Subindex	Object name	Data type	Default	Access
0x100A	0x00	Software ver- sion	string	-	ro

Object 1018: Identify Object

This object provides general information about the device. Keep these values available for service requests.

Index	Subindex	Object name	Data type	Default	Access
0x1018	0x00	Highest sup- ported subindex (Highest subin- dex supported)	unsigned8	0x04	ro
	0x01	Manufacturer ID (vendor ID)	unsigned32	0x000000AD	ro
	0x02	Device ID (prod- uct code)	unsigned32	0x06000002	ro
	0x03	Version number (revision)	unsigned32	0x0000001	ro
	0x04	Serial number	unsigned32	Each read head has its own serial number.	ro

Object 1C00: Sync Manager Communication Type

This object displays the assignment of the four EtherCAT sync managers.

Index	Subindex	Object name	Description	Data type	Default	Access
0x1C00	0x00	Sync manager	Number of sync manag- ers	unsigned8	0x04	ro
	0x01	Subindex 001	Sync manager type chan- nel 1: Mailbox write per- mission	unsigned8	0x01	ro
	0x02	Subindex 002	Sync manager type chan- nel 2: Mailbox read per- mission	unsigned8	0x02	ro
	0x03	Subindex 003	Sync manager type chan- nel 3: Process data write authorization (outputs)	unsigned8	0x03	ro
	0x04	Subindex 004	Sync manager type chan- nel 3: Process data read authorization (inputs)	unsigned8	0x04	ro

Object 1C12: RxPDO Assignment

Since the read head has no output process data, there is no assignment to an RxPDO object.

Index	Subindex	Object name	Data type	Default	Access
0x1C12	0x00	RxPDO assign	unsigned8	0	rw



Object 1C13: TxPDO assignment

Object 1C13h can be used to configure a PDO for sync channel 3. Sync channel 3 is fixed for sending transmit PDOs (node –) controller). In this object, the number of PDOs assigned to this sync channel must be set under sub-index 0.

The object number of the PDO to be assigned to the channel is entered in subindices 1 to 5. Only the object numbers of the previously configured transmit PDOs can be used here (0x1A10 to 0x1A14).

Index	Subindex	Object name	Description	Data type	Default	Access
0x1C13	0x00	TxPDO assign	Number of assigned TxPDOs	unsigned8	0x05	rw
	0x01	Subindex 001	First assigned TxPDO (contains the index of the corresponding TxPDO mapping object)	unsigned1 6	0x1A10	rw
	0x02	Subindex 002	Second assigned TxPDO (con- tains the index of the corre- sponding TxPDO mapping object)	unsigned1 6	0x1A11	rw
	0x03	Subindex 003	Third assigned TxPDO (con- tains the index of the corre- sponding TxPDO mapping object)	unsigned1 6	0x1A13	rw
	0x04	Subindex 004	Fourth assigned TxPDO (con- tains the index of the corre- sponding TxPDO mapping object)	unsigned1 6	0x1A14	rw
	0x05	Subindex 005	Fifth assigned TxPDO (contains the index of the corresponding TxPDO mapping object)	unsigned1 6	0	rw

Object F000: Modular Device Profile

The modular device profile object contains all the information necessary to interpret the module objects.

Index	Subindex	Object name	Description	Data type	Default	Access
0xF000	0x00	Modular device profile	General information for the modular device profile	unsigned8	0x02	ro
	0x01	Modular index distance	Index distance of the objects of the individual channels	unsigned16	0x0010	ro
	0x02	Maximum number of modules	Number of channels Only one active channel is sup- ported	unsigned16	0x0001	ro

Object 3000: Pepperl+Fuchs Serial Number

Pepperl+Fuchs standard serial number.

Index	Subindex	Object name	Data type	Default	Access
0x3000	0x00	Pepperl+Fuchs serial number	string	-	ro

9.6 Process Data Objects (PDOs)

PDO Frame

The process data objects (PDOs) are used for the cyclic transfer of process data between the controller and the bus nodes. They must be configured by the controller in the "Pre-Operational" state before operating the bus node. They are transmitted in PDO frames.

To transfer a PDO via the EtherCAT®-CoE protocol, the transmit and receive PDOs (TxPDOs and RxPDOs) must be assigned to a transfer channel of the sync manager in addition to the PDO configuration (PDO mapping). The data exchange of PDOs for the read head takes place exclusively via the EtherCAT® process data telegram protocol.

PDO Mapping

PDO mapping is used to assign the application objects (real-time process data) from the object directory to the process data objects. For example, the index 0x1A10 from the object directory is reserved for the mapping table of TxPDO1. All mapping objects are predefined and only read access is permitted.

Overview Modules

The read head supports a slot with three different modules (data structures) of the process data objects. Select one of the three modules in your controller. Module 1 is preset.

Index (hex)	Name	Data size	Function	M/Oa/Ou	Link
0x1A10	TxPDO1	1 byte	Status	М	See "TxPDO1—Status" on page 77
0x1A11	TxPDO2	4 bytes	Position binary code	Oa	See "TxPDO2—Position Value Binary Code" on page 78
0x1A12	TxPDO3	4 bytes	Position gray-code	Ou	See "TxPDO3—Position Value Gray Code" on page 78
0x1A13	TxPDO4	1 byte	Speed	Oa	See "TxPD04—Speed" on page 79
0x1A14	TxPDO5	1 byte	Error codes	Ou	See "TxPDO5—Error Codes" on page 79

Module 1—Standard

• M = Mandatory (always transmitted, not selectable)

• Oa = Optional assigned (selectable, active by default)

• Ou = Optional unassigned (selectable, inactive by default))



TxPDO1—Status

The mapping object for PDO1 is defined in the object directory under index 0x1A10.

Index	Subin- dex	Data type	Data size	Offset	Desig- nation	Description
0x6010	0x01	Bit	0.1	0.0	Error	0 = no fault 1 = Error message (error message in PDO 0x1A14)
0x6010	0x02	Bit	0.1	0.1	OUT	0 = read head in code rail 1= read head partially outside the code rail. No valid posi- tion available.
0x6010	0x03	Bit	0.1	0.2	OUT ALL	0 = read head in code rail 1 = read head completely out- side the code rail.
0x6010	0x04	Bit	0.1	0.3	DB	Diagnostic bit 0 = by default, the diagnostic bit is not set 1 = read head is dirty
0x6010	0x05	Bit	0.1	0.4	SST	Speed status signals 0 = valid speed 1 = current speed unknown. Last valid speed in SP0 SP6 saved
0x6010	0x06 0x08	-	-	-	Reserve d	-

TxPDO2—Position Value Binary Code

The mapping object for PDO3 is defined in the object directory under index 0x1A11.

Index	Subindex	Data type	Data size	Offset	Designation
0x6011	0x01	unsigned32	4	0	Position value binary code

Content

Endianness: Little-endian Resolution: 0.8 mm Value range: 0 ... 393204

Position 1 corresponds to 0.8 mm Position 1250 corresponds to 1000 mm

Position 393204 corresponds to 314,563 mm

TxPDO3—Position Value Gray Code

The mapping object for PDO3 is defined in the object directory under index 0x1A12.

Index	Subindex	Data type	Data size	Offset	Designation
0x6011	0x02	unsigned32	4	0	Position value gray code

Content

Endianness: Little-endian Resolution: 0.8 mm Value range: 0 ... 393204

Position 1 corresponds to 0.8 mm Position 1250 corresponds to 1000 mm

Position 393204 corresponds to 314,563 mm

Return gray code

The following function converts a mirrored binary gray code number to a binary number.

```
uint GrayToBinary(uint num)
{
uint mask = num;
while (mask) { //each gray code bit is exclusively anchored with all
higher-order bits.
mask >>= 1;
num ^= mask;
while (mask) {
}
```

TxPD04—Speed

The mapping object for PDO1 is defined in the object directory under index 0x1A13.

Index	Subindex	Data type	Data size	Offset	Designation
0x6012	0x01	unsigned16	1	0	Velocity value [0.1 m/s] 127 = unknown

Content

Endianness: Little endian Resolution: 0.1 m/s Value range: 0 ... 127

SP0 ... SP6 ...

Speed in 0.1 m/s, binary coded

0: Speed less than 0.1 m	/s
--------------------------	----

126: Speed more than 12.5 m/s Speed unknown

For example:

SP0 SP6	1:	Speed 0.1 m/s
	37:	Speed 3.7 m/s
	112:	Speed 11.2 m/s

127:



TxPDO5—Error Codes

The mapping object for PDO5 is defined in the object directory under index 0x1A14.

Index	Subindex	Data type	Data size	Offset	Designation
0x6013	0x01	unsigned16	1	0	Error code number Only valid if the status error bit is set

ERR messages

	Content	
Error	Byte 1 Status	Function
0	ERR00	-
1	ERR01	Current position cannot be determined
2	ERR02	Current position cannot be determined
3	ERR03	Fault in the working memory (RAM)
4	ERR04	Fault in the EPROM memory or in the decoder
5	ERR05	Fault in the ROM memory
6	ERR06	-
7	ERR07	-

Module 2—Position Output

Retrofit structure to ECG110 gateway.

Index (hex)	Name	Data size	Function	M/Oa/Ou	Link
0x1A00	TxPDO1	4 bytes	Item	Μ	See "TxPDO1—Position" on page 80

• M = Mandatory (always transmitted, not selectable)

TxPDO1—Position

The mapping object for PDO1 is defined in the object directory under index 0x1A00.

Index	Subin- dex	Data type	Data size	Offset	Designation	Description
0x6000	0x01	Byte	1	0	Positions byte 0	MSB positions data
0x6000	0x02	Byte	1	1	Positions byte 1	Positions data byte
0x6000	0x03	Byte	1	2	Positions byte 2	LSB positions data
0x6000	0x04	Byte	1	3	Status	Diagnostic byte

Byte/ bit	7	6	5	4	3	2	1	0	Func- tion
1	0	0	0	0	0	XP18	XP17	XP16	Item
2	XP15	XP14	XP13	XP12	XP11	XP10	XP09	XP08	Item
3	XP07	XP06	XP05	XP04	XP03	XP02	XP01	XP00	Item
4	Reserved	Reserved	Reserved	DB	ERR	OUT	Reserved	Reserved	Status

Legend

Designation	Function
ERR	Error message from read head, Error number in XP00 XP04, binary coded.
XP#	Position value in X direction, binary coded with 0.8 mm resolution
OUT	0 = read head in code rail 1 = Read head partially outside the code rail. No valid position available.
DB	Diagnostic bit 0 = by default, the diagnostic bit is not set 1 = read head is dirty

Module 3—Position and Velocity Output

Retrofit structure to ECG110 gateway.

Index (hex)	Name	Data size	Function	M/Oa/Ou	Link
0x1A04	TxPDO1	6 bytes	Position and speed	Μ	See "TxPDO1—Posi- tion and Speed" on page 81

• M = Mandatory (always transmitted, not selectable)

TxPDO1—Position and Speed

The mapping object for PDO1 is defined in the object directory under index 0x1A10.

Index	Subin- dex	Data type	Data size	Offset	Designation	Description
0x6000	0x01	Byte	1	0	Positions byte 0	MSB positions data
0x6000	0x02	Byte	1	1	Positions byte 1	Positions data byte
0x6000	0x03	Byte	1	2	Positions byte 2	LSB positions data
0x6000	0x05	Byte	1	3	Position and speed status	Position and speed informa- tion
0x6000	0x06	Byte	1	4	Zero	Zero byte
0x6000	0x07	Byte	1	5	Speed	Speed value, binary coded [0.1 m/s] 126 > 12.5 m/s 127 = unknown

Byte/ bit	7	6	5	4	3	2	1	0	Func- tion
1	0	0	0	0	0	XP18	XP17	XP16	Item
2	XP15	XP14	XP13	XP12	XP11	XP10	XP09	XP08	Item
3	XP07	XP06	XP05	XP04	XP03	XP02	XP01	XP00	Item
4	Reserved	Reserved	SST	DB	ERR	OUT	Reserved	Reserved	Status
5	0	0	0	0	0	0	0	0	Zero
6	SP7	SP6	SP5	SP4	SP3	SP2	SP1	SP0	Speed



Legend

Designation	Function
ERR	Error message from read head, Error number in XP00 XP04, binary coded.
XP#	Position value in X direction, binary coded with 0.8 mm resolution
OUT	0 = read head in code rail 1= Read head partially outside the code rail. No valid position available.
DB	Diagnostic bit 0 = by default, the diagnostic bit is not set 1 = read head is dirty
SST	Speed status signals 0 = valid speed 1 = current speed unknown. Last valid speed in SP0 SP6 saved
SP	Velocity output

9.7 Firmware Update via the "File access over EtherCAT®" (FoE) protocol

This chapter describes the firmware update for the read head. The read head supports "File access over EtherCAT®" (FoE). This makes it possible to load the firmware onto the read head via the EtherCAT® controller, provided that it supports this function.

A firmware update should only be carried out after consultation with Pepperl+Fuchs Support.



Note

The current firmware version can be downloaded from our website: www.pepperl-fuchs.com. Simply enter the product name or item number in the Product/Keyword field and click "Search." Select your product from the list of search results. Click on the information you require in the product information list, for example, Software. A list of all available downloads is displayed.



Perform the firmware update via TwinCAT

Proceed as follows with the configuration software TwinCAT 3.x:

- 1. Download the new firmware locally to your computer.
- 2. Double-click on "Box 1 (WCS3B-LS710x)" in the project tree.

→ The menu "TwinCAT Project 1" is displayed.

3. Click the "Online" tab (1).

Gen	eral EtherC	AT DC	Process Data	Plc	Slots	Startup	CoE - Online	Online	-(1)
S	tate Machine Init Pre-Op Op)	Bootstrap Safe-Op Clear Error	-2 Cl R	urrent S equeste	tate: d State:	BOOT	3	
D	LL Status								
	Port A:	Carrier	/ Open						
	Port B:	No Car	rrier / Closed						
	Port C:	No Car	rrier / Closed						
	Port D: No Carrier / Closed								
F	ile Access ov Download	ver Ether	CAT Upload						

Figure 9.13 State Machine—Bootstrap

 \mapsto The "State Machine" menu opens.



4. Click the "Bootstrap" button (2).

 \rightarrow The read head changes to the "BOOT" status (3).

- 5. To download the new firmware from the directory, click the "Download" button (4).
 - → A new window opens, in which you can search for your firmware file. All of the "efw" files (EtherCAT® Firmware) are displayed.
- 6. Select your firmware file and click "Open" to confirm your selection.

 \rightarrow The "Edit FoE Name" window opens.

String:	Pepperl+Fuchs-WCS3B-LS710x-0001-2021092	ОК	1
Hex: E	50 65 70 70 65 72 6C 2B 46 75 63 68 73 2D 57	Cancel	
Length:	40		
Password (hex):	0000000		

Figure 9.14 Edit the FoE name

7. Confirm the "Edit FoE Name" window with "OK" (1).

→ The download starts and the firmware file is loaded into the flash memory of the read head. The TwinCAT configuration software displays the download of the firmware file with a progress bar at the bottom of the screen.

8. Click the "Init" button (1).

General EtherCAT DC	Process Data	Plc S	olots	Startup	CoE - Online	Online	
State Machine	Bootstrap	Curre	ent St	ate:	BOOT		
Ор	Clear Error	Requ	uesteo	d State:	BOOT		

Figure 9.15 State Machine—Init

→ The update is in progress. When the update is complete, the read head switches to the normal operating mode.

2024-07

9.8 LED Status Indication

WCS3B-LS7xx*



Description of the LED Indicators

Item	Display	Designation	Color	Display	Meaning
1	STS	S Status indicator green On red On		On	Code rail detected, normal function
				System error	
				Flashing	No code rail detected
2	SPD Velocity display Yellow On		On	The limit speed has not been met	
				Off	The limit speed has been exceeded
3	EC LA	Network connec-	green	Flickers	Data transfer in progress
		tion status (link activity)		Off	No network connection
				On	Network connection OK



Item	Display	Designation	Color	Display	Meaning
4	EC ST	Run—EtherCAT® operating status	green	Off	Device is in the "Initialization" state (normal state after switch- ing on or after a restart).
				Flashing	Device is in the "Pre-Opera- tional" state (configuration of the EtherCAT® network).
				Easy to light up	Device is in the "Safe-Opera- tional" state (e.g., due to a net- work malfunction).
				On	The device is in the "Opera- tional" state (normal operating state).
		Error—Ether-	red	Off	No errors present.
		CATe error		Flashing	Config fault No connection to the Ether- CAT® network
				Easy to light up	EtherCAT® status change due to an error
				Double lights	Watchdog timeout by the sync manager

9.9 Trademarks

 ${\sf EtherCAT} \circledast$ is a registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.



10 IO-Link interface (LS8xx*)

What Is IO-Link?

IO-Link enables seamless communication and digital data transfer from the control panel level down to the sensor level. The intelligent sensors can be used to their full potential with IO-Link, paving the way for Industry 4.0 in automation technology. The internationally standardized interface provides impressive efficiency and sustainable cost reduction from plant design and installation right through operation and servicing.

Standardized device description files ("IODDs") and parameterization via software tools ensure convenient configuration and integration of IO-Link sensors. Intelligent and transparent parameter management increases application flexibility and keeps downtimes to a minimum.

Parameters can be customized quickly and easily, even for complex production and batch changes. Transparency right through to the sensor gives users access to a comprehensive range of parameterization options and device diagnostics functions, allowing them to perform predictive maintenance.

The technology offers particular benefits

- In service (troubleshooting, servicing and device exchange)
- During commissioning (cloning, identification, configuration and localization)
- And during operation (job changeover, continuous parameter monitoring and online diagnostics)

IO-Link offers a number of advantages for industrial applications:

- Internationally standardized interface: The open standard is standardized in accordance with IEC 61131-9 and is compatible with established field buses on the market.
- Increased efficiency with sustainable cost reduction: High interference immunity with simplified cabling, standard cable 4/5-pin with M12 plugs unshielded up to 20 m cable length
- IO-Link minimizes downtimes: IO-Link devices can be easily parameterized via the control system, identified using a localization function and serviced as required - the added value of data reduces downtimes to a minimum.
- Transparency down to the lowest field level: In addition to reliable sensor identification, the newly created transparency enables access to all process and diagnostic data and to device information right down to sensor/actuator level.
- Extremely fast cycle times in the millisecond range enable highly dynamic position detection
- Automated device exchange via IO-Link
- Connection to future generations of frequency inverters with IO-Link
- ID value output directly on IO-Link

Special features of WCS read heads with IO-Link

- Acceleration sensor in 3 axes X, Y, Z
- Automatic rotation of the display via acceleration sensor
- Output of the ID number directly as a value (in conjunction with ID pads, stainless steel tags up to 400° C)
- Display of the identification number on the display
- Preset function (teach-in of a code band position as zero position with automatic offset adjustment)
- Correction of data to metric values. Instead of position values, a meter or MM value is output.
- Diagnostic channel for maintenance data.
- Input of position ranges for switching output/switching signal
- Heartbeat/alive signal
- Output of a "direction bit" (counting up or down in the direction of travel)
- Muting control = position value can be held temporarily by the external controller to overrun problem areas.

PEPPERL+FUCHS

Device Description File (IODD)

The parameters of the sensors are device-specific. A standardized description of these parameters can be found in the IO Device Description (IODD). The IODD can be imported into various engineering tools from different system providers, providing they support IODD. The sensor can be configured or diagnosed using the appropriate tool.

IODDs can be integrated into a control environment to allow IO-Link devices to be used for IO-Link operation. Both programming and exchanging process data can be performed with a PLC. The IODD can also be imported into a range of engineering tools from various system providers for programming and diagnostics, provided these tools support IODD

DTM (Device Type Manager)

If a sensor is not used long-term in an IO-Link environment, but nevertheless needs to be configured, this can be done easily via a PC with installed FDT frame application (e.g. PACTware) and with the DTM (Device Type Manager, a kind of "device driver") available for the sensor. Unlike configuration via the IODD, this method provides extended functions and ensures improved graphic visualization and convenient operation. In addition, functions such as "analysis" are only available via the associated DTM.



Offline parameterization

Figure 10.1

With offline parameterization, the IO-Link read head is configured before installation. To do this, use the Pepperl+Fuchs IO-Link USB master. We recommend using the "PACTware" software as the FDT frame application and user interface.

Both an IODD and a DTM are available for the read head. It is possible to use the IODD for offline parameterization. However, we recommend using the DTM for offline parameterization, because it offers more extensive functions and can present complex situations more easily through graphic representations. Also, some analysis options are only available in the DTM, because graphic representations are required for this.

2024-07



The DTM can be used immediately after installation.

If the IODD is used for offline parameterization instead of the DTM, you must first transform the IODD using the software "IODD Interpreter DTM". "IODD Interpreter DTM" is used to transform the IODD into a tabular user interface for parameterization.

The software components required in each case are collated in the latest version of the "IO-Link Offline Parameterization Tool" software package. The software package and the documentation on its installation and use can be found online at www.pepperl-fuchs.com.

If you use the "IO-Link Offline Parameterization Tool" software package, have active Internet access and have connected your read head via the IO-Link USB master from Pepperl+Fuchs, the PACTware automatically finds the correct IODD via the Internet.

The device description file (IODD) required for integration into an IO-Link system, for parameterization and diagnostics, and for the appropriate DTM for the device, can also be found on the Internet at www.pepperl-fuchs.com on the product page associated with the read head.



Online Parameterization

Figure 10.2

When commissioning machines and systems, you must integrate the master and IO-Link read head into the respective control environment. Depending on the components used, different software is required.

You can then configure and parameterize the devices using an IO-Link configuration tool. During operation, you can check the parameter settings of the IO-Link devices and read out and monitor status and diagnostic data. IO-Link data is integrated into an application program using function blocks.

2024-07



Note Security information

From a security perspective, the following precautions must be taken for the product by the responsible application operator:

- Physically secure the device against unauthorized access
- Ensure that the IO-Link device communicates with the remote station via a point-to-point connection.



10.1 Electrical Connection

IO-Link is a serial, bidirectional point-to-point connection for signal transmission and power supply under any network, fieldbus, or backplane bus.



Caution!

Property damage and system malfunctions due to incorrect pinout

Incorrect assignment of the wire pairs to the respective pins can result in property damage and system malfunctions.

 Note the assignment of the wire pairs to the pins as shown in the respective wiring diagrams.

Read head connection diagram

The read head is connected via a 5-pin M12 plug.





Connection assignment

Pin	Signal	Function
1	L+	Supply voltage
4	C/Q	Data communication IO-Link (SIO mode is not supported)
5	Q3	Parameterizable via IO-Link.
2	Q2	Overspeed, parameterizable via DIP switch
3	L-	Ground



Note

Connecting cable

The connection between the read head and master is made via unshielded 5-core standard cables with a maximum length of 20 m.

10.2

IO-Link Offline Parameterization Using PACTware

The PACTware operating software, which is independent of the manufacturer and fieldbus, can be used to parameterize and operate the read head outside the system, e.g., from your desk. In addition to the IODD, which is always available, the device-specific DTM (device type manager) is also available. These enable simple operation of the read head via a graphical user interface.





10.2.1 Installing the software

Downloading the software

At www.pepperl-fuchs.com you can download all the files you need to commission your IO-Link read head in a software package.

To do this, navigate via the structure tree: Products > Industrial communication > IO-Link > IO-Link software tools to the "Product list" tab and download the "IO-Link Offline Parameterization Tool" software here.

Products	Markets Services+Support	Contact Us Careers	, D	Your Keyword
Home > Indus	strial Sensors > Products > Industria	Communication > IO-Link > I	O-Link Software Tools	
Industrial Se	ensors			
Industrial Co	ommunication			
Industrial	Ethernet		- G+	
AS-Interfa	ice			
IO-Link				
IO-Link	Masters			
IO-Link	Devices			
IO-Link	Software Tools	IO-Link Softw	ware Tools	
SmartB	ridge Interface	IO-EIIIK SOIN		_
		View All Products in G	Group Group Overview Ask an Expert	?
Quick Links	5			
> Ask an E	xpert	Choose your produ	ict	
> Cross Re	ference Request			
> Check or	der status		1-1/1 Items per Page: 10 *	
> News		Product		
 NetPartne 	er Login		IO-Link Offline Parameterization Tool	· · · · · · · · · · · · · · · · · · ·
 Subscribe Automatie 	e to Interface, our Factory on Division e-newsletter		Software	
 Service L instrumer 	evel Agreements for ecom		Installation package for IO-Link offline parameterization: PACTware	DC, drivers for
> Literature		PEPPERL+FUCHS	to sim out model, to be included of m	
> Technolo	gies			

Figure 10.4





Installing the Software

The installation package for IO-Link offline parameterization contains the following components: PACTware DC 5.x, driver for IO-Link USB master, and IODD interpreter device type Manager.

1. Unzip the ZIP file and start the installation by double-clicking on "IO-Link_ParamTool_Setup.exe."



The checkmarks indicate which components will be installed.

- 2. If necessary, select the Microsoft.NET Framework for the installation.
- 3. Accept the license terms and click on "Install."
- 4. Follow the further instructions for the installation routine.



Adding IODDs with IODD DTM Configurator

1. Open the "IODD DTM Configurator" program.

IODD DTM Conf	igurator					- 0
Select all			Installed IOD	Ds		
Vandar	Douise	Vendor	Device	File	Release	Add IODD
Vendor	Device	ID	ID	version	date	Add IODD collection (Folder)
						Add IODD collection (Zip)
						Add IODDs from IODDfinder
						Delete
						Refresh





 \rightarrow You have several options for adding IODDs to the catalog:

Add IODD

Adds an individual IODD to the catalog.

→ * T 📙 « Docu	ments > Softwa	ire > IO-Module > ICE1-8IOL-	GOUL-VID > IODD :	> P+F > OMI	~ 0	Search OM I	1	2
ganize 👻 New folder								(
^	Name	^	Date modified	Туре	Size			
Deskton	Pepperl-Fu	ichs-WCS3B-06291713-202309	03.05.2018 09:27	XML Document		89 KB		
Downloads								
CTSS-Systems 🖈								
Dokumentatior 🖈								
Software 🖈								
Software 🖈								
Software * R2000 * R2300 *								
Software * R2000 * R2300 * 60_TMG Tool *								
Software R2000 R2300 60_TMG Tool AS-i_PM_TVU_! *								
Software R2000 R2300 60_TMG Tool AS-i_PM_TVU_N CTSS Files P+F								
Software R2000 R2300 60_TMG Tool AS-i_PM_TVU_Y CTSS Files P+F								
Software R2000 R2300 60_TMG Tool AS-i_PM_TVU_!* CTSS Files P+F * This PC Desktop								
Software R2000 R2300 G0_TMG Tool AS-i_PM_TVU_!* CTSS Files P+F * This PC Desktop Documents v								

Figure 10.7

Add IODD collection (folder)

Adds a complete folder, which can contain multiple IODDs, to the catalog.

	^		
ase select the ro	ot folder of the IODD collection.		
× 📘	P+F ^		
>	ICA-10DI6DO-G60A-IO		
>	ICA-16DI-G60A-IO		
>	ICA-16DIO-G60A-IO		
>	ICEG60A-IO		
>	, IQT		
>	NRNxx		
>	, OBR		
>	, OBT		
	OMT		
>	, OQT		
>	, PMI		
>	PSE3		
	UC		
>	UC400-F77		
>	UC500 🗸		
	>		

Figure 10.8



Add IODD collection (*.zip)

Adds an archived folder, which may contain multiple IODDs, to the catalog. For example IODD download from the Pepperl+Fuchs homepage.

📎 Open							×
\leftrightarrow \rightarrow \checkmark \uparrow \square \ll Docum	ents > Software > IO-Module	> ICE1-8IOL-G60L-V1D > IODD >	P+F → OMT	✓ Ö Sear	ch OMT		9
Organize 👻 New folder					== -	•	0
📰 Desktop 🛛 🖈 ^	Name	Date modified	Туре	Size			
🖶 Downloads 🛛 🖈 🚽	1833470a.zip	09.05.2019 08:54	Compressed (zipp	808 KB			
CTSS-Systems 🖈	12						
📙 Dokumentatior 🖈							
Software 🖈							
R2000 🖈							
🔜 R2300 💉							
60_TMG Tool 🖈							
AS-i_PM_TVU_N							
CTSS Files P+F 🖈							
This PC							
Desktop							
Documents							
+ Downloads							
Pictures *							
File name:	1833470a.zip			~ ZIP	files (*.zip)		~
					Open	Cancel	

Figure 10.9

Add IODD from IODDfinder

- Enables full access to the IODDfinder database ioddfinder.io-link.com.
- The manufacturer and the device can be narrowed down using the filter mask; for the manufacturer enter "Pepperl+Fuchs" and for the device enter the relevant device you are using.
- Select the required IODD file version of the device (IO-Link icon; here: highlighted in blue) and then click on "Add selected IODD."
- An active Internet connection is required.

Dverview		Show as IODD list	Filter			
Found 2 IODDs from 1 vendor(s): Pepperf-Fuchs (Vendor ID 1) Off100 R100-2EP-IO-V31 (D Off100 R100-2EP-IO-V31	evice ID 1116419) D-V31 (Product ID 267075-100078) Device ID 1116420)		Vendor (name or ID) Device (Name or ID) IO-Link revision	Pepperf+Fuchs OMT100-R100-2EP	-IO-V31	
	J-V31-L (Product ID 267075-100084)		Details			
			Vendor Device Device Selie version File version Venduct State Id (internal) Source Upload date	Name or value PepperI+Fuchs OMT100-R100-2EP-IO-V31 1.1 V1.00 002 OMT100-R100-2EP-IO-V31 APPROVED 4573 API_UPLOAD 8/25/2018 12:39:06 AM	ID 1 1116419 267075-100078	
Add selected IODD						Close







Installing additional device software

- 1. Search for the required IO-Link device on the Pepperl+Fuchs homepage.
- 2. Click on the search result (article name).

Selecting the device drivers

- You will be taken to the product page where you will find information about the device (datasheet, certificates, etc.).
- Here you will find the downloads for commissioning the device with IO-Link under the "Software" tab.

Downloading the device DTM

Clicking on "Software" takes you to the software area of the sensor. You can now download the device DTM for the sensor free of charge.



Note

Under the heading Software you will also find the IODD for download as an alternative to the IODDfinder.

Installing the device DTM



Note

If an older version of the device DTM is installed, uninstall it first!

- Change to the directory into which you downloaded the device DTM.
- Unzip the ZIP file and start the installation program by double clicking on "setup.exe."
- Follow the instructions for the installation process.





10.2.2 Offline Parameterization

This manual sets out how to configure using the "PACTware" FDT frame application in which the DTM (Device Type Manager) is loaded. In principle, you can also use other appropriate FDT frame applications. It is also possible to use the appropriate IODD for configuration instead of using the DTM. However, some analysis options are not available because they require graphic representations.



Note

An M12 connecting cable is required to connect the read head to the IO-Link master. Suitable connecting cables can be found at **www.pepperl-fuchs.com** on the product page for the relevant read head.



Prerequisites For Commissioning

To address the read head via IO-Link using the "PACTware DC" software and the associated DTM (device type manager), proceed as follows:

- 1. Ensure that PACTware DC and the necessary DTMs (device type managers) or the IODD device description for the read head and the IO-Link master are installed.
- 2. Connect the read head to the IO-Link USB master using an M12 connecting cable.
- 3. Connect the IO-Link USB master to the PC using the USB cable.



Setting up read head communication with PACTware DC

1. Launch PACTware DC by double-clicking the PACTware DC icon.

PACTware DC 🚽	合 Device ☆ Favorites 🛞 Settings
1. Start	Start PACTware DC
	Search new device

Figure 10.11

2. Click on Search for new device... at the top.

→ The IO-Link USB master will be detected by the PACTware DC if it is connected to the PC.



Figure 10.12

- 3. Click on IO-Link USB Master 2.0 in the project.
 - → If the read head is connected to the IO-Link USB master, PACTWare DC automatically establishes the connection to the read head.
- 4. Confirm the "Read from Device (Upload)?" dialog with "Yes" to synchronize the parameter values displayed in PACTware with the parameter values in the read head.



>

Read process data cyclically

∧ WCS3B-LS810 series IODD1.1 Parameter							
Address							
Channel_Id_IOLink							
Device type WCS38-LS810 series IODD1.1							
Vendor Pepperl+Fu Product WCS3B-LS	ichs 810DS Productid 199290-0060 🕸 💁 🚳 👰 🎥 🏨 🌆 😵	6					
Menu	Process data values						
Identification							
Parameter Observation							
Diagnosis (1)	Name	Value					
Process data	2 PD Input : MV1.1 - Position	No measurement data					
- Process data structure	Q PD Input : MV1.2 - Ident Number	No pad detected					
Info	PD Input : SSC1.1 - Position Range 1	Low	$\begin{pmatrix} 2 \end{pmatrix}$				
Connection info	PD Input : SSC1.2 - Position Range 2	Low					
	PD Input : SSC1.3 - Position Range 3	Low					
	PD Input : SSC1.4 - Position Range 4	Low					
	PD Input : SSC1.5 - Position Range 5	Low					
	PD Input : STAT1 - Direction	Ascending					
	🔁 PD Input : STAT2 - Preset	Active					
	PD Input : MV2 - Velocity	No measurement data					
	PD Input : MV3.1 - Acceleration X-axis	0,012 g					
	PD Input : MV3.2 - Acceleration Y-axis	0,022 g					
	D Input : MV3.3 - Acceleration Z-axis						
Output (from PLC)							
	Name	Value					
	PD Output : Trigger - Position Preset	Idle ~					
	PD Output : CSC.1 - Position Jump Control (Enabled V					
	PD Output : CSC.2 - Position Preset Control	Enabled ~					

Figure 10.13

- 1. Click on the "Process data" entry (1) in the device selection menu to switch to the process data view (2).
- 2. By default, the process data is not queried cyclically in PACTware and only the values at the time of the last readout of the data, e.g., after establishing a connection, are stored.
- **3.** By clicking the "Enable cyclic read from device for process data" icon, you start the cyclic reading of all process data provided by the read head.
- 4. Now move the connected IO-Link device to generate a change in the measured value/distance.



Reading parameter values

Reading out parameter values is shown using the example of identification data:



Figure 10.14

1. To do this, click on the "Identification" entry (1) in the device selection menu to switch to the device information view (2).



Note

- All the essential product information, such as product name, item number, serial number, etc., is displayed in this view.
- Application-specific information can be saved in this view using the "Application Specific Tag" (3) and "User Tag" (4) parameters in the read head.






Reading parameter values cyclically

To display current diagnostic information or monitoring data for the device, activate the cyclic readout of the parameter data.

PACTware DC 📢	合 Device 🛧 Favorites 🐵 Settings									
1. Start	Set device parameter									
2. Select Communication	Save as favorite									
3. Connection Parameter	Vendor Pepperl+	Fuchs 2								
4. Search		Product id 123496/8	7							
5. Select DTM	Menu	Name	Value	Default value						
	Identification	Service Function								
6. Device	Parameter (1)	- Restore Factory Settings	Restore Factory Settings							
	Diagnosis	Indication Control : Locator Indication	disabled	✓ disabled						
Read from device	Process data	Device Operation	normal operation	v normal operation						
Write to device	Process data structure Events	Device Status Information								
	Info	- Device Status	Device is OK	✓ Device is OK						
Parameter	Connection info	··· Device Operational State : Emitter State	on	✓ on						
		Device Operational State : Local Contr	disabled	✓ disabled						
		😳 🖃 Operation Information	Sector Sector							
		Operating Hours	206 h	0 h						
			safe operation temperature	safe operation temperature						
		Device Characteristics								
		- Device Characteristic - Detection Rang	40 mm	0 mm						

Figure 10.15

- 1. For example, click on the "Diagnostics" entry (1) in the device selection menu to switch to the device diagnostics view.
- 2. Click on the "Enable cyclic read from device for dynamic variables" button (2) to start the cyclic reading of all variables that change in the read head.
 - → All the essential diagnostic information, such as operating hours counter, temperature display, etc., is displayed in this view.



Writing parameter values

Writing parameter values is shown using the example of switching signal 1.

PACTware DC	\land Device 🕁 Favorites 🐼 Settings									
1. Start	Set device parameter									
2. Select Communication	Save as favorite									
3. Connection Parameter	Vendor Pepperl+	Fuchs	2							
4. Search			Product to 12345678	T (1)						
5. Select DTM	Menu	Name		Value	Default value					
	Identification (1)	\$PO	Operation Parameter							
6. Device	Parameter	P (Switching Signal 1 Parameter							
A CONTRACT OF A CONTRACT	Diagnosis	\$	- Switching Signal 1 : Setpoint 1 70	70,0 mm	90,0 mm					
Read from device	Process data	9	- Switching Signal 1 : Setpoint 2	60,0 mm	60,0 mm					
Write to device	Process data structure		Switching Signal 1 Configuration : S	active high - not inverted	active high - not inverted					
	- Info		- Switching Signal 1 Configuration : S	window	window					
Parameter	Connection info		Switching Signal 1 Configuration : S	standard	 ✓ standard 					
			Setpoint Offset for Switching Signal 1	10,0 mm	10,0 mm					
		6	• Switching Signal 2 Parameter							
		Œ	Teach-In Parameter							
		(±	Operation Mode Configuration							
		()	Process Data Configuration							
//		H	Event Configuration							
				Carabara da Caraba						
			··· I/O Type I/Q	ractory derault	<pre> factory default </pre>					
			Output Function	tactory default	✓ factory default					
			Input Function	factory default	 ✓ factory default 					
		Ĥ	Device Locks		T					

Figure 10.16

1. Click on the "Parameters" entry (1) in the device selection menu to switch to the device parameters view.

 \mapsto All the adjustable parameters are displayed in this view.

2. Once you have changed the required parameters, click on the "Write different Values to device" button (2).

 \mapsto The changed parameters are adopted by the read head.



The changed parameters can also be transferred to the read head using the "Write to device (Download)" icon. In this case, all data (changed and unchanged) is written, which takes a little longer.







Cloning parameter values

Cloning parameter values enables quick and easy duplication of complete parameter sets to several IO-Link devices of the same type.

The created parameter set is exported to a PACTware/version-independent XML file format and can then be imported again.



Figure 10.17

- 1. To do this, click on "Export the dataset to a file" (1) in the selection menu of the toolbar.
- 2. Save the created parameter set on your PC and disconnect the connection to the read head.
- 3. Then connect a new read head of the same type to your USB-IO-Link master.
- 4. Click on "Import the dataset from a file" (2) in the selection menu of the toolbar and select the desired dataset.

→ All parameter values that deviate from the standard are labeled with a corresponding icon.

5. Click on the "Write to device (Download)" button (3) to transfer the complete parameter set to the IO-Link device.

 \mapsto The cloning process is now complete.



Note

A parameter set created in this way can be read in any environment with IODD Interpreter DTM and written to a device of the same type.

10.3 Data Log

Device description IODD

An electronic device description is available for each device, the IODD file (IO device description). The IODD contains a wide range of information for system integration:

- Communication properties
- Device parameters with value range and default value
- · Identification, process, and diagnostic data
- Device data
- Text description
- Image of the device
- Logo of the manufacturer

The structure of the IODD is the same for all devices from all manufacturers. The structure of the IODD is always displayed in the same way in the IO-Link configuration tools of the master manufacturers. Operation is therefore guaranteed for all devices regardless of the manufacturer.

Data types

There are essentially four types of data available:

- Process data: Synchronous data
- · Value status: Synchronous data
- Device data: Acyclic data
- Events: Acyclic data

Process Data

The process data of the devices is transmitted cyclically in a data telegram, with the process data size determined by the device. Process data from 0 to 32 bytes are possible per device (input and output in each case). The consistency width of the transmission is not fixed and is therefore master-dependent.

Value status

Each port has a value status (PortQualifier). The value status indicates whether the process data is valid or invalid. The value status can be transmitted cyclically with the process data.

Device data

Device data can be parameters, identification data, or diagnostic information. It is exchanged acyclically and on request from the IO-Link master. Device data can both be written to the device (Write) and from the device (Read).

Events

When an event occurs, the device notifies the master that an event has occurred. The master then reads the event. Events can be error messages (e.g., short circuit) or warnings/maintenance instructions (e.g., contamination, overheating). Error messages are transmitted from the device to the controller or the HMI via the IO-Link master. For its part, the IO-Link master can also transmit events and statuses. Wire breakage and communication termination are examples of such events.

Device parameters or events are transmitted independently of the cyclic transmission of process data. The transmissions do not affect one another.

10.3.1 Process data structure - input data

Input data (sensor > controller)

The process data of the read head consists of 144 bits (18 bytes). The following table provides an overview of the order and structure of the process data.

2024-07



News	Data	1	Bit Off-	Permitted measuring	
Name	Туре	Length	set	range	Comment
MV3.3 Acceleration Z- axis	Integer	16 bits	128	-32,000 g 32,000 g	Displays the current acceleration value for the Z-axis. Resolution per digit: 0.001 g Substitute value "No Measure- ment Data" = 32764
MV3.2 Acceleration Y- axis	Integer	16 bits	112	-32,000 g 32,000 g	Displays the current acceleration value for the Y-axis. Resolution per digit: 0.001 g Substitute value = 32764
MV3.1 Acceleration X- axis	Integer	16 bits	96	-32,000 g 32,000 g	Displays the current acceleration value for the X-axis. Resolution per digit: 0.001 g Substitute value = 32764
MV2 Velocity	Integer	16 bits	80	-32,000 m/s 32,000 m/s	Displays the current speed. Resolution per digit: 0.01 m/s -32760: Out of range (-) 32760: Out of range (+) 32764: No measurement data
MV1.2 Ident Number	UInteger	16 bits	64	1 1260	Displays the current value of the ID number. 0: No ID pad detected
MV1.1 Item	Integer	32 bits	32	-1717986304.0 mm 1717986304.0 mm	Displays the current position value. Resolution per digit: 0.8 mm Substitute value = 2147483644
DSC5.5 VEL/SST	Boolean	1 bit	31	false true	Displays the current status of diag- nostic signal channel 5.5 for sig- naling the validity status of the speed value MV2. 0: Invalid 1: Valid
Reserved			29 30		
DSC5.2 OUT ALL	Boolean	1 bit	28	false true	Displays the current status of diag- nostic signaling channel 5.2 to detect the read head completely outside the code rail. 0: Inactive 1: Active
DSC5.1 OUT	Boolean	1 bit	27	false true	Displays the current status of diag- nostic signaling channel 5.1 for detecting the read head that is partially outside the code rail. 0: Inactive 1: Active
Reserved			26		
DSC3 Pollution	Boolean	1 bit	25	false true	Displays the current status of diag- nostic signal channel 3 for detect- ing contamination of the optical lenses. 0: Inactive 1: Active

Name	Data Type	Length	Bit Off- set	Permitted measuring range	Comment
DSC2 Error Status	Boolean	1 bit	24	false true	Displays the current status of diag- nostic signal channel 2 to signal an error that has occurred. Details are displayed in the "WCS Device Status - Error Code" parameter. 0: Inactive 1: Active
DSC1 Heartbeat	UInteger	8 bit	16	0 255	Displays the current heartbeat value.
Reserved			15 12		
STAT2 Preset	Boolean	1 bit	11	false true	Indicates whether the configured preset value is applied to the posi- tion value MV1.1. 0: Inactive 1: Active
STAT1 Direction	Boolean	1 bit	10	false true	Displays the current direction of travel of the read head. 0: Ascending 1: Descending
Reserved			95		
SSC1.5 Position Range 5	Boolean	1 bit	4	false true	Displays the current status of switching signal channel 1.5 for detecting position range 5. 0: Outside (low state) 1: Inside (high state)
SSC1.4 Position Range 4	Boolean	1 bit	3	false true	Displays the current status of switching signal channel 1.4 for detecting position range 4. 0: Outside (low state) 1: Inside (high state)
SSC1.3 Position Range 3	Boolean	1 bit	2	false true	Displays the current status of switching signal channel 1.3 for detecting position range 3. 0: Outside (low state) 1: Inside (high state)
SSC1.2 Position Range 2	Boolean	1 bit	1	false true	Displays the current status of switching signal channel 1.2 for detecting position range 2. 0: Outside (low state) 1: Inside (high state)
SSC1.1 Position Range 1	Boolean	1 bit	0	false true	Displays the current status of switching signal channel 1.1 for detecting position range 1. 0: Outside (low state) 1: Inside (high state)

DSC5.5 - VEL/SST

Displays the current status of the "Diagnosis Signal Channel 5.5 (DSC5.5)". "Invalid" indicates that there is no valid velocity value in Measurement Value 2 (MV2).

DSC5.2 - OUT ALL

Displays the current status of the "Diagnosis Signal Channel 5.2 (DSC5.2)". "Active" means that the read head is completely outside the code rail.

2024-07



DSC5.1 - OUT

Displays the current status of the "Diagnosis Signal Channel 5.1 (DSC5.1)". "Active" means that the read head is partially outside the code rail.

The behavior of the position at OUT can be configured.

MV Config - behavior at OUT

- 0: Replace value (default setting)
- 1: Hold last valid value

DSC4 - Pollution

Indicates whether the optical lenses are contaminated.

DSC3- Maintenance Warning

Indicates whether at least one of the configured maintenance limits has been exceeded.

DSC2 - ERR

Indicates whether an error has occurred. Further details are displayed in the "WCS Device Status - Error Code" parameter.

SSC2 - VEL

Displays the current status of switching signal 2 for measured value 2 "Speed."

STAT2 - Preset

Preset indicates whether the configured preset value is applied to the position value in "Position (MV1.1)."

STAT1 - Direction

Displays the current drive direction of the read head.

SSC1.5 - Position Range 5

The read head is located in preconfigured position range no. 5. The configuration is carried out in the device data.

SSC1.4 - Position Range 4

The read head is located in preconfigured position range no. 4. The configuration is carried out in the device data.

SSC1.3 - Position Range 3

The read head is located in preconfigured position range no. 3. The configuration is carried out in the device data.

SSC1.2 - Position Range 2

The read head is located in preconfigured position range no. 2. The configuration is carried out in the device data.

SSC1.1 - Position Range 1

The read head is located in preconfigured position range no. 1. The configuration is carried out in the device data.

10.3.2 Process data structure - output data

Output data (controller > sensor)

Name	Data Type	Length	Bit Offset	Value	Comment
Trigger Position Preset	Boolean	1 bit	0	false true	On a transition from 0 to 1, the preset value is applied to the cur- rent position value. 0: Idle 1: Execute
CSC.1 Hold Position on Out	Boolean	1 bit	1	false true	0: Disabled 1: Enabled
CSC.2 Preset Suppression	Boolean	1 bit	2	false true	0: Disabled 1: Enabled

Trigger - Position Preset (Teach function)

On a transition from 0 to 1, the preset value (default position value 0) is applied to the current position value.

The preset function can be used to perform a zero point calibration or a position value correction. For a different value, a corresponding value must be stored in the device data.

The preset value is retained after switching on the voltage.



Example

Application Examples

- The position output can be used for continuous code rail sections from 0 to 314.5 meters, e.g., always starting at 0 to 10 meters.
- Several read heads can be mounted on a vehicle, each of which is set to the same value, e.g., to the position of the center of the vehicle.
- If the code rails are installed in parallel, both read heads can be set to the same value. When traveling in parallel, the thermal expansion and mechanical tolerances of the code rail must be taken into account.

CSC.1 - Hold Position on Out

Controls the holding of the position in the "out" state. When activated, the last valid position is held when the read head is outside the code rail.

CSC.2 - Preset Suppression

Controls the suppression of the position preset. When activated, the preset value is not applied to the position value.



10.4 LED Status Indicator

The read head has three LEDs with the following characteristics:

LED Indicator



Description of the LED Indicators

Item	Display	Designation	Color	Display	Meaning
1	COM Data flow indicator		Green	On	Read head is ready. How- ever, there is no IO-Link com- munication.
			Green	Flashing	IO-Link communication active
2	SPD	PD Velocity display		On	The limit speed has not been met
				Off	The limit speed has been exceeded
3	STS	Status indicator	Green	On	Normal state valid position
			Red	On	Error has occurred
				Flashing	With "OUT" (read head is partially outside the code rail), and with "OUT ALL" (read head is completely outside the code rail)

Localization Function

To make it easier to find the read head in a system, the localization function for the read head LED can be activated/deactivated via IO-Link. In this case, pulsating flashing is activated for all three LEDs; this makes it easier to find the read head in a system.

10.5 Display

The read head features a display module. The following table shows the display options on the display module.

Integrated Display Module

Display module	Display	Description
858805	Read head type	When starting, the read head type appears briefly for 1 to 2 seconds
000035	Position value or ID value	After starting, the position value (default setting) or the ID pad value is displayed. The position values are given in mm.
888888	OUT Indicator	Indicates that the read head is par- tially outside the code rail.
888368	OUT-ALL indicator	Indicates that the read head is completely outside the code rail.
885.888	Position error message	No valid position available.

Display setting

The **Config - Display Orientation** parameter defines the orientation of the indicator on the display. You can make the following settings:

- Auto Detect: The display automatically detects the correct orientation.
- 0° (horizontal mounting)
- 180° (suspended mounting)

The **Config - Display Primary Information** parameter determines what information is primarily shown on the display.

- Position value
- ID number
- Position value [mm]





10.6 Read Head Versions

The following is an overview of the available IO-Link read head versions. Further combinations are available on request.

WCS3	B-LS810
D	Integrated display with seven-segment display.
S	Switching output for signaling when a limit speed is exceeded
Н	Integrated heating element for an extended outside temperature range down to - 40° C.
OM	Read head with outdoor protective enclosure (IP69) and central cable outlet

11 Options and Special Functions

11.1 Option D—Integrated Display in the Read Head, Type LS...D

Integrated Display Module

The WCS3B reader can be equipped with an optional display module or can be retrofitted at the factory. During the reader's movements, the display module reports the current position value and any error messages. If the reader has been stationary for more than 15 seconds, the display module issues additional diagnostics data alternately with the position value in a rotating cycle. (See the WCS catalog).

You can rotate the character position on the display 180° using the S1D DIP switch. This allows you to read the displayed values easily regardless of the installation position of the reader.



Note

M12

The following information does not apply to the IO-Link read head (LS8xx*).



Figure 11.2 Display for a suspended code rail (position 180°)

170286



Adjusting the display with configuration switch S1D

Display	S1D		
position 1 2		2	Comment
0 °	OFF	OFF	The displayed value can be read on a code rail mounted upright.
180°	ON	ON	The displayed value can be read on a code rail mounted suspended.

Note

The set display position is not noted on the nameplate of the read head.

Overview of the display module

The display shows the current position value. After switching on the read head, the following information is displayed in sequence:

Read head type, e.g., "LS-221"

Read head address, e.g., "Addr 0"

Software version, e.g., "Pr. 1.01"

During a downtime, the read head switches to "Information display" mode. The following data is displayed cyclically:

"12.34.56", internal clock (hh.mm.ss) "Good" or "bad"

Status of the optics/optoelectronics:

"LE - - -", no error message

"LE 1", read head has detected error 1

- "Lo --- ", read head was not outside the code rail "Lo 34", read head was outside the code rail 34 times
- "LS ----", limit speed has not been exceeded

"LS 128", limit speed has been exceeded 128 times (only for read head with "speed output" option)



Note

All values are reset after the voltage is switched on. The maximum time is 99:59:59, then the time starts again at 00:00:00. The maximum counter values for Lo and LS are 255.

11.2 Option-E—Extended, Type WCS3B-LS*E*, RS-485

For travel distances greater than 314.573 m, the read head **WCS3-Extended: WCS3B-LS*E*** with RS-485 interface is used. In this case, the additional "E" in the type code identifies the extended version for the extending code rail. Two standard code rail segments with a length of 0 ... 314.573 m are connected to each other with the WCS3-CS70-E code rail extender to achieve a maximum code rail length of up to 629.146 m. The first code rail segment must always be complete, or end with the position at 314.573 m. The second code rail segment can have a shorter length of 314.573 m to X m, but must be used in descending position, starting at 314.573 m.

Extended data protocol with position output

Request byte for read head											
Byte	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0		
	1	0	1	1	0	0	1	A1	A0		

Respon	Response telegram from the read head												
Byte	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0				
Byte 1	0	A1	A0	OVL	/VAL	DB	OUT ALL	OUT	ERR				
Byte 2	0	0	0	0	0	XP19	XP18	XP17	XP16				
Byte 3	0	XP15	XP14	XP13	XP12	XP11	XP10	XP09	XP08				
Byte 4	0	XP07	XP06	XP05	XP04	XP03	XP02	XP01	XP00				
Byte 5	0	xor B1.7 B4.7	xor B1.6 B4.6	xor B1.5 B4.5	xor B1.4 B4.4	xor B1.3 B4.3	xor B1.2 B4.2	xor B1.1 B4.1	xor B1.0 B4.0				

Data protocol with position and velocity output

Reques	Request byte for read head											
Byte	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0			
	1	1	1	1	0	0	1	A1	A0			

Response telegram from the read head									
Byte	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	0	A1	A0	OVL	/VAL	DB	OUT ALL	OUT	ERR
Byte 2	0	0	0	0	0	XP19	XP18	XP17	XP16
Byte 3	0	XP15	XP14	XP13	XP12	XP11	XP10	XP09	XP08
Byte 4	0	XP07	XP06	XP05	XP04	XP03	XP02	XP01	XP00
Byte 5	0	SST	SP6	SP5	SP4	SP3	SP2	SP1	SP0
Byte 6	0	B1.7 B5.7	B1.6 B5.6	B1.5 B5.5	B1.4 B5.4	B1.3 B5.3	B1.2 B5.2	B1.1 B5.1	B1.0 B5.0

Description of the Protocol Data

Byte 1		
A1, A0		Address bits of the read head. Addresses 0 3, binary coding
OVL	0	The read head is located in the readable area of the code rail
	1	The read head is located on WCS3 code rail extender (overlapping area of the code rail segments)
VAL	0:	Position valid
	1	Position invalid; code rail area is not unique after the supply voltage has been connected
DB	0	By default, the diagnostic bit is not set
	1	Diagnostic bit, read head dirty
OUT ALL	0	Read head in code rail
	1	Read head completely outside of the code rail
OUT	0	Read head in code rail
	1	Read head partially outside the code rail No valid position available
ERR	0	No error
	1	Error message (possible errors in XP00 XP01 binary coding)
Byte 2 4		
XP00 XP19		Current position value, binary coding
Byte 5 ¹		
SP0 SP6		Current speed in 0.1 m/s, binary coding For example: • 1: Speed = 0.1 m/s
		• 37: Speed = 3.7 m/s
		• 112: Speed = 11.2 m/s
SST	0	Speed valid
	1	Current speed unknown. Last valid speed in SP0 SP6 saved
Byte 5/6		Exclusive or link, byte 1 Byte 4/5

1. For data protocol with velocity output

Behavior of the Read Head in the Area of the WCS3 Code Rail Extender (WCS3-CS70-E)

The read head retains the last measured end position of the first code rail segment (position = 393203) when traversing the WCS3 code rail extender. The OVL bit is set at the same time. As soon as the first valid position of the second code rail segment is read, the read head switches to the first valid position of the second code rail segment (position = 393318). The first valid position of the second code rail segment (position = 393318). The first valid position of the second code rail segment is dimensioned with an offset of approx. + 92 mm. (see area highlighted in yellow in the figure below.)





Caution!

Impermissible state

If you mount the WCS3 code rail extender in the wrong position, e.g., at an intermediate position of the code rail, the OUT bit is set when this code rail segment is crossed.



Note Cvcle time

Note that the cycle time for the extended variant differs from the standard variant by t = 10 ms.

Start-up Behavior of the Read Head

After the supply voltage has been connected, the X position is set to the last valid X position and the VAL bit is set to 1.

The speed value is 127 and the SST bit is set to 1.

After the read head moves by approx. 5 mm, the VAL bit is set to 0 and the X position is assigned a new calculated X position. The last valid X position is stored in a non-volatile memory if it is detected that the voltage is switched off (+Ub < 9.9 VDC).

2024-07



11.3 Option-H—Heating in Read Head, Type LS...H

For applications with a risk of condensation (quick temperature change from cold to hot, high relative humidity), the WCS read head can be equipped with an optional **heater**. The heating is supplied via the read head, i.e., no additional electrical connection is required for the heating. Ensure that the cross section of the supply line to the read head is sufficiently dimensioned.

The **heater** is switched on immediately after the voltage is connected to the read head. The power consumption is 7 VA for the WCS2B and 9 VA for the WCS3B. The WCS3B heater uses a regulator that automatically switches off the heater at a temperature above 60 °C, measured at the transparent protective lenses of the read head.

With the heater option, the read head can be used in the temperature range of -40 °C ... 60 °C.

11.4 Option-S—Velocity Output, Type LS...S

The WCS3B read head with velocity output features an additional 24 VDC output, which transmits a signal in the event that a limit speed is exceeded. The limit speed can be configured on the 4-way DIP switch in the read head. The limit speed is set to 0.7 m/s on delivery.

Setting the limit speed (option -S only)

	S1			
Limit speed v _{limit}	1	2	3	4
0.7 m/s	Х	Х	OFF	OFF
2.0 m/s	Х	Х	OFF	ON
3.0 m/s	Х	Х	ON	OFF
4.0 m/s	Х	Х	ON	ON

The limit speed is output digitally via pin 5 of the 5-pin M12 connector:

 U_v (pin 5) = operating voltage $U_B \rightarrow v_{current} < v_{limit}$

 U_v (pin 5) = floating (high impedance) --> $v_{current} \ge v_{limit}$



Note

LED status indicator on the WCS3B read head with velocity output

The WCS3B read head has three LEDs on the front. The meaning of the yellow LED is changed according to the speed setting. Illuminated yellow: Limit speed not exceeded Not illuminated yellow: Limit speed exceeded Flashing red: Read head outside the code rail or read head dirty



Note

The set limit speed is not noted on the nameplate of the read head.

12 Model Overview for WCS Read Heads



Туре	2B	WCS2B read head (smaller enclosure, 1200 pos./m with a maximum of 327 m)
	3B	WCS3B read head (1250 pos./m with a maximum of 314.573 m)
	3R	WCS3R read head (833 pos./m with a maximum of 39.3 m)
	3T	WCS3T read head (416 pos./m with a maximum of 78.6 m)

Hardware	1	Read head with RS-485 interface, no RS-485 terminator
	2	Read head with RS-485 interface, with RS-485 terminator
	3	Read head with SSI interface
	4	Read head with CANopen interface
	5	Read head with EtherNet/IP interface
	6	Read head with PROFINET Interface
	7	Read head with EtherCAT interface
	8	Read head with IO-Link interface



Baud rate	Read head with RS-485 interface			
	1	187.50 kBaud		
	2	62.50 kBaud		
	3	31.25 kBaud		
	4	19.20 kBaud		
	5	9.60 kBaud		
	6	38.40 kBaud		
	Read head with S	SI interface		
	1	100 kHz – 1000 kHz		
	Read head with CANopen interface			
	1	125 kBaud, 250 kBaud, 500 kBaud, 1 MBaud		
	Read head with EtherNet/IP interface			
	1	100 Mbit/s		
	Read head with P	ROFINET Interface		
	1	100 Mbit/s		
	Read head with EtherCAT interface			
	1	100 Mbit/s		

Data log	Read head with RS-485 interface			
	1	Data log 1, data log 2 ¹		
	6	Data log 3 with even parity (9 bit/byte)		
	7	Data log 3 without parity (8 bit/byte)		
	Read head with SSI interface			
	0	Data output in binary code		
	1	Data output in Gray code		
	Read head with C faces	ANopen, EtherNet/IP, PROFINET, and EtherCAT inter-		
	0	Data output in binary code		

1. Data log depends on read head request byte

Option	D	Read head with optional integrated display
	E	Read head with "Extended" option
	Н	Read head with optional heating
	S	Read head with optional velocity output
	ОМ	Read head with "Outdoor" option (IP69K) and central cable out- let
	OL	Read head with "Outdoor" option (IP69K) and left-hand-side cable outlet
	OR	Read head with "Outdoor" option (IP69K), and right-hand-side cable outlet

Read head	Read head with RS-485 interface		
address	0	Read head address 0	
	1	Read head address 1	
	2	Read head address 2	
	3	Read head address 3	
	-	Read head address 0	



1 Disposal

The device, built-in components, packaging, and any batteries contained within must be disposed in compliance with the applicable laws and guidelines of the respective country.

14 Appendix

14.1 Cable Overview

The cable types listed below represent a selection of the types available from Pepperl+Fuchs. You can find additional cable types on our website.

Note

Π

For customizable cables, observe the cable length restrictions specified by the interface specifications. Refer to the relevant interface chapters for maximum cable length recommendations.

RS-485 (LS1xx*, LS2xx*)

Cable	Description		
Field attachable cab	le		
V15-G-2M-PUR-ABG	M12 single-ended female cordset, 5-pin, straight, 2 m PUR cable, shielded		
V15-G-5M-PUR-ABG	M12 single-ended female cordset, 5-pin, straight, 5 m PUR cable, shielded		
V15-G-10M-PUR- ABG	M12 single-ended female cordset, 5-pin, straight, 10 m PUR cable, shielded		
Field attachable single-ended female cordsets and available by the meter			
V15-G-ABG-PG9	Five-pin single-ended female cordset, field attachable, shielded		
V15-G-ABG-PG9-FE	Five-pin single-ended female cordset, field attachable, shielded with grounding terminal		
CBL-PVC-GY- 3x2x014-100M	100 meter cable ring, 6-pin data cable + shield, 0.14 mm ² 3×2 twisted pair wire		
CBL-PUR-GY- 3x2x025-100M	100 meter cable ring, 6-pin data cable + shield, 0.25 mm ² 3×2 twisted pair wire, suitable for drag chains		

SSI (LS3xx*)

Cable	Description		
Field attachable cab	le		
V19-G-2M-PUR-ABG	M12 single-ended female cordset, 8-pin, straight, 2 m PUR cable, shielded		
V19-G-5M-PUR-ABG	M12 single-ended female cordset, 8-pin, straight, 5 m PUR cable, shielded		
V19-G-10M-PUR- ABG	M12 single-ended female cordset, 8-pin, straight, 10 m PUR cable, shielded		
V19-G-2M-PVC-TP	Single-ended female cordset, M12, 8-pin, shielded, 2 m PVC cable shielded and twisted in pairs		
V19-G-5M-PVC-TP	Single-ended female cordset, M12, 8-pin, shielded, 5 m PVC cable shielded and twisted in pairs		
V19-G-10M-PVC-TP	Single-ended female cordset, M12, 8-pin, shielded, 10 m PVC cable shielded and twisted in pairs		
Field attachable single-ended female cordsets and available by the meter			
V19-G-ABG-PG9	Eight-pin single-ended female cordset, field attachable, shielded		
V19-G-ABG-PG9-FE	Eight-pin single-ended female cordset, field attachable, shielded with grounding terminal		

2024-07

Cable	Description
CBL-PVC-GY- 3x2x014-100M	100 meter cable ring, 6-pin data cable + shield, 0.14 mm ² 3×2 twisted pair wire
CBL-PUR-GY- 3x2x025-100M	100 meter cable ring, 6-pin data cable + shield, 0.25 mm ² 3 x 2 twisted pair wire, suitable for drag chains

CANopen (LS4xx*)

Cable	Description	
Field attachable cable		
V15-G-2M-PUR-CAN	CANopen bus cable, M12 to open cable end, 2 m PUR cable, 5-pin	
V15-G-2M-PUR-CAN- V15-G	CANOpen bus cable, M12 to M12, 2 m PUR cable, 5-pin	
V15-G-5M-PUR-CAN- V15-G	CANOpen bus cable, M12 to M12, 5 m PUR cable, 5-pin	
V15-G-10M-PUR- CAN-V15-G	CANOpen bus cable, M12 to M12, 10 m PUR cable, 5-pin	
Field attachable single-ended female cordsets and available by the meter		
V15-G-ABG-PG9-FE	M12 single-ended female cordset, 5-pin, shielded, field-attachable	
CBL-PVC-GY- 3x2x014-100M	100 meter cable ring, 6-pin data cable + shield, 0.14 mm ² 3×2 twisted pair wire	
CBL-PUR-GY- 3x2x025-100M	100 meter cable ring, 6-pin data cable + shield, 0.25 mm ² 3×2 twisted pair wire, suitable for drag chains	

EtherNet/IP (LS5xx*), PROFINET (LS6xx*) & EtherCAT (LS7xx*)

Cable	Description	
Hybrid cable with shared data line and supply voltage		
V19SY-G-BK2M- PUR-ABG	Hybrid cable, M12, 8-pin, Y coding, 2 m PUR cable, shielded	
V19SY-G-BK5M- PUR-ABG	Hybrid cable, M12, 8-pin, Y coding, 5 m PUR cable, shielded	
V19SY-G-BK10M- PUR-ABG	Hybrid cable, M12, 8-pin, Y coding, 10 m PUR cable, shielded	
Y-splitter and cable (data line and supply voltage separate)		
V19SY-Y-V1D/V1S	Y-splitter, M12 plug Y-coded to A-coded M12 plug/D-coded socket	
V1SD-G-*M-PUR- ABG-V45-G ¹	Cordset, M12 to 4-pin RJ45 PUR cable, CAT5e, in conjunction with Y-plug (data cable)	
V1-G-BK10M-PUR-U	Single-ended female cordset, M12, four pins, PUR cable in conjunction with Y-plug (supply voltage)	

1. This type of cable is available in different lengths of 2 ... 45 m.

Your automation, our passion.

Explosion Protection

- Intrinsic Safety Barriers
- Signal Conditioners
- FieldConnex[®] Fieldbus
- Remote I/O Systems
- Electrical Ex Equipment
- Purge and Pressurization
- Industrial HMI
- Mobile Computing and Communications
- HART Interface Solutions
- Surge Protection
- Wireless Solutions
- Level Measurement

Industrial Sensors

- Proximity Sensors
- Photoelectric Sensors
- Industrial Vision
- Ultrasonic Sensors
- Rotary Encoders
- Positioning Systems
- Inclination and Acceleration Sensors
- Fieldbus Modules
- AS-Interface
- Identification Systems
- Displays and Signal Processing
- Connectivity

Pepperl+Fuchs Quality Download our latest policy here:



www.pepperl-fuchs.com/quality



www.pepperl-fuchs.com © Pepperl+Fuchs · Subject to modifications / DOCT-5959C