

Instruction Manual

1. Marking

Control Stations, Stainless Steel SR.CS*
ATEX certificate CML 16 ATEX 3009X ATEX marking: Ⓢ II 2 GD Ex db eb IIC T* Gb Ex ib IIC T* Gb Ex db eb ib IIC T* Gb Ex tb IIIC T** °C Db T6/T80 °C @ Ta +40 °C T5/T95 °C @ Ta +55 °C T4/T130 °C @ Ta +55 °C
IECEX certificate IECEX CML 16.0008X CCC certificate: 2020322304002545
Pepperl+Fuchs Group Lilienthalstraße 200, 68307 Mannheim, Germany Internet: www.pepperl-fuchs.com

The *-marked letters of the type code are placeholders for versions of the device.

2. Target Group, Personnel

Responsibility for planning, assembly, commissioning, operation, maintenance, and dismantling lies with the plant operator.
The personnel must be appropriately trained and qualified in order to carry out mounting, installation, commissioning, operation, maintenance, and dismantling of the device. The trained and qualified personnel must have read and understood the instruction manual.

3. Reference to Further Documentation

Observe directives, standards, and national laws applicable to the intended use and the operating location.
The corresponding datasheets, manuals, declarations of conformity, EU-type examination certificates, certificates, and control drawings if applicable (see datasheet) are an integral part of this document. You can find this information under www.pepperl-fuchs.com.
In order to access this documentation, enter the product name, i. e. the type code, or the item number of the product in the search field of the website.
For specific device information such as the year of construction, scan the QR code on the device. As an alternative, enter the serial number in the serial number search at www.pepperl-fuchs.com.

4. Intended Use

The device is only approved for appropriate and intended use. Ignoring these instructions will void any warranty and absolve the manufacturer from any liability.
The enclosures of the SR* series are made of stainless steel.
The device can be used indoors.
The device can be used outdoors.
The device can be used in Zone 1.
The device can be used in Zone 21.
The device can be used in Zone 2.
The device can be used in Zone 22.
The device is designed for wall mounting.
The device is designed for mounting to a steel framework.
Use suitable fixing material for mounting.
Mount the enclosure at the fixing points provided.

5. Improper Use

Do not mount the device on the ceiling.
Protection of personnel and the plant is not ensured if the device is not used according to its intended use.

6. Mounting and Installation

Observe the installation instructions according to IEC/EN 60079-14.
If you intend to install the device or enclosure in areas that may be exposed to aggressive substances, ensure that the stated surface materials are compatible with these substances. If required, contact Pepperl+Fuchs for further information.
Observe directives, standards, and national laws applicable to the intended use and the operating location.
Observe Directive 1999/92/EC in relation to hazardous areas.
Examples for such regulations are regulations regarding electricity, grounding, installation as well as hygiene and safety.
Observe the requirements according to IEC/EN 60079-31 regarding excessive dust deposits.

To ensure compliance with the temperature class, ensure that there is adequate free air space around the enclosure.
Ensure that there are no external heat sources around the enclosure.
Safety-relevant markings are found on the nameplate supplied.
Ensure that the nameplate is present and legible. Take the ambient conditions into account.
Additional warning markings may be affixed next to the nameplate.
The permitted ambient temperatures of the built-in components must not be exceeded.
Avoid mechanical impacts to the device (e. g. from heavy or sharp-edged objects).
Ensure that the enclosure is not damaged, distorted, or corroded.
Ensure that all seals are clean, undamaged, and correctly fitted.
Tighten all screws of the enclosure/enclosure cover with the appropriate torque.
Ensure that unused terminal screws are properly tightened down.
For cable glands only use incoming cable diameters of the appropriate size.
Tighten all cable glands with the appropriate torque.
Close all unused cable glands with the appropriate sealing plugs.
Only use stopping plugs that are suitably certified for the application.
Close all unused enclosure holes with the appropriate stopping plugs.
If mounting the enclosure on concrete use expansion anchors.
When mounting the enclosure to a steel framework use vibration resistant mounting material.
Ensure that the enclosure is mounted on a flat surface.
Do not install fuse terminals, relays, miniature circuit breakers, contactors etc. in the enclosure.
If external connections are present, ensure that the connections are in good condition, and are not damaged or corroded.
In order to prevent condensation in the enclosure, use suitably certified breather drains.

6.1. Requirements for Cable Glands

Only use cable glands that are suitably certified for the application.
Only use cable glands with a temperature range appropriate to the application.
Ensure that the degree of protection is not violated by the cable glands.
Ground metal cable glands.

6.2. Requirements for Internal Components

Select suitable conductors in order to ensure that the maximum permitted temperature of the conductors fit to the maximum permitted ambient temperature of the control station.
Only use cables and connection lines with a temperature range appropriate to the application.
Keep the separation distances between all non-intrinsically safe circuits and intrinsically safe circuits according to IEC/EN 60079-14.
Ensure that the terminals are in good condition and are not damaged or corroded.
Use only one conductor per terminal.
Observe the tightening torque of the terminal screws.
Use the shortest possible cable lengths and avoid small core cross sections.
Observe the minimum bending radius of the conductors.
When installing the conductors the insulation must reach up to the terminal.
When using stranded conductors, crimp wire end ferrules on the conductor ends.
Unused cables and connection lines must be either connected to terminals or securely tied down and isolated.
Insulation by tape alone is not permitted.
Refer to document **Supplement of the Instruction Manual** for information to the specific conditions of use.
Do not bunch more than 6 conductors to avoid hot spots.
Arrange the earth connections for incoming and outgoing cables in a way that the ground fault current is not routed between separate grounding plates.
Contact Pepperl+Fuchs before installing additional components.
Pepperl+Fuchs will check whether these components are listed in the certificate. The maximum power dissipation of this installation solution must be within the permitted limits.

7. Operation, Maintenance, Repair

Observe the requirements according to IEC/EN 60079-14 during operation.
Observe IEC/EN 60079-17 for maintenance and inspection.
Observe the requirements according to IEC/EN 60079-19 for repair and overhaul.
Before opening the enclosure make sure that the built-in components are de-energized.
When energized, the enclosure may only be opened for maintenance, if only intrinsically safe circuits are used inside the enclosure.
Check the wear on the device and the device components at specific intervals. The interval between checks depends on the operating conditions and loads that occur.

Avoid electrostatic charges which could result in electrostatic discharges while installing, operating, or maintaining the device.
If cleaning is necessary while the device is located in a hazardous area, in order to avoid electrostatic charging only use a clean damp cloth.
Before assembly, check that the seal and sealing surface are clean and in good condition to ensure the degree of protection.
If there is a defect, the device must be repaired by Pepperl+Fuchs.
Alternatively the device can be repaired by a qualified electrician in compliance with IEC/EN 60079-19.

8. Delivery, Transport, Disposal

Store the device in a clean and dry environment. The permitted ambient conditions must be considered, see datasheet.
Check the packaging and contents for damage.
Check if you have received every item and if the items received are the ones you ordered.
The device, built-in components, packaging, and any batteries contained within must be disposed in compliance with the applicable laws and guidelines of the respective country.