



PROCESS AUTOMATION

INSTALLATION AND OPERATION MANUAL

POWERSCAN

PSCAN-D-1D-D2

Division 2 Barcode Reader



Table of contents

I. General information	1
II. Safety	1
General safety instructions	1
Delivery, transport, and storage	1
PSCAN-D-1* intended use	1
Installation and commissioning	1
Technical data	1
Hazardous location label	1
Laser safety compliance	2
Repair and maintenance	2
Applied standards and guidelines	2
III. Product Specifications	2
PSCAN-D-1D-D2 function	2
Best reading angles	2
Reading characteristics	3
PSCAN and connector dimensions	3
General specifications, Accessories	3
IV. Installation	5
Preparation	5
Installation wiring	5
Status indicators	5
Holder mounting	6
Installing the earth stud	6
V. Configuration	7
Reading configuration barcodes	7
PSCAN-D-1D-D2 setup	8
USB reader configuration	8
USB start up	8
Change default settings	8
RS232 parameters	9
USB parameters	14
Data format	19
Reading parameters	28
Decoding parameters	33
Code selection	35
Advanced formatting	52
VI. References	70
ACN/NACK protocol	70
FIFO	70
RX timeout	70
Reading parameters	70
Decoding parameters	71
Advanced formatting	71
Custom default configuration	71
Code type recognition	71
VII. Message formatting	72
Messages from host to reader	72
Code/character sets	73
Code identifier table	75
Configuration codes	77
Hex and numeric tables	78
IX. Maintenance and repair	80

General information

Copyright © 2017 by Pepperl+Fuchs GmbH
All rights reserved

The publisher reserves the right to alter the information and data contained in this manual without prior notice. Unless otherwise indicated, the company names as well as other names and data used in the examples are purely fictitious. The publisher may have registered patents or pending patent applications for subject matter covered in the manual. This manual does not give you license to these patents.

LIMITED WARRANTY:

NO WARRANTY IS PROVIDED FOR THE ACCURACY OF THE INFORMATION CONTAINED IN THIS MANUAL. AS MISTAKES CANNOT BE ENTIRELY AVOIDED DESPITE TAKING THE GREATEST OF CARE, WE WOULD BE GRATEFUL TO RECEIVE INFORMATION ABOUT ANY ERRORS YOU MAY DISCOVER. THE PUBLISHER DISCLAIMS ALL LEGAL RESPONSIBILITY OR LIABILITY FOR ERRORS AS WELL AS FOR SUBSEQUENT DAMAGES AND CLAIMS.

MANUFACTURER:

PEPPERL-FUCHS, INC.
1600 ENTERPRISE PKWY
TWINSBURG, OH 44087USA
www.pepperl-fuchs.us

Tel. 330-486-0002
Fax 330-963-5827
E-Mail: info@us.pepperl-fuchs.com

Safety

General safety instructions

- The plant owner is responsible for its planning, installation, commissioning, operation, maintenance, and disassembly.
- Installation and commissioning of all devices must be performed by a trained professional only.
- Protection of operating personnel and the system is not ensured if the product is not used in accordance with its intended purpose.
- Laws and regulations applicable to the usage or the intended purpose must be observed.
- The devices are only approved for appropriate and intended use. Ignoring these instructions will void any warranty and absolve the manufacturer from any liability.
- The Declaration of Conformity, Certificate of Compliance, Statement of Conformity, EC type-examination certificate and data sheets are an integral part of this document.
- The data sheet contains the electrical data of the Declaration of Conformity, the Certificate of Compliance, and the EC-type-examination certificate.
- The documents mentioned are available from <http://www.pepperl-fuchs.com> or your local Pepperl+Fuchs representative.

Delivery, transport, and storage

- Check the packaging and contents for damage.
- Check if you have received every item and if the items received are the ones you ordered.
- Keep the original packaging. Always store and transport the device in the original packaging.
- Always store the device in a clean and dry environment. The permitted storage temperature (see datasheet) must be considered.

PSCAN-D-1* intended use

The PSCAN-D-1D-D2 EX barcode reader can be used in Class I/Div. 2, Class II/Div. 2, and Class III/Div.2 hazardous areas. The barcode reader is able to read all standard 1-D code families. An audible beep will be heard once a successful scan is completed. Bidirectional communication between barcode reader and host is also possible.

Supply and communication of the barcode reader is made by a nonincendive barrier that is required for Div. 2 installation. The devices are only approved for appropriate and intended use. Ignoring these instructions will void any warranty and absolve the manufacturer from any liability.

Installation and commissioning

The installation instructions in accordance with IEC/EN 60079-14 must be observed. If devices have already been operated in general electrical systems, they may no longer be installed in electrical systems used in combination with hazardous areas. The respective peak values of the field device and the associated apparatus with regard to explosion protection should be considered when connecting nonincendive field devices.

Technical data

Data for Use in Conjunction with Hazardous Areas	
Voltage (U)	10 VDC
Current (I)	500 mA
Capacitance (C)	250 µF
Inductance (L)	75 µH
Operating Temperature	
Ambient temperature	-10 °C to 50 °C (14 °F to 122 °F)

Hazardous location label



Laser safety compliance

The barcode reader conforms to the following applicable requirements at the date of manufacture:

- EN 60825-1
- CDRH 21 CFR 1040

The laser light is visible to the human eye and is emitted from the output window.

Warning! Laser Light



Warning

- The human eye can be damaged.
- Do not stare into beam of the laser light.
- Any changes to the device are forbidden. These could cause a dangerous laser light.
- Please consider the procedures described in these operating instructions.
- Prevent the laser beam from hitting reflective surfaces such as mirrors, etc.

A warning label is attached to the barcode reader describing the laser and laser category. The device is a class 2 laser. It is not necessary to open the barcode reader for installation, application, or maintenance. Labels cannot be attached to a laser diode. Hence, the respective values are listed below:



Maximum Output	0.9 mW
Wavelength according to Class 2 N-60825-1 and CDRH21CFR 1040	630-690 nm

Repair and maintenance

The devices must not be repaired, changed, or manipulated. If there is a defect, the product must always be replaced with an original device.

Applied standards and guidelines

Electromagnetic compatibility	NE 21
Low voltage	ANSI/UL 60950-1-2007
Explosion protection	ANSI/ISA-12.12.01-2007; CSA C22.2 No. 213-M1987, R2008

Product specifications

PSCAN-D-1D-D2 function

The PSCAN-D-1D-D2EX barcode reader can be used in Class I/Div. 2 and Class II/Div. 2 hazardous areas. The barcode reader is able to read all standard 1-D code families. After a successful read, a beep to indicate a good read is sent out for easy operation. In addition, a bidirectional communication is possible. Supply and communication of the barcode reader is made by a nonincendive interface.

Additional functions include:

Aiming system


First, a partial trigger produces a red spot for easy aiming. By completely pressing the trigger, a line appears to start code scanning.

GL-technics (3 green lights)

A good read is shown via an audio signal, green LEDs on upside and underside, plus a green scan line directly on the barcode.

Using PSCAN-D-1D-D2 readers


The PSCAN-D-1* barcode reader automatically scans barcodes up to a certain distance. See the Reading characteristics chart on page xx. Simply aim and pull the trigger. Code scanning is performed along the scan line emitted from the reading window. The line must cross the entire code.



Best reading angles


For good reading performance, do not hold the barcode reader vertically. Use the reading angles in the figure below.

Device components




- Barcode reader
- Connecting cable consisting of a helix cable 3 m and a male 4-pin connector (M12 connector) mounted.


Reading characteristics



PSCAN dimensions (mm)



4-pin connector dimensions (mm)



PSCAN-D-1D-D2-20-10-N

General specifications

Readable codes	2/5 Family, Code 39, (plus Code 32, Clip 39), EAN/UPC, EAN 128, Code 128, Code 93, CODABAR, Code 49, Code MSI, Code 11, Code 16K, ISBN/ISSN, ISBT 128, GS1DataBar™ (once RSS)
Laser class	Class 2 - EN 60825-1, CDRH
Scan rate	30 to 40 s-1
Beam deviation angle	Max. 42 °
Resolution	0.076 mm (3 mils)
Light type	Laser diode 630 to 680 nm

Electrical specifications

Operating voltage	5 VDC
Electromagnetic compatibility	120 mA

Ambient conditions

Operating temperature	-10 °C to 50 °C (14 °F to 122 °F)
Storage temperature	-20 °C to 60 °C (-4 °F to 140 °F)
Relative humidity	90% noncondensing

Mechanical specifications

Protection degree	IP44
Weight	340 g
Dimensions	190 mm x 135 mm x 70 mm
Cable length	3 m stretched

Data for use in conjunction with hazardous area


Voltage (U)	5.8 VDC
Current (I)	495 mA
Capacitance (C)	250 µF
Inductance (L)	75 µH

PSCAN-D-1D-D2-20-10-N Accessories

Accessory	Model number
Div. 2 nonincendive barrier for USB connection	SK-PC-D2-UN2-10-HS
Div. 2 nonincendive barrier for RS232 connection	SK-PC-D2-RN2-10-HS
Scanner holder	Scanner-Holder-VisuNet-RM/PC
Replacement cable for PSCAN-D-1D-D2 for USB mode	CBL-PSCAN-M12-4-USB
Replacement cable for PSCAN-D-1D-D2 for RS232 mode	CBL-PSCAN-M12-4-RS232

Holder for barcode reader

Dimensions



Replacement connection cable

The PSCAN-D-1D-D2 connecting cable is a cable for replacement for the barcode reader PSCAN-D-1D-D2. The mounting instructions are found in the Maintenance and Repair section on page 80.


Connection cable



M12 connector, male 4-pin



Female 4-pin receptacle



Connector RJ45



Installation

Preparation

Unpacking the unit

1. Check that all package contents are present and undamaged. If anything is damaged, inform the shipper and contact the supplier.
2. Check that all items are present and correct based on your order and the shipping documents.
3. Keep the original packing material in case you need to store or ship the unit at a later time

If you have any questions, please contact Pepperl+Fuchs.

Installation wiring

When connecting the barcode reader wiring to the SK-PC-D2 nonincendive barrier, please follow the tables below. The color coding is based on the Pepperl+Fuchs cable accessories that are sold with the PSCAN-D-1D-D2.

Field side barrier connection				Field side			
SK-PC-D2-UN2-10-HS		SK-PC-D2-RN2-10-HS		SK-PC-D2-XN2-10-HS			
Terminal	Wire Color	Terminal	Wire Color	CH1 V+	CH1 D+	CH1 D-	CH1 V-
V+	Brown	V+	Brown	⊙	⊙	⊙	⊙
D+	Blue	D+	Blue	⊙	⊙	⊙	⊙
D-	White	D-	White	⊙	⊙	⊙	⊙
V-	Black	V-	Black	⊙	⊙	⊙	⊙
PC side barrier connection				PC side			
SK-PC-D2-UN2-10-HS		SK-PC-D2-RN2-10-HS		SK-PC-D2-XN2-10-HS			
Terminal	Wire Color	Terminal	Wire Color	CH1 D+	CH1 D-	PWR +	PWR -
D+	Green	D+	Red (Tx)	⊙	⊙	⊙	⊙
D-	White	D-	Brown (Rx)	⊙	⊙	⊙	⊙
Ground	Black	Ground	Yellow (Gnd)	⊙	⊙	⊙	⊙

NOTE: Color codes are in reference to Pepperl+Fuchs cable assemblies


Field side barrier connection			
SK-PC-D2-UN2-10-HS		SK-PC-D2-RN2-10-HS	
Cable length	15' (4.6 m)	Cable length	45' (13.7 m)
PC side barrier connection			
SK-PC-D2-UN2-10-HS		SK-PC-D2-RN2-10-HS	
Cable length	6' (1.8 m)	Cable length	45' (13.7 m)
Total distance (PC to barcode reader)			
SK-PC-D2-UN2-10-HS		SK-PC-D2-RN2-10-HS	
Cable length	18' (5.5 m)	Cable length	50' (15.2 m)

Status Indicators


The barcode reader has two indicator LEDs, a good read spot, and a beeper. They signal several operating conditions that are described in the following table.

H=	High tone		
L=	Low tone		
*=	Tone and intensity are user-configurable		
#=	The data entry "good read tone" is user-configurable with all beeper commands in the Reading Parameters section.		
Start up			
Beeper*	Meaning		
LLLL	Parameter loading correctly		
H H H H long tones	Parameter loading error, reading, or writing error in the nonvolatile memory		
HLHL	Hardware error in EEPROM		
Configuration			
Beeper*	Meaning		
HHHH	Correct entry or exit from configuration mode		
L	Good read of a command		
LLLL	Command read error		
Reader data entry			
Beeper*	LED	Good read spot	Meaning
One beep	On	On	Correct read of a code in normal mode
HL			TX buffer full (when FIFO is enabled)
H long	On	On	Successful advanced format concatenation
HHHH			Timeout expired - operation not completed
HH long			Error in advanced data formatting
	Off	Off	Ready to read a code
	On	Off	Ready to read a code



Mounting the holder for the barcode reader




Edge protection



Hole pattern holder for the barcode reader



Holder for the barcode reader, top view




1	Distance plate
2	M3 washer
3	M3 lock washer
4	Hex nut
5	Gasket
6	Adapter (bracket)
7	M4 countersunk head screw (2)
8	M4 washer (2)
9	M4 nut (2)
10	M4 nut (2)
11	Holder for barcode reader
12	M5 countersunk head screw (2)

Contact holes

1. Contact 2 holes for fastening the holder for barcode reader (2x \varnothing 4.5).
2. Contact 1 hole for the earth stud for equipotential bonding (1x \varnothing 3.5).

Installing the earth stud

Connect the earth stud with the equipotential bonding of the system. (cross section min. 4 mm²).





Configuration

Reading configuration barcodes

This manual can be used for complete setup and configuration of your reader by following the setup procedures in this chapter. If you wish to change the default settings, this manual provides complete configuration of your reader in an easy way.

To configure your reader:

- 1) Open the folded page in manual with the hex-numeric table and keep it open during the device configuration.
- 2) Read the Enter Configuration code ONCE.
- 3) Modify the desired parameters in one or more sections following the procedures given for each group.
- 4) Read the Exit and Save Configuration code ONCE.

PSCAN-D-1D-D2 SETUP

1. Read the restore default parameters code below.

Restore PSCAN-D-1D-D2 Default



Interface selection

RS-232

Standard



USB

USB-KBD



USB-KBD-ALT-MODE



USB-KBD-APPLE



USB-COM*



USB-IBM-Table Top



USB-IBM-Hand Held



When configuring USB-COM, the relevant files and drivers must be installed from the USB Device Installation software, which can be downloaded from the web site <http://www.scanning.datalogic.com>

USB reader configuration

The USB interface is available for the PScan-D-1D-D2 device and is compatible with the following Operating Systems:

Windows 98 (and later)	IBM POS for Windows
Mac OS 8.0 (and later)	4690 Operating System

USB Start-up

As with all USB devices, upon connection, the host performs several checks by communicating with the device. During this phase, normal operations are suspended (the LED on the PSCAN-D-1D-D2 reader blinks). Two basic conditions must be met before the device is ready—the correct USB driver must be loaded and sufficient power must be supplied to the reader.

1. For all systems, the correct USB driver for the default USB-KBD interface is included in the host operating system and will either be loaded automatically or will be suggested by the O.S. and should therefore be selected from the dialog box (the first time only). Normally, the host supplies sufficient power to the device and the start-up phase ends correctly. (The reader's LED stops blinking and the reader emits the beep OK signal). In rare cases, if the host does not supply sufficient power to the device, a dialog box will appear on the host and the device will be blocked (the reader's LED continues blinking). In this case, disconnect the USB device cable at the host (the reader's LED stops blinking), and then try a different USB port as indicated by the operating system message. (The device emits the beep OK signal. You can now read codes).
2. At this point, you can read the USB interface configuration code according to your application. Load drivers from the O.S. (if requested). When configuring the USB-COM interface, the relevant files and drivers must be installed from the USB Device Installation software, which can be downloaded at <http://www.scanning.datalogic.com>.

The device is ready. Successive start-ups will automatically recognize the previously loaded drivers

Changing default settings

Once your reader is set up, you can change the default parameters to meet your application needs. Refer to the preceding paragraphs for initial configuration in order to set the default values and select the interface for your application. In this manual, the configuration parameters are divided into logical groups making it easy to find the desired function based on its reference group.

The following parameter groups are common to all interface applications:

DATA FORMAT parameters regarding the messages sent to the host system.

POWER SAVE manages overall current consumption in the reading device.

READING PARAMETERS control various operating modes and indicator status functioning.

DECODING PARAMETERS maintain correct barcode decoding in certain special reading conditions.

CODE SELECTION parameters allow configuration of a personalized mix of codes, code families, and their options.

ADVANCED FORMATTING PARAMETERS allow code concatenation and advanced formatting of messages

RS232 parameters

- Baud rate
- Parity
- Data bits
- Stop bits
- Handshaking
- Ack/nack protocol
- FIFO
- Inter-character delay
- Rx timeout
- Serial trigger lock

1. Read the **Enter Configuration** code ONCE.
2. Read configuration codes from the desired groups.
 - Read the code and follow the procedure given
 - ◆ Default value
3. Read the **Exit and Save Configuration** code ONCE.



\$+\$*
Restore PSCAN-D default

Default serial interface	
Parameter	Default
Baud rate	9600
Parity	Disabled
Data bits	8
Stop bits	1
Handshaking	Disabled
ACK/NAK protocol	Disabled
FIFO	Enabled
Inter-character delay	Disabled
Rx timeout	5 seconds
Serial trigger lock	Disabled
Default data format	

Parameter	Default
Code identifier	Disabled
Custom code identifier	Disabled
Header	No
Terminator	No
Field adjustment	Disabled
Field adjustment character	Disabled
Code length Tx	Not transmitted
Character replacement	Disabled
Default power save	
Parameter	Default
Sleep state	Disable
Enter sleep timeout	0.6 seconds
Default reading parameter	
Parameter	Default
Trigger type	Hardware trigger
Trigger signal	Trigger active level
Trigger click	Disabled
Trigger-off timeout	Disabled
Flash mode	On 1 second, off 0.6 seconds
Reads per cycle	1
Safety time	0.5 seconds
Beeper intensity	High intensity
Beeper tone	Tone 2
Beeper type	Monotone
Beeper length	Short



Enter Configuration



Exit and Save Configuration



RS-232

BAUD RATE

300 baud



600 baud



1200 baud



2400 baud



4800 baud



◆ 9600 baud



19200 baud



38400 baud



PARITY

◆ none



even parity



odd parity





Enter Configuration



Exit and Save Configuration



RS-232

DATA BITS

7 bits



◆ 8 bits



9 bits



STOP BITS

◆ 1 stop bit



2 stop bits



HANDSHAKING

◆ disable



hardware (RTS/CTS)



software (XON/XOFF)



RTS always ON





Enter Configuration



Exit and Save Configuration



RS-232

ACK/NACK PROTOCOL

◆ disable



enable



FIFO

disable



◆ enable



INTER-CHARACTER DELAY



delay between characters transmitted to Host



Read 2 numbers from the table where:

00 = DELAY disabled

01-99 = DELAY from 1 to 99 milliseconds

◆ delay disabled



Enter Configuration



Exit and Save Configuration



RS-232

RX TIMEOUT



timeout control in reception from Host



Read 2 numbers from the table where:

- 00 = TIMEOUT disabled
- 01-99 = TIMEOUT from .1 to 9.9 seconds

◆ rx timeout 5 seconds

SERIAL TRIGGER LOCK

◆ disabled



enable and select characters



Read 2 characters from the Hex/Numeric table in the range 00-FE where:

- First Character enables device trigger
- Second Character inhibits device trigger until the first character is received again.



USB Parameters

USB-COM

- Handshaking
- Ack/Nack protocol
- FIFO
- Inter-character delay
- Rx timeout
- Serial trigger lock

USB-KBD

- Keyboard nationality
- FIFO
- Inter-character delay
- Inter-code delay
- USB keyboard speed

USB-IBM

- No parameter selection required
1. Read the Enter Configuration code ONCE.
 2. Read configuration codes from the desired groups.
 - Read the code and follow the procedure given
 - ◆ Default value
 3. Read the Exit and Save Configuration code ONCE.

Enter Configuration



Exit and Save Configuration



USB-COM

HANDSHAKING

◆ disable



hardware (RTS/CTS)



software (XON/XOFF)



RTS always ON



ACK/NACK PROTOCOL

◆ disable



enable



FIFO

disable



◆ enable





Enter Configuration



USB-COM

Exit and Save Configuration



INTER-CHARACTER DELAY



delay between characters transmitted to Host



Read 2 numbers from the table where:

- 00 = DELAY disabled
- 01-99 = DELAY from 1 to 99 milliseconds

◆ delay disabled

RX TIMEOUT



timeout control in reception from Host



Read 2 numbers from the table where:

- 00 = TIMEOUT disabled
- 01-99 = TIMEOUT from .1 to 9.9 seconds

◆ rx timeout 5 seconds

SERIAL TRIGGER LOCK

◆ disabled



enable and select characters



Read 2 characters from the Hex/Numeric table in the range 00-FE where:

- First Character enables device trigger
- Second Character inhibits device trigger until the first character is received again.



ENTER CONFIGURATION



USB-KBD

Exit and Save Configuration



KEYBOARD NATIONALITY

Not Available for USB-KBD-ALT-MODE Interface

This parameter default value is restored through the Interface Selection code and not Restore Default.

Belgian



English (UK)



French



German



Italian



Spanish



Swedish



◆ USA





ENTER CONFIGURATION



USB-KBD

Exit and Save Configuration



The Japanese and Eastern Block Keyboard Nationality selections are valid only for IBM AT compatible PCs.

Japanese



Russian (Latin)



Russian (Cyrillic)



Hungarian



Slovenian, Croatian,
Serbian (Latin)



Romanian



Czech Republic



FIFO

disable



◆ enable



ENTER CONFIGURATION



USB-KBD

Exit and Save Configuration



INTER-CHARACTER DELAY



delay between characters transmitted to Host



Read 2 numbers from the table where:

- 00 = DELAY disabled
- 01-99 = DELAY from 1 to 99 milliseconds

◆ delay disabled

INTER-CODE DELAY



delay between codes transmitted to Host



Read 2 numbers from the table where:

- 00 = DELAY disabled
- 01-99 = DELAY from 1 to 99 seconds

◆ delay disabled

USB KEYBOARD SPEED

◆ Normal



Fast



Data format

- Code identifier
- Custom code identifier
- Header
- Terminator
- Special keys
- Field adjustment
- Field adjustment character
- Code length Tx
- Character replacement

Default reading parameter	
Parameter	Default
Flash mode	On 1 second, off 0.6 seconds
Reads per cycle	1
Safety time	0.5 seconds
Beeper intensity	High intensity
Beeper tone	Ton 2
Beeper type	Monotone
Beeper length	Short
Good read spot duration	Medium
Aiming system	Disabled

Default decoding parameters	
Parameter	Default
Ink spread	Enabled
Overflow control	Enabled
Interdigit control	Enabled
Decoding safety	One read
Puzzle solver	Disabled

Default code selection	
Parameter	Default
EAN /UPC - family	EAN 8/EAN 13 / UPC A/UPC E Check digit control No conversion
2/5 family	Interleaved 2/5 Check digit control and transmission Variable code length: 4-55 characters
Code 39 family	Standard Code 39 No check digit control Variable code length: 1-99 characters
Code 128 family	Code 128 Check digit control without transmission Add GS before code = disabled
Code 93	Disabled
Codabar family	Disabled
MSI	Disabled
Code 11	Disabled
Code 16K	Disabled
Code 49	Disabled
GS1 DATABAR codes	Disabled

Default advanced formatting	
Parameter	Default
Concatenation	Disabled
Advanced formatting	No advanced formatting enabled

To change the default values

1. Read the "Enter Configuration" code once.
2. Read configuration codes from the desired groups or follow the procedure given for this code group.
3. When desired you can change further configuration codes directly.
4. Read the "Exit and Save Configuration" code once.

Code identifier			
Code	AIM standard	Datalogic standard	Custom
2/5 interleaved]ly	N	
2/5 industrial]Xy	P	
2/5 normal 5 bars]Sy	O	
2/5 matrix 3 bars]Xy	Q	
EAN 8]E4	A	
EAN 13]E0	B	
UPC A]Xy	C	
UPC E]Xy	D	
EAN 8 with 2 ADD ON]E5	J	
EAN 8 with 5 ADD ON]E6	K	
EAN 13 with 2 ADD ON]E1	L	
EAN 13 with 5 ADD ON]E2	M	
UPC A with 2 ADD ON]Xy	F	
UPC A with 5 ADD ON]Xy	G	
UPC E with 2 ADD ON]Xy	H	
UPC E with 5 ADD ON]Xy	I	
Code 39]Ay	V	
Code 39 full ASCII]Ay	W	
CODABAR]Fy	R	
ABC CODABAR]Xy	S	
Code 128]Cy	T	
EAN 128]Cy	k	
ISBT 128]C4	f	
Code 93]Gy	U	
CIP/39]Xy	Y	
CIP/HR]Xy	e	
Code 32]Xy	X	
MSI]My	Z	
Code 11]Hy	b	
Code 16 K]K0	p	
Code 49]Ty	q	
GS1 DataBar™ expanded and stacked]e0	t	
GS1 DataBar limited]e0	v	
GS1 DataBar 14 linear and stacked]e0	u	

Reference

AIM standard identifiers are not defined for all codes: the X identifier is assigned to the code for which the standard is not defined. The y value depends on the selected options (check digit tested or not, check digit tx or not, etc.).

When customizing the Datalogic Standard code identifiers, one or two identifier characters can be defined for each code type. If only one identifier character is required, the second character must be selected as FF (disabled).

The code identifier can be singly disabled for any code by simply selecting FF as the first identifier character.

Write in the custom character identifiers in the table above for your records.



Enter Configuration



Exit and Save Configuration



DATA FORMAT

CODE IDENTIFIER

◆ disable



Datalogic standard



AIM standard



custom



CUSTOM CODE IDENTIFIER



define custom code identifier(s)



- ① Read the above code.
(Code Identifiers default to Datalogic standard, see table on previous page).
- ② Select the code type from the code table in the **Message formatting** section, pages 72-79 for the identifier you want to change.
- ③ You can define 1 or 2 identifier characters for each code type. If only 1 identifier character is required, the second character must be selected as **FF** (disabled). Read the hexadecimal value corresponding to the character(s) you want to define as identifiers for the code selected in step ②: valid characters are in the range **00-FD**.

Example: To define Code 39 Code Identifier = @

Read  +  + 40 + FF

Enter Configuration



DATA FORMAT

Exit and Save Configuration



HEADER

no header



one character header



two character header



three character header



four character header



five character header



six character header



seven character header




eight character header



After selecting **one** of the desired Header codes, read the character(s) from the HEX table. Valid characters are in the range **00-FE**.

Example:

four character header
 + 41 + 42 + 43 + 44 = Header **ABCD**



Enter Configuration



DATA FORMAT

Exit and Save Configuration



TERMINATOR

no terminator



one character terminator



two character terminator



three character terminator



four character terminator



five character terminator



six character terminator



seven character terminator



eight character terminator



After selecting **one** of the desired Header codes, read the character(s) from the HEX table. Valid characters are in the range **00-FE**.

Example:

two character terminator



+ 0D + 0A = Terminator CR LF



DATA FORMAT




FIELD ADJUSTMENT

◆ disable field adjustment



Field adjustment allows a number of characters *n*, to be added to or subtracted from the barcode read. The adjustment can be different for each enabled code type. To define the field adjustment:

① Read the enable field adjustment code:



② Select the code type from the Code Identifier Table, page 75.

③ Select the type of adjustment to perform:



④ Read a number in the range **01 - 32** from the Hex/Numeric Table to define how many characters to add or delete:

Conditions:

- Adjustment is only performed on the barcode data, the Code Identifier and Code Length Transmission fields are not modified by the field adjustment parameter.
- If the field setting would subtract more characters than exist in the barcode, the subtraction will take place only to code length 0.
- You can set up to a maximum of 10 different field adjustments on the same barcode family or on different barcode families.

Example: To add 4 characters to the right of Standard Code 39 Codes:





Enter Configuration



Exit and Save Configuration



DATA FORMAT

FIELD ADJUSTMENT CHARACTER

- ① Read the field adjustment character code:



- ② Read the hexadecimal value corresponding to the character you want to use for field adjustment. Valid characters are in the range **00-FE**.

Example:

To define the field adjustment character = **A**:



CODE LENGTH TX

- ◆ code length not transmitted



code length transmitted in variable-digit format



code length transmitted in fixed 4-digit format



The code length is transmitted in the message after the Headers and Code Identifier characters. The code length is calculated after performing any field adjustment operations.

Enter Configuration



Exit and Save Configuration



DATA FORMAT

CHARACTER REPLACEMENT

◆ disable character replacement



This parameter allows up to three characters to be replaced from the barcode read. These substitutions are stored in memory. To define each character replacement:

① Read one of the following character replacement codes:

first character replacement



second character replacement



third character replacement



② From the Code Identifier Table on page 75, read the Code Identifier for the desired code family.

0 = character replacement will be effective for all code families.

③ From the Hex/Numeric Table read two characters corresponding to the Hex value (**00-FE**), which identifies the character to be replaced.

④ From the Hex/Numeric Table read two characters corresponding to the Hex value (**00-FE**), which identifies the new character to replace.

FF = the character to be replaced will be substituted with no character, that is, it will be removed from the code.



Enter Configuration



DATA FORMAT


Exit and Save Configuration




Example:

The following strings define:

1. *First Character Replacement:* substitution in *Code 39 barcodes* of all occurrences of the **0** character with the **1** character.
2. *Second Character Replacement:* substitution in *Code 39 barcodes* of all occurrences of the **A** character with the **B** character.



For Code 39 codes containing the string "0123", the contents transmitted will be "1123".



For Code 39 codes containing the string "ABCD", the contents transmitted will be "BBCD".



Reading parameters

- Trigger type
- Trigger signal
- Trigger click
- Trigger-off timeout
- Flash mode
- Reads per cycle
- Safety time
- Beeper intensity
- Beeper tone
- Beeper type
- Beeper length
- Good read spot duration
- Aiming system
- Cradle beeper intensity

1. Read the Enter Configuration code ONCE.
 2. Read configuration codes from the desired groups.
 - Read the code and follow the procedure given
 - ◆ Default value
- Read the Exit and Save Configuration code ONCE.



READING PARAMETERS

TRIGGER TYPE

- ◆ hardware trigger



Restores TRIGGER MODE

- software trigger



Enables FLASH MODE

- always on



TRIGGER SIGNAL

- ◆ trigger active level



- trigger active pulse



TRIGGER CLICK

- ◆ disable



- enable





Enter Configuration



Exit and Save Configuration



READING PARAMETERS

TRIGGER-OFF TIMEOUT



trigger-off timeout



Read 2 numbers in the range 00-99:

00 = disables the trigger-off timeout

01-99 = corresponds to a max. 99-sec. delay after the trigger press to allow the reader to turn off automatically.

◆ trigger-off timeout disabled

FLASH MODE



"FLASH" ON duration



"FLASH" OFF duration



Read 2 numbers in the range 01-99:

01 to 99 = from .1 to 9.9 seconds.

◆ Flash-ON = 1 sec. Flash-OFF = 0.6 sec

READS PER CYCLE

◆ one read per cycle



multiple reads per cycle





Enter Configuration



READING PARAMETERS

Exit and Save Configuration



SAFETY TIME



safety time



Limits same code consecutive reading.

Read 2 numbers in the range 00-99:

00 = no same code consecutive reading until reader is removed (no decoding) for at least 400 ms.

01-99 = timeout from .1 to 9.9 seconds before a consecutive read on same code.

◆ safety time = 0.5 sec

BEEPER INTENSITY

* very low intensity



low intensity



medium intensity



◆ high intensity



* This sets the beeper OFF for data entry, while for all other beeper signals it has the meaning "very low intensity". The Beeper Intensity parameter is effective for all operating conditions





Enter Configuration



READING PARAMETERS

Exit and Save Configuration



BEEPER TONE

tone 1



◆ tone 2



tone 3



tone 4



BEEPER TYPE

◆ monotone



bitonal



BEEPER LENGTH

long



◆ short





Enter Configuration



Exit and Save Configuration



READING PARAMETERS

GOOD READ SPOT DURATION

disable



short



◆ medium



long



AIMING SYSTEM

◆ disabled



enabled



CRADLE BEEPER INTENSITY

disable



low intensity



medium intensity



◆ high intensity





Decoding parameters

- Ink spread
- Overflow control
- Interdigit control
- Decoding safety
- Puzzle solver™



Warning

Before changing these parameter values, be aware that these parameters are intended to enhance the decoding capability of the reader for particular applications. Used incorrectly, they can degrade the reading performance or increase the possibility of a decoding error.

1. Read the Enter Configuration code ONCE, available at the top of each page.
2. Read configuration codes from the desired groups.
◆ = Default value
3. Read the Exit and Save Configuration code ONCE, available at the top of each page.

Enter Configuration



Exit and Save Configuration



DECODING PARAMETERS

INK SPREAD

disable



◆ enable



OVERFLOW CONTROL

disable



◆ enable



INTERDIGIT CONTROL

disable



◆ enable





DECODING PARAMETERS



DECODING SAFETY

◆ one read



two reads



three reads



four reads



Required number of good reads before accepting code.

PUZZLE SOLVER™

◆ disable



enable



In the case of damaged or poorly printed codes, this parameter allows reading multiple parts of the single code to reconstruct it.

To read codes using this technology, simply move the illuminated bar over the code so that each line of the code is scanned. During this process a series of brief “ticks” indicates that reading is proceeding correctly.

Conditions:

- This parameter is only valid for the following codes:

EAN 8 without Add-on	EAN 13 without Add-on	UPC A without Add-on
Code 128	Code 39	

- **For Code 39, Check digit control is forced.**
- PuzzleSolver™ is not valid for ISBT 128 code.



Code selection

- Auto-configuration
- EAN/UPC family
- 2/5 family
- Code 39 family
- Code 128 family
- Codabar family
- Code 93
- MSI
- Code 11
- Code 16K
- Code 49
- Gs1 databar codes

1. Read the Enter Configuration code ONCE.
2. Read configuration codes from the desired groups.
 - Read the code and follow the procedure given
 - ◆ Default value
3. Read the Exit and Save Configuration code ONCE.

Code selections may be performed according to two different procedures:

- **Auto configuration**, allowing an automatic recognition and selection of the code families to be read;
- **Manual configuration**, requiring configuration and selection of each code family to be read.

Auto configuration

- The following codes do not require reading the Enter and Exit configuration codes.

In auto configuration mode the reader enters a particular state, during which it reads, recognizes and saves all information received from the decoding of an existing code (with the exception of MSI, Code 49 and Code 16k code types). In this way, the code families will be automatically configured.

It is possible to configure up to 10 code types, whose length is variable and check digit ignored.


If reading different codes belonging to the same family, information about the last code will overwrite the information about the previous one.

Follow the given procedure to auto-configure the desired code families:



Warning If no code is read during the auto-configuration procedure (step 2), the configuration will be empty and therefore the reader will be unable to read codes.

1. Read the following code to enter the auto-configuration mode:



2. Read an existing code belonging to the code families that you need to configure.
3. Read the following code to save the configuration automatically and return to the reader's normal functioning:



If you need to change the configuration, repeat the auto-configuration procedure, follow the manual configuration by setting the parameters for each single code family. Be careful that in the latter case all reader parameters will be restored.

Enter Configuration



CODE SELECTION

Exit and Save Configuration



DISABLE ALL CODE FAMILIES



The reader allows up to 10 code selections. This does not limit the number of CODES enabled to 10, as it depends on the code family.

NOTE

Single selections

- ONE combination code from the EAN family
- ONE code from the 2/5 family

Example

5 code selections:

1. **2/5 Interleaved**
2. **2/5 Industrial**
3. Code 128 + EAN 128
4. Code 39 Full ASCII + Code 32
5. **UPC A/UPC E**
6. *etc.*

In this section all SINGLE code selections are underlined and in bold.



Enter Configuration



Exit and Save Configuration



CODE SELECTION

EAN/UPC FAMILY

disable the family



① Read the desired family code

NOTE: Since the EAN/UPC without ADD ON code selection is enabled by default, to correctly enable another selection, first disable the family.

EAN 8/EAN 13/UPC A/UPC E with and without ADD ON



WITHOUT ADD ON

◆ EAN 8/EAN 13/UPC A/UPC E



EAN 8/EAN 13



UPC A/UPC E



WITH ADD ON 2 AND 5

EAN 8/EAN 13/UPC A/UPC E



EAN 8/EAN 13



UPC A/UPC E





Enter Configuration



Exit and Save Configuration



CODE SELECTION

WITH ADD ON 2 ONLY

EAN 8/EAN 13



UPC A/UPC E



WITH ADD ON 5 ONLY

EAN 8/EAN 13



UPC A/UPC E



WITH AND WITHOUT ADD ON

◆ EAN/UPC with and without ADD ON no
Autodiscrimination



EAN/UPC Autodiscrimination ADD ON by
Prefix



By setting the EAN/UPC Autodiscrimination ADD ON by Prefix, the desired prefixes must be selected by reading the corresponding codes given in the following section, since no prefix is configured by default.



Enter Configuration



CODE SELECTION

Exit and Save Configuration



SELECT EAN/UPC PREFIXES

	<p>NOTE</p> <p><i>When scanning the following codes, barcodes starting with <u>the selected prefixes</u> will be read and transmitted only if the <u>ADD ON</u> is present. If no <u>ADD ON</u> is found, the barcode will not be read. Barcodes starting with different characters are read regardless of <u>ADD ON</u> presence and transmitted always without <u>ADD ON</u>.</i></p>
--	--

◆ Cancel All Selections



OR

select one or more of the following prefixes:

378/379



434/439



414/419



977



978



979



The commands above are not mutually exclusive. They can be used to configure more than one set of prefixes simultaneously.



Enter Configuration



CODE SELECTION

Exit and Save Configuration



Example:

The following string allows reading and transmitting with ADD ON all EAN/UPC starting with the 434/439, 977 and 978 prefixes:

1. EAN/UPC Autodiscrimination ADD ON by Prefix.
2. 434/439: enables reading and transmission with ADD ON of all EAN/UPC barcodes starting with 434/439 prefixes.
3. 977: enables reading and transmission with ADD ON of all EAN/UPC barcodes starting with 977 prefix.
4. 978: enables reading and transmission with ADD ON of all EAN/UPC barcodes starting with 978 prefix.



To clear the current prefix selections:

1. *Cancel all Selections*





Enter Configuration



CODE SELECTION

Exit and Save Configuration



EAN/UPC CHECK DIGIT TX SELECTIONS

For each code type in this family you can choose to transmit the check digit or not

CHECK DIGIT TRANSMISSION

◆ EAN 8



◆ EAN 13



◆ UPC A



◆ UPC E



NO CHECK DIGIT TRANSMISSION

EAN 8



EAN 13



UPC A



UPC E





Enter Configuration



Exit and Save Configuration



CODE SELECTION

CONVERSION OPTIONS

UPC E to UPC A conversion



UPC E to EAN 13 conversion



UPC A to EAN 13 conversion



EAN 8 to EAN 13 conversion



Enable only ISBN conversion



Enable only ISSN conversion



Enable both ISBN and ISSN conversion



Disable both ISBN and ISSN conversion





Enter Configuration



CODE SELECTION

Exit and Save Configuration



2/5 FAMILY

disable the family



① Read the desired family code



◆ Interleaved 2/5



Normal 2/5 (5 Bars)



Industrial 2/5 (IATA)



Matrix 2/5 (3 Bars)



The pharmaceutical code below is part of the 2/5 family but has no check digit or code length selections.

Code CIP/HR



French pharmaceutical code

② Read a check digit selection

CHECK DIGIT TABLE

no check digit control



◆ check digit control and transmission



check digit control without transmission



③ Read 4 numbers for the code length where:

- **First 2 digits** = minimum code length.
- **Second 2 digits** = maximum code length.

The maximum code length is **99** characters.

The minimum code length must always be less than or equal to the maximum.

Examples:

0199 = variable from 1 to 99 digits in the code.

1010 = 10 digit code length only.




Enter Configuration

CODE SELECTION



Exit and Save Configuration

CODE 39 FAMILY





① Read the desired family code

② Read a check digit selection

CHECK DIGIT TABLE



The pharmaceutical codes below are part of the Code 39 family but have no check digit selections.



CODE LENGTH (optional)

The code length selection is valid for the entire Code 39 family

Read the code + 4 numbers for the code length where:

First 2 digits = minimum code length.

Second 2 digits = maximum code length.

set code length



The maximum code length is **99** characters.

The minimum code length must always be less than or equal to the maximum.

Examples: **0199** = variable from 1 to 99 digits in the code. **1010** = 10 digit code length only.



Enter Configuration



Exit and Save Configuration



CODE SELECTION

CODE 128 FAMILY

disable the family



- ① Read the desired family code
 - ◆ **Code 128**



control without transmission of check digit

EAN 128



control without transmission of check digit

ISBT 128



enabling ISBT 128 automatically disables Puzzle Solver™.

Transmit GS Before Code

Code EAN 128 uses the ASCII <GS> character to separate a variable length code field from the next code field. This character can also be transmitted before the code.

◆ disable



enable



If the <GS> character has been modified in the Character Replacement parameter, the new character is affected by this command.

CODE LENGTH (optional)

The code length selection is valid for the entire Code 128 family and is calculated on the output string.

Read the code + 4 numbers for the code length where:

set code length



First 2 digits = minimum code length.

Second 2 digits = maximum code length.

The maximum code length is **99** characters.

The minimum code length must always be less than or equal to the maximum.

Examples: **0199** = variable from 1 to 99 digits in the code. **1010** = 10 digit code length only.



Enter Configuration



CODE SELECTION

Exit and Save Configuration



CODE 93

◆ disable the code



Code 93



control without transmission
of check digit

CODABAR FAMILY

◆ disable the family



① Read the desired equality control code

② Read a start/stop transmission selection

Standard Codabar



no start/stop character equality control

START/STOP CHARACTER TRANSMISSION

no transmission



Standard Codabar



start/stop character equality control

transmission





Enter Configuration



Exit and Save Configuration



CODE SELECTION

The Codabar ABC code below uses a fixed start/stop character transmission selection.

Codabar ABC



no start/stop character equality control but transmission.

Codabar ABC Forced Concatenation

enable Codabar ABC with forced concatenation



non start/stop character equality control but transmission

CODE LENGTH (optional)

The code length selection is valid for the entire Codabar family

Read the code + 4 numbers for the code length where:

set code length



First 2 digits = minimum code length.

Second 2 digits = maximum code length.

The maximum code length is **99** characters.

The minimum code length must always be less than or equal to the maximum.

Examples: **0199** = variable from 1 to 99 digits in the code. **1010** = 10 digit code length only.

START/STOP CHARACTER CASE IN TRANSMISSION

The start/stop character case selections below are valid for the entire Codabar family:

transmit start/stop characters in lower case



transmit start/stop characters in upper case





Enter Configuration



CODE SELECTION

Exit and Save Configuration



MSI

◆ disable the family



Enable the code by selecting one of the check digit selections.

no check digit control



MOD10 check digit control
no check digit transmission



MOD10 check digit control
check digit transmission



MOD11 - MOD10 check digit control
no check digit transmission



MOD11 - MOD10 check digit control
check digit transmission



MOD10 - MOD10 check digit control
no check digit transmission



MOD10 - MOD10 check digit control
check digit transmission





Enter Configuration



Exit and Save Configuration



CODE SELECTION

CODE 11

◆ disable the family



Enable the code by selecting one of the check digit selections.

no check digit control



Type C check digit control
check digit transmitted



Type C check digit control
check digit not transmitted



Type K check digit control
check digit transmitted



Type K check digit control
check digit not transmitted



Type C and Type K
check digit control
check digits transmitted



Type C and Type K
check digit control
check digits not transmitted





Enter Configuration



CODE SELECTION

Exit and Save Configuration



CODE 16K

◆ disable the code



Code 16K



To read stacked codes, simply move the reader over the code so that each line of the code is scanned. During this process a series of brief "ticks" indicates that reading is proceeding correctly.

CODE 49

◆ disable the code



Code 49



To read stacked codes, simply move the reader over the code so that each line of the code is scanned. During this process a series of brief "ticks" indicates that reading is proceeding correctly.



Enter Configuration



Exit and Save Configuration



CODE SELECTION

GS1 DATABAR™ CODES

◆ disable the family



DISABLE CODE

ENABLE CODE

disable GS1 DataBar Expanded Linear and Stacked



enable GS1 DataBar Expanded Linear and Stacked



disable GS1 DataBar Limited



enable GS1 DataBar Limited



disable GS1 DataBar 14 Linear and Stacked



enable GS1 DataBar 14 Linear and Stacked



To read stacked codes, simply move the reader over the code so that each line of the code is scanned. During this process a series of brief "ticks" indicates that reading is proceeding correctly.

Advanced formatting

- Concatenation
- Advanced formatting



NOTE

Please follow the setup procedure carefully for these parameters

1. Read the Enter Configuration code ONCE.
2. Read configuration codes from the desired groups.
 - Read the code and follow the procedure given
 - ◆ Default value
3. Read the Exit and Save Configuration code ONCE.

Enter Configuration



ADVANCED FORMATTING

Exit and Save Configuration



CONCATENATION

◆ disable



enable



Permits the concatenation of two codes defined by code type and length. It is possible to set a timeout for the second code reading and to define code transmission if the timeout expires.

The order of transmission is CODE 1-CODE 2.

Define Concatenation

1

Code 1

code ID



Read the code type from the [Code Identifier Table](#), page 75.

code length



Read a number in the range **01-99** from the Hex/Numeric Table.



Exit and Save Configuration

ADVANCED FORMATTING



2

Code 2

code ID



Read the code type from the Code Identifier Table, page 75.

code length



Read a number in the range **01-99** from the Hex/Numeric Table.

3

Concatenation Result Code ID

use code 1 ID



use code 2 ID



Since you can concatenate codes from different families, you must select the Code ID character of the resulting code. The Code ID character will be sent in the output message only if it is enabled according to the Code Identifier selection (Datalogic, AIM, or Custom).

4

Concatenation Timeout

timeout



Read two numbers in the range **00 to 99**

00= no timeout

01-99 = timeout from 1 to 99 seconds

Define the timeout, which determines the valid waiting period between the two codes, in order to accept concatenation. If the timeout expires, the resulting action will be based on the following selection. (HHDII)



Exit and Save Configuration



ADVANCED FORMATTING

5

Transmission after Timeout

no code transmitted
after timeout



only code 1 transmitted
(if read) after timeout



only code 2 transmitted
(if read) after timeout



either code 1 or code 2 transmitted
after timeout






ADVANCED FORMATTING

ADVANCED FORMATTING

Advanced formatting has been designed to offer you complete flexibility in changing the format of barcode data **before** transmitting it to the host system. This formatting will be performed when the barcode data meets certain criteria, which you will define in the following procedure.

Up to 4 advanced code management formats can be defined and saved in memory. For each format you must complete the entire configuration procedure:





ADVANCED FORMATTING

1 Begin Format Definition

begin Format 1 definition





begin Format 2 definition




begin Format 3 definition




begin Format 4 definition



2 Match Code Type

match code type




Read the above code + the code type to match from the Code Identifier Table, page 75.

OR

any code type



3 Match Code Length

match code length




Read the above code + two numbers in the range **01** to **99** for the exact code length.

OR

any code length





Exit and Save Configuration

ADVANCED FORMATTING



4



Match with Predefined Characters

no match





OR



match with 1 character



match with a 2-character string

match with a 3-character string


match with a 4-character string



After selecting the predefined match code, read the character(s) from the HEX table. Range of characters = **00-FE**.

Example:
Match code with the 2-character predefined string = "@@".

Match with a 2-character string

Read  + 40 + 40

AND position of first character in predefined string

Read the above code + two numbers in the range **01** to **99** representing the character position in the code where the first character of the predefined string must be found.

Read **00** if the match string can be found in any character position.

Exit and Save Configuration



ADVANCED FORMATTING

5 Divide Code into Fields

divide code into fields



Read one number in the range **1** to **5** to divide the code into fields.

6 Define Code Fields

define code fields

Each code field length can be set by either:

- a) defining a field separator character to be found in the code itself. In this case you can choose to **discard** the code separator character or **include** it as the last character of the field.

OR BY

- b) defining a match character to be found consecutively repeated in the code itself. In this case the field ends with the first character that does not match.

OR BY

- c) specifying a specific character length up to the maximum of 99 characters.

OR BY

- d) selecting the last field as variable length (if any).

You must define the same number of fields as selected in step 5, including fields that will not be transmitted.







Exit and Save Configuration





ADVANCED FORMATTING



DEFINE FIELD 1 BY: EITHER

a)  field separator

 Read the field separator character from the HEX table. Range of characters = **00-FE**.
 discard separator  include separator 

OR

b)  match character

 Read the match character from the HEX table. Range of characters = **00-FE**.

OR

c)  field length

 Read two numbers in the range **01** to **99** to define the field length.

OR

d)  this is the last field (variable length)


AND

Field 1 Terminators

no field terminators



1 field terminator



2 field terminators



Read the field terminator character(s) from the HEX table. Valid range of characters for all readers = **00-FE**.

Exit and Save Configuration

ADVANCED FORMATTING



**DEFINE FIELD 2 BY:
EITHER**

a) field separator
 field separator
 Read the field separator character from the HEX table. Range of characters = **00-FE**.
 discard separator include separator

OR

b) match character
 match character
 Read the match character from the HEX table. Range of characters = **00-FE**.

OR

c) field length
 field length
 Read two numbers in the range **01** to **99** to define the field length.

OR

d) this is the last field (variable length)

AND

Field 2 Terminators

no field terminators



1 field terminator



2 field terminators



Read the field terminator character(s) from the HEX table. Valid range of characters for all readers = **00-FE**.





Exit and Save Configuration



ADVANCED FORMATTING





DEFINE FIELD 3 BY: EITHER

a)  field separator 

Read the field separator character from the HEX table. Range of characters = **00-FE**.



discard separator  include separator 

OR

b)  match character 

Read the match character from the HEX table. Range of characters = **00-FE**.

OR

c)  field length 

Read two numbers in the range **01 to 99** to define the field length.

OR



d)  this is the last field (variable length) 

AND

Field 3 Terminators

no field terminators 

 1 field terminator 

 2 field terminators 

Read the field terminator character(s) from the HEX table. Valid range of characters for all readers = **00-FE**.



Exit and Save Configuration

ADVANCED FORMATTING



DEFINE FIELD 4 BY: EITHER

a) field separator
 field separator
 Read the field separator character from the HEX table. Range of characters = **00-FE**.
 discard separator include separator

OR

b) match character
 match character
 Read the match character from the HEX table. Range of characters = **00-FE**.

OR

c) field length
 field length
 Read two numbers in the range **01 to 99** to define the field length.

OR

d) this is the last field (variable length)

AND

Field 4 Terminators

no field terminators



1 field terminator



2 field terminators



Read the field terminator character(s) from the HEX table. Valid range of characters for all readers = **00-FE**.





Exit and Save Configuration



ADVANCED FORMATTING





DEFINE FIELD 5 BY: EITHER

a)   field separator

Read the field separator character from the HEX table. Range of characters = **00-FE**.



 discard separator  include separator

OR

b)   match character

Read the match character from the HEX table. Range of characters = **00-FE**.

OR

c)   field length

Read two numbers in the range **01** to **99** to define the field length.

OR

d)   this is the last field (variable length)

AND

Field 5 Terminators

no field terminators



1 field terminator



2 field terminators



Read the field terminator character(s) from the HEX table. Valid range of characters for all readers = **00-FE**.



Exit and Save Configuration

ADVANCED FORMATTING



7

First Additional Fixed Field

no fixed field



1 character fixed field



2 character fixed field



3 character fixed field



4 character fixed field



5 character fixed field




6 character fixed field



After selecting **one** of the Additional Fixed Field codes, read the corresponding character(s) from the HEX table. Range of characters = **00-FE**.

Example:

4 Character Fixed Field



$$+ 4D + 41 + 49 + 4E = \text{MAIN}$$



Exit and Save Configuration



ADVANCED FORMATTING

8

Second Additional Fixed Field

no fixed field



1 character fixed field



2 character fixed field



3 character fixed field



4 character fixed field



5 character fixed field



6 character fixed field



After selecting **one** of the Additional Fixed Field codes, read the corresponding character(s) from the HEX table. Range of characters = **00-FE**.

Example:

3 Character Fixed Field



+ 53 + 45 + 54 = SET



Exit and Save Configuration



ADVANCED FORMATTING

9

Field Transmission

number of fields to transmit



Read one number in the range 1 to 7 for the number of fields to transmit. **Include only fields to be transmitted.**

Field Order Transmission

Read the codes corresponding to the fields to transmit in the order in which they are to be transmitted. A field can be transmitted more than once. See example.

field 1



field 2



field 3



field 4



field 5



additional field 1



additional field 2



Example:

The barcode is divided into 3 defined fields plus 1 additional fixed field.
Transmit in the order: Field 2, Additional Field 1, Field 1, Field 2.





Exit and Save Configuration

ADVANCED FORMATTING



10

Standard Formatting

do not apply standard formatting



apply standard formatting



PSCAN-D-1D-D2: After performing Advanced Formatting on the barcode read, Standard Formatting (Headers, Code Length, Code ID, Terminators) can be applied to the message to be transmitted.

11

End Format Definition

end Format 1 definition



end Format 2 definition



end Format 3 definition



end Format 4 definition





Enter Configuration



ADVANCED FORMATTING

Exit and Save Configuration



Enable Advanced Format

◆ no Advanced Formats enabled



Advanced Format 1

enable



disable



Advanced Format 2

enable



disable



Advanced Format 3

enable



disable



Advanced Format 4

enable



disable





Enter Configuration



ADVANCED FORMATTING

Exit and Save Configuration



No Match Result

clear data - no transmission



transmit data using standard
format



This selection determines the action to be taken when codes read do not conform to the advanced format requisites (no match).


- Codes not matching can be ignored, cleared from memory and not transmitted.
- Codes not matching can be transmitted using the Standard formatting (Headers, Code Length, Code ID, Terminators).

References

ACK/NACK protocol

PSCAN-D-1D-D2 readers

This parameter sets a transmission protocol in which the host responds to the reader after every code transmitted. The host sends an ACK character (06 HEX) in the case of good reception or the NACK character (15 HEX) requesting re-transmission, in the case of bad reception



If the reader does not receive an ACK or NACK, transmission is ended after the RX Timeout. When ACK/NACK protocol is enabled, FIFO must be disabled manually.

FIFO

PSCAN-D-1D-D2 readers

This parameter determines whether data (barcodes) are buffered on a First In First Out basis allowing faster data collection in certain cases, for example when using slow baud rates and/or hardware handshaking. If the FIFO buffering is enabled, codes are collected and sent out on the serial line in the order of acquisition. About 800 characters can be collected (buffer full), after which the reader signals an error and discards any further codes until the transmission is restored. If the FIFO buffering is disabled, each code must be transmitted before another one can be read.

RX timeout

When the RS-232 interface is selected, the host can be used to configure the device by sending it command strings. This parameter can be used to automatically end data reception from the host after the specified period of time. If no character is received from the host, after the timeout expires, any incomplete string (any string not terminated by <CR>) is flushed from the device buffer.

Reading parameters

Trigger signal

This mode determines how the reading phase is controlled when the hardware trigger operating mode is selected:

- **Trigger active level:** the reader goes ON when the trigger is pressed and goes OFF when it is released
- **Trigger active pulse:** the reader goes ON at the first trigger press and goes OFF only at a second press

Trigger click

When enabled, it activates a "click" sound upon each trigger pressure.

Trigger-off timeout

When this timeout is selected, the reader turns OFF automatically after the desired period of time.

Reads per cycle

In general, a reading cycle corresponds to the ON + OFF times of a device.

The resulting effects of this parameter on code reading depend on other related configuration conditions. Here are the definitions of ON and OFF times.

- For readers using the software trigger parameter (FLASH MODE), a reading cycle corresponds to the flash on + flash off times. Code reading takes place during the flash on time.
- For readers using the hardware trigger parameter, a reading cycle corresponds to a trigger press (ON) + one of the following OFF events: trigger release (for trigger active level) a second trigger press (for trigger active pulse) trigger-off timeout

When one read per cycle is selected, the device decodes only one code during the ON period and immediately turns the reader OFF. It is only possible to read another code when the next ON time occurs. In multiple reads per cycle, the ON period is extended so that the device can continue decoding codes until an OFF event occurs. For software trigger mode, the flash on period is immediately reset after each read and therefore extended. If another code is decoded before the reset flash on period expires, it is again reset and the effect is that the device remains ON, decoding codes until the flash on or timeout period expires. The safety time parameter should be used in this case to avoid unwanted multiple reading of the same code.

Safety time

Safety time prevents the device from immediately decoding the same code more than once. Same code consecutive reading can be disabled requiring the reader to be removed from the code (no decoding) for at least 400 ms, or a timeout can be set up to 9.9 seconds before the decoder will accept the same code. Reading is immediate if the code changes. The safety time parameter is not applicable when reading stacked codes or when setting one read per cycle in hardware trigger operating mode, since these settings require voluntary action by the user.

Decoding parameters



Warning

These parameters are intended to enhance the decoding capability of the reader for particular applications. Used incorrectly, they can degrade the reading performance or increase the possibility of a decoding error.

Ink-spread

The ink-spread parameter allows the decoding of codes that are not perfectly printed because the page texture tends to absorb the ink.

Overflow control

The overflow control parameter can be disabled when decoding codes printed on small surfaces that do not allow the use of an overflow space. This command does not affect code families 2/5, Code 128, and Code 93.

Interdigit control

The interdigit control parameter verifies the interdigit spacing for code families Code 39 and Codabar.



Advanced formatting

Match conditions

Selecting an Advanced Formatting and specifying a Match restriction (Code Type, Code Length, Predefined Characters), the code will be transmitted according to the order of the defined formats.

For example, defining 2 formats where:

- Format 1: Match Code type = Code128
- Format 2: Match Code length = 15 and Match with Predefined Characters "DATA" a Code128 "DATA:12345ABCDE" with code length 15 will be formatted following the Format 1.

To send the same code with the Format 2, it is necessary to invert the format order as follows:

- Format 1: Match Code length = 15 and Match with Predefined Characters "DATA"
- Format 2: Match Code type = Code128

Custom default configuration

Read the following code to set the reader user-defined configuration as custom default configuration:

Save User-defined Configuration as Custom Default



Read the following code whenever you need to restore the custom default configuration:

Restore Custom Default Configuration



Code type recognition

This procedure allows the reader to enter a particular state during which it reads and transmits to the host information about the family type of codes unknown to the user (with the exception of MSI, Code 49, and Code 16k code types). It is also possible to read and transmit configuration strings without interpreting them. All codes are read ignoring the check digit. Follow the given procedure:

- ① Read the following code to enter the code type recognition mode:



code type recognition



- ② Read existing codes whose family type you need to check.

- ③ Read the following code to return to the reader's normal functioning:

exit code type recognition mode



Message formatting

The system always provides PSCAN-D (barcode reader) to host data communication using the following message formatting:

```
[Header][Barcode reader-Address]
[Barcode reader-Adresse_delimiter][Base
stationaddr.][Base station addr_delimiter]
[Time stamp][Time stamp_delimiter][Code
ID][Codlength] CODE [Terminator][items in
square brackets are optional]
```

Messages from Host to Reader

The general format to enable the barcode reader for 2 way communication is:

```
[Barcode reader_address][Barcode reader_address_
delimiter]<Message>CR
```

Note!

- If you enabled the barcode reader address stamping or the Barcode reader address delimiter, you must specify them in every message.
- If you have not enabled the barcode reader address stamping or the barcode reader address Delimiter, you must not specify them.
- Messages cannot start with "\$+" because they would be interpreted as a configuration command.

The message field can store plain text and escape sequences.

- Escape sequences are interpreted as commands.
- Plain text is directly printed on the display. If writing beyond the end of line, the display does not wrap automatically. Extra characters are ignored. Control characters are not interpreted.

Cursor Control

```
ESC[n A Up n rows, no scroll
ESC[n B Down n rows, no scroll
ESC[n C Right n columns
ESC[n D Left n columns
ESC[G CR
ESC[r;cH Move to row r, column c, ESC[1;1H is the upper left character
position of the display)
ESC D Down 1 row, with scroll
ESC E CR and cursor down 1 row with scroll
ESC M Up 1 row and scroll
```

Note

- Since <CR> is used as the message terminator, you must use ESC [G order ESC E to print a CR.
- The cursor row position is not affected by the currently selected front. The display always has 4 rows, so when writing with the large font, actually two rows are written to the current one and the one below it. You will need two ESC E commands to step from one row to the next when using the large font.
- The cursor column position is affected by the currently selected font. Therefore, column 6 is 36 pixels from the left border only if you last selected the 6x8 font; otherwise, it could be 48 or 72 pixels from the left border.

Font Selection

ESC [0 m Normal mode

ESC [7 m Reverse mode

ESC # 4 Large font: subsequent characters are written on the current row and the row below it using the 12x16 font which allows for two of eight characters on the display.

ESC # 5 Normal font: subsequent characters are written using the 6x8 font which allows for four rows of sixteen characters on the display.

ESC # 7 Medium font: subsequent characters are written using 8x8 font which allows for four rows of twelve characters on the display.

LED and Beeper Control

ESC [0 q Emit short high tone + short delay

ESC [1 q Emit short low tone + short delay

ESC [2 q Emit long low tone + short delay

ESC [3 q Emit good read tone

ESC [4 q Emit bad tx tone

ESC [5 q Wait 100 ms

ESC [6 q Turn on the green LED

ESC [7 q Turn off the green LED

ESC [8 q Turn on red LED

ESC [9 q Turn off red LED

The LED control escape sequences are intended to activate the LEDs for short periods of time and can be used in combination with the beeper. The LED and beeper will be controlled by the system after the entire command sequence is interpreted.

Example:

ESC [6 ESC [3 q ESC [7 q Turns on the green LED, emits a good read tone, and turns off the green LED.

ESC [6 ESC [5 q ESC [7 q Turns on the green LED for 100 ms and then turns off the green LED.

Setting RTC

ESC [0 p T T M M J J Set date to day, month, year.

























ESC [1 p H H M M Set time to hours, minutes, seconds are automatically set to 00.















Codes and character sets

Single codes

- To enter numerical values, scan successively the digits 0-9.
- Read alphanumeric values by scanning their hex values, i.e., 'L' (hexadecimal value: 4C): first scan '4' then 'C'.

 0	 1	 2
 3	 4	 5
 6	 7	 8
 9	 A	 B
 C	 D	 E
 F	 G	 H
 I	 J	 K
 L	 M	 N

Codes and character sets (cont.)

 O	 P	 Q
 R	 S	 T
 U	 V	 W
 X	 Y	 Z



Code identifier table

2/5 Interleaved



N

2/5 Industrial



P

2/5 normal 5 bars



Q

2/5 matrix 3 bars



Q

EAN 8



A

EAN 13



B

UPC A



C

UPC E



D

EAN 8 with 2 ADD ON



J

EAN 8 with 5 ADD ON



K

Code identifier table (cont.)

EAN 13with2 ADD ON



L

UPC Awith2 ADD ON



F

UPC Ewith2 ADD ON



H

Code 39



V

Codabar



R

Code 128



T

Code 93



U

CIP/HR



e

EAN 13with5 ADD ON



M

UPC A with5 ADD ON



G

UPC Ewith5 ADD ON



I

Code 39 Full ASCII



W

ABC Codabar



S

EAN 128



k

CIP/39



Y

Code 32



X



Code identifier table (cont.)

ISBT 128



f

MSI



Z

Code 16K



p

Code 11



b

Code 49



q

GS1 Databar Expanded Linear and Stacked



t

GS1 Databar Limited



v

GS1 Databar 14 Linear and Stacked



u

Configuration codes

Enter configuration



\$+

Exit and save configuration



\$-

Abort current setting



\$%

Cancel all current settings
(without exit)



\$/

Send Firmware Version



\$+!

Restore Default



\$+*

Hex and numeric tables

Decimal	Hexadecimal	Character	Meaning of the most important Control characters
0	00 h	NUL	without effect
1	01 h	SOH	Start of header
2	02 h	STX	Start of text
3	03 h	ETX	End of text
4	04 h	EOT	End of transmission
5	05 h	ENQ	Enquiry
6	06 h	ACK	Acknowledge
7	07 h	BEL	Bell
8	08 h	BS	Back space
9	09 h	HT	Horizontal tabulating
10	0A h	LF	Line feed
11	0B h	VT	Vertical tabulating
12	0C h	FF	Form Feed
13	0D h	CR	Carriage Return
14	0E h	SO	SHIFT out,
15	0F h	SI	SHIFT in
16	10 h	DLE	Data link escape
17	11 h	DC1	XON
18	12 h	DC2	
19	13 h	DC3	XOFF
20	14 h	DC4	
21	15 h	NAK	Negative acknowledge
22	16 h	SYN	Sync character
23	17 h	ETB	End of transmission block
24	18 h	CAN	Cancel
25	19 h	EM	End of Medium
26	1A h	SUB	Substitute
27	1B h	ESC	ESCAPE
28	1C h	FS	FIELD separator
29	1D h	GS	Group separator
30	1E h	RS	Record separator
31	1F h	US	Until separator, Space

Hex and numeric tables (cont)

Decimal	Hexa-decimal	Character	Decimal	Hexa-decimal	Character	Decimal	Hexa-decimal	Character
32	20 h	SPACE	64	40 h	@	96	60 h	`
33	21 h	!	65	41 h	A	97	61 h	a
34	22 h	"	66	42 h	B	98	62 h	b
35	23 h	#	67	43 h	C	99	63 h	c
36	24 h	\$	68	44 h	D	100	64 h	d
37	25 h	%	69	45 h	E	101	65 h	e
38	26 h	&	70	46 h	F	102	66 h	f
39	27 h	'	71	47 h	G	103	67 h	g
40	28 h	(72	48 h	H	104	68 h	h
41	29 h)	73	49 h	I	105	69 h	i
42	2A h	*	74	4A h	J	106	6A h	j
43	2B h	+	75	4B h	K	107	6B h	k
44	2C h	,	76	4C h	L	108	6C h	l
45	2D h	-	77	4D h	M	109	6D h	m
46	2E h	.	78	4E h	N	110	6E h	n
47	2F h	/	79	4F h	O	111	6F h	o
48	30 h	0	80	50 h	P	112	70 h	p
49	31 h	1	81	51 h	Q	113	71 h	q
50	32 h	2	82	52 h	R	114	72 h	r
51	33 h	3	83	53 h	S	115	73 h	s
52	34 h	4	84	54 h	T	116	74 h	t
53	35 h	5	85	55 h	U	117	75 h	u
54	36 h	6	86	56 h	V	118	76 h	v
55	37 h	7	87	57 h	W	119	77 h	w
56	38 h	8	88	58 h	X	120	78 h	x
57	39 h	9	89	59 h	Y	121	79 h	y
58	3A h	:	90	5A h	Z	122	7A h	z
59	3B h	;	91	5B h	[123	7B h	{
60	3C h	<	92	5C h	\	124	7C h	
61	3D h	=	93	5D h]	125	7D h	}
62	3E h	>	94	5E h	^	126	7E h	~
63	3F h	?	95	5F h	_	127	7F h	DEL

Maintenance and Repair

Repair

If repair is needed, please contact your local Pepperl+Fuchs office.

Installation cable "Cable PSCAN-D-1D-D2" to barcode reader PSCAN-D-*

Exchange of the cable on barcode reader PSCAN-D-1D-D2

Scope of supply



Removing old cable at the PSCAN-D-1*

Removing old cable

1. Make sure that the barcode reader is disconnected from the mains during installation.




2. Unscrew the screw at the barcode reader.

3. First, slide down the strain relief and then the cover over the yellow "tooth." Slide down the cable spacer.



4. Pull the plug out of the handle and pull down the plastic boot and the rubber gasket



Connecting the new cable

- (1) rubber gasket
- (2) plastic boot
- (3) cable spacer
- (4) cover
- (5) strain relief

Install the new cable on the barcode reader

1. Make sure that the barcode reader is disconnected from the mains during installation.
2. Slip the cover (4) over the cable.
3. Push the plastic boot (2) into the rubber gasket (1). Take care that the tab on the plastic boot (2) is aligned with the notch in the rubber gasket.



(1) notch
(2) tab

4. Insert the cable into the socket of the plastic boot (2) with the rubber gasket (1). Ensure that the "FRONT" marking on the plastic boot (2) is facing out.



5. Insert the cable with the plastic boot (2) and gasket (1) into the handle. Ensure that the "FRONT" marking on the plastic boot (2) is facing out, with the arrow pointing towards the front of the barcode reader.



6. Insert the cable spacer (3) into the cable wire and slide it towards the handle.



(3) cable spacer


7. Push the cover (4) along the cable toward the reader, and hook it over the yellow "tooth."



8. Insert the strain relief (5) into the cover (4) and tighten the screw to fix the whole assembly to the reader handle.



PROCESS AUTOMATION – PROTECTING YOUR PROCESS



Worldwide Headquarters

Pepperl+Fuchs GmbH
68307 Mannheim · Germany
Tel. +49 621 776 2222
E-Mail: pa-info@de.pepperl-fuchs.com

For the Pepperl+Fuchs representative
closest to you, visit www.pepperl-fuchs.com/contact

www.pepperl-fuchs.com

 **PEPPERL+FUCHS**
PROTECTING YOUR PROCESS