

Pepperl+Fuchs SE
Lilienthalstraße 200
68307 Mannheim
Germany
Phone +49 621 776-0
Fax +49 621 776-1000

No. / Nr.: DOC-3630A
Date / Datum: 2026-03-13

Copyright Pepperl+Fuchs
www.pepperl-fuchs.com

 **PEPPERL+FUCHS**

Declaration of conformity / Konformitätserklärung

We, Pepperl+Fuchs SE declare under our sole responsibility that the **products** listed below are in conformity with the listed **European Directives, Regulations and standards**.

*Die Pepperl+Fuchs SE erklärt hiermit in alleiniger Verantwortung, dass die unten gelisteten **Produkte** den genannten **Europäischen Richtlinien, Verordnungen und Normen** entsprechen.*

Productfamily / Produktfamilie

Productfamily / Produktfamilie	Description / Beschreibung
E*58*.*****_****	Optical Absolute Encoder Ethernet

The „ * “ marked letters of the type code are placeholders and replaced by the code described in ANNEX TYPE CODE.
*Die mit „ * “ markierten Stellen im Typenschlüssel sind Platzhalter und können durch den Schlüssel ersetzt werden der in ANNEX TYPE CODE beschrieben ist.*

Directives and Standards / Richtlinien und Normen

EU-Directive <i>EU-Richtlinie</i>	Standards <i>Normen</i>
EMC 2014/30/EU (L96/79-106)	EN 61000-6-2:2005-08 EN 61000-6-2/AC:2005-09 EN 61000-6-4:2007-01 EN 61000-6-4/A1:2011-02
RoHS 2011/65/EU (L174/88-110)	EN IEC 63000:2018-12
Supplemental Standards	EN IEC 61000-6-2:2019-02 EN IEC 61000-6-4:2019-09

Affixed CE Marking / Angebrachte CE-Kennzeichnung



Signatures / Unterschriften

Mannheim, 2025-03-13



i.V. Stefan Horvatic
Head of Innovation Unit Motion &
Condition Sensors



i.V. Christian Güntert
Head of Product Management
Innovation Unit Motion & Condition
Sensors

ANNEX TYPE CODE

The „*“ marked letters of the type code are placeholders and replaced by the following code:
Die mit „*“ markierten Stellen im Typenschlüssel sind Platzhalter und können durch folgenden Schlüssel ersetzt werden:

Produkt Familie <i>Product Family</i>	Gehäuse- material <i>Housing material</i>		Wellen- durch- messer <i>Shaft Di- mension</i>	Flansch <i>Flange</i>	An- schlussart/ Protokoll <i>Connec- tion type/ Protocol</i>	Abgang <i>Exit po- sition</i>	Option 1 <i>Option 1</i>	Ausga- becode <i>Output code</i>	Option 2 <i>Option 2</i>		Anzahl der Bits Multiturn <i>Number of bits multi turn</i>	Anzahl der Bits Single- turn <i>Number of bits single turn</i>
E**58	*	-	**	*	**	*	*	*	*	-	**	**
SS, SM, VS, VM	N, I, W, A	-	01, 02, 03, F1, F2, F3, F5, FA	1, 2, A	EC, IZ, PN, PZ, TZ	R	0	B	N, T	-	00, 12, 14	12,13,14, 15,16