



Commissioning sheet

Classic mode



Advanced display mode

underlined data can be selected



Basic Operation


The device starts in the traditional mode. You can switch between the two modes with ESC or OK. In the advanced mode the cursor is moved by the arrow buttons. Pushing OK puts you to the superior menu (in the drawing one step to the right side). ESC puts you back to the previous menu. To edit data move with arrow buttons the marking to desired line first and then select the item with OK, change the data by using the arrow buttons and finally press OK button to accept the input. Pushing ESC cancels the editing.

Commissioning sheet

Classic mode



Advanced display mode



Notes:
 underlined data can be selected
 items in *italics* are not always available

Basic Operation

The device starts in the traditional mode. You can switch between the two modes with **ESC** or **OK**. In the advanced mode the cursor is moved by both arrow buttons. Pushing **OK** puts you to the superior menu (in the drawing one step to the right side). **ESC** puts you back to the previous menu. To edit data you first mark them with the cursor and then select them with **OK**, change them with the arrow buttons and finally apply them with **OK**. Pushing **ESC** cancels the editing.


Commissioning sheet

Classic mode




Advanced display mode

Notes:
underlined data can be selected




Commissioning sheet

Classic mode



Advanced display mode



Basic Operation


The device starts in the traditional mode. You can switch between the two modes with ESC or OK. In the advanced mode the cursor is moved by both arrow buttons. Pushing OK puts you to the superior menu (in the drawing one step to the right side). ESC puts you back to the previous menu. To edit data you first mark them with the cursor and then select them with OK, change them with the arrow buttons and finally apply them with OK. Pushing ESC cancels the editing.

Commissioning sheet

Classic mode



Advanced display mode



Notes:
 underlined data can be selected
 items in *italics* are not always available

Basic Operation


The device starts in the traditional mode. You can switch between the two modes with ESC or OK. In the advanced mode the cursor is moved by both arrow buttons. Pushing OK puts you to the superior menu (in the drawing one step to the right side). ESC puts you back to the previous menu. To edit data you first mark them with the cursor and then select them with OK, change them with the arrow buttons and finally apply them with OK. Pushing ESC cancels the editing.

Commissioning sheet

Classic mode



Advanced display mode



Basic Operation

The device starts in the traditional mode. You can switch between the two modes with ESC or OK. In the advanced mode the cursor is moved by both arrow buttons. Pushing OK puts you to the superior menu (in the drawing one step to the right side). ESC puts you back to the previous menu. To edit data you first mark them with the cursor and then select them with OK, change them with the arrow buttons and finally apply them with OK. Pushing ESC cancels the editing.