


Classic mode

1.12A

underlined data can be selected

Advanced display mode




#### **Basic Operation**

The device starts in the traditional mode. You can switch between the two modes with *ESC* or *OK*. In the advanced mode the cursor is moved by both arrow buttons. Pushing *OK* puts you to the superior menue (in the drawing one step to the right side). *ESC* puts you back to the previous menue. To edit data you first mark them with the cursor and then select them with *OK*, change them with the arrow buttons and finally apply them with *OK*. Pushing *ESC* cancels the editing.






Advanced display mode








advanced display mode







advanced display mode



### **Basic Operation**

The device starts in the traditional mode. You can switch between the two modes with *ESC* or *OK*. In the advanced mode the cursor is moved by both arrow buttons. Pushing *OK* puts you to the superior menue (in the drawing one step to the right side). *ESC* puts you back to the previous menue. To edit data you first mark them with the cursor and then select them with *OK*, change them with the arrow buttons and finally apply them with *OK*. Pushing *ESC* cancels the editing.