

Корпус (F)XL*2 (P_{max} 15 Вт)

Table with columns: Ток [A], CSA [мм²], and 16 current values (0.5 to 240). Rows show power distribution for 3, 6, 10, 16, 20, 25, 35, 50, 63, 80, 100, 125, 160, 200, 250 A.

Table for (F)XL*3 max power 21 W. Columns: Ток [A], CSA [мм²], 16 current values. Rows show power distribution for 125, 160, 200, 250 A.

Корпус (F)XL*4 (P_{max} 15 Вт)

Table for (F)XL*4 max power 15 W. Columns: Ток [A], CSA [мм²], 15 current values (0.5 to 150). Rows show power distribution for 3, 6, 10, 16, 20, 25, 35, 50, 63, 80, 100, 125, 160, 200, 250 A.

Корпус (F)XL*5 (P_{max} 29 Вт)

Table for (F)XL*5 max power 29 W. Columns: Ток [A], CSA [мм²], 15 current values (0.5 to 240). Rows show power distribution for 3, 6, 10, 16, 20, 25 A.

Table for (F)XL*5 max power 29 W. Columns: Ток [A], CSA [мм²], 15 current values (0.5 to 240). Rows show power distribution for 35, 50, 63, 80, 100, 125, 160, 200, 250 A.

Корпус (F)XL*6 (P_{max} 30 Вт)

Table for (F)XL*6 max power 30 W. Columns: Ток [A], CSA [мм²], 15 current values (0.5 to 240). Rows show power distribution for 3, 6, 10, 16, 20, 25, 35, 50, 63, 80, 100, 125, 160, 200, 250 A.

Корпус (F)XL*7 (P_{max} 21 Вт)

Table for (F)XL*7 max power 21 W. Columns: Ток [A], CSA [мм²], 16 current values (0.5 to 240). Rows show power distribution for 3, 6, 10, 16, 20, 25, 35, 50, 63, 80, 100, 125, 160, 200, 250 A.

Корпус (F)XL*8 (P_{max} 30 Вт)

Table for (F)XL*8 max power 30 W. Columns: Ток [A], CSA [мм²], 15 current values (0.5 to 150). Rows show power distribution for 3, 6, 10, 16, 20, 25, 35, 50, 63, 80, 100, 125 A.

Корпус (F)XL*3 (P_{max} 21 Вт)

Table for (F)XL*3 max power 21 W. Columns: Ток [A], CSA [мм²], 16 current values (0.5 to 240). Rows show power distribution for 3, 6, 10, 16, 20, 25, 35, 50, 63, 80, 100 A.

