

Instruction Manual

1. Marking

Gateway Module HD2-GTR-4PA (segment coupler for power hub, 4 segments)
ATEX certificate: TÜV 04 ATEX 2500 X ATEX marking: Ⓜ II 3 G Ex nA IIC T4 Gc IECEX certificate: IECEX TUN 13.0038X IECEX marking: Ex nA IIC T4 Gc
Pepperl+Fuchs Group Lilienthalstraße 200, 68307 Mannheim, Germany
Internet: www.pepperl-fuchs.com

2. Validity

Specific processes and instructions in this instruction manual require special provisions to guarantee the safety of the operating personnel.

3. Target Group, Personnel

Responsibility for planning, assembly, commissioning, operation, maintenance, and dismantling lies with the plant operator.

The personnel must be appropriately trained and qualified in order to carry out mounting, installation, commissioning, operation, maintenance, and dismantling of the device. The trained and qualified personnel must have read and understood the instruction manual.

4. Reference to Further Documentation

Observe laws, standards, and directives applicable to the intended use and the operating location. Observe Directive 1999/92/EC in relation to hazardous areas.

The corresponding datasheets, manuals, declarations of conformity, EU-type examination certificates, certificates, and control drawings if applicable supplement this document. You can find this information under www.pepperl-fuchs.com.

For specific device information such as the year of construction, scan the QR code on the device. As an alternative, enter the serial number in the serial number search at www.pepperl-fuchs.com.

Due to constant revisions, documentation is subject to permanent change. Please refer only to the most up-to-date version, which can be found under www.pepperl-fuchs.com.

5. Intended Use

The PROFIBUS Segment Coupler is part of the Power Hub. The device is designed to connect PROFIBUS PA segments to PROFIBUS DP.

The FieldConnex® Power Hub is designed to power segments of the fieldbus according to IEC/EN 61158-2.

The Power Hub consists of a motherboard and power supply modules. Depending on the configuration, further components are gateways and diagnostic modules. See the respective product documentation for these components.

The device is an electrical apparatus for hazardous areas of Zone 2.

The device may be installed in gas groups IIC, IIB, and IIA.

The device must only be operated in the specified ambient temperature range and at the specified relative humidity without condensation.

6. Improper Use

Protection of the personnel and the plant is not ensured if the device is not used according to its intended use.

7. Mounting and Installation

Prior to mounting, installation, and commissioning of the device you should make yourself familiar with the device and carefully read the instruction manual.

Only manipulate the connections within the specified ambient temperature range.

Temperature range	-5 °C to +70 °C
-------------------	-----------------

Observe the installation instructions according to IEC/EN 60079-14.

Do not mount a damaged or polluted device.

The device may be installed in a corrosive atmosphere according to ISA-S71.04-1985, severity level G3.

7.1. Hazardous Area

7.1.1. Gas

7.1.1.1. Zone 2

Connection or disconnection of energized non-intrinsically safe circuits is only permitted in the absence of a potentially explosive atmosphere.

The device must be installed and operated only in a controlled environment that ensures a pollution degree 2 (or better) according to IEC/EN 60664-1.

The device must be installed and operated only in surrounding enclosures that

- comply with the requirements for surrounding enclosures according to IEC/EN 60079-0,
- are rated with the degree of protection IP54 according to IEC/EN 60529.

8. Operation, Maintenance, Repair

Do not repair, modify, or manipulate the device.

Do not use a damaged or polluted device.

Connection or disconnection of energized non-intrinsically safe circuits is only permitted in the absence of a potentially explosive atmosphere.

If cleaning is necessary while the device is located in a hazardous area, in order to avoid electrostatic charging only use a clean damp cloth.

If there is a defect, always replace the device with an original device.

9. Delivery, Transport, Disposal

Check the packaging and contents for damage.

Check if you have received every item and if the items received are the ones you ordered.

Keep the original packaging. Always store and transport the device in the original packaging.

Store the device in a clean and dry environment. The permitted ambient conditions must be considered, see datasheet.

The device, built-in components, packaging, and any batteries contained within must be disposed in compliance with the applicable laws and guidelines of the respective country.