

Instruction Manual

1. Marking

Viator® USB HART Interface HM-PF-USB-010031
Viator® RS-232 HART Interface HM-PF-RS232-010001
Viator® RS-232 HART Interface HM-PF-HCF-TOOL-010007

Pepperl+Fuchs Group Lilienthalstraße 200, 68307 Mannheim, Germany
Internet: www.pepperl-fuchs.com

2. Target Group, Personnel

Responsibility for planning, assembly, commissioning, operation, maintenance, and dismantling lies with the plant operator.

The personnel must be appropriately trained and qualified in order to carry out mounting, installation, commissioning, operation, maintenance, and dismantling of the device. The trained and qualified personnel must have read and understood the instruction manual.

Prior to using the product make yourself familiar with it. Read the instruction manual carefully.

3. Reference to Further Documentation

Observe laws, standards, and directives applicable to the intended use and the operating location.

The corresponding datasheets, instruction manuals, manuals, declarations of conformity, EU-type examination certificates, certificates, and control drawings if applicable supplement this document. You can find this information under www.pepperl-fuchs.com.

In order to access this documentation, enter the product name, i. e. the type code, or the item number of the product in the search field of the website.

For specific device information such as the year of construction, scan the QR code on the device. As an alternative, enter the serial number in the serial number search at www.pepperl-fuchs.com.

4. Intended Use

The device is only approved for appropriate and intended use. Ignoring these instructions will void any warranty and absolve the manufacturer from any liability.

The device is used in control and instrumentation technology (C&I technology).

The device provides a flexible PC communication link to HART networks. The device is used for commissioning, maintenance, calibration and data acquisition of HART field devices or transmitters.

Use the device only within the specified ambient and operating conditions.

5. Improper Use

Protection of the personnel and the plant is not ensured if the device is not used according to its intended use.

6. Mounting and Installation

Do not mount a damaged or polluted device.

Observe the ambient and operating conditions when mounting and installing the device.

The device may be installed in the non-hazardous area.

7. Operation, Maintenance, Repair

Prior to using the product make yourself familiar with it. Read the instruction manual carefully.

Do not repair, modify, or manipulate the device.

Do not use a damaged or polluted device.

If there is a defect, always replace the device with an original device.

If there is a defect, the device must be repaired by Pepperl+Fuchs.

Observe the warning markings.

Do not remove the warning markings.

The housing is factory-sealed. Do not open the housing.

8. Delivery, Transport, Disposal

Check the packaging and contents for damage.

Check if you have received every item and if the items received are the ones you ordered.

Always store and transport the device in the original packaging.

Store the device in a clean and dry environment. The permitted ambient conditions must be considered, see datasheet.

The device, built-in components, packaging, and any batteries contained within must be disposed in compliance with the applicable laws and guidelines of the respective country.