

Thru-beam sensor (pair) OBE2000-R3-SE3-P



- 45° cable outlet for maximum mounting freedom under extremely tight space constraints
- Extremely large detection range in Long Range Mode
- Option of switching to high precision mode for greater switching accuracy


Thru-beam sensor for standard applications, miniature design, 2000 mm detection range, red light, light on, PNP output, 2 m fixed cable



Function

The nano sensor has been developed for a broad range of applications. It offers excellent durability and is exceptionally easy to install. The housing is compact and, with its 45° cable outlet, can be installed in the smallest spaces. New functional principles and functionality open up a range of new options.

Dimensions



Receiver **General specifications**


Release date: 2023-04-04 Date of issue: 2023-04-04 Filename: 70141753_eng.pdf

OBE2000-R3-E3-P

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 1111 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Technical Data

OBE2000-R3-SE3-P

Effective detection range		Long range mode: 0 2 m High precision mode: 0 200 mm	
Threshold detection range		Long range mode: 2.5 m High precision mode: 300 mm	
Light source		LED	
Light type		modulated visible red light , 630 nm	
Angle deviation		approx. 2 °	
Diameter of the light spot		Long range mode: 150 mm at a distance of 2000 mm High precision mode: 0.5 mm at a distance of 50 mm	
Opening angle		approx. 2 °	
Optical face		frontal	
Ambient light limit		EN 60947-5-2 : 30000 Lux	
Functional safety related parameters			
MTTF _d		806 a	
Mission Time (T _M)		20 a	
Diagnostic Coverage (DC)		0 %	
Indicators/operating means			
Operation indicator		LED green, statically lit Power on , short-circuit : LED green flashing (approx. 4 Hz)	
Function indicator		Receiver: LED yellow, lights up when light beam is free, flashes when falling short of the operating reserve ; OFF when light beam is interrupted	
Electrical specifications			
Operating voltage	UB	10 30 V DC , class 2	
No-load supply current	lo	Emitter: ≤ 11 mA	
		Receiver: ≤ 8 mA	
Input			
Control input		Emitter selection BK: not connected, Long Range mode BK: 0 V, High Precision Mode	
Switching threshold		Teach-In input	
Output			
Switching type		NC contact / light on	
Signal output		1 PNP output, short-circuit protected, reverse polarity protected, open collector	
Switching voltage		max. 30 V DC	
Switching current		max. 50 mA , resistive load	
Voltage drop	U_d	≤ 1.5 V DC	
Switching frequency	f	approx. 800 Hz	
Response time		600 µs	
Conformity			
Product standard		EN 60947-5-2	
Approvals and certificates			
UL approval		cULus Recognized, Class 2 Power Source	
CCC approval		CCC approval / marking not required for products rated ≤36 V	
Ambient conditions			
Ambient temperature		-25 60 °C (-13 140 °F)	
Storage temperature		-30 70 °C (-22 158 °F)	
Mechanical specifications			
Housing width		7.5 mm	
Housing height		26 mm	
Housing depth		13.8 mm	
Degree of protection		IP67	
Connection		2 m fixed cable	
Material			
Housing		PC/ABS and TPU	
Optical face		PC	
Cable		PUR	
Mass		approx. 20 g per sensor	
Cable length		2 m	


 Refer to "General Notes Relating to Pepperl+Fuchs Product Information".


 Pepperl+Fuchs Group
 USA: +1 330 486 0001
 Get

 www.pepperl-fuchs.com
 fa-info@us.pepperl-fuchs.com
 fa-info@us.pepperl-fuchs.com


Germany: +49 621 776 1111 fa-info@de.pepperl-fuchs.com


Connection Assignment





Assembly







1	Operating display	gre
2	Signal display	yel
3	Emitter long range	
4	Emitter high precision	
5	Receiver	

green yellow


Characteristic Curve




Refer to "General Notes Relating to Pepperl+Fuchs Product Information"



Characteristic Curve






Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

4

Characteristic Curve



Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

5

Teach-In

The thru-beam sensor enables the switching points to be taught in for optimum adaptation to specific applications. This eliminates the need for additional components such as apertures.

Essentially, all Teach-in methods can be used in both "High Precision" and "High Power" operating modes.

The sensitivity of the thru-beam sensor can be adjusted using three Teach-in methods:

Position Teach

When using this Teach-in method, the following settings are made on the thru-beam sensor:

- The gain is set to an optimum value
- The signal threshold is set to a minimum



Recommended application:

This method enables extremely small differences in contrast to be detected, as well as minuscule particles in the beam path, and provides exceptional positioning accuracy.

The best results are achieved in "High Precision" mode.


- 1. Make sure that there are no objects in the beam path and that the sensor is connected to the power supply.
- 2. Connect the white cable on the receiver (WH/IN) to the blue cable (BU/0 V) on the receiver.
- The green and yellow LED indicators flash simultaneously at 2.5 Hz
- 3. Disconnect the white cable on the receiver (WH/IN) from the blue cable (BU/0 V) on the receiver.
- The green and yellow LED indicators flash alternately at 2.5 Hz
- 4. The end of the Teach-in process is indicated when the green LED indicator lights up sold and yellow LED blinks.

Two-Point Teach-In

When using this Teach-in method, the following settings are made on the thru-beam sensor:

- The gain is set to an optimum value
- The signal threshold is set in the center between the two taught signal values

Signal s	trength	
Max		
	Teach-in value 1 (avg))
	Threshold level	Contrast level
	Teach-in value 2 (avg)	J



Recommended application:

Enables detection of transparent objects.

The best results are achieved in "High Precision" mode.

- 1. Make sure that there are no objects in the beam path and that the sensor is connected to the power supply.
- 2. Connect the white cable on the receiver (WH/IN) to the blue cable (BU/0 V) on the receiver.
- The green and yellow LED indicators flash simultaneously at 2.5 Hz 3. Position the object in the beam path.
- 4. Disconnect the white cable on the receiver (WH/IN) from the blue cable (BU/0 V) on the receiver.
- The green and yellow LED indicators flash alternately at 2.5 Hz


5. The end of the Teach-in process is indicated when the green LED indicator lights up sold.

Maximum Teach-In

When using this Teach-in method, the following settings are made on the thru-beam sensor:

- The gain is set to a maximum
- The signal threshold is set to a minimum

Signal strengt	b	
Max		
	Threshold level	
0 +		,



Thru-beam sensor (pair)

Recommended application:

Enables an object to be detected with a high excess gain. This can be useful if there is severe environmental contamination or to achieve long operating times.

The best results are achieved in "High Precision" mode.

- 1. Make sure that there are no objects in the beam path and that the sensor is connected to the power supply.
- 2. Cover the receiver or transmitter.
- 3. Connect the white cable on the receiver (WH/IN) to the blue cable (BU/0 V) on the receiver. The green and yellow LED indicators flash simultaneously at 2.5 Hz
- Disconnect the white cable on the receiver (WH/IN) from the blue cable (BU/0 V) on the receiver. The green and yellow LED indicators flash alternately at 2.5 Hz
- 5. The end of the Teach-in process is indicated when the green LED indicator lights up sold.

