# **Battery**

The battery of the pocket unit is not fully charged.

It is recommended to charge the pocket unit for five hours before using it for the first time. The full capacity of the battery is reached after 3-4 complete charge/discharge cycles.

# Warranty

The warranty of this product follows the General Conditions of Delivery and Payment of Pepperl+Fuchs SE, which are available at www.pepperl-fuchs.com, or alternatively they can be requested directly from the manufacturer.

## Support

E-Mail: support@ecom-ex.com

Copyright® 2022 ECOM Instruments GmbH

The contents of this document, either in part or in their entirety, may not be reproduced, forwarded, distributed or saved in any way without ECOM Instruments GmbH prior written consent.

The contents of this document are presented as they currently exist. ecom instruments GmbH does not provide any express or tacit guarantee for the correctness or completeness of the contents of this document, including, but not restricted to, the tacit guarantee of market suitability or fitness for a specific purpose unless applicable laws or court decisions make liability mandatory. ecom instruments GmbH reserves the right to make changes to this document or to withdraw it any time without prior notice.

DOCT-8285 | 06/2022 WEEE-Reg.-Nr. DE 934 99306 Subject to change without notice.

#### Note:

Please also observe the safety requirements in the specific operating instructions and the information in the full user guide for your device. The documents can be downloaded from the relevant product page at www.ecom-ex.com

ECOM Instruments GmbH | Industriestraße 2 | 97959 Assamstadt | Germany Phone +49 62 94 42 24 0 | Fax +49 62 94 42 24 100 sales@ecom-ex.com | www.ecom-ex.com





QUICK START GUIDE

FOR GLOBAL HAZARDOUS AREAS

#### **Quick Start Guide**

You can use this guide to get started with your Visor-Ex®01 right away and refer to the sections in the user guide if parts are unclear. However, it is still advisable to read through the complete user guide in order to learn all the ins and outs of the Visor-Ex®01.

#### Please follow the steps below to continue with the quick start:

#### Step 1

- Position the Visor-Ex® 01 flat on a surface with the display positioned on the side of your dominant eye and the cameras faced front.
- To change the display position to the side of your dominate eye unscrew
  the connector on the top of the Visor-Ex® 01 with a 1.5 mm hex key and
  screw the connector onto the other side of the Visor-Ex® 01.

### Step 2

Download and install the Iristick Services application through Google Play on the Smart-Ex® 02.

#### Step 3

Start the Iristick Services application and grant the permissions.

#### Step 4

- Open the charging dust cover of the Smart-Ex® 02 and rotate the cover 180°.
- Insert the smartphone into the cradle in the prescribed order as shown in the illustration below.



#### Step 5

Connect the head unit (Port 1) to the pocket unit (Port 2) with the coaxial cable.

#### Step 6

- Connect the coiled cable of the cradle to the pocket unit via the USB (Port 3)
- Tap "OK" in the dialog on the smartphone's screen to launch the Iristick Services app.
- 3. Tap "START NOW" in the dialog to activate the heads-up display.

#### Step 7

Use the touchpad of the head unit, voice commands and/or the Smart-Ex® 02 to navigate through the menus and launch for example the Iristick Examples app or the Iristick Camera app.

\*Recommendation: For optimal experience enable "Always optimize UI for HUD" in the Iristick Services settings.

# How to fix the Helmet Adapter V01 and Cable Guide V01 to a helmet

- Before you fix the Helmet Adapter V01 and the Cable Guide V01 to a helmet the relevant surfaces must be clean dry and free of grease.
- Please mark the middle position of the helmet visor and use the arrow indicator on the adapter to align and to stick it to the right position.
- 3. Finally please affix the two clips as shown in the images.

#### **Helmet Adapter V01**



Helmet Adapter V01



Bottom view



Top view

Side view Helmet

#### Cable Guide V01





Cable Guide V01

Helmet with Cable Guide

# **Head Unit** Connector Port 1 Smart-Ex® 02 with Cradle Visor-Fx 01 USB Cable Port 2 Model: PU-Ex V01 DZ1 FEPPERL+FUCHS ecom 4 0 0 **Pocket Unit**