








Accessories Pad-Ex®: Installation guides

Models	Attach Types		
	Hand-Strap	X-Strap	Shoulder-Strap
<p>Pad-Ex® 01</p>  	<p>CA P01 A01</p>  <p>Hand-Strap for Pad-Ex® 01 D2, DZ2 Art.-No.: 482843</p>	<p>HA P01 A01</p>  <p>X-Strap for Pad-Ex® 01 D2, DZ2 Art.-No.: 483703</p> <p>Step 1: Remove all protection plates (f, g, h & i)</p> <p>Step 2: Install the included X-Strap mounting plates with the included screws (f, g, h & i)</p> <p>Step 3: Attach X-Strap to the mounting plates</p> 	<p>CH P01 A01</p>  <p>4-Point Shoulder-Strap for Pad-Ex® 01 D2, DZ2 Art.-No.: 482842</p> <p>Note: Detach the screws from Place A, B, C & E, then lock NEW screws with D-rings on Place A, B, C & E.</p> 
	<p>Note: Detach the screws from Place A & B, then lock NEW screws with D-rings on Place A&B.</p> 