



FACTORY AUTOMATION

Manual

VBG-PB-K25

AS-i/PROFIBUS Gateway
in acc. to specification 3.0



PEPPERL+FUCHS

With regard to the supply of products, the current issue of the following document is applicable: The General Terms of Delivery for Products and Services of the Electrical Industry, published by the Central Association of the "Elektrotechnik und Elektroindustrie (ZVEI) e.V. in their most recent version as well as the supplementary clause: "Extended reservation of title".

We at Pepperl+Fuchs recognise a duty to make a contribution to the future, For this reason, this printed matter is produced on paper bleached without the use of chlorine.

Table of Contents

1	The Symbols Used	5
2	Safety	6
2.1	Intended Use	6
2.2	General Safety Information	6
3	General Information	7
4	New AS-i Specification 3.0	7
5	Connections, Displays and Operating Keys	8
5.1	Basic Master	9
5.1.1	Connections of the AS-i/PROFIBUS Gateway Art. -no. VBG-PB-K25	9
5.1.1.1	Function Ground	10
5.2	PROFIBUS Interface	10
5.2.1	Bus Termination	11
5.3	Display and Operating Elements	12
5.3.1	LED-Display Profibus	12
6	Commissioning of the AS-i/PROFIBUS Gateways	13
6.1	Basic Master	13
6.1.1	Commissioning of the AS-i/PROFIBUS Gateway Article-no. VBG-PB-K25	13
6.1.2	Setting the PROFIBUS-DP Address	13
6.1.2.1	Switching to the Configuration Mode	13
6.1.2.2	Connect AS-i Slaves	14
6.1.2.3	Store AS-i Configuration	14
6.1.3	Error Tracing	15
6.1.3.1	Incorrect Slaves (one error)	15
6.1.3.2	Incorrect Slaves (multiple errors)	15
6.1.3.3	Error Display	16
6.1.4	Addressing	16
6.1.4.1	Delete Slave Address 5	16
6.1.5	Program Slave 0 to Address 4	17
7	PROFIBUS DP	18
7.1	DP Telegrams	18
7.1.1	Diagnosis	18
7.1.1.1	Parameters	20
7.1.2	Configuration DP V0 (cyclic data)	21
7.1.2.1	Options	21
7.1.3	I/O Data	24
7.1.3.1	Process data	24
7.1.3.2	EC-Flags and AS-i watchdog	25
7.1.3.3	AS-i 16-Bit Data	26
7.1.3.4	Command Interface	26

7.2	DP V1	27
8	Command Interface	28
8.1	Construction	28
8.1.1	List of all Commands	29
8.1.2	Values for Results	31
8.2	Commands of the Command Interface	31
8.2.1	AS-i 16-Bit Data	31
8.2.1.1	Overview of the Commands	31
8.2.1.2	Read 1 16-bit-Slave in Data (RD_7X_IN)	32
8.2.1.3	Write 1 16-bit-Slave out Data (WR_7X_OUT)	32
8.2.1.4	Read 1 16-bit-Slave out.Data (RD_7X_OUT)	33
8.2.1.5	Read 4 16-bit-Slave in.Data (RD_7X_IN_X)	33
8.2.1.6	Write 4 7.3-Slave out.Data (WR_7X_OUT_X)	34
8.2.1.7	Read 4 7.3-Slave out.Data (RD_7X_OUT_X)	34
8.2.1.8	Read 16 Kanäle 16-Bit-Slave in.Data (OP_RD_16BIT_IN_CX)	35
8.2.1.9	Write 16 Kanäle 16-Bit-Slave out.Data (OP_WR_16BIT_IN_CX)	35
8.2.1.10	WR_74_75_PARAM	36
8.2.1.11	RD_74_75_PARAM	36
8.2.1.12	RD_74_75_ID	37
8.2.1.13	RD_74_DIAG	38
8.2.1.14	WRITE_ACYCLIC_TRANS	38
8.2.1.15	READ_ACYCLIC_TRANS	40
8.2.2	Overview of the Commands	41
8.2.2.1	Get Lists and Flags (Get_LPS, Get_LAS, Get_LDS, Get_Flags) (GET_LISTS)	41
8.2.2.2	Get Flags (GET_FLAGS)	41
8.2.2.3	Get Delta List (GET_DELTA)	43
8.2.2.4	Get List of Corrupted Slaves (GET_LCS and GET_LCS_R6 (6CH))	43
8.2.2.5	Get List of Activated Slaves (GET_LAS)	43
8.2.2.6	Get List of Detected AS-i slaves (GET_LDS)	43
8.2.2.7	Get list of peripheral faults (GET_LPF)	44
8.2.2.8	Get List of Offline Slaves (GET_LOS)	44
8.2.2.9	Set List of Off-line Slaves (SET_LOS and SET_LOS_R6 (6Dh))	44
8.2.2.10	Get transm.err.counters (GET_TECA)	44
8.2.2.11	Get transm.err.counters (GET_TECB)	45
8.2.2.12	Get transm.err.counters (GET_TEC_X)	46
8.2.2.13	Functional profiles	46
8.2.3	Functional profiles	47
8.2.3.1	"Safety at Work" List 1	47
8.2.3.2	"Safety at Work" Monitor Diagnosis	48
8.2.3.3	Integrated AS-i Sensors: Warnings	54
8.2.3.4	Integrated AS-i Sensors: Availability	54
8.2.3.5	Failsafe	55
8.2.3.6	IDI Filter	56
8.2.3.7	Change Buffer	57
8.2.3.8	Replacement of Safety Slaves Input Data	58
8.2.3.9	List of Safety Slaves	59
8.2.4	Configuration of the AS-i Master	60

Table of Contents

8.2.4.1	Overview of the Commands	60
8.2.4.2	Set Operation Mode (SET_OP_MODE: Set_Operation_Mode)	60
8.2.4.3	Store Actual Configuration (STORE_CDI)	61
8.2.4.4	Read Actual Configuration (READ_CDI)	61
8.2.4.5	Set Permanent Configuration (SET_PCD)	62
8.2.4.6	Get Extended Permanent Configuration (GET_PCD)	63
8.2.4.7	Set List of Projected Slaves (SET_LPS and SET_LPS_R6 (6Bh))	63
8.2.4.8	Get List of Projected Slaves (GET_LPS)	64
8.2.4.9	Store Actual Parameters (STORE_PI)	64
8.2.4.10	Write Parameter (WRITE_P)	64
8.2.4.11	Read Parameter (READ_PI: Read_Parameter)	65
8.2.4.12	Set_Permanent_Parameter (SET_PP)	65
8.2.4.13	Get_Permanent_Parameter (GET_PP)	66
8.2.4.14	Set Auto Address Enable (SET_AAE)	66
8.2.5	Other Commands	67
8.2.5.1	Overview of the Commands	67
8.2.5.2	IDLE	67
8.2.5.3	Read Input Data Image (READ_IDI)	68
8.2.5.4	Write Output Data Image (WRITE_ODI)	68
8.2.5.5	Read Output Data Image (READ_ODI)	69
8.2.5.6	Change Slave Address (SLAVE_ADDR)	69
8.2.5.7	Write AS-i Slave Extended ID1 (WRITE_XID1)	70
8.2.5.8	Set Offline Mode (SET_OFFLINE)	70
8.2.5.9	Release Data Exchange (SET_DATA_EX)	71
8.2.5.10	BUTTONS	71
8.2.5.11	FP_PARAM	72
8.2.5.12	FP_DATA	72
8.2.5.13	EXT_DIAG	73
8.2.5.14	RD_EXT_DIAG	73
8.2.5.15	INVERTER	74
8.2.5.16	Write Flag	75
8.2.5.17	Read Flag	75
8.2.5.18	READ_MFK_PARAM	76
8.3	Command Interface Examples	76
8.3.1	Reading 16-Bit Input Values	76
8.3.2	Store current Configuration to the AS-i Master	78
8.3.3	Store new Configuration for all Slaves	82
9	Commissioning Tools and Accessories	90
9.1	Windows Software AS-i Control Tools	90
9.2	Further Information	93
10	Appendix	94
10.1	Codes indicated by the Display	94
10.2	Codes indicated by basic master	95

AS-Interface Table of Contents

11	Appendix: Installation/Commissioning Instructions	96
11.1	Installation/Commissioning Instruction AS-i/PROFIBUS Gateway	
	Article No.: VBG-PB-K25	96
12	Glossary: AS-i Terms	105

issue date 21.12.05

1 The Symbols Used

 Warning	This symbol warns the user of possible danger. Not following this warning can lead to personal injury or death and/or destruction of the equipment.
--	---

 Attention	This symbol warns the user of a possible failure. Not following this warning can lead to total failure of the device or any other connected equipment.
--	--

 Note	This symbol draws the user's attention to important information.
---	--

2 Safety

2.1 Intended Use



Warning

The protection of operating personnel and the system against possible danger is not guaranteed if the control interface unit is not operated in accordance with its intended use.

The device may only be operated by appropriately qualified personnel in accordance with this operating manual.

2.2 General Safety Information



Warning

Safety and correct functioning of the device cannot be guaranteed if any operation other than that described in this operation manual is performed.

Connecting the equipment and any maintenance work to be carried out with voltage applied to the equipment must exclusively be performed by appropriately qualified electrotechnical personnel.

In case a failure cannot be repaired, the device must be taken out of operation and kept from inadvertently being put back into operation.

Repair work is to be carried out by the manufacturer only. Additions or modifications to the equipment are not allowed and will void the warranty.



Note

The operator is responsible for the observance of local safety standards.

3 General Information

This operating instruction holds for the following devices of the Pepperl+Fuchs GmbH:

VBG-PB-K25	AS-i/PROFIBUS Gateway in stainless steel - basic master
------------	---

The AS-i/PROFIBUS gateways already fulfill to connect AS-Interface systems to the PROFIBUS. They act as a master for the AS-Interface and as a slave for the PROFIBUS.

4 New AS-i Specification 3.0

The AS-i/PROFIBUS gateways already fulfil the new AS-i Specification 3.0.

The previous specifications (2.1 and 2.0) are supported as well.

All AS-i functions are provided as well cyclically as acyclically via PROFIBUS DP V1.

In the cyclic data transfer optionally up to 32 bytes I/O data are being transferred for the binary data of one AS-i network. Additionally, analog signals and all further commands of the new AS-i specification can be transferred in the management channel via PROFIBUS.

Advanced Diagnostics

Diagnostics, which go far beyond the standard diagnostics, facilitate the simple detection of occasionally occurring configuration errors and further irritations influencing the AS-i communication. In case of an error, the down time of machines can be minimized or preventive maintenance can be initiated.

Commissioning and monitoring

The AS-i/PROFIBUS gateways can be commissioned or programmed with the help of the software "AS-i Control Tools" in combination with the PROFIBUS DP master simulator. The GSD file is included in the package.


Commissioning, debugging and setting up the AS-i parameters without the software can only be accomplished by directly using the system's push-buttons, the display and the LEDs.

Accessories:

Software "AS-i Control Tools"

PROFIBUS DP master simulator.

5 Connections, Displays and Operating Keys




On the front panel of the device in stainless steel housing are located:

- [1] LEDs
- [2] SUB-D connector as PROFIBUS interface
- [3] LC display
- [4] push-buttons to configure the device
- [5] Terminals to connect the power supply and the AS-i circuit.


5.1 Basic Master

5.1.1 Connections of the AS-i/PROFIBUS Gateway Art. -no. VBG-PB-K25



 Note	It is not allowed to connect slaves or repeaters to the hatched marked cable.
 Note	It is not allowed to connect AS-i power supplies or another master to the yellow marked cable.


5.1.1.1 Function Ground



 Note	<ul style="list-style-type: none"> The function ground can be connected either at the ground screw or at the terminal. The function ground should be connected with a cable as short as possible to guarantee a good EMC property. Therefore it is preferable to connect the ground via the ground screw.
--	--

5.2 PROFIBUS Interface

The PROFIBUS interface is realized as a 9-pin SUB-D connector, in accordance to the standard for PROFIBUS DIN 19245. It is placed at the top left-hand corner of the master



The AS-i/PROFIBUS gateway sends and receives on pins 3 and 8 of the SUB-D socket. The PROFIBUS signal "RxD/TxD-N (data line A)"¹ is located on pin 8, the signal "RxD/TxD-P (data line B)"¹ is located on pin 3.

The pins 5 (0 V) and 6 (5 V) supply 5 V DC for the bus termination.

1. If you measure the DC voltage between RxD/TxD-P (data line B) and RxD/TxD-N (data line A), RxD/TxD-P (data line B) is the positive pole when the bus is silent.

5.2.1 Bus Termination

If the AS-i/PROFIBUS gateway is at the end of the PROFIBUS line, the termination resistors in the PROFIBUS connector have to be switched on.

PIN	Designation of the SUB-D connector
Pin 3	Data line B („RxD/TxD-P“)
Pin 5	DGND (0 V)
Pin 6	VP / +5 V
Pin 8	Data line A („RxD/TxD-N“)




If the gateway will be installed in a two wire circuit (only A + B Line), means no 5 Volt supply, the gateway has to be placed at the end of the line.



Please install the bustermination as close as possible to the Sub-D connector of the gateway.

Terminating resistors with RS 485:



5.3 Display and Operating Elements

5.3.1 LED-Display Profibus

On the front panel of the PROFIBUS gateways there are seven light-emitting diodes. The meaning of them are as follow:

Power	The master's power supply is sufficient.
Profibus	LED on: Gateway is allocated to a PROFIBUS master. LED off: Gateway is not allocated to a PROFIBUS master.
Config err	Configuration error: At least one configured slave is missing, at least one detected slave is not projected or for at least one projected and detected slave the actual configuration data does not match the nominal configuration data. This LED flashes if there is at least one periphery fault at one AS-i slave in the AS-i network. If there are configuration errors as well as periphery faults, only configuration error is displayed.
U AS-i	The AS-i circuit is sufficiently powered.
AS-i active	Normal operation active. (Flashes, if a B slave is displayed)
prg enable	Automatic address programming enabled. Exactly one slave is missing in protected operating mode. The slave can be replaced by another slave of the same type with address zero. The master addresses the new slave to the faulty address and thus eliminates the configuration error.
prj mode	The AS-i master is in configuration mode.


6 Commissioning of the AS-i/PROFIBUS Gateways

6.1 Basic Master

6.1.1 Commissioning of the AS-i/PROFIBUS Gateway Article-no. VBG-PB-K25

 Note	If PROFIBUS active, no configuration settings by push buttons!
--	--

6.1.2 Setting the PROFIBUS-DP Address




Das Gerät ist werkseitig auf Adresse 3 eingestellt.
 The device is set to address 3 at the factory.
 L'appareil est réglé en usine à l'adresse 3.
 Il dispositivo viene de la fábrica con l'indirizzo 3.
 El aparato viene ajustado de fábrica en la dirección 3.

- 0:** Adressänderung über PROFIBUS ist gesperrt (default)
 Address change via PROFIBUS is locked (default)
- Changement d'adresse est verrouillé par PROFIBUS (default)**
- Cambiamento di indirizzo è bloccato via PROFIBUS (default)**
- Cambio de la dirección es bloqueado vía PROFIBUS (default)**


- 1:** Adressänderung über PROFIBUS ist erlaubt
 Address change via PROFIBUS is allowed
- Changement d'adresse est permis par PROFIBUS**
- Cambiamento di indirizzo è permesso via PROFIBUS**
- Cambio de la dirección se permite vía PROFIBUS**

6.1.2.1 Switching to the Configuration Mode




AS-Interface Commissioning of the AS-i/PROFIBUS Gateways

6.1.2.2 Connect AS-i Slaves




6.1.2.3 Store AS-i Configuration




Issue date - 21.12.2005

6.1.3 Error Tracing

6.1.3.1 Incorrect Slaves (one error)




6.1.3.2 Incorrect Slaves (multiple errors)




AS-Interface Commissioning of the AS-i/PROFIBUS Gateways

6.1.3.3 Error Display




6.1.4 Addressing

6.1.4.1 Delete Slave Address 5



Issue date - 21.12.2005

6.1.5 Program Slave 0 to Address 4



7 PROFIBUS DP

This chapter contains all necessary information to operate the AS-i/PROFIBUS gateways in a PROFIBUS DP network.

 Note	The respective bits <i>ground fault, overvoltage, noise, double address</i> will only be set if AS-i masters are used, which also support these functions.
--	---

7.1 DP Telegrams

7.1.1 Diagnosis

DP Diagnosis - Single Master					
PDU byte	user byte		DP	DP V1	user
1	–	station_status 1	4		
2	–	station_status 2	4		
3	–	station_status 3	4		
4	–	master address	4		
5	–	ident high	4		
6	–	ident low	4		
7	1	header	4	4	
8	2	type		4	
9	3	slot		4	
10	4	spec		4	
11	5	ec-flags (high)			4
12	6	ec-flags (low)			4
13	7	delta (0...7)			4
14	8	delta (8...15)			4
...
20	14	delta (56...63)			4
21	15	LPF (0...7)			4
...
28	22	LPF (56 ... 63)			4

ec-flags (high):

- Bit 0: periphery fault
- Bit 1 ... Bit 2 reserved
- Bit 3: failure redundant 24 V
- Bit 4: earth fault
- Bit 5: over voltage
- Bit 6: noise
- Bit 7: 

ec-flags (low):

- Bit 0: configuration error
- Bit 1: slave with address0 detected
- Bit 2: Auto_address_assignment not possible
- Bit 3: Auto_address_assignment available
- Bit 5: not in normal operation
- Bit 4: configuration mode active
- Bit 6: AS-i power fail
- Bit 7: AS-i master is offline

Delta List: List of AS-i slaves with configuration error.

- 1: ConfigError
- 0: no ConfigError

LPF: List of AS-i slaves with periphery fault.

- 1: periphery fault
- 0: no periphery fault

Each element of the user diagnosis (ec-flags and slave lists) can be switched off by setting the appropriate bit in the parameter telegram.

Each element which is not used will be filled up with zeroes. This way the data elements in the diagnosis telegram will keep its designated position (and clear text diagnosis still fits to the data).

Only if an element at the end of the user diagnosis is not used, the length of the diagnosis will be shortened.

ExtDiag will be set if at least one of the following conditions is fulfilled:

- ConfigError = 1
- APF = 1
- PeripheryFault = 1

The conditions when to set the ExtDiag bit can be chosen using the user parameters or the commands of the command interface.

The GSD file includes the following presettings:

- The diagnosis transmits ec-flags, delta list and LPF.
- ExtDiag will be set if ConfigError = 1 and APF = 1. ExtDiag will not be set if there is a periphery fault.

7.1.1.1 Parameters

With the user parameters you can choose if and which slave list will be displayed in the diagnosis. Furthermore you can select which conditions have to be fulfilled to set the ExtDiag bit within the diagnosis telegram.

DP Parameters - Single Master						
PDU byte	user byte		DP	DP V1	user	default
1	–	Station_Status	4			
2	–	WD_Fact_1	4			
3	–	WD_Fact_2	4			
4	–	min T _{sdr}	4			
5	–	Ident High	4			
6	–	Ident Low	4			
7	–	Group_Ident	4			
8	1	DPV Status 1		4		80 ₁₆
9	2	DPV Status 2		4		00 ₁₆
10	3	DPV Status 3		4		00 ₁₆
11	4	User Byte 1			4	0B ₁₆
12	5	User Byte 2			4	06 ₁₆
13	6	User Byte 3			4	00 ₁₆

The bits in "User Byte 1" and "User Byte 3" have the following meanings:

User Byte 1								
	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
	-	-			LPF	-	D	F
default	0	0	0	1	0	1	1	
User Byte 2								
	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
	FD	0	CS	PF	APF	CF	-	
default	0	0	0	0	1	1	0	
User Byte 3								
	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
	-						0	
default	0						0	

LPF: 1: LPF will be transmitted in the diagnosis

0: LPF will not be transmitted

D: 1: Delta list will be transmitted in the diagnosis

0: Delta list will not be transmitted

- F: 1: EC-flags will be transmitted in the diagnosis
0: EC-flags will not be transmitted
- FD: If this bit is set, the PROFIBUS diagnosis is refreshed only if the PROFIBUS norm dictates this ("freeze diagnosis"). In doubt the data of the PROFIBUS masters diagnosis are not up to date.
- CS: 1: ExtDiag will be set if the LCS is not empty
0: ExtDiag will not be set if the LCS is not empty
- PF: 1: ExtDiag will be set if there is a periphery fault at the AS-i line
0: ExtDiag will not be set.
- APF: 1: ExtDiag will be set if there is an AS-i Power Fail
0: ExtDiag will not be set.
- CF: 1: ExtDiag will be set if there is a configuration error
0: ExtDiag will not be set.

The GSD's default user parameter telegram is:

80 ₁₆	00 ₁₆	00 ₁₆	0B ₁₆	06 ₁₆	00 ₁₆
------------------	------------------	------------------	------------------	------------------	------------------

(DPV1 enabled, diagnosis settings according to chapter 7.1.1)

7.1.2 Configuration DP V0 (cyclic data)

The configuration of the AS-i/PROFIBUS gateways is made with the GSD file. Therefore the provided GSD file has to be imported into your PROFIBUS configuration tool.

7.1.2.1 Options

The original data input and outlet data can be used with different „Spezial IDs“.

The advantages of special input and output IDs are, that they can include up to 64 elements (bytes or words), and that the length of input and output data can be different. Additionally, "manufacturer specific" data bytes describing the ID type are possible. These "manuaafaturer specific" data bytes describe the which type ID is.

The GSD file offers here several combinations (several lengths) for transmitting I/O date, command interface (management) and analog data.

Therefore the analog data can be transmitted directly in the process data channel and do not have to be requested by the slower DP V1 commands.

Maximally 8 modules can be configurated.

The detailed possibilities:

Length	Description
4 bytes	digital input (slaves 0 - 7)
8 bytes	digital input (slaves 0 - 15)
12 bytes	digital input (slaves 0 - 23)
16 bytes	digital input (slaves 0 - 31)
20 bytes	digital input (slaves 0 - 7B)
24 bytes	digital input (slaves 0 - 15B)
28 bytes	digital input (slaves 0 - 23B)
32 bytes	digital input (slaves 0 - 31B)

Length	Description
4 bytes	digital output (slaves 0 - 7)
8 bytes	digital output (slaves 0 - 15)
12 bytes	digital output (slaves 0 - 23)
16 bytes	digital output (slaves 0 - 31)
20 bytes	digital output (slaves 0 - 7B)
24 bytes	digital output (slaves 0 - 15B)
28 bytes	digital output (slaves 0 - 23B)
32 bytes	digital output (slaves 0 - 31B)

Length	Description
16 bytes	digital in/out (slaves 0 - 31)
16 Bytes	digital in/out (slaves 0B - 31B)
32 bytes	digital in/out (slaves 0 - 31B)

 Note	2 command interfaces can be integrated.
---	---

Length	Description
2 bytes	management (command interface)
4 bytes	management (command interface)
8 bytes	management (command interface)
11 bytes	management (command interface)
12 bytes	management (command interface)
34 bytes	management (command interface)
36 bytes	management (command interface)

Length	Description
24 bytes	analog input (slaves 29 - 31)
56 bytes	analog input (slaves 25 - 31)
88 bytes	analog input (slaves 21 - 31)
120 bytes	analog input (slaves 17 - 31)
128 bytes	analog input (slaves 16 - 31)
16 bytes	analog input (slaves 14 - 15)

Length	Description
24 bytes	analog output (slaves 29 - 31)
56 bytes	analog output (slaves 25 - 31)
88 bytes	analog output (slaves 21 - 31)
120 bytes	analog output (slaves 17 - 31)
128 bytes	analog output (slaves 16 - 31)
16 bytes	analog output (slaves 14 - 15)

Length	Description
2 bytes ... 128 bytes	analog input data circuit 1, dynamic ¹
2 bytes ... 128 bytes	analog output data circuit 1, dynamic ¹
2 bytes ... 128 bytes	analog input data circuit 2, dynamic ¹
2 bytes ... 128 bytes	analog output data circuit 2, dynamic ¹

1. Module parameters necessarily

Length	Description
2 bytes	flags and AS-i detector circuit 1
2 bytes	flags and AS-i detector circuit 2

7.1.3 I/O Data

7.1.3.1 Process data

In V2.1 mode the AS-i I/O data are mapped in the process data as known from the Siemens and AS-i/InterBus masters. This means that the lower nibble describes the data of the AS-i slave with the higher slave address. The ec-flags or hi-flags are additionally mapped at the nibble of AS-i slave 0.

byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
0	flags					slave 1/1A		
	F3	F2	F1	F0	D3	D2	D1	D0
1	slave 2/2A					slave 3/3A		
2	slave 4/4A					slave 5/5A		
3	slave 6/6A					slave 7/7A		
4	slave 8/8A					slave 9/9A		
5	slave 10/10A					slave 11/11A		
6	slave 12/12A					slave 13/13A		
7	slave 14/14A					slave 15/15A		
8	slave 16/16A					slave 17/17A		
9	slave 18/18A					slave 19/19A		
10	slave 20/20A					slave 21/21A		
11	slave 22/22A					slave 23/23A		
12	slave 24/24A					slave 25/25A		
13	slave 26/26A					slave 27/27A		
14	slave 28/28A					slave 29/29A		
15	slave 30/30A					slave 31/31A		
16	reserved					slave 1B		
17	slave 2B					slave 3B		
18	slave 4B					slave 5B		
19	slave 6B					slave 7B		
20	slave 8B					slave 9B		
21	slave 10B					slave 11B		
22	slave 12B					slave 13B		
23	slave 14B					slave 15B		
24	slave 16B					slave 17B		
25	slave 18B					slave 19B		
26	slave 20B					slave 21B		
27	slave 22B					slave 23B		
28	slave 24B					slave 25B		
29	slave 26B					slave 27B		
30	slave 28B					slave 29B		
31	slave 30B					slave 31B		

Flags		
	input data	output data
F0	ConfigError	Offline
F1	APF	LOS master bit
F2	PeripheryFault	→ ConfigurationMode
F3	ConfigurationActive	→ ProtectedMode

ConfigError: 0 = ConfigOK, 1 = ConfigError

APF: 0 = AS-i Power OK, 1 = AS-i Power Fail

PeripheryFault: 0 = PeripheryOK, 1 = PeripheryFault

ConfigurationActive: 0 = ConfigurationActive, 1 = ConfigurationInactive

Offline: 0 = Online, 1 = Offline

LOS-Master-Bit 0 = Offline by ConfigError deactivated

1 = Offline by ConfigError activated

A rising edge of F2 and F3 switch the master to the desired mode.

A rising edge of the "LOS master bit" effects that all bits in the LOS are set. A falling edge effects that all bits are deleted.

7.1.3.2 EC-Flags and AS-i watchdog

In addition to ECflags, the AS-i watchdog flags will be transferred in diagnostic data too.

Diagnostic data are assembled as follows:

ec-flags (high):

- Bit 0: periphery fault
- Bit 1 ... Bit 2 reserved
- Bit 3: failure redundant 24 V (option single master)
- Bit 4: earth fault
- Bit 5: over voltage
- Bit 6: noise
- Bit 7: --

ec-flags (low):

- Bit 0: configuration error
- Bit 1: slave with address0 detected
- Bit 2: Auto_address_assignment not possible
- Bit 3: Auto_address_assigment available
- Bit 4: configuration mode active
- Bit 5: not in normal operation

7.1.3.3 AS-i 16-Bit Data

 Note	<p>A-Slaves map the data on channels 1 and 2. B-Slaves map the data on channels 3 and 4.</p>
--	--

In addition to the access via the command interfaces, the 16-bit data for or by the slaves with 16-bit value can be exchanged cyclically (profile 7.3., S-7.4, S-6.0, S-7.5, S-7.A.8, S-7.A.9, S-7.A.A). Competing writing access attempts on analog output data will not be blocked by each other. If analog data for a particular slave are being transmitted both cyclically and acyclically with the command interface or via DP V1 connections, the acyclically transmitted values will be overwritten by the cyclically transmitted values.

AS-i 16-bit data can be transmitted in a reserved data area. Therefore accessing analog data is as easy as accessing digital data.

AS-i 16-bit data								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	slave 31-n/8, channel 1, high byte							
2	slave 31-n/8, channel 1, low byte							
3	slave 31-n/8, channel 2, high byte							
4	slave 31-n/8, channel 2, low byte							
...	...							
n-3	slave 31, channel 3/slave 31B, channel 1, high byte							
n-2	slave 31, channel 3/slave 31B, channel 1, low byte							
n-1	slave 31, channel 4/slave 31B, channel 2, high byte							
n	slave 31, channel 4/slave 31B, channel 2, low byte							

7.1.3.4 Command Interface

Only using the IDs of the process data field the AS-i/PROFIBUS gateway can be used as M0 AS-i master. By using the command interface (see chapter 7.1.3) the functions of a M3 master become available.

Request									
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0	
1	command								
2	T	circuit							
3	request parameter byte 1								
...	...								
36	request parameter byte 34								

Answer								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	command (mirrored)							
2	result							
3	response parameter byte 1							
...	...							
34	response parameter byte 32							

A command of the command interface will be edited if the toggle bit T has changed. This way the same command can be used repeatedly.

The commands of the command interface can also be activated with PROFIBUS DP V1. Even the process data exchange is possible via the command interface. This way the Windows configuration software "AS-i Control Tools" can run the whole communication via DP V1.

7.2 DP V1

To exchange data between the PROFIBUS master and the AS-i/PROFIBUS gateway via PROFIBUS DP V1 only one data block is used - slot 1, index 16. Within this data block a command interface is installed like the one used in the DP telegram.

The DP V1-command interfaces are edited every time they are sent. Therefore it is possible to execute the same command several times without changing "command" or "circuit" and setting a toggle bit.

8 Command Interface

8.1 Construction

If an AS-i slave is addressed in a command or in a response, the address is structured as shown below

Request														
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0						
1	command													
2	T	-	circuit											
3	request parameter byte 1													
...	...													
36	request parameter byte 34													

Response														
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0						
1	command													
2	T	-	result											
3	response parameter byte 1													
...	...													
36	response parameter byte 34													

Command byte and T-bit are always part of the response. The T-bit is necessary to operate the command interface via a MSC1 connection (PROFIBUS DP V0). This way the same command of the command interface can be used two twice repeatedly, possibly with different parameters.

The execution of a command of the command interface is declined, if the number of the transferred parameters is too small which means that the command interface in the cyclic channel is too small or the DP V1-telegram is too short.

The commands of the command interface are valid as well for PROFIBUS DP V0 as for PROFIBUS DP V1.Circuit = 0If an AS-i gateway with one AS-i master or the master 1 of an AS-i

gateway with 2 masters should be choosen.

Circuit = 1 If master 2 of a double master should be chosen.

The commands for reading and writing exist in two variations. At the first variation the bits in the slave lists are arranged as usually with Pepperl+Fuchs products: Data for slave with lower address appear in the lower bits. The second variation is compatible to Siemens masters: The sequence of the bits in the slave lists bytes are inverse.

Switching between the two variations can be done with bit 2^6 in byte 2 of the request. If it is deleted, the Pepperl+Fuchs arrangement is selected, otherwise the Siemens compatible arrangement is selected.

The coding of requests for commands to reading and writing is following therefore:

Request														
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰						
1	command													
2	T	0	circuit											
3	Request parameter byte 1													
...	...													

8.1.1 List of all Commands

Values for command					
command	value	meaning	Req Len	Res Len	
RD_7X_IN	50 ₁₆	Read 1 7.3-slave in.data	3	10	
WR_7X_OUT	51 ₁₆	Write 1 7.3-slave out.data	11	2	
RD_7X_OUT	52 ₁₆	Read 1 7.3-slave out.data	3	10	
RD_7X_IN_X	53 ₁₆	Read 4 7.3-slaves in.data	3	34	
WR_7X_OUT_X	54 ₁₆	Write 4 7.3-slaves out.data	35	2	
RD_7X_OUT_X	55 ₁₆	Read 4 7.3-slaves out.data	3	34	
WR_74_PARAM	5A ₁₆	Write S-7.4/S-7.5-slave parameter	≥6	2	
RD_74_PARAM	5B ₁₆	Read S-7.4/S-7.5-slave parameter	4	≥3	
RD_74_ID	5C ₁₆	Read S-7.4/S-7.5-slave ID string	4	≥3	
RD_74_DIAG	5D ₁₆	Read S-7.4/S-7.5-slave diagnosis string	4	≥3	
GET_LISTS	30 ₁₆	Get LDS, LAS, LPS, Flags	2	29	
GET_FLAGS	47 ₁₆	Get_Flags	2	5	
GET_DELTA	57 ₁₆	Get list of config. diff.	2	10	
GET_LCS	60 ₁₆	Get LCS	2	10	
GET_LAS	45 ₁₆	Get_LAS	2	10	
GET_LDS	46 ₁₆	Get_LDS	2	10	
GET_LPF	3E ₁₆	Get_LPF	2	10	
GET_LOS	61 ₁₆	GET_LOS	2	10	
SET_LOS	62 ₁₆	SET_LOS	10	2	
GET_TECA	63 ₁₆	Get transm.err.counters	2	34	
GET_TECB	64 ₁₆	Get transm.err.counters	2	34	
GET_TEC_X	66 ₁₆	Get transm.err.counters	4	≥3	
READ_FAULT_DETECTOR	10 ₁₆	Read Fault Detector	2	4	
SET_OP_MODE	0C ₁₆	Set_Operation_Mode	3	2	
STORE_CDI	07 ₁₆	Store_Actual_Configuration	2	2	
READ_CDI	28 ₁₆	Read_Actual_Configuration	3	4	
SET_PCD	25 ₁₆	Set_Permanent_Config	5	2	

Values for command				
command	value	meaning	Req Len	Res Len
GET_PCD	26 ₁₆	Get_Permanent_Config	3	4
SET_LPS	29 ₁₆	SET_LPS	11	2
GET_LPS	44 ₁₆	Get_LPS	2	10
STORE_PI	04 ₁₆	Store_Actual_Parameter	2	2
WRITE_P	02 ₁₆	Write_Parameter	4	3
READ_PI	03 ₁₆	Read_Parameter	3	3
SET_PP	43 ₁₆	Set_Permanent_Parameter	4	2
GET_PP	01 ₁₆	Get_Permanent_Parameter	3	3
SET_AAE	0B ₁₆	Set_Auto_Address_Enable	3	2
IDLE	00 ₁₆	No order	2	2
READ_IDI	41 ₁₆	Read IDI	2	36
WRITE_ODI	42 ₁₆	Write_ODI	34	2
READ_ODI	56 ₁₆	Read ODI	2	34
SLAVE_ADDR	0D ₁₆	Change_Slave_Address	4	2
WRITE_XID1	3F ₁₆	Write_Extended_ID-Code_1	3	2
SET_OFFLINE	0A ₁₆	Set_Offline_Mode	3	2
SET_DATA_EX	48 ₁₆	Set_Data_Exchange_Active	3	2
BUTTONS	75 ₁₆	Disable pushbuttons	3	2
FP_PARAM	7D ₁₆	„Functional Profile“ Param.	≥3	≥2
FP_DATA	7E ₁₆	„Functional Profile“ Data	≥3	≥2
EXT_DIAG	71 ₁₆	ExtDiag generation	6	2
RD_EXT_DIAG	7B ₁₆	Read ExtDiag Settings	2	7
INVERTER	7C ₁₆	Configure Inverter Slaves	12	4
MB_OP_CTRL_WR_FLAGS	0x85	Write flag	6	2
MB_OP_CTRL_RD_FLAGS	0x86	Read flag	4	4
RD_MFK_PARAM	0x59	Read SEW MFK21 parameter	6	5
WRITE_ACYC_TRANS	4E ₁₆	Write acyclic transfer	≥7	2
READ_ACYC_TRANS	4E ₁₆	Read acyclic transfer	5	≥2
OP_RD_16BIT_IN_CX	4C ₁₆	Read 16 channels 16-bit-slave in.data	3	34
OP_RD_16BIT_IN_CX	4C ₁₆	Write 16 channels 16-bit-slave in.data	36	2

8.1.2 Values for Results

Values for result			
	value	place	meaning
OK	00 ₁₆	—	execution without fault
HI_NG	11 ₁₆	HI	general fault
HI_OPCODE	12 ₁₆	HI	illegal value in command
HI_LENGTH	13 ₁₆	HI	length of the command interface is too short
HI_ACCESS	14 ₁₆	HI	no access right
EC_NG	21 ₁₆	EC	general fault
EC SND	22 ₁₆	EC	"slave (source addr) not detected"
EC_SD0	23 ₁₆	EC	"slave 0 detected"
EC_SD2	24 ₁₆	EC	"slave (target addr) not detected"
EC_DE	25 ₁₆	EC	"delete error"
EC_SE	26 ₁₆	EC	"set error"
EC_AT	27 ₁₆	EC	"address temporary"
EC_ET	28 ₁₆	EC	"extended ID1 temporary"
EC_RE	29 ₁₆	EC	"read (extended ID1) error"

8.2 Commands of the Command Interface

8.2.1 AS-i 16-Bit Data

8.2.1.1 Overview of the Commands

Values for command				
command	value	meaning	Req Len	Res Len
RD_7X_IN	50 ₁₆	Read 1 7.3-slave in.data	3	10
WR_7X_OUT	51 ₁₆	Write 1 7.3-slave out.data	11	2
RD_7X_OUT	52 ₁₆	Read 1 7.3-slave out.data	3	10
RD_7X_IN_X	53 ₁₆	Read 4 7.3-slaves in.data	3	34
WR_7X_OUT_X	54 ₁₆	Write 4 7.3-slaves out.data	35	2
RD_7X_OUT_X	55 ₁₆	Read 4 7.3-slaves out.data	3	34
WR_74_PARAM	5A ₁₆	Write S-7.4/S-7.5-slave parameter	≥6	2
RD_74_PARAM	5B ₁₆	Read S-7.4/S-7.5-slave parameter	4	≥3
RD_74_ID	5C ₁₆	Read S-7.4/S-7.5-slave ID string	4	≥3
RD_74_DIAG	5D ₁₆	Read S-7.4/S-7.5-slave diagnosis string	4	≥3
OP_RD_16BIT_IN_CX	4C ₁₆	Read 16 channels 16-bit-slave in.data	3	34
OP_RD_16BIT_IN_CX	4C ₁₆	Write 16 channels 16-bit-slave in.data	36	2

8.2.1.2 Read 1 16-bit-Slave in Data (RD_7X_IN)

With this command, the four 16 bit channels of an AS-i input slave according to the slave profile (S-7.3, S-7.4, S-7.5, S-7.A.8, S.A.9, S-7.A.A) can be read.

 Note	A-Slaves map the data on channels 1 and 2. B-Slaves map the data on channels 3 and 4. As a slave address can only values among 1 and 31 be taken.
--	---

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	50_{16}							
2	T	-	circuit					
3	-	0	slave address					

Response														
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0						
1	50_{16}													
2	T	result												
3	channel 1, high byte													
...	...													
10	channel 4, low byte													

8.2.1.3 Write 1 16-bit-Slave out Data (WR_7X_OUT)

With this command, the four 16 bit channels of an AS-i output slave according to the slave profile (S-7.3, S-7.4, S-7.5, S-7.A.8, S.A.9, S-7.A.A) can be written.

Request														
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0						
1	51_{16}													
2	T	-	circuit											
3	-	0	slave address											
4	channel 1, high byte													
...	...													
11	channel 4, low byte													

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	51_{16}							
2	T	result						

8.2.1.4 Read 1 16-bit-Slave out.Data (RD_7X_OUT)

With this command, the four 16 bit channels of an AS-i output slave according to the slave profile (S-7.3, S-7.4, S-7.5, S-7.A.8, S.A.9, S-7.A.A) can be read out of the AS-i/PROFIBUS gateway.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	52_{16}							
2	T	-	circuit					
3	-	0	slave address					

Response										
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0		
1	52_{16}									
2	T	result								
3	channel 1, high byte									
...	...									
10	channel 4, low byte									

8.2.1.5 Read 4 16-bit-Slave in.Data (RD_7X_IN_X)

With this command, the four 16 bit channels of 4 AS-i input slaves with successive addresses according to slave profile (S-7.3, S-7.4, S-7.5, S-7.A.8, S.A.9, S-7.A.A) can be read.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	53_{16}							
2	T	-	circuit					
3	-	0	1st slave address					

Response										
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0		
1	53_{16}									
2	T	result								
3	1st slave, channel 1, high byte									
...	...									
34	4th slave, channel 4, low byte									

8.2.1.6 Write 4 7.3-Slave out.Data (WR_7X_OUT_X)

With this command the four 16 bit channels of four AS-i output slaves with successive addresses according to slave profile (S-7.3, S-7.4, S-7.5, S-7.A.8, S.A.9, S-7.A.A) can be written.

Request														
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0						
1	54_{16}													
2	T	-	circuit											
3	-	0	1st slave address											
4	1st slave, channel 1, high byte													
...	...													
35	4th slave, channel 4, low byte													

Response									
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0	
1	54_{16}								
2	T	result							

8.2.1.7 Read 4 7.3-Slave out.Data (RD_7X_OUT_X)

With this command, the four 16 bit channels of four AS-i output slaves with successive addresses according to slave profile (S-7.3, S-7.4, S-7.5, S-7.A.8, S.A.9, S-7.A.A) can be read.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	55_{16}							
2	T	-	circuit					
3	-	0	1st slave address					

Response												
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0				
1	55_{16}											
2	T	result										
3	1st slave, channel 1, high byte											
...	...											
34	4th slave, channel 4, low byte											

8.2.1.8 Read 16 Kanäle 16-Bit-Slave in.Data (OP_RD_16BIT_IN_CX)

With this command, the 16 channels of the 16-bit input-data for slaves with successive addresses according to slave profile (S-7.3, S-7.4, S-7.5, S-7.A.8, S.A.9, S-7.A.A) can be read

Request														
Byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0						
1	$4C_{16}$													
2	T	-	circuit											
3	1. slave													
4	1. channel													

Response														
Byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0						
1	$4C_{16}$													
2	T	-	result											
3	1. slave, channel 1, high byte													
4	1. slave, channel 1, low byte													
...	...													
33	16. channel, high byte													
34	16. channel, low byte													

8.2.1.9 Write 16 Kanäle 16-Bit-Slave out.Data (OP_WR_16BIT_IN_CX)

With this command, the 16 channels of the 16-bit input-data for slaves with successive addresses according to slave profile (S-7.3, S-7.4, S-7.5, S-7.A.8, S.A.9, S-7.A.A) can be written.

Request														
Byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0						
1	$4D_{16}$													
2	T	-	circuit											
3	1. slave													
4	1. channel													
5	1. slave, 1. channel, high byte													
6	1. slave, 1. channel, low byte													
...	...													
35	16. channel, high byte													
36	16. channel, low byte													

Response								
Byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	$4D_{16}$							
2	T	-	result					

8.2.1.10 WR_74_75_PARAM

Description:

- with this function the parameter string of a slave according to profile S-7.4 is being written

or

- the data transfer with a slave according to profile S-7.5 is started.

If it is about a slave according to profile 7.5, data have to be registered into the buffer in the same form, as they have to be sent by AS-i.

Since the string can be longer than the command interface, it will partly be written into the buffer and then be transferred to the slave.

n is the length of the part of the string which should be written into the buffer from index i on.

If i = 0, then the string is being transferred to the slave.

Request														
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰						
1	5A ₁₆													
2	T	-	circuit											
3	slave address													
4	i													
5	n													
6	buffer byte i													
...	...													
n+5	buffer byte i+n-1													

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	5A ₁₆							
2	T	results						

8.2.1.11 RD_74_75_PARAM

Description:

- with this function the parameter string of a slave according to profile S-7.4 is being read

or

- the slave response according to profile S-7.5 is being read.

If it is about a slave according to profile 7.5, so have the data in the response buffer the following meaning:

FFh 00h: Transfer is still active

FFh xxh: Transfer finished with error

The first byte in the buffer notequal FFH: slave response. The response is in the same form registered in the buffer and transmitted over AS-i.

Since the string can be longer than the command interface, it is written into the buffer. The content of the buffer can read in parts from index i.

The first byte of the buffer is the length of the read string.

If $i \equiv 0$, the string is being read from the slave, otherwise the function responses out of the memory; the data can be read consistently.

Request														
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0						
1	$5B_{16}$													
2	T	-	circuit											
3	slave address													
4	i													

Response														
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0						
1	$5B_{16}$													
2	T	-	result											
3	buffer byte i													
...	...													
n+2	buffer byte i+n-1													

8.2.1.12 RD_74_75_ID

With this function the ID string of a slave according to profile S-7.4 or the 16-bit slave configuration according to profile 7.5 is being read. Since the string can be longer than the command interface, it is written into the buffer. The content of the buffer can read in parts from index i.

The first byte of the buffer is the length of the read string.

If $i \equiv 0$, the string is being read from the slave, otherwise the function responses out of the memory, the data can be read consistently.

Request														
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0						
1	$5C_{16}$													
2	T	-	circuit											
3	slave address													
4	i													

Response														
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0						
1	5C ₁₆													
2	T	result												
3	buffer byte i													
...	...													
n+2	buffer byte i+n-1													

By a 7.5 slave is the request always 1. The response byte contains the cyclic 16-bit slave configuration according to S-7.5 profile (analog/transparent bits are cancelled). If the response is 08h, that means that the cyclic 16-bit configuration could not be detected.

8.2.1.13 RD_74_DIAG

With this function the diagnosis string of a slave according to profile S-7.4 is being read. Since the string can be longer than the command interface, it is written into the buffer. The content of the buffer can be read in parts from indexi.

The first byte of the buffer indicates the length of the read string.

If i = 0, the string is being read from the slave, otherwise the function responses out of the memory, the data can be read consistently.

Request														
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0						
1	5D ₁₆													
2	T	-	circuit											
3	slave address													
4	i													

Response														
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0						
1	5D ₁₆													
2	T	-	result											
3	buffer byte i													
...	...													
n+2	buffer byte i+n-1													

8.2.1.14 WRITE_ACYCLIC_TRANS

This function activates different arts of acyclic transfer (S-7.4, S-7.5 and safety monitor). The results have to be read out with READ_ACYCLIC_TRANS. Even though this function runs in the background and doesn't hold the master during the transmission, it is intended to act as a substitute for (RD_74_75_PARAM, WR_74_75_PARAM, RD_74_75_ID, RD_74_DIAG and „Safety at Work“- monitor diagnostis).

Since the transferred data can be longer than the command interface, it is written into the buffer. The content of the buffer can be read in parts from index.

n is the length of the part string, that (from Index (i)) should be written in the buffer. The transmission proceeds, if i=0.

Request								
Byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	4Eh							
2	circuit							
3	slave							
4	buffer Index (i) high							
5	buffer Index (i) low							
6	command ¹							
7	number of(n)							
8	data							
...	...							
x	data+n							

1. Following commands are supported:

- 1: S-7.4 ID String Read (no sent data required).
- 2: S-7.4 Diag String Read (no sent data required).
- 3: S-7.4 Param String Read (no sent data required).
- 4: S-7.4 Param String Write (buffer contains sent string).
- 5: S-7.5 Transfer. Buffer contains sent string in the same form, as the telegram, that have to be sent over AS-i.
- 6: S-7.5 Cyclic 16-Bit Slave Configuration Read (analog/transparent bits are cancelled in the response). The cyclic 16-bit configuration cannot be detected, if the response is 08h.
- 7: Safety Monitor sorted Read (no sent data required).
- 8: Safety Monitor unsorted (all devices) Read (no sent data required).

	Please view the <chapter 8.2.3.2 Monitor Diagnosis> for further information.
---	--

Response								
Byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	4E ₁₆							
2	response							

8.2.1.15 READ_ACYCLIC_TRANS

With this call the response of the transfer command (started with WRITE_ACYCLIC_TRANS) is read out.

The first byte in the response buffer indicates the current command.

FF₁₆ means transfer still active, FE₁₆ means transfer interrupted with errors.

The both following bytes (high,low) set the lenght of the response buffer.

It is always recommended to read the data starting with the index i = 0.

Request								
Byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	4F ₁₆							
2	circuit							
3	slave							
4	buffer index (i) high							
5	buffer index (i) low							

Response								
Byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	4F ₁₆							
2	response							
3	data							
...	...							
x	data+n							

The response data have the same format, as by commands RD_74_75_PARAM, RD_74_75_ID and „safety at work“-monitor diagnostics.

8.2.2 Overview of the Commands

Values for command				
Command	value	meaning	Req Len	Res Len
GET_LISTS	30 ₁₆	Get LDS, LAS, LPS, Flags	2	29
GET_FLAGS	47 ₁₆	Get_Flags	2	5
GET_DELTA	57 ₁₆	Get list of config. diff.	2	10
GET_LCS	60 ₁₆	Get LCS	2	10
GET_LAS	45 ₁₆	Get_LAS	2	10
GET_LDS	46 ₁₆	Get_LDS	2	10
GET_LPF	3E ₁₆	Get_LPF	2	10
GET_LOS	61 ₁₆	GET_LOS	2	10
SET_LOS	62 ₁₆	SET_LOS	10	2
GET_TECA	63 ₁₆	Get transm.err.counters	2	34
GET_TECB	64 ₁₆	Get transm.err.counters	2	34
GET_TEC_X	66 ₁₆	Get transm.err.counters	4	≥3

8.2.2.1 Get Lists and Flags (Get_LPS, Get_LAS, Get_LDS, Get_Flags) (GET_LISTS)

With this call, the following entries are read out of the AS-i/PROFIBUS gateway:

- The list of active AS-i slaves (LAS)
- The list of detected AS-i slaves (LDS)
- The list of projected AS-i slaves (LPS)
- The flags according to the AS-i slave specification

Pok	Periphery_Ok
S0	LDS.0
AAs	Auto_Address_Assign
AAv	Auto_Address_Available
CA	Configuration_Active
NA	Normal_Operation_Active
APF	APF
OR	Offline_Ready
Cok	Config_Ok
AAe	Auto_Address_Enable
OL	Offline
DX	Data_Exchange_Active

8.2.2.2 Get Flags (GET_FLAGS)

With this call, the following entry is read out of the AS-i/PROFIBUS gateway: the flags according to the AS-i slave specification.

Request									
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰	
1									47 ₁₆

Request									
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0	
2	T	–	circuit						

Response									
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0	
1	47_{16}								
2	T	response							
3									Pok
4	OR	APF	NA	CA	AAv	AAs	S0	Cok	
5	–				AAe	OL	DX		

Pok Periphery_Ok

This flag is set when no AS-i slave is signaling a peripheral fault.

S0 LDS.0

This flag is set when an AS-i slave with address 0 exists.

AAs Auto_Address_Assign

This flag is being set when the automatic address programming is possible (in other words, AUTO_ADDR_ENABLE = 1; no "incorrect" slave connected to the AS-i).

AAv Auto_Address_Available

This flag is set when the automatic address programming can be executed, exactly one AS-i slave is currently out of operation.

CA Configuration_Active

The flag is set in configuration mode and reset in protected mode.

NA Normal_Operation_Active

This flag is set when the AS-i master is in normal operation.

APF AS-i Power Fail

This flag is set when the voltage on the AS-i cable is too low.

OR Offline_Ready

The flag is set when the offline phase is active.

Cok Config_Ok

This flag is set when the desired (configured) and actual configuration match.

AAe Auto_Address_Enable

This flag indicates whether the automatic address programming is enabled (bit = 1) or disabled (bit = 0) by the user.

OL Offline

This flag is set when the mode should be changed to OFFLINE or when this mode has already been reached.

DX Data_Exchange_Active

If the "Data_Exchange_Active" flag is set, the data exchange between AS-i master and slaves is available in the data exchange phase. If this bit is not set the data exchange is not available. The read ID telegrams are transmitted to the slave.

The bit is set if the AS-i master enters the offline phase.

8.2.2.3 Get Delta List (GET_DELTA)

The delta list contains the list of slave addresses with configuration errors.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1							57_{16}	
2	T	0					circuit	

Response (if O ≡ 0)								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1							57_{16}	
2	T						result	
3	7A	6A	5A	4A	3A	2A	1A	-
...							...	
10	31B	30B	29B	28B	27B	26B	25B	24B

Response (if O ≡ 1)								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1							57_{16}	
2	T						result	
3	0	1A	2A	3A	4A	5A	6A	7A
...							...	
10	24B	25B	26B	27B	28B	29B	30B	31B

8.2.2.4 Get List of Corrupted Slaves (GET_LCS and GET_LCS_R6 (6CH))

The call GET_LCS_R6 (6CH) differs to the call GET_LCS in the half long LCS list. With the bit 2^5 is selected if the upper (=1) or lower (=0) part of the LCS is read. Read first with 2^5 in order to create a local copy of the LCS. Reading with bit $2^5=1$ transmits the upper part of the copy.

With the call GET_LCS, the List of Corrupted Slaves (LCS) is read out of the AS-i/PROFIBUS Gateway.

8.2.2.5 Get List of Activated Slaves (GET_LAS)

With this call, the following entry is read out of the AS-i/PROFIBUS gateway: The list of activated slaves (LAS).

8.2.2.6 Get List of Detected AS-i slaves (GET_LDS)

With this call, the following entry is read out of the AS-i/PROFIBUS gateway: The list of detected AS-i slaves (LDS).

8.2.2.7 Get list of peripheral faults (GET_LPF)

With this call, the list of peripheral faults (*LPF*) signaled by the AS-i slaves is read out from the AS-i master. The LPF is updated cyclically by the AS-i master. If and when an AS-i slave signals faults of the attached peripherals (for example broken wire) can be found in the description of the AS-i slave.

8.2.2.8 Get List of Offline Slaves (GET_LOS)

With this call, the list of slaves causing the offline phase when a configuration error occurs in being read out (List of Offline Slaves, *LOS*).

The user can choose the reaction of the master when a configuration error occurs. The master can be switched off line when an important slave causes a configuration error; less important slaves can send an error to the host, AS-i however will not be switched offline.

8.2.2.9 Set List of Off-line Slaves (SET_LOS and SET_LOS_R6 (6Dh))

The call **SET_LOS_R6 (6D₁₆)** differs to the call **GET_LOS** in the half long LOS list.

With the bit 2^5 is selected if the upper (=1) or lower (=0) part of the LOS is written.

With this call, the list of slaves causing the offline phase when a configuration error occurs in being defined (List of Offline Slaves, *LOS*).

The user can choose the reaction of the master when a configuration error occurs. The master can be switched offline when an important slave causes a configuration error; less important slaves can send an error to the host, AS-i however will not be switched offline.

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	62_{16}							
2	T	result						

8.2.2.10 Get transm.err.counters (GET_TECA)

 Note	To get the real number of transcription errors, multiply the value with 2.
--	--

With this call the error counters of all single slaves/A-slaves can be read (see chapter 7).

With every reading out of the counts, the error counters will be restarted.

The counts are being read out via the corresponding host interface and will be deleted with every read access. The counter's value is limited to 254. 255 will cause a counter overflow.

The counts could be independent of the counters, which are displayed in the display of the gateway.

Request									
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0	
1	63_{16}								
2	T	-	circuit						

Response									
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0	
1	63_{16}								
2	T	-	result						
3	APF								
4	slave 1A								
...	...								
34	slave 31A								

8.2.2.11 Get transm.err.counters (GET_TECB)

 Note	To get the real number of transcription errors, multiply the value with 2.
--	--

With this call, the counts of the error counters for B-slaves are being read out (see chapter 7).

With every reading out of the counts, the error counters will be restarted.

The counts are being read out via the corresponding host interface and will be deleted with every read access. The counter's value is limited to 254. 255 will cause a counter overflow.

The counts could be independent of the counters, which are displayed in the display of the gateway.

Request									
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0	
1	64_{16}								
2	T	-	circuit						

Response									
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰	
1	64_{16}								
2	T	result							
3	APF								
4	slave 1B								
...	...								
34	slave 31B								

8.2.2.12 Get transm.err.counters (GET_TEC_X)

Beginning with a definite slave address, the counts of the n error counters are being read out with this call.

With every reading out the counts, the error counters will be restarted.

The counts are being read out via the corresponding host interface and will be deleted with every read access. The counter's value is limited to 254. 255 will cause a counter overflow.

The counts could be independent of the counters, which are displayed in the display of the gateway.

Request														
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰						
1	66_{16}													
2	T	-	circuit											
3	1. slave address													
4	number of counters													

Response														
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰						
1	66_{16}													
2	T	-	result											
3	counter 1													
...	...													
n	counter n - 2													

8.2.2.13 Functional profiles

Further diagnosis functions for "Safety at Work" and for availability vice versa for warnings of integrated sensors are explained detailed in the chapter "Functional profiles" (chapter 8.2.3).

8.2.3 Functional profiles

8.2.3.1 "Safety at Work" List 1

Function: 00₁₆

List of "safety-directed input slaves" ("AS-i Safety at Work"), whose safety function is released.

Safety-directed input slaves have the profile S-7.B or S-0.B (IO = 0 or 7, ID = B, see chapter 8.2.4.4: Read Actual Configuration).

The "Safety at Work" list 1 is a bit list which contains a bit for each possible slave address (1 - 31). This list is written in the bytes 5 until 8 in the response of the command of the command interface. Additionally, the response contains the ec-flags of the AS-i master in the bytes 3 and 4 (see chapter 8.2.2.2: "Get Flags").

The bits of the "Safety at Work" list 1 are set if the safety function of the slave is activated (e.g. emergency button pressed). The bit is only set at security slaves when both contacts are released, otherwise the bits have the value 0. "Normal" (non-security) slaves also have the value 0.

Since the security monitor is also being activated if a security slave is missing or if the AS-i circuit is shut off (offline active), the ec-flags will also be transmitted. It is sufficient however to monitor the group error message Cok (configuration error). As long as no configuration error, the list of the "safety-directed input slaves" can be used.

Configured safety slaves which are not available, and available slaves sending a wrong coder order, will not be entered in this list.

With the bit "O", the sequence of the bits within the "Safety at Work" list 1 can be chosen.

Cok	Config_Ok
S0	LDS.0
AAs	Auto_Address_Assign
AAv	Auto_Address_Available
CA	Configuration_Active
NA	Normal_Operation_Active
APF	APF
OR	Offline_Ready
Pok	Periphery_Ok

Example for O ≡ 0:

Configuration OK,
periphery OK (no peripheral fault),
2 safety slaves with released safety function,
AS-Interface addresses 4 and 10
1 safety slave with unreleased safety function,
AS-Interface address 5.

Reponse: 7E 00 01 25 10 04 00 00

Function: 0D₁₆

There is a funktion **0D₁₆** in addition to the function **00₁₆**. The funktion **0D₁₆** has no EcFlags in the response. The response falls short for 2 bytes.

Request								
Byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	7E ₁₆							
2	T	O	circuit					
3	0Dh							

Response (by O = 0)								
Byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	7E ₁₆							
2	T	response						
3	7	6	5	4	3	2	1	-
4	15	14	13	12	11	10	9	8
5	23	22	21	20	19	18	17	16
6	31	30	29	28	27	26	25	24

Response (by O = 1)								
Byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	7E ₁₆							
2	T	response						
3	-	1	2	3	4	5	6	7
4	8	9	10	11	12	13	14	15
5	16	17	18	19	20	21	22	23
6	24	25	26	27	28	29	30	31

8.2.3.2 "Safety at Work" Monitor Diagnosis

Function: **02₁₆**

Since the "Safety at Work" monitor can make more than 32 Byte diagnosis data, these must be read with several command interface calls. The byte 5 declares the start index in the field of the diagnosis data.

If the start index is 0, new data is fetched from the monitor. Otherwise, the function will respond out of the memory; the data can be read consistently.

Setting of AS-i diagnosis

 Note	The function unsorted diagnosis is available only with monitors in the version 2.0 and higher. The function sorted diagnosis is available with all monitors.
---	---

The setting of the ASi diagnosis takes place in the window *Information about monitor and bus* of the configuration software **asimon** for the AS-i safety monitor.

- Call the menu *Edit/Information about monitor and bus*




Fig. 1. Calling of Information about monitor and bus

- Set in the window *Information about monitor and bus* the function range




Fig. 2. Setting of function range

- Select in the window *Information about monitor and bus* the tab *Diagnosis/Service*
- Select within the range *Data selection sorted* (sorted by OSSD) or *unsorted* (all

devices)




Fig. 3. Data selection (sorted/unsorted)

Enhanced Diagnosis

Since the "Safety at Work" monitor diagnosis is longer than the maximum size of the command interface, it must be read with several adjacent requests.

The byte 5 ('index') declares the start index in the array of diagnostic data. If this start index is 0, the whole diagnosis is fetched from the monitor and stored to an internal buffer. Otherwise, the AS-i Master will respond out of the internal buffer. Thus, even though several requests are necessary to read the whole buffer, data integrity is maintained.

Request													
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0					
1	$7E_{16}$												
2	T	L ¹	U ²	circuit									
3	02_{16}												
4	slave address												
5	index												

1. L=1 long diagnosis for advanced monitor

2. U=1 unsorted diagnosis (all devices)

Response														
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0						
1	$7E_{16}$													
2	T	result												
3	diagnosis byte #index+0													
4	diagnosis byte #index+1													
...	...													
n	diagnosis byte #index+n-3													

The diagnosis array is set up as follows:

Safety Monitor Diagnosis Array <i>"basic function range" and "sorted by OSSD"</i>								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
0	00_{16}							
1	state of monitor							
2	state of OSSD1							
3	state of OSSD2							
4	number of devices not green, OSSD1							
5	number of devices not green, OSSD2							
6	device index 32, OSSD1							
7	color of device 32, OSSD1							
8	device index 33, OSSD1							
9	color of device 33, OSSD1							
...	...							
68	device index 63, OSSD1							
69	color of device 63, OSSD1							
70	device index 32, OSSD2							
71	color of device 32, OSSD2							
...	...							
132	device index 63, OSSD2							
133	color of device 63, OSSD2							

Safety Monitor Diagnosis Array <i>"enhanced function range" and "sorted by OSSD"</i>								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
0	00_{16}							
1	state of monitor							
2	state of OSSD1							
3	state of OSSD2							
4	number of devices not green, OSSD1							
5	number of devices not green, OSSD2							
6	device index 32, OSSD1							
7	color of device 32, OSSD1							
8	device index 33, OSSD1							
...	...							
133	color of device 95, OSSD1							
134	device index 32, OSSD2							
...	...							
261	color of device 95, OSSD2							

Safety Monitor Diagnosis Array <i>"basic function range" and "all devices"</i>								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
0	00_{16}							
1	state of monitor							
2	state of OSSD1							
3	state of OSSD2							
4	number of devices not green							
5	—							
6	device index 32							
7	color of device 32							
8	device index 33							
9	color of device 33							
...	...							
68	device index 63							
69	color of device 63							
70	device index 32							
71	assignment of device 32 to OSSD							
...	...							
132	device index 63							
133	assignment of device 63 to OSSD							

Safety Monitor Diagnosis Array <i>"enhanced function range" and "all devices"</i>								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
0	00_{16}							
1	state of monitor							
2	state of OSSD1							
3	state of OSSD2							
4	number of devices not green							
5	—							
6	device index 32							
7	color of device 32							
8	device index 33							
...	...							
133	color of device 95							
134	device index 32							
135	assignment of device 32 to OSSD2							
...	...							
261	assignment of device 95 to OSSD							

Possible assignment:

00_{16} : preprocessing

01_{16} : OSSD 1

02_{16} : OSSD 2

03_{16} : OSSD 1+2

80_{16} : device does not exist

See the "Safety at Work" monitor documentation for a description of the codes used for monitor state, OSSD state, device colors and assignments to OSSDs.

8.2.3.3 Integrated AS-i Sensors: Warnings

Function: 03_{16}

List of integrated AS-i sensors according to profile S-1.1 (without extended addressing) or profile S-3.A.1 (with extended addressing), by which the input data bit D1 ("Warning") being deleted.

For creating of this list CDI and IDI are used only. Integrated AS-i slaves which are projected but not existing therefore are not entered here.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	$7E_{16}$							
2	T	O	circuit					
3	03_{16}							

Response (if O = 0)								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	$7E_{16}$							
2	T	result						
3	7A	6A	5A	4A	3A	2A	1A	0
...	...							
10	31B	30B	29B	28B	27B	26B	25B	24B

Response if O = 1)								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	$7E_{16}$							
2	T	result						
3	0	1A	2A	3A	4A	5A	6A	7A
...	...							
10	24A	25A	26A	27A	28A	29A	30A	31A

8.2.3.4 Integrated AS-i Sensors: Availability

Function: 04_{16}

List of the integrated slaves according to profile S-1.1 whose input data bits D2 ("Availability") are deleted.

For creating this list, CDI and IDI are used only. Integrated AS-i slaves which are projected but not existing therefore are not entered here.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	$7E_{16}$							
2	T	O	circuit					
3	04_{16}							

Response (if O = 0)								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	$7E_{16}$							
2	T	result						
3	7	6	5	4	3	2	1	0
...	...							
6	31	30	29	28	27	26	25	24

Response (if O = 1)								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	$7E_{16}$							
2	T	result						
3	0	1	2	3	4	5	6	7
...	...							
6	24	25	26	27	28	29	30	31

8.2.3.5 Failsafe

Function 05₁₆

This function influences input data by break down of AS-i Slaves (clear = clear bits, set= set bits, hold= leave old data).

Set:

Request														
Byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0						
1	$7D_{16}$													
2	T	circuit												
3	05_{16}													
4	failsafe status ¹													

- Value: 0= Clear, 1= Set, 2=Hold

Response									
Byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰	
1	7D ₁₆								
2	T	result							

Read:

Request									
Byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰	
1	7E ₁₆								
2	T	circuit							
3	05 ₁₆								

Response									
Byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰	
1	7E ₁₆								
2	T	response							
3	failsafe status ¹								

1. Value: 0= Clear, 1= Set, 2=Hold

8.2.3.6 IDI Filter

Function 06₁₆

This function influences filtering of input data. If the value is alike with the two successively following scannings, then the entrance is regarded as stable.

If the value is "0", then is the filter passiv, otherwise active.

Set:

Request									
Byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰	
1	7D ₁₆								
2	T	circuit							
3	06 ₁₆								
4	filter delay (0h-Fh)								

Response									
Byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰	
1	7D ₁₆								
2	T	response							
3	7	6	5	4	3	2	1	0	

Read:

Request									
Byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0	
1	$7E_{16}$								
2	T	circuit							
3	06_{16}								

Response									
Byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0	
1	$7E_{16}$								
2	T	response							
3	filter delay (0h-Fh)								

8.2.3.7 Change Buffer

Function 08_{16}

This function allows to power-on/off the input data of the change buffer.

Set:

Request									
Byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0	
1	$7D16$								
2	T	circuit							
3	08_{16}								
4	change buffer ¹								

1. Value: 0=change buffer off, 1=change buffer on)

Response									
Byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0	
1	$7D_{16}$								
2	T	result							

Read:

Request									
Byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0	
1	$7E_{16}$								
2	T	circuit							
3	08_{16}								

Response								
Byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	7E ₁₆							
2	T	result						
3	change buffer ¹							

1. Value: 0=change buffer off, 1=change buffer on)

8.2.3.8 Replacement of Safety Slaves Input Data

Function 0F₁₆

Use this function to replace safety slaves input data with "interpretation data". If the function is active, so have safety slaves input data the following meaning:

Bit 0,1: 00=channel 1 has released 11=channel 1 has not released.

Bit 2,3: 00=channel 2 has released, 11=channel 2 has not released.

 Note	This command replaces the old command MB_FP_LSS_ENABLE
--	--

Set:

Request														
Byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰						
1	7D ₁₆													
2	T	–	circuit											
3	0F ₁₆													
4	safety slaves ¹													

1. Value: 0= no substitute value, 1=substitute value for safety slaves

Response								
Byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	7D ₁₆							
2	T	–	result					

Read:

Request								
Byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	7E ₁₆							
2	T	–	circuit					
3	0F ₁₆							

Response								
Byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	$7E_{16}$							
2	T	result						
4	safety slaves ¹							

1. Value: 0= no substitute value, 1=substitute value for safety slaves

8.2.3.9 List of Safety Slaves

Function 10_{16}

Use this function to find out the addresses of safety slaves.

Read:

Request								
Byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	$7D_{16}$							
2	T	O ¹	circuit					
3	10_{16}							

1. O = orientation

Response (by O ≡ 0)								
Byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	$7D_{16}$							
2	T	result						
3	7	6	5	4	3	2	1	0
...	...							
6	31	30	29	28	27	26	25	24

Response (bei O ≡ 1)								
Byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	$7D_{16}$							
2	T	result						
3	0	1	2	3	4	5	6	7
...	...							
6	24	25	26	27	28	29	30	31

8.2.4 Configuration of the AS-i Master

8.2.4.1 Overview of the Commands

Values for command				
comamnd	value	meaning	Req Len	Res Len
SET_OP_MODE	0C ₁₆	Set_Operation_Mode	3	2
STORE_CDI	07 ₁₆	Store_Actual_Configuration	2	2
READ_CDI	28 ₁₆	Read_Actual_Configuration	3	4
SET_PCD	25 ₁₆	Set_Permanent_Config	5	2
GET_PCD	26 ₁₆	Get_Permanent_Config	3	4
SET_LPS	29 ₁₆	SET_LPS	11	2
GET_LPS	44 ₁₆	Get_LPS	2	10
STORE_PI	04 ₁₆	Store_Actual_Parameter	2	2
WRITE_P	02 ₁₆	Write_Parameter	4	3
READ_PI	03 ₁₆	Read_Parameter	3	3
SET_PP	43 ₁₆	Set_Permanent_Parameter	4	2
GET_PP	01 ₁₆	Get_Permanent_Parameter	3	3
SET_AAE	0B ₁₆	Set_Auto_Adress_Enable	3	2

8.2.4.2 Set Operation Mode (SET_OP_MODE: Set_Operation_Mode)

This call switches between configuration mode and protected mode.

In protected mode, only AS-i slaves entered in the LPS and whose expected and actual configurations match, are being activated.

In other words: The slaves are being activated if the I/O configuration and the ID codes of the detected AS-i slaves are identical to the configured values.

In configuration mode, all detected AS-i slaves (except for AS-i slave "0") are activated. This also applies to AS-i slaves for which there are differences between the expected and actual configuration.

The "OPERATION MODE" bit is stored permanently; in other words, it is retained after a cold/warm restart.

When you change from configuration mode to protected mode, the AS-i master will do a warm restart (change to the offline phase followed by a change to the online mode).

 Note	<p>If an AS-i slave with address "0" is entered in the LDS, the AS-i/PROFIBUS gateway cannot change from configuration mode to protected mode.</p>
--	--

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	$0C_{16}$							
2	T	-	circuit					
3	operation mode							

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	$0C_{16}$							
2	T		result					

Meaning of bit operation mode:

0 = protected mode

1 = configuration mode

8.2.4.3 Store Actual Configuration (STORE_CDI)

With this call, the (actual) configuration data (I/O configuration, ID code, extended ID1 code and extended ID2 code) of all AS-i slaves are stored permanently in the EEPROM as the (expected) configuration data. The list of activated AS-i slaves (LAS) is adopted in the list of permanent AS-i slaves (LPS).

When this command is executed, the AS-imaster changes to the offline phase and then changes back to the normal mode (warm restart on the AS-i master).

This command can only be executed in the configuration mode.

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	07_{16}							
2	T		result					

8.2.4.4 Read Actual Configuration (READ_CDI)

With this call, the following configuration data of an addressed AS-i slave obtained by the AS-i master on the AS-Interface are read.

- I/O configuration
- ID code
- Extended ID1 code
- Extended ID2 code

The configuration data are specified by the manufacturer of the AS-i slave.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	28_{16}							
2	T	-	circuit					
3	-	B	slave address					

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	28_{16}							
2	T	result						
3	xID2				xID1			
4	ID				IO			

Meaning of bit B:

B = 0 Single AS-i slave or A-slave

B = 1 B-slave

8.2.4.5 Set Permanent Configuration (SET_PCD)

This call sets the following configuration data for the addressed AS-i slave:

- I/O configuration
- ID code
- Extended ID1 code
- Extended ID2 code

The configuration data are stored permanently on the EEPROM of the AS-i/PROFIBUS gateway and are used as the expected configuration by the AS-i master in the protected mode. The configuration data are specified by the manufacturer of the AS-i slave.

If the addressed AS-i slave does not support an extended ID code 1/2, the value F_{hex} must be specified.

When this command is executed, the AS-i master changes to the offline phase and then changes back to the normal mode (warm restart).

This command can only be executed in the configuration mode.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	25_{16}							
2	T	–	circuit					
3	–	B	slave address					
4	xID2				xID1			
5	ID				IO			

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	25_{16}							
2	T	result						

Meaning of bit B:

B = 0 Single AS-i slave or A-slave

B = 1 B-slave

8.2.4.6 Get Extended Permanent Configuration (GET_PCD)

This call reads the following configuration data (configured data) of an addressed AS-i slave stored on the EEPROM of the AS-i master:

- I/O configuration
- ID code
- Extended ID1 code
- Extended ID2 code

The configuration data are specified by the manufacturer of the AS-i slave.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	26_{16}							
2	T	-	circuit					
3	-	B	slave address					

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	26_{16}							
2	T	result						
3	xID2				xID1			
4	ID				IO			

Meaning of bit B:

B = 0 Single AS-i slave or A-slave

B = 1 B-slave

8.2.4.7 Set List of Projected Slaves (SET_LPS and SET_LPS_R6 (6Bh))

The command **SET_LPS_R6 (6Bh)** differs from the command **SET-LPs** in:

- no empty byte (3)
- half so long LPS list

With the bit 2^5 is selected if the upper (=1) or lower (=0) part of the LCS is read.

With this call, the list of configured AS-i slaves is transferred for permanent storage in the EEPROM of the master.

When this command is executed, the AS-imaster changes to the offline phase and then changes back to the normal mode (warm restart).

This command can only be executed in the configuration mode.

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	29_{16}							
2	T	result						

8.2.4.8 Get List of Projected Slaves (GET_LPS)

With this call, the following entry is read out of the AS-i/PROFIBUS gateway: The list of projected AS-i slaves (*LPS*).

8.2.4.9 Store Actual Parameters (STORE_PI)

With this call, the configured parameters stored on the EEPROM are overwritten with the current, permanently stored (actual) parameters; in other words, the current parameters of all AS-i slaves are stored.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1								04_{16}
2	T	–						circuit

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1								04_{16}
2	T							result

8.2.4.10 Write Parameter (WRITE_P)

The AS-i slave parameter value transferred with the command is passed on to the addressed AS-i slave.

The parameter is stored in the AS-i/PROFIBUS gateway only temporarily and is not stored as a configured parameter in the EEPROM!

The AS-i slave transfers its current parameter value in the response (parameter echo). This can deviate from the value that has just been written according to the AS-i master specification.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1								02_{16}
2	T	–						circuit
3	–	B						slave address
4	–	–						parameter

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1								02_{16}
2	T							result
3	–	–						slave response

Meaning of bit B:

B = 0 Single AS-i slave or A-slave

B = 1 B-slave

8.2.4.11 Read Parameter (READ_PI: Read_Parameter)

This call returns the current parameter value (actual parameter) of an AS-i slave sent by the AS-i/PROFIBUS gateway. This value must not be confused with the parameter echo that is supplied by the AS-i slave as a response to the write_p job.

This command can not be used for a directly reading of an AS-i parameter out of an AS-i slave.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	03_{16}							
2	T	-	circuit					
3	-	B	slave address					

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	03_{16}							
2	T	result						
3	-	PI						

Meaning of bit B:

B = 0Single AS-i slave or A-slave

B = 1B-slave

8.2.4.12 Set_Permanent_Parameter (SET_PP)

With this call, a parameter value for the specified AS-i slave is configured. The value is stored permanently in the EEPROM of the gateway.

The configured parameter value is transferred only when the AS-i slave is activated after turning on the power supply on the AS-i/PROFIBUS gateway.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	43_{16}							
2	T	-	circuit					
3	-	B	slave address					
4	-	PP						

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	43_{16}							
2	T	result						

8.2.4.13 Get_Permanent_Parameter (GET_PP)

With this call, a slave-specific parameter value stored on the EEPROM of the AS-i/PROFIBUS gateway is read.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	01_{16}							
2	T	-	circuit					
3	-	B	slave address					

Response									
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0	
1	01_{16}								
2	T	result							
3	-			PP					

Meaning of bit B:

- B = 0 Single AS-i slave or A-slave
- B = 1 B-slave

8.2.4.14 Set Auto Address Enable (SET_AAE)

This call can enable or disable the "automatic address programming" function.

The AUTO_ADDR_ENABLE bit is stored permanently; in other words, it is retained after a warm/hot restart on the AS-i master.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	$0B_{16}$							
2	T	-	circuit					
3	Auto_Address_Enable							

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	$0B_{16}$							
2	T	result						

8.2.5 Other Commands

8.2.5.1 Overview of the Commands

Value for command				
command	value	meaning	Req Len	Res Len
IDLE	00 ₁₆	No request	2	2
READ_IDI	41 ₁₆	Read IDI	2	36
WRITE_ODI	42 ₁₆	Write_ODI	34	2
READ_ODI	56 ₁₆	Read ODI	2	34
SLAVE_ADDR	0D ₁₆	Change_Slave_Address	4	2
WRITE_XID1	3F ₁₆	Write_Extended_ID-Code_1	3	2
SET_OFFLINE	0A ₁₆	Set_Off-Line_Mode	3	2
SET_DATA_EX	48 ₁₆	Set_Data_Exchange_Active	3	2
BUTTONS	75 ₁₆	Disable Pushbuttons	3	2
FP_PARAM	7D ₁₆	„Functional Profile“ Param.	≥3	≥2
FP_DATA	7E ₁₆	„Functional Profile“ Data	≥3	≥2
EXT_DIAG	71 ₁₆	ExtDiag generation	6	2
RD_EXT_DIAG	7B ₁₆	Read ExtDiag Settings	2	7
INVERTER	7C ₁₆	Configure Inverter Slaves	12	4
MB_OP_CTRL_WR_FLAGS	0x85	Write Flag	≥5	2
MB_OP_CTRL_RD_FLAGS	0x86	Read Flag	4	≥3
RD_MFK_PARAM	0x59	Read SEW MFK21 Parameter	6	≥3

8.2.5.2 IDLE

When the value of "command" is zero, no request will be fulfilled.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	00 ₁₆							
2	T	-	circuit					

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	00 ₁₆							
2	T	result						

8.2.5.3 Read Input Data Image (READ_IDI)

With this call, the input data values of all AS-i slaves are read out of the AS-i/PROFIBUS gateway in addition to the cyclic data exchange. Though the command READ_IDI transmits all execution control flags (byte 3 and byte 4).

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	41 ₁₆							
2	T	–	circuit					

Response								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	41 ₁₆							
2	T	result						
3	–							
4	OR	APF	NA	CA	AAv	AAs	s0	Cok
5	–				slave 1A			
6	slave 2A				slave 3A			
...	...							
36	slave 30B				slave 31B			

Pok Periphery_Ok

S0 LDS.0

AAs Auto_Address_Assign

AAv Auto_Address_Available

CA Configuration_Active

NA Normal_Operation_Active

APF APF

OR Offline_Ready

Cok Config_Ok

8.2.5.4 Write Output Data Image (WRITE_ODI)

With this call the output data values of all AS-i slaves are written in addition to the cyclic data exchange.

Request								
byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
1	42 ₁₆							
2	T	–	circuit					
3	–				slave 1A			
4	slave 2A				slave 3A			
...	...							
34	slave 30B				slave 31B			

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	42_{16}							
2	T							result

8.2.5.5 Read Output Data Image (READ_ODI)

With this call, the output data values of all AS-i slaves is being read out of the AS-i/PROFIBUS gateway.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	56_{16}							
2	T	-						circuit

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	56_{16}							
2	T	-						result
3	-				slave 1A			
	slave 2A				slave 3A			
...	...							
34	slave 30B				slave 31B			

8.2.5.6 Change Slave Address (SLAVE_ADDR)

With this call, the AS-i address of an AS-i slave can be modified.

This call is mainly used to add a new AS-i slave with the default address "0" to the AS-Interface. In this case, the address is changed from "AS-i slave address old" = 0 to "AS-i slave address new".

This change can only be made when the following conditions are fulfilled:

1. An AS-i slave with "AS-i slave address old" exists.
2. If the old AS-i slave address is not equal to 0, an AS-i slave with address "0" cannot be connected at the same time.
3. The "AS-i slave address new" must have a valid value.
4. An AS-i slave with "AS-i slave address new" must not exist.



Note

When the AS-i slave address is changed, the AS-i slave is not reset, in other words, the output data of the AS-i slave are retained until new data are received at the new address.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	$0D_{16}$							
2	T	–	circuit					
3	–	B	source address					
4	–	B	target address					

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	$0D_{16}$							
2	T	result						

Meaning of bit B:

B = 0 Single AS-i slave or A-slave

B = 1 B-slave

8.2.5.7 Write AS-i Slave Extended ID1 (WRITE_XID1)

With this call, the extended ID1 code of an AS-i slave with address "0" can be written directly via the AS-i cable. The call is intended for diagnostic purposes and is not required in the normal master mode.

The AS-i master passes the extended ID1 code on to the AS-i slave without any plausibility check.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	$3F_{16}$							
2	T	–	circuit					
3	–				xID1			

Response								
Byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	$3F_{16}$							
2	T	result						

8.2.5.8 Set Offline Mode (SET_OFFLINE)

This call switches between online and offline mode.

The online mode is the normal operating state for the AS-i master. The following jobs are processed cyclically:

- During the data exchange phase, the fields of the output data are transferred to the slave outputs for all AS-i slaves in the LAS. The addressed AS-i slaves submit the values of the slave inputs to the master when the transfer was free of errors.
- This is followed by the inclusion phase in which existing AS-i slaves are searched and newly added AS-i slaves are entered in the LDS or LAS.

- In the management phase, jobs by the user such as writing parameters are executed.

In the offline mode, the AS-i/PROFIBUS gateway processes jobs by the user only. (Jobs that involve the immediate addressing of an AS-i slave are rejected with an error). There is no cyclic data exchange with the AS-i slaves.

When offline, the AS-i circuit is in a safe state.

The OFFLINE = TRUE bit is not permanently stored; in other words, following a cold/warm restart, the AS-i/PROFIBUS gateway is once again in the online mode.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	$0A_{16}$							
2	T	-	circuit					
3	Off-Line							

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	$0A_{16}$							
2	T	-	result					

The master changes to the offline phase, if there is a 1 written in byte 3.

The master will change to online mode if there is a 0 written in byte 3.

8.2.5.9 Release Data Exchange (SET_DATA_EX)

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	48_{16}							
2	T	-	circuit					
3	Data_Exchange_Active							

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	48_{16}							
2	T	-	result					

8.2.5.10 BUTTONS

With this call, the use of the buttons can be enabled/disabled.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	75_{16}							
2	T	-	circuit					
3	Buttons disabled							

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	75_{16}							
2	T	result						

8.2.5.11 FP_PARAM

This command is used for parametrization of "functional profiles".

The content of the request and response bytes depends on the called function (see chapter 8.2.3).

Request														
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0						
1	$7D_{16}$													
2	T	-	circuit											
3	function													
4	request byte 1													
...	...													
n	request byte n-3													

Response															
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0							
1	$7D_{16}$														
2	T	result													
3	response byte 1														
...	...														
n	response byte n-2														

8.2.5.12 FP_DATA

This command is used for the data exchange with "functional profiles".

The content of the request and response bytes depends on the called function (see chapter 8.2.3).

Request														
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0						
1	$7E_{16}$													
2	T	-	circuit											
3	function													
4	request byte 1													
...	...													
n	request byte n-3													

Response														
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0						
1	$7E_{16}$													
2	T	result												
3	reponse byte 1													
...	...													
n	response byte n-2													

8.2.5.13 EXT_DIAG

With this call, the conditions when to set the ExtDiag bit can be selected.

Request														
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0						
1	71_{16}													
2	T	-	circuit											
3	CF													
4	APF													
5	PF													
6	CS													

Response								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	71_{16}							
2	T	-	result					

CF ExtDiag is set, if ConfigError = 1

APF ExtDiag is set, if APF = 1

PF ExtDiag is set, if PeripheryFault = 1

CS ExtDiag is set, if LCS is not empty

8.2.5.14 RD_EXT_DIAG

With this call, the conditions when the ExtDiag bit is set can be read.

Request								
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	$7B_{16}$							
2	T	-	circuit					

Response									
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0	
1	75_{16}								
2	T	result							
3	CF								
4	APF								
5	PF								
6	CS								
7	FD								

CF ExtDiag is set by ConfigError = 1

APF ExtDiag is set by APF = 1

PF ExtDiag is set by PeripheryFault = 1

CS ExtDiag is set, if LCS is not empty

FD Diagnosis will be updated only if this is dictated by the PROFIBUS norm.
Diagnosis date are not up to date when in doubt.

8.2.5.15 INVERTER

With this call, an AS-i slave for frequency inverters is switched from cyclical mode to the transmission mode of four 16 bit values, in order to operate again with the selected AS-i destination parameter.

Request														
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0						
1	$7C_{16}$													
2	T	–	circuit											
3	slave address													
4	destination parameter													
5	value 1, high byte													
6	value 1, low byte													
7	value 2, high byte													
8	value 2, low byte													
9	value 3, high byte													
10	value 3, low byte													
11	value 4, high byte													
12	value 4, low byte													

Response									
byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0	
1	$7C_{16}$								
2	T	result							

8.2.5.16 Write Flag

Use this command to write the flag of a control program.

The control program of devices with control functions accept data from the PB interface.

Request												
Byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0				
1	0x85											
2	T	-	circuit									
3	introductory address											
4	number n											
5	number 1											
...	...											
n	number n											

Response								
Byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	0x85							
2	T	-	result					

8.2.5.17 Read Flag

Use this command to read out the flags of a control program.

The control program of devices with control functions accept data from the interface

Request												
Byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0				
1	0x86											
2	T	-	circuit									
3	introductory address											
4	number n											

Response												
Byte	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0				
1	0x86											
2	T	-	result									
3	data 1											
...												
n	data n											

8.2.5.18 READ_MFK_PARAM

Use this command to read multiple commands of a SEW MFK21 slave.

Request														
Byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰						
1	0x59													
2	T	-	circuit											
3	slave													
4	index high													
5	index low													
6	number (n)													

Response														
Byte	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰						
1	0x59													
2	T	result												
3	prm byte (index)													
4	prm byte (index+1)													
n+2	prm byte (index+n-1)													

8.3 Command Interface Examples

You can find actual command interface examples in the download area of the homepage.

8.3.1 Reading 16-Bit Input Values

Command RD_7X_IN: Reading of 16-bit input values.

PROFIBUS DP V0: cyclic data exchange

Used ID/module in the GSD file: 12 bytes management

Meaning of the bytes:

Request: RD_7X_IN	
Byte 1	50 _{hex} (RD_7X_IN)
Byte 2	00 _{hex} (master 1, single master)
Byte 3	1D _{hex} (slave address 29)
Byte 4	00 _{hex}
...	...
Byte 12	00 _{hex}

Response	
Byte 1	00 _{hex} (or old values)
Byte 2	00 _{hex} (or old values)
Byte 3	00 _{hex} (or old values)
Byte 4	00 _{hex} (or old values)
...	...
Byte 12	00 _{hex} (or old values)

The call of the command interface has not been answered with the valid values since the toggle bit has not been set.

Set of toggle bit:

Request	
Byte 1	50 _{hex}
Byte 2	80 _{hex} (toggle bit, result)
Byte 3	1D _{hex} (slave address 29)
Byte 4	00 _{hex}
...	...
Byte 12	00 _{hex}

Result: See chapter 8.1.2 "Values for Results"

Response	
Byte 1	50 _{hex}
Byte 2	80 _{hex} (toggle bit, master1)
Byte 3	16-bit channel 1 high byte _{hex}
Byte 4	16-bit channel 1 low byte _{hex}
Byte 5	16-bit channel 2 high byte _{hex}
Byte 6	16-bit channel 2 low byte _{hex}
Byte 7	16-bit channel 3 high byte _{hex}
Byte 8	16-bit channel 3 low byte _{hex}
Byte 9	16-bit channel 4 high byte _{hex}
Byte 10	16-bit channel 4 low byte _{hex}
Byte 11	00 _{hex} not used
Byte 12	00 _{hex} not used

To get the input data again, the T-bit has to be reset again.

8.3.2 Store current Configuration to the AS-i Master

1. Switch master to configuration mode
2. Write the current slave configuration to the master
3. Switch master to protected mode
4. Wait until master is in normal (protected) operation mode

12 Byte Management

1. Switch master to config mode

Request: SET_OP_MODE	
Byte 1	0C _{hex} (SET_OP_MODE)
Byte 2	00 _{hex} (T = 0, master 1, single master)
Byte 3	01 _{hex} (= config mode)
Byte 4	00 _{hex}
...	...
Byte 12	00 _{hex}

Response	
Byte 1	00 _{hex} (or old values)
Byte 2	00 _{hex} (or old values)
...	...
Byte 12	00 _{hex} (or old values)

No result because toggle bit = 0.

Set the Toggle Bit:

Request: SET_OP_MODE	
Byte 1	0C _{hex} (SET_OP_MODE)
Byte 2	80 _{hex} (T = 1, master 1, single master)
Byte 3	01 _{hex} (= config mode)
Byte 4	00 _{hex}
...	...
Byte 12	00 _{hex}

Response	
Byte 1	0C _{hex}
Byte 2	80 _{hex} (T = 1, result = 0)
Byte 3	00 _{hex} (or old values)
...	...
Byte 12	00 _{hex} (or old values)

Master is now in configuration mode.

Result = 0 ⇒ No error, for other result codes see chapter 8.1.2 "Values for Results".

2. Write the actual slave configuration to the master

Request: STORE_CDI	
Byte 1	07 _{hex} (STORE_CDI)
Byte 2	00 _{hex} (T = 0, master 1, single master)
Byte 3	00 _{hex}
...	...
Byte 12	00 _{hex}

Response	
Byte 1	00 _{hex} (or old values)
Byte 2	00 _{hex} (or old values)
...	...
Byte 12	00 _{hex} (or old values)

No result because toggle bit = 0.

Set the toggle bit:

Request: STORE_CDI	
Byte 1	07 _{hex} (STORE_CDI)
Byte 2	80 _{hex} (T = 0, master 1, single master)
Byte 3	00 _{hex}
...	...
Byte 12	00 _{hex}

Response	
Byte 1	00 _{hex}
Byte 2	80 _{hex} (T = 1, result = 0)
Byte 3	00 _{hex} (or old values)
...	...
Byte 12	00 _{hex} (or old values)

The current configuration data has been written.

3. Set master to protected mode

Request: SET_OP_MODE	
Byte 1	0C _{hex} (SET_OP_MODE)
Byte 2	00 _{hex} (T = 0, master 1, single master)
Byte 3	00 _{hex} (= protected mode)
Byte 4	00 _{hex}
...	...
Byte 12	00 _{hex}

Response	
Byte 1	00 _{hex} (or old values)
Byte 2	00 _{hex} (or old values)
...	...
Byte 12	00 _{hex} (or old values)

No result because toggle bit = 0.

Set the toggle bit:

Request: SET_OP_MODE	
Byte 1	0C _{hex} (SET_OP_MODE)
Byte 2	80 _{hex} (T = 1, master 1, single master)
Byte 3	00 _{hex} (= protected mode)
Byte 4	00 _{hex}
...	...
Byte 12	00 _{hex}

Response	
Byte 1	0C _{hex}
Byte 2	80 _{hex} (T = 1, result = 0)
Byte 3	00 _{hex} (or old values)
...	...
Byte 12	00 _{hex} (or old values)

The master has now been ordered to switch to protected mode. It must be waited until the master is switching in this operation mode.

4.Wait until master is in normal operation mode (and protected mode)

Reading out the flags until NA (Normal Operation Active) has been set.

Request: GET_FLAGS	
Byte 1	47 _{hex} (GET_FLAGS)
Byte 2	00 _{hex} (T = 0, master 1, single master)
Byte 3	00 _{hex}
...	...
Byte 12	00 _{hex}

Response	
Byte 1	00 _{hex} (or old values)
Byte 2	00 _{hex} (or old values)
...	...
Byte 12	00 _{hex} (or old values)

No result because toggle bit = 0.

Setting the toggle bit:

Request: GET_FLAGS	
Byte 1	47 _{hex} (GET_FLAGS)
Byte 2	00 _{hex} (T = 0, master 1, single master)
Byte 3	00 _{hex}
Byte 4	00 _{hex}
...	...
Byte 12	00 _{hex}

Response	
Byte 1	47 _{hex}
Byte 2	80 _{hex} (T = 1, result = 0)
Byte 3	- - - - - - - POK
Byte 4	OR APF NA CA AA V AAs S0 COK
Byte 5	AA e OL DX
Byte 6	00 _{hex}
...	
Byte 12	00 _{hex}

The flag NA has to be set before the application is started. In case it is not set, the flags have to be read out until this flag has been set to 1.

The flag NA indicates that the master is in normal operation mode.

Normal operation mode is necessary to run the application safely.

8.3.3 Store new Configuration for all Slaves

1. Switch master in configuration mode
2. Write slave configuration to master
3. Write new list of projected slaves (*LPS*)
4. Write permanent parameter (*PP*) to master
5. Switch master to protected mode
6. Wait until master is in normal operation Mode (and protected mode)

12 Byte Management

1. Set master in config mode

Request: SET_OP_MODE	
Byte 1	0C _{hex} (SET_OP_MODE)
Byte 2	00 _{hex} (T = 0, master 1, single master)
Byte 3	01 _{hex} (= config mode)
Byte 4	00 _{hex}
...	...
Byte 12	00 _{hex}

Response	
Byte 1	00 _{hex} (or old values)
Byte 2	00 _{hex} (or old values)
Byte 3	00 _{hex} (or old values)
Byte 4	00 _{hex} (or old values)
...	...
Byte 12	00 _{hex} (or old values)

No result because toggle bit = 0.

Set the toggle bit:

Request: SET_OP_MODE	
Byte 1	0C _{hex} (SET_OP_MODE)
Byte 2	80 _{hex} (T = 1, master 1, single master)
Byte 3	01 _{hex} (= config mode)
Byte 4	00 _{hex}
...	...
Byte 12	00 _{hex}

Response	
Byte 1	0C _{hex}
Byte 2	80 _{hex} (T = 1, result = 0)
Byte 3	00 _{hex} (or old values)
Byte 4	00 _{hex} (or old values)
...	...
Byte 12	00 _{hex} (or old values)

The master is now in configuration mode.

Result: See chapter 8.1.2 "Values for Results".

2. Write single configuration to master

Writing a configuration of an AS-i slave to the master.

For example:

16-bit input 4 CH at address 4 (Slave datasheet)
 ID: 3_{hex}
 ID2: E_{hex}
 IO: 7_{hex}
 ID1: F_{hex}

Request: SET_PCD	
Byte 1	25 _{hex} (SET_PCD)
Byte 2	00 _{hex} (T = 0, master 1, single master)
Byte 3	04 _{hex} (slave address to write to master)
Byte 4	EF _{hex} (ID + IO to configurate)
Byte 5	37 _{hex} (xID2 + xID1 to configurate)
Byte 6	00 _{hex}
...	...
Byte 12	00 _{hex}

Response	
Byte 1	00 _{hex} (or old values)
Byte 2	00 _{hex} (or old values)
Byte 3	00 _{hex} (or old values)
Byte 4	00 _{hex} (or old values)
...	...
Byte 12	00 _{hex} (or old values)

No result because toggle bit = 0.

Set the toggle bit:

Request: SET_PCD	
Byte 1	0C _{hex} (SET_PCD)
Byte 2	80 _{hex} (T = 1, master 1, single master)
Byte 3	04 _{hex} (slave address to write to master)
Byte 4	EF _{hex} (ID + IO to configurate)
Byte 5	37 _{hex} (ID + IO to configurate)
Byte 6	00 _{hex}
...	...
Byte 12	00 _{hex}

Response	
Byte 1	25 _{hex}
Byte 2	80 _{hex} (T = 1, result = 0)
Byte 3	00 _{hex} (or old values)
Byte 4	00 _{hex} (or old values)
...	...
Byte 12	00 _{hex} (or old values)

The single slave configuration for the 16-bit module is written.

This command must be repeated for all 31 A-slaves and all 31 B-slaves. If you don't connect a slave to an address, write F_{hex} for ID, IO, ID1, ID2.

3. Write new list of projected slaves

Write the complete LPS of your AS-i circuit.

Every bit in the LPS corresponds to one slave after the following scheme:

Byte0/Bit 0:slave 0/0A - can not be set!

Byte1/Bit 1:slave 1/1A

...

Byte3/Bit 7:slave 31/31A

Byte4/Bit 0:slave 0B - can not be set!

Byte4/Bit 1:slave 1B

...

Byte7/Bit 7:slave 31B

The slave is projected if the bit is set.

Example above: 16-bit module at address 4 \Rightarrow Set bit 4/byte 0:

Request: SET_LPS	
Byte 1	29 _{hex} (SET_LPS)
Byte 2	00 _{hex} (T = 0, master 1, single master)
Byte 3	00 _{hex}
Byte 4	10 _{hex} (LDS byte 0)
Byte 5	00 _{hex} (LDS byte 1)
...	...
Byte 11	00 _{hex} (LDS byte 7)
Byte 12	00 _{hex}

Response	
Byte 1	00 _{hex} (or old values)
Byte 2	00 _{hex} (or old values)
...	...
Byte 12	00 _{hex} (or old values)

No result because toggle bit = 0.

Setting the toggle bit:

Request: SET_LPS	
Byte 1	29 _{hex}
Byte 2	80 _{hex} (T = 1, master 1, single master)
Byte 3	00 _{hex}
Byte 4	10 _{hex} (LDS byte 0)
Byte 5	00 _{hex} (LDS byte 1)
...	...
Byte 11	00 _{hex} (LDS byte 7)
Byte 12	00 _{hex}

Response	
Byte 1	29 _{hex}
Byte 2	80 _{hex} (T = 1, result = 0)
Byte 3	00 _{hex} (or old values)
...	...
Byte 12	00 _{hex} (or old values)

The new list of protected slaves (LPS) is written.

4. Write permanent parameter (power on parameter) to master

Example as above: 16-bit module at address 4 with PP = 07_{hex}

Request: SET_PP	
Byte 1	43 _{hex} (SET_PP)
Byte 2	00 _{hex} (T = 0, master 1, single master)
Byte 3	04 _{hex} (slave address to write to master)
Byte 4	07 _{hex} (PP to write (use low nibble))
Byte 5	00 _{hex} (LDS byte 1)
...	...
Byte 12	00 _{hex}

Response	
Byte 1	00 _{hex} (or old values)
Byte 2	00 _{hex} (or old values)
...	...
Byte 12	00 _{hex} (or old values)

No result because toggle bit = 0

Setting the toggle bit:

Request: SET_PP	
Byte 1	43 _{hex} (SET_PP)
Byte 2	80 _{hex} (T = 0, master 1, single master)
Byte 3	04 _{hex} (slave address to write to master)
Byte 4	07 _{hex} (PP to write (use low nibble))
Byte 5	00 _{hex}
...	...
Byte 12	00 _{hex}

Response	
Byte 1	43 _{hex}
Byte 2	80 _{hex} (T = 1, Result = 0)
Byte 3	00 _{hex}
...	...
Byte 12	00 _{hex}

The permanent parameter for the 16-bit module is written.

This command must be repeated for all 31 A-slaves and all 31 B-slaves. If you don't connect a slave to an address, write the default value to the masterff_{hex} as a permanent parameter.

5. Switch Master to Protected Mode

Request: SET_OP_MODE	
Byte 1	0C _{hex} (SET_OP_MODE)
Byte 2	00 _{hex} (T = 0, master 1, single master)
Byte 3	00 _{hex} (= protected mode)
Byte 4	00 _{hex}
...	...
Byte 12	00 _{hex}

Response	
Byte 1	00 _{hex} (or old values)
Byte 2	00 _{hex} (or old values)
...	...
Byte 12	00 _{hex} (or old values)

No result because toggle bit = 0.

Setting the toggle bit:

Request: SET_OP_MODE	
Byte 1	0C _{hex} (SET_OP_MODE)
Byte 2	80 _{hex} (T = 1, master 1, single master)
Byte 3	00 _{hex} (= protected mode)
Byte 4	00 _{hex}
...	...
Byte 12	00 _{hex}

Response	
Byte 1	0C _{hex}
Byte 2	80 _{hex} (T = 1, result = 0)
Byte 3	00 _{hex} (or old values)
...	...
Byte 12	00 _{hex} (or old values)

The master has now been ordered to switch to protected mode.

6. Wait until master is in normal (protected) operation mode

Read out the flags, until the NA (Normal Operation Active) has been set.

Request: GET_FLAGS	
Byte 1	47 _{hex} (GET_FLAGS)
Byte 2	00 _{hex} (T = 0, master 1, single master)
Byte 3	00 _{hex}
...	...
Byte 12	00 _{hex}

Response	
Byte 1	00 _{hex} (or old values)
Byte 2	00 _{hex} (or old values)
...	...
Byte 12	00 _{hex} (or old values)

No result because toggle bit = 0.

Setting the toggle bit:

Request: GET_FLAGS	
Byte 1	47 _{hex} (GET_FLAGS)
Byte 2	00 _{hex} (T = 0, master 1, single master)
Byte 3	00 _{hex}
Byte 4	00 _{hex}
...	...
Byte 12	00 _{hex}

Response	
Byte 1	47 _{hex}
Byte 2	80 _{hex} (T = 1, result = 0)
Byte 3	- - - - - - POK
Byte 4	OR APF NA CA AAv AAs S0 COK
Byte 5	AAe OL DX
Byte 6	00 _{hex}
...	
Byte 12	00 _{hex}

The flag NA has to be set before the application is started. In case it is not set, the flags have to be read out until this flag has been set to 1.

The flag NA indicates that the master is in normal operation mode.

Normal operation mode is necessary to run the application safely.

If a command of the command interface is used via PROFIBUS DP V1, it is not necessary to use the toggle bit.

The flag NA indicates that the master is in the normal operating mode which is necessary for the application to run safely.

9 Commissioning Tools and Accessories


The Windows based software "AS-i Control Tools" is designed to make the commissioning of the AS-i/PROFIBUS gateway so easy as possible.

The software communicates with the AS-i/PROFIBUS gateway using a PROFIBUS DP master simulator DP V1.


9.1 Windows Software AS-i Control Tools

The Windows software "AS-i-Control-Tools" enables you to configure the AS-i circuit in a very comfortable way.


1. For this purpose plug in a Master Simulator DP V1 or a serial PROFIBUS Master to the D-SUB-connector of the AS-i/PROFIBUS gateway and connect the device with a fully covered cable to the serial interface of your PC.
2. Start the AS-i-Control-Tools.
3. Call the command Master | New.




4. Choose PROFIBUS as protocol.
5. Do the appropriate settings. (e.g. serial interface COM 2, station address <auto>, AS-i circuit <1>)



6. Call the command Master | AS-i configuration.
The AS-i configuration editor will be started. All detected and projected AS-i slaves are displayed in this window.




7. Click on a slave entry to open the dialog box slave configuration.



Changing a slave address, setting AS-i parameters or AS-i configuration data is possible here. Additionally, inputs and outputs can be tested.

8. Click in the main menu on the second button from the right side to acquire a graphic presentation of the "AS-i Control Tools".



A very easy approach to configure the AS-i circuit is connecting each AS-i slave to the line and setting the AS-i slave address one after the other. After that press the button "Store configuration" to adopt the detected AS-i circuit to the AS-i master as projected data.

Furthermore you can use the **AS-i Address Assistant**. This tool automatically changes the address of an AS-i slave to the desired address after connecting the slave to the AS-i line. The desired AS-i configuration can be created offline before and then be stored to a file. When building up the plant you only have to connect the AS-i slaves to the AS-i line one after the other.

Further descriptions to all features of the software can be obtained from the integrated help.

PROFIBUS DP Master Simulator The PROFIBUS DP Master Simulator is an easy to use software for data exchange with PROFIBUS slaves of almost all manufacturers via PROFIBUS DP. The PROFIBUS DP master simulator can exchange data with many PROFIBUS slaves even without GSD file or type-file. The PROFIBUS slaves can be put into operation with the default I/O window. Input data can be read and output data can be written. Furthermore, the PROFIBUS DP Master Simulator also processes GSD-files. User parameters can be edited and the configuration can be modified and stored. The PROFIBUS station address can be changed with the PROFIBUS DP master simulator as well, this is useful for PROFIBUS I/O modules in protection class IP67 without addressing switches.

The PROFIBUS DP Master Simulator offers the possibility to scan a PROFIBUS network for connected slaves and to display them graphically. In this case, the case the PROFIBUS UART has to be connected directly to a PROFIBUS slave. The I/O data and the PROFIBUS user diagnosis can be displayed binary, hexadecimal and now also as ASCII code. The PROFIBUS output data can be transmitted consistently to the PROFIBUS slave. In **type mode** it is possible to set an output as long as the mouse button is pressed.

The new version of the PROFIBUS DP Master Simulator (supports PROFIBUS DP V1). PROFIBUS slaves can be operated in the acyclic mode DP V1. This is especially helpful for commissioning complex field devices like drives, modular I/O systems etc.

The PROFIBUS Master Simulator consists of the software and the **PROFIBUS UART** which is the ideal interface converter between the RS 232 interface of a PC and the PROFIBUS slave. The **UART** does not need any additional external powersupply. Therefore it is also suitable for mobile use with a laptop or a notebook. The **PROFIBUS UART** is simply inserted between the PROFIBUS slave and the RS 232 connector cable.

Besides the software "PROFIBUS DP master simulator", **DLL drivers** for Windows98, Windows Me, Windows 2000 and Windows NT as well as examples written in C come with the PROFIBUS UART. This offers the possibility to **use the PROFIBUS UART in combination with an own software**. However the PROFIBUS UART is a monitoring and commissioning tool for PROFIBUS slaves, it is not designed to control automation processes.

9.2

Further Information

For further information please visit the homepage.

10 Appendix

10.1 Codes indicated by the Display

In the basic state of the configuration mode, the display shows the addresses of all detected slaves at a rate of two per second one after the other. A blank display indicates that the *LDS* is empty, no slaves were detected.

In the basic state of the protected operating mode, the display is either blank or displays the address of a faulty assignment (see chapter).

During manual address programming, the slave address display has a different meaning (see chapter 6.2.4).

All displayed numbers bigger than 31 which can not be interpreted as a slave address are status or error messages of the master. They have the following meanings:

39	Advanced AS-i diagnostics: After pressing the 'set'-button a short-time AS-i power failure occurred.
40	The AS-i master is in offline phase.
41	The AS-i master is in detection phase.
42	The AS-i master is in activation phase.
43	The AS-i master starts the normal operating mode.
70	Hardware error: The AS-i master's EEPROM cannot be written.
71	Wrong PIC-type.
72	Hardware error: wrong PIC-processor.
73	Hardware error: wrong PIC-processor.
74	Checksum error in the EEPROM.
75	Error in the internal RAM.
76	Error in the external RAM.
77	AS-i control software error: Stack overflow (AS-i control II)
78	AS-i control software error: Checksum error in the control program.
80	Error while attempting to exit the configuration mode: A slave with address zero exists.
81	General error while changing a slave address.
82	The front panel operation is blocked. Until repowering-up the device can only be accessed from the host via the interface.
83	Program reset of the AS-i Control programm: The AS-i Control programm is being read out of EEPROM and copied into the RAM.
88	Display test while starting up the AS-i master
90	Error while changing a slave address in protected operating mode: No slave with address 0 existing.
91	Error while changing slave address: Target address is already used.
92	Error while changing slave address: New address could not be set.
93	Error while changing slave address: New address could only be stored volatilely in the slave.

Issue date - 21.12.2005

94	Error while changing the slave address in protected operating mode: Slave has wrong configuration data.
95	Error while changing slave address in protected operating mode: The configuration error was caused by a superfluous slave (instead of a missing slave).


10.2 Codes indicated by basic master

The basic master cannot display the following messages in a numeric form:


APF	Offline because of Power Fail
LOS	Offline because of LOS
OFH	Offline because of Host
OFL	Offline - other cause
SEA	Collet phase
... 	(Current lignht) error-free function
EFL	Ground fault

11 Appendix: Installation/Commissioning Instructions

11.1 Installation/Commissioning Instruction AS-i/PROFIBUS Gateway Article No.: VBG-PB-K25



Abmessungen/Dimensions/Dimensions/Dimensioni/Dimensiones [mm]



Issue date - 21.12.2005

Montage/Montage/Fitting/Montaggio/Montaje



auf Montageplatte mit 35-mm-Hutschiene ①

on mounting plate with 35 mm top-hat rail ①


sur plaque de montage avec profilé-support 35 mm ①

su piastra di montaggio con guida DIN 35 mm ①

sobre placa de montaje con guía simétrica de 35 mm ①



Frontview and Connections



⑥ AS-i-Kreis/AS-i circuit/Bus AS-i/AS-i Circuito/AS-i Circuit

⑦ AS-i-Netzteil/AS-i power supply/Alimentation bus/Alimentazione AS-i/Alimentación AS-i

Hinweis/Hint/Remarque/Indicazione/Nota

Am Kabel für das Netzteil dürfen keine Slaves oder Repeater angeschlossen werden.

Am Kabel für den AS-i-Anschluss dürfen keine AS-i-Netzteile oder weitere Master angeschlossen werden.

At the cable for power supply no slaves or repeaters may be attached.

At the cable for AS-i circuit no power supplies or further masters may be attached.

Au câble pour l'alimentation aucun esclave ou répéteur peut ne pas être attaché.

Au câble pour le circuit AS-i aucune alimentation ou autre maître ne peut être attachée


Al cavo per il alimentazione nessun schiavi o ripetitore possono essere fissati.

Al cavo per il AS-i circuito nessun alimentazione o ulteriori padrone possono essere fissati.

En el cable para la alimentación ningunos esclavos o repetidores pueden ser unidos.

En el cable para el AS-i circuito ninguna alimentación u otros amos pueden ser unidos.

Operating temperature: 0°C ... +55°C



Temperature rating for cable: 60/75°C
Use copper conductors only

1 x 0.5 - 1.5 mm² (16AWG/kcmil: min. 24/max.12)

- ① LED-Statusanzeige
- ② Tasten für Handbedienung
- ③ LED-Anzeige
- ④ PROFIBUS-Anschluss
- ⑤ Erde
- ⑥ Stromversorgung
- ⑦ AS-i-Anschluss

- ① LED status display
- ② Buttons for hand operation
- ③ LED display
- ④ PROFIBUS connection
- ⑤ Earth
- ⑥ Power supply
- ⑦ AS-i connection

- ① Afficheur d'état DEL
- ② Boutons pour commande manuelle
- ③ Afficheur LED
- ④ Raccordement PROFIBUS
- ⑤ Terre
- ⑥ Alimentation
- ⑦ Connexion AS-i


- ① Visualizzazione a LED
- ② Pulsanti per le impostazioni manuali
- ③ Indicazione LED
- ④ Collegamento PROFIBUS
- ⑤ Terra
- ⑥ Alimentazione
- ⑦ Collegamento interfaccia AS-i

- ① LED visualización
- ② Teclas para accionamiento manual
- ③ Indicación LED
- ④ Conexión PROFIBUS
- ⑤ Tierra
- ⑥ Alimentación eléctrica
- ⑦ Conexión AS-i

1. Startup

 Note	<p>If PROFIBUS is active, no configuration settings by push buttons!</p>
--	--

1.1 Setting the PROFIBUS DP Address



Das Gerät ist werkseitig auf Adresse 3 eingestellt.
The device is set to address 3 at the factory.

L'appareil est réglé en usine à l'adresse 3.


Il dispositivo viene de la fábrica con l'indirizzo 3.

El aparato viene ajustado de fábrica en la dirección 3.


- 0:** Adressänderung über PROFIBUS ist gesperrt (default)
Address change via PROFIBUS is locked (default)
Changement d'adresse est verrouillé par PROFIBUS (default)
Cambiamento di indirizzo è bloccato via PROFIBUS (default)
Cambio de la dirección es bloqueado vía PROFIBUS (default)

- 1:** Adressänderung über PROFIBUS ist erlaubt
Address change via PROFIBUS is allowed
Changement d'adresse est permis par PROFIBUS
Cambiamento di indirizzo è permesso via PROFIBUS
Cambio de la dirección se permite vía PROFIBUS


1.2 Switching to the configuration mode



1.3 Connect AS-i Slaves




1.4 Store AS-i Configuration




2. Error tracing


2.1 Incorrect slaves (one error)



2.2 Incorrect slaves (multiple errors)




2.3 Error Display (last error)




3. Addressing

3.1 Delete Slave Address 5



Issue date - 21.12.2005

3.2 Program Slave 0 to Address 4



4. Accessories

4.1 Software "AS-i Control Tools"

4.2 Serial PROFIBUS Master

12 Glossary: AS-i Terms

A/B slave

AS-i slave with extensible addressing: The address range of an A/B slave runs from 1A to 31A and from 1B to 31B. As the master needs the fourth output data bit for switching between A and B address, A/B slaves only have three output data bits maximum.

Activation Phase

In the activation phase the detected slaves are activated by sending the parameter. This is indicated by a "42" on the Master's Display. This phase takes only 10 ms, tops, to short to be displayed.

AS-i power fail

Voltage drop on the AS-i line; by falling below an assigned value the master changes to the \Rightarrow Off-line phase.

Inclusion Phase

After the data exchange with all AS-i slaves the master is searching for new slaves. For this purpose an detection telegram is sent to one AS-i address and in case of an answer the master tries to read the \Rightarrow actual configuration of the slave. Depending on the mode (\Rightarrow protected mode or \Rightarrow configuration mode) and on the actual configuration the detected slave will be activated.

After each data exchange with all AS-i slaves only one detection telegram is sent to one slave address. So the AS-i cycle is always one telegram longer as expected from the number of activated slaves (\Rightarrow LAS).

Autoprog Flags

Auto Address Enable; flag from the Host to the AS-i Master

With this flag, automatic addressing can be enabled or inhibited.

This flag is stored non-volatile in the Master.

Auto Address Assign, Auto Address Possible; flag from the AS-i Master to the Host
The automatic programming is not inhibited and there is no configuration error.
A failing slave could be addressed automatically.

Auto Address Available, flag from the AS-i Master to the Host

Exactly one AS-i slave is missing and the automatic programming is not inhibited. If a slave with the address 0 and the profile of the missing slave is connected, it receives the address of the missing slave automatically.

IO-Code

The first digit of the slave profile indicates the number of inputs and outputs of the slave. A 4I/4O slave e.g. is associated to "7", a slave with 4 digital Inputs to "0".

Detection phase

In the detection phase at start-up the master is scanning for AS-slaves. It remains in this phase until at least one slave is detected. If the master remains in the detection phase this means that no slave was found. The reason for this may be a wrong power supply or a wiring error.

The detection phase is displayed by code "41".

Protected mode

In protected mode only those slaves are activated which are registered in the $\Rightarrow LPS$ and whose actual configuration matches with the target configuration.

See \Rightarrow *configuration mode*. This mode is intended for the normal operation, since all AS-i protective measures are activated.

ID code

The ID code is unchangeably set by the manufacturer of the AS-i slave. The AS-i Association defines the ID codes assigned to a certain category of slaves. All $\Rightarrow A/B$ slaves e.g. possess the ID code "A".

ID1 code, extended ID1 code

The ID1 code is specified by the manufacturer of the slave. In contrast to the other codes defining the profile this code can be modified by the master or by an addressing unit. The user should make use of this possibility only in exceptional cases, otherwise \Rightarrow *configuration errors* may occur.

To make the distinction between the A and the B addresses in the case of A/B slaves, the bit with the highest value of the ID1 code is used. That is why only the three lowest bits are relevant for these slaves. Since this code has been introduced with the new AS-i specification 2.1, it is also called extended ID1 code.

ID2 code, extended ID2 code

The ID2 code is unchangeably set by the manufacturer of the slave. The AS-i Association defines the ID2 codes assigned to a certain category of slaves. All two-channel 16-bit input slaves with the profile S-7.3 possess the ID2 code "D". Since this code has been introduced with the new AS-i specification 2.1, it is also called extended ID2 code.

Actual configuration

The configuration data of all slaves detected by the master. The configuration data of one slave, the \Rightarrow *slave profile*, consists of:

\Rightarrow *IO code*, \Rightarrow *ID code*, \Rightarrow *extended ID1code 1*, \Rightarrow *extended ID2 code*.

Actual parameter

The AS-i parameter that have been sent last to the AS-i slave, in contrary to ⇒ permanent parameters.

Configuration Error/Config Error

An configuration error is indicated, when target and actual configuration of the connected slaves do not match. The following cases may result in configuration errors:

Missing slave: A slave entered in the ⇒ *LPS* is not available

Erroneous type of slave: The ⇒ *slave profile* of the connected slave does not comply with the configured one.

Unknown slave: A connected slave is not entered in the ⇒ *LPS*.

LAS - List of Activated Slaves

The master exchanges IO data with the slaves entered in the LAS. In the proteced mode only those detected slaves (⇒ *LDS*) are activated whichare expected by the master and are entered in the ⇒ *LPS*. In the configuration mode all slaves entered in the ⇒ *LDS* are activated.

LDS - List of Detected Slaves

All slaves from which the master was able to read the ⇒ *slave profile* are entered in the LDS.

LPF - List of Peripheral Faults

There is a list of peripheral faults only for masters fulfilling the new specification 2.1. This list includes an entry for each slave that signals a ⇒ *peripheral fault*.

LPS - List of Projected Slaves

The list of projected slaves includes all slaves expected by the master. All entries of the ⇒ *LDS* are taken over to the LPS by storing the actual configuration (except for a not addressed slave with the address 0).

Offline phase

In the offline phase all input and output data is reset. This phase is entered at start-up of the master, after a ⇒ *AS-i power fail*, and at the transition of the ⇒ *configuration mode* to the ⇒ *protected mode*.

Furthermore the master can actively be put into the offline phase with the offline flag.

During the offline phase, masters with a display show code "40".

Peripheral fault

A peripheral fault is shown on the master and on the slave by a red flashing LED. Depending on the slave type it is possible to visualize an overflow, an overload of the sensor's power supply or another fault regarding the peripheral equipment of the slave.

Permanent configuration

The configuration data of all expected slaves stored in the master (\Rightarrow *slave profile*). If the permanent configuration differs from the \Rightarrow *actual configuration*, there is a configuration error.

Permanent parameter

The parameter stored in the master that are sent to the slave after start-up of the master in the \Rightarrow *activation phase*.

Configuration mode

During the configuration mode the master exchanges data with all connected slaves, no matter which of the slaves are projected. In this mode it is possible to commission a system without being obliged to configure it before.

See also \Rightarrow *protected mode*.

Single slave

Compared to an \Rightarrow *A/B slave* a single slave can only be addressed from the address 1 to 31; the fourth data output bit can be used. All slaves of the older specification 2.0 are single slaves.

There are also slaves fulfilling the new specification 2.1 that are single slaves, e.g. the newer 16-bit slaves.

Slave profil

The configuration data of a slave consisting of:


\Rightarrow *IO code*, \Rightarrow *ID code*, \Rightarrow *extended ID1 code*, \Rightarrow *extended ID2 code*.

The slave profile is to differentiate between the different slave categories. It is specified by the AS-i Association and preset by the slave manufacturer.

AS-i 2.0 slaves do not have extended ID1 and ID2 codes. In this case an AS-i master 2.1 enters "F" the extended ID1 and the extended ID2 code.

With regard to the supply of products, the current issue of the following document is applicable: The General Terms of Delivery for Products and Services of the Electrical Industry, published by the Central Association of the "Elektrotechnik und Elektroindustrie (ZVEI) e.V. in their most recent version as well as the supplementary clause: "Extended reservation of title".

We at Pepperl+Fuchs recognise a duty to make a contribution to the future, For this reason, this printed matter is produced on paper bleached without the use of chlorine.



www.pepperl-fuchs.com

Worldwide Headquarters

Pepperl+Fuchs GmbH · Königsberger Allee 87
68307 Mannheim · Germany
Tel. +49 621 776-0 · Fax +49 621 776-1000
e-mail: info@de.pepperl-fuchs.com

USA Headquarters

Pepperl+Fuchs Inc. · 1600 Enterprise Parkway
Twinsburg, Ohio 44087 · USA
Tel. +1 330 4253555 · Fax +1 330 4254607
e-mail: sales@us.pepperl-fuchs.com

Asia Pacific Headquarters

Pepperl+Fuchs Pte Ltd. · P+F Building
18 Ayer Rajah Crescent · Singapore 139942
Tel. +65 67799091 · Fax +65 68731637
e-mail: sales@sg.pepperl-fuchs.com

 **PEPPERL+FUCHS**
SIGNALS FOR THE WORLD OF AUTOMATION