Functional Safety

Frequency Converter with Trip Values KF**-UFC-(Ex)1.D

Manual



IEC 61508/61511





Your automation, our passion.

With regard to the supply of products, the current issue of the following document is applicable: The General Terms of Delivery for Products and Services of the Electrical Industry, published by the Central Association of the Electrical Industry (Zentralverband Elektrotechnik und Elektroindustrie (ZVEI) e.V.) in its most recent version as well as the supplementary clause: "Expanded reservation of proprietorship"

Worldwide

Pepperl+Fuchs Group Lilienthalstr. 200 68307 Mannheim Germany Phone: +49 621 776 - 0 E-mail: info@de.pepperl-fuchs.com **North American Headquarters** Pepperl+Fuchs Inc. 1600 Enterprise Parkway Twinsburg, Ohio 44087 USA Phone: +1 330 425-3555 E-mail: sales@us.pepperl-fuchs.com Asia Headquarters Pepperl+Fuchs Pte. Ltd. P+F Building 18 Ayer Rajah Crescent Singapore 139942 Phone: +65 6779-9091 E-mail: sales@sg.pepperl-fuchs.com https://www.pepperl-fuchs.com

1	Introd	uction
	1.1	Content of this Document 5
	1.2	Safety Information
	1.3	Symbols Used
2	Produ	ct Description
	2.1	Function
	2.2	Interfaces
	2.3	Marking
	2.4	Standards and Directives for Functional Safety
3	Planni	ng
	3.1	System Structure
	3.2	Assumptions
	3.3	Safety Function and Safe State 12
	3.4	Characteristic Safety Values 13
	3.5	Useful Lifetime
4	Mount	ing and Installation
	4.1	Configuration
5	Opera	tion
	5.1	Proof Test
6	Mainte	enance and Repair
7	List of	Abbreviations

PEPPERL+FUCHS

1 Introduction

1.1 Content of this Document

This document contains information for usage of the device in functional safety-related applications. You need this information to use your product throughout the applicable stages of the product life cycle. These can include the following:

- Product identification
- Delivery, transport, and storage
- Mounting and installation
- Commissioning and operation
- Maintenance and repair
- Troubleshooting
- Dismounting
- Disposal

i

This document does not substitute the instruction manual.

Note

Note

For full information on the product, refer to the instruction manual and further documentation on the Internet at www.pepperl-fuchs.com.

The documentation consists of the following parts:

- Present document
- Instruction manual
- Manual
- Datasheet

Additionally, the following parts may belong to the documentation, if applicable:

- EU-type examination certificate
- EU declaration of conformity
- Attestation of conformity
- Certificates
- Control drawings
- FMEDA report
- Assessment report
- Additional documents

For more information about Pepperl+Fuchs products with functional safety, see www.pepperl-fuchs.com/sil.

1.2 Safety Information

Target Group, Personnel

Responsibility for planning, assembly, commissioning, operation, maintenance, and dismounting lies with the plant operator.

Only appropriately trained and qualified personnel may carry out mounting, installation, commissioning, operation, maintenance, and dismounting of the product. The personnel must have read and understood the instruction manual and the further documentation.

Intended Use

The device is only approved for appropriate and intended use. Ignoring these instructions will void any warranty and absolve the manufacturer from any liability.

The device is developed, manufactured and tested according to the relevant safety standards.

Use the device only

- for the application described
- with specified environmental conditions
- with devices that are suitable for this safety application

Improper Use

Protection of the personnel and the plant is not ensured if the device is not used according to its intended use.



1.3 Symbols Used

This document contains symbols for the identification of warning messages and of informative messages.

Warning Messages

You will find warning messages, whenever dangers may arise from your actions. It is mandatory that you observe these warning messages for your personal safety and in order to avoid property damage.

Depending on the risk level, the warning messages are displayed in descending order as follows:



Danger!

This symbol indicates an imminent danger. Non-observance will result in personal injury or death.



Warning!

This symbol indicates a possible fault or danger.

Non-observance may cause personal injury or serious property damage.

Caution!

This symbol indicates a possible fault.

Non-observance could interrupt the device and any connected systems and plants, or result in their complete failure.

Informative Symbols



Note

This symbol brings important information to your attention.



Action

This symbol indicates a paragraph with instructions. You are prompted to perform an action or a sequence of actions.



2 Product Description

2.1 Function

General

The device is a universal frequency converter that changes a digital input signal into a proportional free adjustable 0/4 mA to 20 mA analog output signal and functions as a switch amplifier and a trip alarm.

The functions of the switch outputs (2 relay outputs and 1 potential free transistor output) are easily adjustable [trip value display (min/max alarm), serially switched output, pulse divider output, error signal output].

The start-up override feature sets the relay contact outputs to default conditions defined by the user for up to 1000 seconds.

A fault is signalized by LEDs.

The device is easily configured by the use of keypad or with the PACTware configuration software.

The device is mounted on a 35 mm DIN mounting rail according to EN 60715.

KFD2-UFC-1.D

This signal conditioner provides the galvanic isolation between field circuits and control circuits.

The input is designed for use with 2- or 3-wire sensors.

The input frequency is compared to the user-defined reference frequency. The input frequency is 1 mHz to 10 kHz.

The device is supplied by a power supply of 24 V DC.

If the device is operated via Power Rail, additionally a collective error message is available.

KFD2-UFC-Ex1.D

This isolated barrier is used for intrinsic safety applications.

The input is designed for use with 2-wire sensors.

The input frequency is compared to the user-defined reference frequency. The input frequency is 1 mHz to 5 kHz.

The device is supplied by a power supply of 24 V DC.

If the device is operated via Power Rail, additionally a collective error message is available.

KFU8-UFC-1.D

This signal conditioner provides the galvanic isolation between field circuits and control circuits.

The input is designed for use with 2- or 3-wire sensors.

The input frequency is compared to the user-defined reference frequency. The input frequency is 1 mHz to 10 kHz.

The device can be supplied by a power supply from 20 V DC to 90 V DC or from 48 V AC to 253 V AC.



KFU8-UFC-Ex1.D

This isolated barrier is used for intrinsic safety applications.

The input is designed for use with 2-wire sensors.

The input frequency is compared to the user-defined reference frequency. The input frequency is 1 mHz to 5 kHz.

The device can be supplied by a power supply from 20 V DC to 90 V DC or from 48 V AC to 253 V AC.

2.2 Interfaces

The device has the following interfaces:

- Safety relevant interfaces: input, output I, output II, output III, output IV
- Non-safety relevant interfaces:
 - Start-up override input
 - KFD2-UFC-(Ex)1.D: collective error message output



Note

For corresponding connections see datasheet.

2.3 Marking

Pepperl+Fuchs Group Lilienthalstraße 200, 68307 Mannheim, Germany Internet: www.pepperl-fuchs.com

KFD2-UFC-1.D, KFD2-UFC-Ex1.D, KFU8-UFC-1.D, KFU8-UFC-Ex1.D Up to SIL 2

2.4 Standards and Directives for Functional Safety

Device-specific standards and directives

Functional safety	IEC/EN 61508, part 2, edition 2010: Functional safety of electrical/electronic/programmable electronic safety-related systems (manufacturer)

System-specific standards and directives

Functional safety	IEC/EN 61511, part 1 – 3, edition 2003:
	Functional safety – Safety instrumented systems for the process industry sector (user)



3 Planning

3.1 System Structure

3.1.1 Low Demand Mode of Operation

If there are two control loops, one for the standard operation and another one for the functional safety, then usually the demand rate for the safety loop is assumed to be less than once per year.

The relevant safety parameters to be verified are:

- the PFD_{avg} value (average Probability of dangerous Failure on Demand) and the T₁ value (proof test interval that has a direct impact on the PFD_{avg} value)
- the SFF value (Safe Failure Fraction)
- the HFT architecture (Hardware Fault Tolerance)

3.1.2 High Demand or Continuous Mode of Operation

If there is only one safety loop, which combines the standard operation and safety-related operation, then usually the demand rate for this safety loop is assumed to be higher than once per year.

The relevant safety parameters to be verified are:

- the PFH value (**P**robability of dangerous **F**ailure per **H**our)
- Fault reaction time of the safety system
- the SFF value (Safe Failure Fraction)
- the HFT architecture (Hardware Fault Tolerance)

3.1.3 Safe Failure Fraction

The safe failure fraction describes the ratio of all safe failures and dangerous detected failures to the total failure rate.

 $\mathsf{SFF} = (\lambda_{\mathsf{s}} + \lambda_{\mathsf{dd}}) / (\lambda_{\mathsf{s}} + \lambda_{\mathsf{dd}} + \lambda_{\mathsf{du}})$

A safe failure fraction as defined in IEC/EN 61508 is only relevant for elements or (sub)systems in a complete safety loop. The device under consideration is always part of a safety loop but is not regarded as a complete element or subsystem.

For calculating the SIL of a safety loop it is necessary to evaluate the safe failure fraction of elements, subsystems and the complete system, but not of a single device.

Nevertheless the SFF of the device is given in this document for reference.



3.2 Assumptions

The following assumptions have been made during the FMEDA:

- Failure rate based on the Siemens standard SN 29500.
- Failure rates are constant, wear is not considered.
- External power supply failure rates are not included.
- The device will be used under average industrial ambient conditions comparable to the classification **stationary mounted** according to MIL-HDBK-217F.

Alternatively, operating stress conditions typical of an industrial field environment similar to IEC/EN 60654-1 Class C with an average temperature over a long period of time of 40 °C may be assumed. For a higher average temperature of 60 °C, the failure rates must be multiplied by a factor of 2.5 based on experience. A similar factor must be used if frequent temperature fluctuations are expected.

- The indication of a dangerous failure (via fault bus) is detected within 1 hour by the programmable logic controller (PLC).
- The application program in the programmable logic controller (PLC) is configured to detect underrange and overrange failures. These failures have been classified as dangerous detected failures.
- If you are using the device in high demand mode, observe also the useful lifetime limitations of the output relays according to the datasheet.
- The display function and the displayed values are not part of the safety function.
- The IEC/EN 61511-1 section 11.4.4 allows devices to be used in applications one SIL higher than given by table 3 of IEC/EN 61508-2, if the device is proven-in-use. The assessment and proven-in-use demonstration lead to the result that the device may be used in applications up to SIL 2. However, it is the responsibility of the end-user to decide on applying proven-in-use devices.

SIL 2 application

- To build a SIL safety loop for the defined SIL, it is assumed as an example that this device uses 15 % of the available budget for PFD_{avg}/PFH.
- For a SIL 2 application operating in low demand mode the total PFD_{avg} value of the SIF (Safety Instrumented Function) should be smaller than 10⁻², hence the maximum allowable PFD_{avg} value would then be 1.5 x 10⁻³.
- For a SIL 2 application operating in high demand mode the total PFH value of the SIF should be smaller than 10⁻⁶ per hour, hence the maximum allowable PFH value would then be 1.5 x 10⁻⁷ per hour.
- The safety-related device is considered to be of type **B** device with a hardware fault tolerance of **0**.

3.3 Safety Function and Safe State

Safe State

The safe state of output I to output IV is the de-energized state (high impedance).

Safety Function

The safe state is achieved, when the measured frequency leaves the permissible range for the application.

The output follows the input frequency with a tolerance of 5 % of the full scale.

Device Settings via Keypad

Function	Mode	Menu
Password protection	enabled	Service
Smoothing	no smoothing = 0 s	Smoothing
Short circuit detection	enabled	Line fault
Lead breakage detection	enabled	Line fault

Table 3.1



Note

For more information see the manual.

Line Fault Detection

For use in a safety function enable the line fault detection.

The input loop of all versions is supervised. The related safety function is that the outputs go to fault state (safe state) if a line fault is detected.



Note

The collective error message output is not safety-relevant.





3.4 Characteristic Safety Values

KFU8-UFC-1.D, KFU8-UFC-Ex1.D, current output

Parameters	Characteristic values	
Assessment type and documentation	FMEDA report and proven-in-use assessment	
Device type	В	
Mode of operation ¹	Low demand mode or high demand mode	Low demand mode
HFT	0	·
SIL (SC)	2	
Safety function	Proportional analog output sig	Inal
Fault reaction time ²	1 s	5 min
λ_s^3	0 FIT	0 FIT
λ_{dd}	243 FIT	274 FIT
λ_{du}	107 FIT	75 FIT
$\lambda_{\text{total (safety function)}}^3$	350 FIT	349 FIT
λ _{not part}	33.6 FIT	33.6 FIT
SFF ³	69 %	69 %
MTBF ⁴	194 years	194 years
PFH	1.07 x 10 ⁻⁷ 1/h	7.54 x 10 ⁻⁸ 1/h
PFD_{avg} for $T_1 = 1$ year	4.69 x 10 ⁻⁴	3.30 x 10 ⁻⁴
PFD_{avg} for $T_1 = 2$ years	9.38 x 10 ⁻⁴	6.61 x 10 ⁻⁴
PFD_{avg} for $T_1 = 5$ years	2.35 x 10 ⁻³	1.65 x 10 ⁻³
PTC	99 %	99 %
Reaction time ⁵	1 s + 1/f	

Table 3.2

¹ The values for a fault reaction time of 5 min benefit from internal software diagnostic functions and are therefore deemed suitable only for low demand application.

² The fault reaction time is the delay time after discovering an internal fault by diagnostics in the device. The sampling rate is not relevant.

³ No effect failures are not influencing the safety function and are therefore not included in the SFF and the failure rates.

⁴ acc. to SN29500. This value includes failures which are not part of the safety function/MTTR = 8 h. The value is calculated for one safety function of the device.



KFU8-UFC-1.D, KFU8-UFC-Ex1.D, transistor output

Parameters	Characteristic values	
Assessment type and documentation	FMEDA report and proven-in-use assessment	
Device type	В	
Mode of operation ¹	Low demand mode or high demand mode	Low demand mode
HFT	0	
SIL (SC)	2	
Safety function	De-energized to safe	
Fault reaction time ²	1 s	5 min
λ_s^3	223 FIT	222 FIT
λ _{dd}	29.6 FIT	61 FIT
λ _{du}	115 FIT	84 FIT
$\lambda_{\text{total (safety function)}}^3$	367 FIT	367 FIT
λ _{not} part	35.2 FIT	35.2 FIT
SFF ³	68 %	77 %
MTBF ⁴	186 years	186 years
PFH	1.15 x 10 ⁻⁷ 1/h	8.37 x 10 ⁻⁸ 1/h
PFD_{avg} for $T_1 = 1$ year	5.04 x 10 ⁻⁴	3.67 x 10 ⁻⁴
PFD_{avg} for $T_1 = 2$ years	1.01 x 10 ⁻³	7.33 x 10 ⁻⁴
PFD_{avg} for $T_1 = 5$ years	2.52 x 10 ⁻³	1.83 x 10 ⁻³
PTC	99 %	99 %
Reaction time ⁵	1 s + 1/f	

Table 3.3

¹ The values for a fault reaction time of 5 min benefit from internal software diagnostic functions and are therefore deemed suitable only for low demand application.

² The fault reaction time is the delay time after discovering an internal fault by diagnostics in the device. The sampling rate is not relevant.

³ No effect failures are not influencing the safety function and are therefore not included in the SFF and the failure rates.

⁴ acc. to SN29500. This value includes failures which are not part of the safety function/MTTR = 8 h. The value is calculated for one safety function of the device.



Parameters	Characteristic values	
Assessment type and documentation	FMEDA report and proven-in-use assessment	
Device type	В	
Mode of operation ¹	Low demand mode or high demand mode	Low demand mode
HFT 0		
SIL (SC)	2	
Safety function	De-energized to safe	
Fault reaction time ²	1s	5 min
λ_s^3	237 FIT	236 FIT
λ_{dd}	29.6 FIT	61 FIT
λ _{du}	132 FIT	101 FIT
$\lambda_{\text{total (safety function)}}^3$	398 FIT	398 FIT
λ _{not part}	31.6 FIT	31.6 FIT
SFF ³	66 %	74 %
MTBF ⁴	178 years	178 years
PFH	1.32 x 10 ⁻⁷ 1/h	1.01 x 10 ⁻⁷ 1/h
PFD_{avg} for $T_1 = 1$ year	5.78 x 10 ⁻⁴	4.42 x 10 ⁻⁴
PFD_{avg} for $T_1 = 2$ years	1.16 x 10 ⁻³	8.85 x 10 ⁻⁴
PFD_{avg} for $T_1 = 5$ years	2.89 x 10 ⁻³	2.21 x 10 ⁻³
PTC	99 %	99 %
Reaction time ⁵	1 s + 1/f	-

KFU8-UFC-1.D, KFU8-UFC-Ex1.D, relay contact outputs

Table 3.4

- ² The fault reaction time is the delay time after discovering an internal fault by diagnostics in the device. The sampling rate is not relevant.
- ³ No effect failures are not influencing the safety function and are therefore not included in the SFF and the failure rates.
- ⁴ acc. to SN29500. This value includes failures which are not part of the safety function/MTTR = 8 h. The value is calculated for one safety function of the device.

¹ The values for a fault reaction time of 5 min benefit from internal software diagnostic functions and are therefore deemed suitable only for low demand application.

KFD2-UFC-1.D	, KFD2-UFC-Ex1.D,	current output	ut
--------------	-------------------	----------------	----

Parameters	Characteristic values	
Assessment type and documentation	FMEDA report and proven-in-use assessment	
Device type	В	
Mode of operation ¹	Low demand mode or high demand mode	Low demand mode
HFT	0	
SIL (SC)	2	
Safety function	Proportional analog output sig	nal
Fault reaction time ²	1s	5 min
λ_s^3	0 FIT	0 FIT
λ _{dd}	194 FIT	225 FIT
λ _{du}	116 FIT	84 FIT
$\lambda_{\text{total (safety function)}}^3$	310 FIT	309 FIT
λ _{not} part	33.8 FIT	33.8 FIT
SFF ³	62.6 %	72.8 %
MTBF ⁴	219 years	219 years
PFH	1.16 x 10 ⁻⁷ 1/h	8.40 x 10 ⁻⁸ 1/h
PFD_{avg} for $T_1 = 1$ year	5.08 x 10 ⁻⁴	3.68 x 10 ⁻⁴
PFD_{avg} for $T_1 = 2$ years	1.02 x 10 ⁻³	7.36 x 10 ⁻⁴
PFD_{avg} for $T_1 = 5$ years	2.54 x 10 ⁻³	1.84 x 10 ⁻³
PTC	99 %	99 %
Reaction time ⁵	1 s + 1/f	

Table 3.5

¹ The values for a fault reaction time of 5 min benefit from internal software diagnostic functions and are therefore deemed suitable only for low demand application.

² The fault reaction time is the delay time after discovering an internal fault by diagnostics in the device. The sampling rate is not relevant.

³ No effect failures are not influencing the safety function and are therefore not included in the SFF and the failure rates.

⁴ acc. to SN29500. This value includes failures which are not part of the safety function/MTTR = 8 h. The value is calculated for one safety function of the device.



Parameters Characteristic values		
Assessment type and documentation	FMEDA report and proven-in-use assessment	
Device type	В	
Mode of operation ¹	Low demand mode or high demand mode	Low demand mode
HFT	0	
SIL (SC)	2	
Safety function	De-energized to safe	
Fault reaction time ²	1s	5 min
λ_s^3	183 FIT	182 FIT
λ_{dd}	20.9 FIT	52 FIT
λ _{du}	124 FIT	92 FIT
$\lambda_{\text{total (safety function)}}^3$	327 FIT	327 FIT
λ _{not part}	35.4 FIT	35.4 FIT
SFF ³	62 %	71 %
MTBF ⁴	209 years	209 years
PFH	1.24 x 10 ⁻⁷ 1/h	9.24 x 10 ⁻⁸ 1/h
PFD_{avg} for $T_1 = 1$ year	5.43 x 10 ⁻⁴	4.04 x 10 ⁻⁴
PFD_{avg} for $T_1 = 2$ years	1.09 x 10 ⁻³	8.09 x 10 ⁻⁴
PFD _{avg} for T ₁ = 5 years	2.72 x 10 ⁻³	2.02 x 10 ⁻³
PTC	99 %	99 %
Reaction time ⁵	1 s + 1/f	

KFD2-UFC-1.D, KFD2-UFC-Ex1.D, transistor output

Table 3.6

- ² The fault reaction time is the delay time after discovering an internal fault by diagnostics in the device. The sampling rate is not relevant.
- ³ No effect failures are not influencing the safety function and are therefore not included in the SFF and the failure rates.
- ⁴ acc. to SN29500. This value includes failures which are not part of the safety function/MTTR = 8 h. The value is calculated for one safety function of the device.

¹ The values for a fault reaction time of 5 min benefit from internal software diagnostic functions and are therefore deemed suitable only for low demand application.

KFD2-UFC-1.D	, KFD2-UFC-Ex	1.D, relay	contact	outputs
--------------	---------------	------------	---------	---------

Parameters	Characteristic values		
Assessment type and documentation	FMEDA report and proven-in-use assessment		
Device type	В		
Mode of operation ¹	Low demand mode or high demand mode	Low demand mode	
HFT	0		
SIL (SC)	2		
Safety function	De-energized to safe		
Fault reaction time ²	1s	5 min	
λ_s^3	189 FIT	188 FIT	
λ _{dd}	20.9 FIT	52 FIT	
λ _{du}	138 FIT	107 FIT	
$\lambda_{\text{total (safety function)}}^3$	347 FIT	347 FIT	
λ _{not} part	33.0 FIT	33.0 FIT	
SFF ³	60.3 %	69 %	
MTBF ⁴	202 years	202 years	
PFH	1.38 x 10 ⁻⁷ 1/h	1.07 x 10 ⁻⁷ 1/h	
PFD_{avg} for $T_1 = 1$ year	6.04 x 10 ⁻⁴	4.69 x 10 ⁻⁴	
PFD_{avg} for $T_1 = 2$ years	1.21 x 10 ⁻³	9.37 x 10 ⁻⁴	
PFD_{avg} for $T_1 = 5$ years	3.02 x 10 ⁻³	2.34 x 10 ⁻³	
PTC	99 %	99 %	
Reaction time ⁵	1 s + 1/f		

Table 3.7

¹ The values for a fault reaction time of 5 min benefit from internal software diagnostic functions and are therefore deemed suitable only for low demand application.

² The fault reaction time is the delay time after discovering an internal fault by diagnostics in the device. The sampling rate is not relevant.

- ³ No effect failures are not influencing the safety function and are therefore not included in the SFF and the failure rates.
- ⁴ acc. to SN29500. This value includes failures which are not part of the safety function/MTTR = 8 h. The value is calculated for one safety function of the device.

⁵ For the reaction time, the delay time of the electronic circuit and the delay resulting from sampling the signals (1/f) are added.

The characteristic safety values like PFD, PFH, SFF, HFT and T_1 are taken from the FMEDA report. Observe that PFD and T_1 are related to each other.

The function of the devices has to be checked within the proof test interval (T_1) .



3.5 Useful Lifetime

Although a constant failure rate is assumed by the probabilistic estimation this only applies provided that the useful lifetime of components is not exceeded. Beyond this useful lifetime, the result of the probabilistic estimation is meaningless as the probability of failure significantly increases with time. The useful lifetime is highly dependent on the component itself and its operating conditions – temperature in particular. For example, electrolytic capacitors can be very sensitive to the operating temperature.

This assumption of a constant failure rate is based on the bathtub curve, which shows the typical behavior for electronic components.

Therefore it is obvious that failure calculation is only valid for components that have this constant domain and that the validity of the calculation is limited to the useful lifetime of each component.

It is assumed that early failures are detected to a huge percentage during the installation and therefore the assumption of a constant failure rate during the useful lifetime is valid.

However, according to IEC/EN 61508-2, a useful lifetime, based on general experience, should be assumed. Experience has shown that the useful lifetime often lies within a range period of about 8 to 12 years.

As noted in DIN EN 61508-2:2011 note N3, appropriate measures taken by the manufacturer and plant operator can extend the useful lifetime.

Our experience has shown that the useful lifetime of a Pepperl+Fuchs product can be higher if the ambient conditions support a long life time, for example if the ambient temperature is significantly below 60 °C.

Please note that the useful lifetime refers to the (constant) failure rate of the device. The effective life time can be higher.

The estimated useful lifetime is greater than the warranty period prescribed by law or the manufacturer's guarantee period. However, this does not result in an extension of the warranty or guarantee services. Failure to reach the estimated useful lifetime is no a material defect.

Derating

For the safety application, reduce the number of switching cycles or the maximum current. A derating to 2/3 of the maximum value is adequate.

Maximum Switching Power of Output Contacts

The useful lifetime is limited by the maximum switching cycles of the relays under load conditions.

For requirements regarding the connected output load, refer to the documentation of the connected peripheral devices.

Note

See corresponding datasheets for further information.



Mounting and Installation

Mounting and Installing the Device

- 1. Observe the safety instructions in the instruction manual.
- 2. Observe the information in the manual.
- 3. Observe the requirements for the safety loop.
- 4. Connect the device only to devices that are suitable for this safety application.
- 5. Check the safety function to ensure the expected output behavior.

4.1 Configuration



4

Configuring the Device via Keypad

The device is configured via keypad. The keypad for setting the safety functions is on the front of the device.

- 1. Open the cover.
- 2. Configure the device for the required safety function via the keypad, see chapter 3.3.
- **3.** Activate the password protection in the device to prevent unauthorized or accidental changes to the configuration.
- 4. Leave the parameterization mode to prevent unintentional adjustments.
- 5. Close the cover.
- 6. Check the device to ensure that the expected safety function is guaranteed.
- 7. Document any changes to the device configuration.





Configuring the Device via PACTware Operating Software

The device can also be configured via the PACTware operating software. The interface for connecting a personal computer for configuring is on the front of the device.

- 1. Open the cover.
- 2. Connect a personal computer via the K-ADP-USB adapter to the device.
- **3.** Configure the device for the required safety function via the PACTware operating software, see chapter 3.3.
- 4. Protect the device configuration by a password against changing.
- 5. Leave the parameterization mode to prevent unintentional adjustments.
- 6. Disconnect the personal computer from the device.
- 7. Close the cover.
- 8. Check the device to ensure that the expected safety function is guaranteed.
- 9. Document any changes to the device configuration.

Note

For more information see the manual.



5

Danger!

Operation

Danger to life from missing safety function

If the safety loop is put out of service, the safety function is no longer guaranteed.

- Do not deactivate the device.
- Do not bypass the safety function.
- Do not repair, modify, or manipulate the device.



Danger!

Danger to life from missing safety function

With enabled start-up override, dangerous faults can remain undetected. The safety function is no longer guaranteed.

Observe that the safety function is not carried out correctly while the start-up override is active. Ensure that the input of the start-up override is not accidentally bridged.



Danger!

Danger to life from missing safety function

The outputs of the device use common components. If you use these outputs in safety functions, the outputs can fail all at the same time. You cannot establish redundancy this way.

When planning a safety function, observe that these outputs can fail simultaneously due to a failure in the same component.



Danger!

Danger to life from missing safety function

If the outputs of the device are not tested regularly, the safety function is no longer guaranteed. If you use the device in low demand mode applications, test the outputs once a year.



Operating the device

- 1. Observe the safety instructions in the instruction manual.
- 2. Observe the information in the manual.
- 3. Use the device only with devices that are suitable for this safety application.
- 4. Correct any occurring safe failures within 8 hours. Take measures to maintain the safety function while the device is being repaired.



5.1 Proof Test

This section describes a possible proof test procedure. The user is not obliged to use this proposal. The user may consider different concepts with an individual determination of the respective effectiveness, e. g. concepts according to NA106:2018.

According to IEC/EN 61508-2 a recurring proof test shall be undertaken to reveal potential dangerous failures that are not detected otherwise.

Check the function of the subsystem at periodic intervals depending on the applied PFD_{avg} in accordance with the characteristic safety values. See chapter 3.4.

It is under the responsibility of the plant operator to define the type of proof test and the interval time period.

Equipment required:

Digital multimeter with an accuracy of 0.1 % Use for the proof test of the intrinsic safety side of the device a special digital multimeter for intrinsically safe circuits.

If intrinsically safe circuits are operated with non-intrinsically safe circuits, they must no longer be used as intrinsically safe circuits.

- Frequency generator configured to deliver NAMUR signals with an accuracy of 1 %
- · Power supply set to nominal voltage
- Load resistor i. e. 240 Ω , 2.5 W
- Simulate the sensor state by a potentiometer of 4.7 kΩ (threshold for normal operation), by a resistor of 200 Ω (short circuit detection) and by a resistor of 220 kΩ (lead breakage detection).





Proof Test Procedure for the Switching Threshold

- 1. Test in the proof test with the same configuration which is used in the application. Substitute the sensors by sensor simulators or calibrators.
- 2. If the start-up override is enabled, disable the start-up override. That means, do not bridge the input of the start-up override.
- 3. Test the input channel. The switching threshold depends on the device type:
 - KF**-UFC-1.D devices: 1.4 mA to 1.9 mA
 - KF**-UFC-Ex1.D devices: 1.9 mA to 2.5 mA
 - → For normal mode of operation the corresponding yellow LED must have lit, if the input current is above the threshold.
- 4. Connect a resistor R_{SC} (200 Ω) or a resistor R_{LB} (220 k Ω) to the input.
 - → The device must detect an external fault. This state is indicated by red LED and the relay of the corresponding output must be de-activated.
- 5. Attach a load and supply defined by the application's current and voltage.
- 6. After the test, reset the device to the original settings.
- 7. Leave the parameterization mode to prevent unintentional adjustments.
- 8. Check the settings after the configuration by suitable tests.



Proof Test Procedure for the Current Output

- 1. Test in the proof test with the same configuration which is used in the application. Substitute the sensors by sensor simulators or calibrators.
- 2. Connect the frequency generator to terminals 1+ and 3-.
- 3. Connect a digital multimeter and the load defined by the application to terminals 7- and 8+.
- 4. Set the frequencies on the frequency generator to those representing 4 mA, 12 mA, and 20 mA, depending on the used configuration. Measure the output current.

→ The Proof test for the current output is passed if the measured output values are:

- for 4 mA application: 3.0 mA to 5.0 mA
- for 12 mA application: 11.0 mA to 13.0 mA
- for 20 mA application: 19.0 mA to 21.0 mA
- 5. If the line fault detection is activated, remove the frequency generator on terminals 1+ and 3-.

 \rightarrow The red LED must be flashing.

- 6. Test the circuit diagnosis by creating a short circuit or a lead breakage at the input and
 - measure an output current of 21.5 mA ±1 % if **Up** is configured in the fault current setting.
 - measure an output current of 2.0 mA ±1 % if **Down** is configured in the fault current setting.

 \mapsto The red LED must be flashing.

- 7. After the test, reset the device to the original settings.
- 8. Check the settings after the configuration by suitable tests.



Proof Test Procedure for the Relay Contact Outputs and the Transistor Output

- 1. Test in the proof test with the same configuration which is used in the application. Substitute the sensors by sensor simulators or calibrators.
- 2. Connect the frequency generator to terminals 1+ and 3-.
- Set the frequency on the frequency generator 1 % below and 1 % above the defined threshold for the considered output. Check the hysteresis behavior and adjust the trip point accordingly.
- 4. Connect a digital multimeter to the output. Attach a load and supply defined by the application's current and voltage.
- 5. Measure the output behavior. Compare the output behavior with the intended behavior.
 - → If you use the pulse divider functionality, the output frequency must have a value corresponding to the configured divider ratio.
- 6. Test the current loop diagnosis by simulating 2.0 mA ±1 % on the input if a MAX alarm is configured and 21.5 mA ±1 % if a MIN alarm is configured.

→ The red LED must be flashing. The output must be in de-energized state (high impedance).

- 7. After the test, reset the device to the original settings.
- 8. Check the settings after the configuration by suitable tests.



Figure 5.1 Proof test set-up for KF**-UFC-(Ex)1.D

Usage in Zone 0, 1, 2/Div. 1, 2 only for KFD2-UFC-Ex1.D and KFU8-UFC-Ex1.D

6

Maintenance and Repair



Danger!

Danger to life from missing safety function

Changes to the device or a defect of the device can lead to device malfunction. The function of the device and the safety function is no longer guaranteed.

Do not repair, modify, or manipulate the device.



Maintaining, Repairing or Replacing the Device

In case of maintenance, repair or replacement of the device, proceed as follows:

- 1. Implement appropriate maintenance procedures for regular maintenance of the safety loop.
- While the device is maintained, repaired or replaced, the safety function does not work. Take appropriate measures to protect personnel and equipment while the safety function is not available. Secure the application against accidental restart.

3. Do not repair a defective device. A defective device must only be repaired by the manufacturer.

4. If there is a defect, always replace the device with an original device.



Reporting Device Failure

If you use the device in a safety loop according to IEC/EN 61508, it is required to inform the device manufacturer about possible systematic failures.

Report all failures in the safety function that are due to functional limitations or a loss of device function – especially in the case of possible dangerous failures.

In these cases, contact your local sales partner or the Pepperl+Fuchs technical sales support (service line).

It is not necessary to report failures in the safety function that are due to external influences or damage.



7

List of Abbreviations

DC	Diagnostic Coverage of dangerous faults		
FIT	Failure In Time in 10 ⁻⁹ 1/h		
FMEDA	Failure Mode, Effects, and Diagnostics Analysis		
λ _s	Probability of safe failure		
λ_{dd}	Probability of dangerous detected failure		
λ _{du}	Probability of dangerous undetected failure		
λ_{no} effect	Probability of failures of components in the safety loop that have no effect on the safety function.		
$\lambda_{not part}$	Probability of failure of components that are not in the safety loop		
$\lambda_{ ext{total}}$ (safety function)	Probability of failure of components that are in the safety loop		
HFT	Hardware Fault Tolerance		
MTBF	Mean Time Between Failures		
MTTF _D	Mean Time To dangerous Failure		
MTTR	Mean Time To Restoration		
PCS	Process Control System		
PFD avg	Average Probability of dangerous Failure on Demand		
PFH	Average frequency of dangerous failure per hour		
PL	Performance Level		
PLC	Programmable Logic Controller		
РТС	Proof Test Coverage		
SC	Systematic Capability		
SFF	Safe Failure Fraction		
SIF	Safety Instrumented Function		
SIL	Safety Integrity Level		
SIS	Safety Instrumented System		
T ₁	Proof Test Interval		
FLT	Fault		
LB	Lead Breakage		
LFD	Line Fault Detection		
SC	Short Circuit		
T _{service}	Time from start of operation to putting the device out of service		





Your automation, our passion.

Explosion Protection

- Intrinsic Safety Barriers
- Signal Conditioners
- FieldConnex[®] Fieldbus
- Remote I/O Systems
- Electrical Ex Equipment
- Purge and Pressurization
- Industrial HMI
- Mobile Computing and Communications
- HART Interface Solutions
- Surge Protection
- Wireless Solutions
- Level Measurement

Industrial Sensors

- Proximity Sensors
- Photoelectric Sensors
- Industrial Vision
- Ultrasonic Sensors
- Rotary Encoders
- Positioning Systems
- Inclination and Acceleration Sensors
- Fieldbus Modules
- AS-Interface
- Identification Systems
- Displays and Signal Processing
- Connectivity

Pepperl+Fuchs Quality Download our latest policy here:



www.pepperl-fuchs.com/quality



www.pepperl-fuchs.com © Pepperl+Fuchs · Subject to modifications Printed in Germany / DOCT-5164A