

Ultrasonic sensor


UB500-F54-E5-V15

- Switching output
- 5 different output functions can be set
- Program input
- Synchronization options
- Deactivation option
- Temperature compensation


Single head system



Dimensions



Bore hole and countersinking for screws/hexagon M4



Technical Data

Release date: 2022-12-01 Date of issue: 2022-12-01 Filename: 104715_eng.pdf

General specifications	
Sensing range	30 500 mm
Adjustment range	50 500 mm
Dead band	0 30 mm
Standard target plate	100 mm x 100 mm
Transducer frequency	approx. 380 kHz
Response delay	≤ 50 ms
Indicators/operating means	
LED green	solid green: monitoring system green flashing: program function

Technical Data LED yellow indication of the switching state flashing: program function object detected flashing: normal mode: error LED red Program function: no object detected permanently: Program mode, object uncertain **Electrical specifications** Operating voltage U_{R} 10 ... 30 V DC , ripple 10 $\%_{\text{SS}}$ No-load supply current I_0 Input/Output 1 synchronous input 0 level: U_B...+1 V 1 level: +4 V...+U_B input impedance: > 12 KOhm Synchronization synchronization pulse: 0.1 ... 8 ms Synchronization frequency max. 100 Hz Common mode operation ≤ 100 / n Hz, n = number of sensors Multiplex operation 1 program input, switching point A1: -U_B ... +1 V, switching point A2: +4 V ... +U_B input impedance: > 4.7 k Ω , program pulse: \geq 1 s Input type Output 1 switch output E5, PNP, NO/NC Output type Rated operating current 200 mA, short-circuit/overload protected I_{e} Voltage drop U^{q} Repeat accuracy ≤ 1 % of full-scale value max. 10 Hz Switching frequency f Range hysteresis Н ≤ 1 % of the set operating distance Temperature influence ± 1.5 % of full-scale value Compliance with standards and directives Standard conformity Standards EN IEC 60947-5-2:2020 IEC 60947-5-2:2019 Approvals and certificates cULus Listed, Class 2 Power Source UL approval CCC approval CCC approval / marking not required for products rated ≤36 V **Ambient conditions** Ambient temperature -25 ... 70 °C (-13 ... 158 °F) Storage temperature -40 ... 85 °C (-40 ... 185 °F) Mechanical specifications Connection type Connector plug M12 x 1, 5-pin IP65 Degree of protection Material Housing ABS Transducer epoxy resin/hollow glass sphere mixture; polyurethane foam Mass 100 g

Ultrasonic sensor UB500-F54-E5-V15

Connection

Standard symbol/Connections:

(version E5, pnp) + U_B 2 (WH) Program input 5 (GY) 4 (BK) Switch output

3 (BU) 🗖 Wire colors in accordance with EN 60947-5-2.

- U_B

Connection Assignment




Wire colors in accordance with EN 60947-5-2

ΒN (brown) 2 WH (white) BU (blue) 4 BK (black) GY (gray)


Characteristic Curve

Characteristic response curve



Curve 1: flat surface 100 mm x 100 mm Curve 2: round bar, Ø 25 mm

Programmable output modes



5. A1 -> ∞, A2 -> ∞: Object presence detection mode Object detected: Switch output closed No object detected: Switch output open

Accessories

21	UB-PROG2	Programming unit
6/	V15-G-2M-PVC	Female cordset single-ended M12 straight A-coded, 5-pin, PVC cable grey
6/	V15-W-2M-PUR	Female cordset single-ended M12 angled A-coded, 5-pin, PUR cable grey

Additional Information

Synchronisation

The sensor features a synchronisation input for the suppression of mutual interference. If this input is not used, the sensor will operate using an internally generated clock rate. The synchronisation of multiple sensors can be realised as follows:

External synchronisation

The sensor can be synchronised by the external application of a square wave voltage. A synchronisation pulse at the synchronisation input starts a measuring cycle. The pulse must have a duration greater than $100 \, \mu s$. The measuring cycle starts with the falling edge of a synchronisation pulse. A low level $> 1 \, s$ or an open synchronisation input will result in the normal operation of the sensor. A high level at the synchronisation input disables the sensor.

Two operating modes are available

- 1. Multiple sensors can be controlled by the same synchronisation signal. The sensors are synchronised.
- 2. The synchronisation pulses are sent cyclically to individual sensors. The sensors operate in multiplex mode.

Internal synchronisation

The synchronisation connections of up to 5 sensors capable of internal synchronisation are connected to one another. When power is applied, these sensors will operate in multiplex mode. The response delay increases according to the number of sensors to be synchronised. Synchronisation cannot be performed during TEACH-IN and vice versa. The sensors must be operated in an unsynchronised manner to teach the switching point.

Note:

If the option for synchronisation is not used, the synchronisation input has to be connected to ground (0V) or the sensor has to be operated via a V1 cable connector (4-pin).

Adjusting of switching points

The ultrasonic sensor features a switch output with two teachable switching points. These are set by applying the supply voltage $-U_B$ or $+U_B$ to the TEACH-IN input. The supply voltage must be applied to the TEACH-IN input for at least 1 s. LEDs indicate whether the sensor has recognised the target during the TEACH-IN procedure. Switching point A1 is taught with $-U_B$, A2 with $+U_B$.

Five different output functions can be set

- 1. Window mode, normally-open function
- 2. Window mode, normally-closed function
- 3. One switching point, normally-open function
- 4. One switching point, normally-closed function
- 5. Detection of object presence

TEACH-IN window mode, normally-open function

- Set target to near switching point
- TEACH-IN switching point A1 with -U_B
- Set target to far switching point
- TEACH-IN switching point A2 with +U_B

TEACH-IN window mode, normally-closed function

- Set target to near switching point
 - TEACH-IN switching point A2 with +U_B
- Set target to far switching point
- TEACH-IN switching point A1 with -U_B

TEACH-IN one switching point, normally-open function

- Set target to near switching point
- TEACH-IN switching point A2 with +U_B
- Cover sensor with hand or remove all objects from sensing range
- TEACH-IN switching point A1 with -U_B

TEACH-IN one switching point, normally-closed function

- Set target to near switching point
- TEACH-IN switching point A1 with -U_B
- Cover sensor with hand or remove all objects from sensing range
- TEACH-IN switching point A2 with +U_B

TEACH-IN detection of object presence

- Cover sensor with hand or remove all objects from sensing range
- TEACH-IN switching point A1 with -U_B
- TEACH-IN switching point A2 with +U_B

Default setting of switching points

A1 = unusable area

A2 = nominal sensing range



Displays in dependence on operating mode	Red LED	Yellow LED	Green LED
TEACH-IN switching point:			
Object detected	off	flashes	flashes
No object detected	flashes	off	flashes
Object uncertain (TEACH-IN invalid)	on	off	flashes
Normal operation	off	switching	on
		state	
Fault	flashes	previous	off
		state	