

RTD Converter LB5001A


- 1-channel
- Converter for 2-, 3- and 4-wire Pt100, slide wire sensors
- Installation in Zone 2 or safe area
- Simulation mode for service operations (forcing)
- Line fault detection (LFD)
- Permanently self-monitoring
- Module can be exchanged under voltage



Function

The RTD converter accepts 2-, 3-, 4-wire RTD signals (Pt100) from the hazardous area. Open and short-circuit line faults are detected. The input is galvanically isolated from the bus and the power supply.

Connection



Zone 2

Technical Data Slots Occupied slots Supply backplane bus Connection Rated voltage Ur 12 V DC, only in connection with the power supplies LB9*** Power dissipation 0.4 W 0.4 W Power consumption Internal bus Connection backplane bus Interface manufacturer-specific bus to standard com unit temperature input Number of channels Suitable field devices

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group www.pepperl-fuchs.com USA: +1 330 486 0002 pa-info@us.pepperl-fuchs.com Germany: +49 621 776 2222 pa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 pa-info@sg.pepperl-fuchs.com



RTD Converter

Technical Data	
Field device	resistance thermometer
Field device [3]	slide-wire sensors
Field device interface	
Connection	2-wire sensor
Connection [2]	3-wire sensor
Connection [3]	4-wire sensor
Connection	2-wire connection: 5, 6 3-wire connection: 1, 5, 6 4-wire connection: 1, 2, 5, 6
Measurement range	10 400 Ω (500 Ω incl. line resistance)
Slide-wire sensor	10 400 Ω
Measuring current	200 μΑ
Smallest span	20 Ω for 0.1 % accuracy
Linearity error	0.1 %
Conversion time	max. 20 ms without LFD max. 150 ms with LFD
Lead resistance	max. 50 Ω per strand
Line fault detection	can be switched on/off for each channel via configuration tool
Short-circuit	< 10 Ω
Open-circuit	> 1 kΩ
Transfer characteristics	
Deviation	
Influence of ambient temperature	max. 0,1 %/10 K
Indicators/settings	
LED indication	Power LED (P) green: supply Status LED (1) red: line fault
Coding	optional mechanical coding via front socket
Directive conformity	
Electromagnetic compatibility	
Directive 2014/30/EU	EN 61326-1:2013
Conformity	
Electromagnetic compatibility	NE 21
Degree of protection	IEC 60529
Environmental test	EN 60068-2-14
Shock resistance	EN 60068-2-27
Vibration resistance	EN 60068-2-6
Damaging gas	EN 60068-2-42
Relative humidity	EN 60068-2-78
Ambient conditions	
Ambient temperature	-40 60 °C (-40 140 °F)
Storage temperature	-40 85 °C (-40 185 °F)
Relative humidity	95 % non-condensing
Altitude	max. 2000 m
Shock resistance	shock type I, shock duration 11 ms, shock amplitude 15 g, number of shocks 18
Vibration resistance	frequency range 10 150 Hz; transition frequency: 57.56 Hz, amplitude/acceleration \pm 0.075 mm/1 g; 10 cycles frequency range 5 100 Hz; transition frequency: 13.2 Hz amplitude/acceleration \pm 1 mm/0.7 g; 90 minutes at each resonance
Damaging gas	designed for operation in environmental conditions acc. to ISA-S71.04-1985, severity level G3
Mechanical specifications	
Degree of protection	IP20 when mounted on backplane
Connection	removable front connector with screw flange (accessory) wiring connection via spring terminals (0.14 1.5 mm ²) or screw terminals (0.08 1.5 mm ²)
Mass	approx. 90 g
Dimensions	16 x 100 x 102 mm (0.63 x 3.9 x 4 inch)


Release date: 2023-10-19 Date of issue: 2023-10-19 Filename: 254734_eng.pdf

Germany: +49 621 776 2222 pa-info@de.pepperl-fuchs.com

Technical Data

Data for application in connection with hazardous areas		
Certificate	PF 08 CERT 1234 X	
Marking	ll 3 G Ex nA [ic] IIC T4 Gc	
Galvanic isolation		
Input/power supply, internal bus	safe electrical isolation acc. to EN 60079-11, voltage peak value 375 V	
Directive conformity		
Directive 2014/34/EU	EN IEC 60079-0:2018+AC:2020 EN 60079-11:2012 EN 60079-15:2010	
International approvals		
IECEx approval		
IECEx certificate	IECEx BVS 09.0037X	
IECEx marking	Ex nA [ic] IIC T4 Gc	
General information		
System information	The module has to be mounted in appropriate backplanes (LB9***) in Zone 2 or outside hazardous areas. Here, observe the corresponding declaration of conformity. For use in hazardous areas (e. g. Zone 2 or Zone 22) the module must be installed in an appropriate enclosure.	
Supplementary information	EC-Type Examination Certificate, Statement of Conformity, Declaration of Conformity, Attestation of Conformity and instructions have to be observed where applicable. For information see www.pepperl-fuchs.com.	

Assembly



Refer to "General Notes Relating to Pepperl+Fuchs Product Information".