

Thru-beam sensor (pair) OBE10M-R2-SE2-0,2M-V31-L



- Ultra-small housing design
- DuraBeam Laser Sensors durable and employable like an LED
- 45° cable outlet for maximum mounting freedom under extremely tight space constraints
- Improvement in machine availability with abrasion-resistant, antistatic glass front

Laser thru-beam sensor, ultra-small design with M2 mounting, very high 10 m detection range, PNP output, 200 mm fixed cable with plug M8, 4-pin




Function

The R2 series nano sensor has been developed for a broad range of applications. It offers excellent durability and is exceptionally easy to install. The housing is compact and, with its 45° cable outlet, can be installed in the smallest spaces. New functional principles and functionality open up a range of new options. The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.


Dimensions


Transmitter







3.8











Technical Data


System components OBE10M-R2-0,2M-V31-L Emitter Receiver OBE10M-R2-E2-0,2M-V31-L General specifications Effective detection range 0 ... 10 m Threshold detection range 15 m Light source laser diode modulated visible red light, 680 nm Light type Laser nominal ratings LASER LIGHT, DO NOT STARE INTO BEAM Note Laser class Wave length 680 nm Beam divergence > 5 mrad Pulse length approx. 3 µs Repetition rate approx. 16.6 kHz 9.5 nJ max. pulse energy Diameter of the light spot approx. 20 mm at a distance of 10 m Opening angle approx. 0.5° Optical face frontal Ambient light limit EN 60947-5-2: 30000 Lux Functional safety related parameters MTTF_d 806 a Mission Time (T_M) 20 a 0 % Diagnostic Coverage (DC) Indicators/operating means Operation indicator LED green, statically lit Power on, short-circuit: LED green flashing (approx. 4 Hz) Receiver: LED yellow, lights up when light beam is free, flashes when falling short of the operating reserve; OFF when light beam is interrupted Function indicator **Electrical specifications** Operating voltage U_{B} 12 ... 24 V Emitter: ≤ 10 mA No-load supply current I_0 Receiver: ≤ 8 mA Protection class Ш Input Test input Test of switching function at 0 V Switching threshold Teach-In input Output Switching type NO contact Signal output 1 PNP output, short-circuit protected, reverse polarity protected, open collector Switching voltage max. 30 V DC max. 50 mA, resistive load Switching current Voltage drop U_{d} ≤ 1.5 V DC Switching frequency f approx. 2 kHz Response time 250 μs Conformity EN 60947-5-2 Product standard EN 60825-1:2007 Laser safety Approvals and certificates **EAC** conformity TR CU 020/2011 E87056, cULus Recognized, Class 2 Power Source **UL** approval CCC approval CCC approval / marking not required for products rated ≤36 V IEC 60825-1:2007 Complies with 21 CFR 1040.10 and 1040.11 except for deviations FDA approval


Ambient conditions

pursuant to Laser Notice No. 50, dated June 24, 2007

Technical Data Ambient temperature -20 ... 60 °C (-4 ... 140 °F) -30 ... 70 °C (-22 ... 158 °F) Storage temperature **Mechanical specifications** Housing width 7.5 mm Housing height 24 mm Housing depth 11.2 mm Degree of protection IP67 Connection 200 mm fixed cable with 4-pin, M8x1 connector Material Housing PC/ABS and TPU Optical face glass **PUR** Cable Installation Fixing screws , 2 x M2 allen head screws included with delivery Mass approx. 10 g per sensor Cable length 200 mm

Connection





Connection Assignment





Wire colors in accordance with EN 60947-5-2

1	BN	(brown
2	WH	(white)
3	BU	(blue)
4	BK	(black)

1	Operating display	green
2	Signal display	yellow
3	Emitter	
4	Receiver	

Characteristic Curve







CLASS 1 LASER PRODUCT

IEC 60825-1: 2007 certified. Complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007

CLASS 1 LASER PRODUCT

IEC 60825-1: 2007 certified. Complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007

Accessories

	V31-WM-2M-PUR	Female cordset single-ended M8 angled A-coded, 4-pin, PUR cable grey
W.	MH-R2-01	Mounting aid for R2 series, Mounting bracket
1370	MH-R2-02	Mounting aid for R2 series, Mounting bracket
	MH-R2-03	Mounting aid for R2 series, Mounting bracket
	MH-R2-04	Mounting aid for R2 series, Mounting bracket

The thru-beam sensor enables the switching points to be taught in for optimum adaptation to specific applications. This eliminates the need for additional components such as apertures.


The sensitivity of the thru-beam sensor can be adjusted using three Teach-in methods:

Position Teach

When using this Teach-in method, the following settings are made on the thru-beam sensor:

- The gain is set to an optimum value
- The signal threshold is set to a minimum





Recommended application:


This method enables minuscule particles in the beam path to be detected, and provides exceptional positioning accuracy. Make sure that there are no objects in the beam path and that the sensor is connected to the power supply.


- Connect the white cable on the receiver (WH/IN) to the blue cable (BU/0 V) on the receiver. The green and yellow LED indicators flash simultaneously at 2.5 Hz
- Disconnect the white cable on the receiver (WH/IN) from the blue cable (BU/0 V) on the receiver. The green and yellow LED indicators flash alternately at 2.5 Hz
- The end of the Teach-in process is indicated when the green LED indicator lights up static and yellow LED blinks.

Two-Point Teach-In

When using this Teach-in method, the following settings are made on the thru-beam sensor:

- The gain is set to an optimum value
- The signal threshold is set in the center between the two taught signal values





- Make sure that there are no objects in the beam path and that the sensor is connected to the power supply.
- Connect the white cable on the receiver (WH/IN) to the blue cable (BU/0 V) on the receiver.

The green and yellow LED indicators flash simultaneously at 2.5 Hz


- Position the object in the beam path.
- Disconnect the white cable on the receiver (WH/IN) from the blue cable (BU/0 V) on the receiver. The green and yellow LED indicators flash alternately at 2.5 Hz
- The end of the Teach-in process is indicated when the green LED indicator lights up static.

Maximum Teach-In

When using this Teach-in method, the following settings are made on the thru-beam sensor:

- The gain is set to a maximum
- The signal threshold is set to a minimum





Recommended application:

Enables an object to be detected with a high excess gain. This can be useful if there is severe environmental contamination or to achieve long operating times.

Make sure that there are no objects in the beam path and that the sensor is connected to the power supply.

- Cover the receiver or transmitter.
- Connect the white cable on the receiver (WH/IN) to the blue cable (BU/0 V) on the receiver.

Thru-beam sensor (pair)

The green and yellow LED indicators flash simultaneously at 2.5 Hz

- 8. Disconnect the white cable on the receiver (WH/IN) from the blue cable (BU/0 V) on the receiver. The green and yellow LED indicators flash alternately at 2.5 Hz
- 9. The end of the Teach-in process is indicated when the green LED indicator lights up static.