### Ultrasonic sensor UB2000-30GM-E0-V15



### Features

- Switch output
- 5 different output functions can be set
- TEACH-IN input
- Synchronisation options

Electrical connection

中

+ U<sub>B</sub>

- U<sub>B</sub>

Switch output

Teaching input

Sync. input

Standard symbol/Connections:


(version E0, npn)

U

 $\Phi$ 

Deactivation option

# Dimensions



### **Technical data**

General specifications Sensing range Unusable area Standard target plate Transducer frequency Response delay Indicators/operating means LED green LED yellow LED red Electrical specifications Operating voltage No-load supply current I<sub>0</sub> Input Input type

#### Pulse length

Synchronisation frequency Common mode operation Multiplex operation

Output Output type Repeat accuracy Rated operational current le Voltage drop U<sub>d</sub> Switching frequency f Range hysteresis H Temperature influence Standard conformity Standards Ambient conditions Ambient temperature Storage temperature Mechanical specifications Protection degree Connection Material Housing Transducer Mass

200 ... 2000 mm 0 ... 200 mm 100 mm x 100 mm approx. 175 kHz

"Power on", TEACH-IN function object detected indication of the switching state, TEACH-IN function-no object detected "Error", object uncertain

20 ... 30 V DC , ripple 10  $\%_{SS}$   $\leq$  60 mA

approx. 145 ms

1 TEACH-IN input, operating distance 1: -U<sub>B</sub> ... (-U<sub>B</sub> +2 V), operating distance 2: (+U<sub>B</sub> -2 V) ... +U<sub>B</sub> 1 synchronous input level 0: -U<sub>B</sub> ... (-U<sub>B</sub> + 1 V), level 1: (-U<sub>B</sub> + 5 V) ... +U<sub>B</sub> Input impedance 27 kOhm Synchronisation pulse:  $\geq$  100  $\mu$ s Synchronisation pulse pause:  $\geq$  100  $\mu$ s

CE

 $\leq 40~Hz$   $\leq 40/n~Hz$  , n = number of sensors

1 switch output E0/E1, npn, normally open/closed, programmable  $\leq$  1 % 200 mA , short-circuit/overload protected  $\leq$  3 V max. 3.4 Hz  $\leq$  1 % of the set operating distance 0.17 % / K

#### EN 60947-5-2

-25 ... 70 °C (248 ... 343 K) -40 ... 85 °C (233 ... 358 K)

IP65 connector V15 (M12 x 1), 5 pin

brass, nickel-plated, plastic components PBT epoxy resin/hollow glass sphere mixture; polyurethane foam 145 g

2005-07-27

**Connector V15** 



Subject to reasonable modifications due to technical advances

Copyright Pepperl+Fuchs, Printed in Germany

### Model number

### UB2000-30GM-E0-V15

### Function

### Synchronization

The sensor features a synchronization input for the suppression of mutual interference. It can be synchronized by applying a square wave voltage. The falling edge of a synchronization pulse at the synchronization input starts a measuring cycle. A low level > 1 s or an open synchronization input will result in the non-synchronized normal operation of the sensor. A high level at the synchronization input disables the sensor. Synchronization cannot be performed during TEACH-IN and vice versa.

Two operating modes are possible:

- The sync. inputs of 2... 5 Sensors are connected with each other. The sensors synchronize themselves and operate cyclically (multiplex mode).
- 2. Multiple sensors can be controlled by the same synchronization signal. The sensors are synchronized.
- The synchronization pulses are sent cyclically to individual sensors. The sensors operate in multiplex mode.

In case of synchronized operation, the response time of the sensor increases due to a longer measuring cycle time caused by synchronization.

### Note:

If the option for synchronization is not used, the synchronization input has to be connected to ground (0V) or the sensor has to be operated via a V1 cable connector (4-pin).

### Setting the switching points


The ultrasonic sensor features a switch output with two teachable switching points. These are set by applying the supply voltage -UB or +UB to the TEACH-IN input. The supply voltage must be applied to the TEACH-IN input for at least 1 s. LEDs indicate whether the sensor has recognised the target during the TEACH-IN procedure. Switching point A1 is taught with -UB, A2 with +UB.

Five different output functions can be set:


Function	TEACH-IN procedure			
Window mode, close function	<ul> <li>Set object to near switching point</li> <li>Teach switching point A1 with -UB</li> <li>Set object to far switching point</li> <li>Teach switching point A2 with +UB</li> </ul>			
Window mode, open function	<ul> <li>Set object to near switching point</li> <li>Teach switching point A2 with +UB</li> <li>Set object to far switching point</li> <li>Teach switching point A1 with -UB</li> </ul>			
1 switching point, close function	<ul> <li>Set object to near switching point</li> <li>Teach switching point A2 with +UB</li> <li>Cover sensor or remove all objects from sensing range</li> <li>Teach switching point A1 with -UB</li> </ul>			
1 switching point, open function	<ul> <li>Set object to near switching point</li> <li>Teach switching point A1 with -UB</li> <li>Cover sensor or remove all objects from sensing range</li> <li>Teach switching point A2 with +UB</li> </ul>			
Detection of object presence	<ul> <li>Cover sensor or remove all objects from sensing range</li> <li>Teach switching point A1 with -UB</li> <li>Teach switching point A2 with +UB</li> </ul>			

## Characteristic curves/additional information


### Characteristic response curve







### **LED-Window**



Copyright Pepperl+Fuchs, Printed in Germany

Default setting of switching points: A1 = blind range, A2 = nominal distance

Displays in dependence on operat-	Green LED	Red LED	Yellow LED
ing mode			
Teach switching point			
Object detected	Flashing	Off	Off
No object detected	Flashing	Off	On
Object uncertain (TEACH-IN invalid)	Off	Flashing	Off
Normal operation	On	Off	Switching state
Interference (e.g. compressed air)	Off	Flashing	Previous state

### **Mounting conditions**

If the sensor is installed in places where the operating temperature can fall below 0 °C, the BF30, BF30-F or BF 5-30 fixing clamp must be used.

Copyright Pepperl+Fuchs, Printed in Germany