

## Pin-Out Table

Termination Board field side			Modules		Termination Board control side	Yokogawa signal name
Module	Channel	IS terminals TB1	IS terminals SL2 field side	Non-IS terminals SL1 control side	System connector CN1, CN2	AAV141
1	1	1	5a	8a	40	IN1+
		4	5b	7a	39	IN1-
		7	7a			
	2	2	1a	10a	38	IN2+
		5	1b	9a	37	IN2-
		6	3b			
2	3	1	5a	8a	36	IN3+
		4	5b	7a	35	IN3-
		7	7a			
	4	2	1a	10a	34	IN4+
		5	1b	9a	33	IN4-
		6	3b			
3	5	1	5a	8a	32	IN5+
		4	5b	7a	31	IN5-
		7	7a			
	6	2	1a	10a	30	IN6+
		5	1b	9a	29	IN6-
		6	3b			
4	7	1	5a	8a	28	IN7+
		4	5b	7a	27	IN7-
		7	7a			
	8	2	1a	10a	26	IN8+
		5	1b	9a	25	IN8-
		6	3b			
5	9	1	5a	8a	24	IN9+
		4	5b	7a	23	IN9-
		7	7a			
	10	2	1a	10a	22	IN10+
		5	1b	9a	21	IN10-
		6	3b			
6	11	1	5a	8a	20	IN11+
		4	5b	7a	19	IN11-
		7	7a			
	12	2	1a	10a	18	IN12+
		5	1b	9a	17	IN12-
		6	3b			
7	13	1	5a	8a	16	IN13+
		4	5b	7a	15	IN13-
		7	7a			
	14	2	1a	10a	14	IN14+
		5	1b	9a	13	IN14-
		6	3b			
8	15	1	5a	8a	12	IN15+
		4	5b	7a	11	IN15-
		7	7a			
	16	2	1a	10a	10	IN16+
		5	1b	9a	9	IN16-
		6	3b			
					3, 4, 5, 6, 7, 8	n.c.
					1, 2	CBSE


07/2015

TDOCT-2846BENG 250386

## Pin-Out Table

Terminal pin-out		
Power supply	X20	3+
		4-
	X20	5+
		6-
Potential-free fault indication output	X20	1, 2

Module pin-out (SL1): module 1 ... 8	
V <sub>cc</sub>	2a (+)
	2b (+)
GND	1a (-)
	1b (-)
Fault (HiD2030 only)	6b

 The loop drawing has to be observed. For information see corresponding data sheet on [www.pepperl-fuchs.com](http://www.pepperl-fuchs.com).