

Instruction manual

Marking

Inductive slot sensor
SJ3,5-S1N
Pepperl+Fuchs GmbH
Lilienthalstraße 200, 68307 Mannheim, Germany

Range of application	Certification	Group, category, type of protection
ATEX 1G	PTB 00 ATEX 2049 X	Ⓜ II 1G Ex ia IIC T6...T1 Ga
ATEX 2G	PTB 00 ATEX 2049 X	Ⓜ II 1G Ex ia IIC T6...T1 Ga
ATEX 3G (nL)		Ⓜ II 3G EEx nL IIC T6 X
ATEX 3G (ic)		Ⓜ II 3G Ex ic IIC T6...T1 Gc
ATEX 1D	ZELM 03 ATEX 0128 X	Ⓜ II 1D Ex iaD 20 T 108 °C (226.4 °F)

Validity

Specific processes and instructions in this document require special precautions to guarantee the safety of the operating personnel.

Target group, personnel

Responsibility for planning, assembly, commissioning, operation, maintenance, and dismantling lies with the plant operator.

Mounting, installation, commissioning, operation, maintenance and disassembly of any devices may only be carried out by trained, qualified personnel. The instruction manual must be read and understood.

Reference to further documentation

Observe laws, standards, and directives applicable to the intended use and the operating location. Observe Directive 1999/92/EC in relation to hazardous areas.

The corresponding datasheets, declarations of conformity, EC-type-examination certificates, certificates and control drawings if applicable (see datasheet) are an integral part of this document. You can find this information under www.pepperl-fuchs.com.

Due to constant revisions, documentation is subject to permanent change. Please refer only to the most up-to-date version, which can be found under www.pepperl-fuchs.com.

Intended use

The device is only approved for appropriate and intended use. Ignoring these instructions will void any warranty and absolve the manufacturer from any liability.

Range of application 1D

Manual electrical apparatus for hazardous areas
for use in hazardous areas with combustible dust

Range of application 1G

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist

Range of application 2G

Manual electrical apparatus for hazardous areas
for use in hazardous areas with gas, vapour and mist

Range of application 3G (nL)

Manual electrical apparatus for hazardous areas
for use in hazardous areas with gas, vapour and mist

Range of application 3G (ic)

Manual electrical apparatus for hazardous areas
for use in hazardous areas with gas, vapour and mist

Improper use

Protection of the personnel and the plant is not ensured if the product is not being used according to its intended use.

Mounting and installation

Prior to mounting, installation and commissioning of the device you should make yourself familiar with the device and carefully read the instruction manual.

Mount the device so that it is not exposed to any mechanical hazard. For example, mount the device in a protective housing.

Range of application 1D

The connection cables are to be laid in accordance with EN 50281-1-2 and must not normally be subjected to chaffing during use.

Range of application 1G

When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

Range of application 2G

When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

Range of application 3G (nL)

The sensor must not be mechanically damaged.

When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

The connection parts are to be installed, such that a minimum protection class of IP20 is achieved, in accordance with IEC 60529.

Range of application 3G (ic)

The sensor must not be mechanically damaged.

When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

The connection parts are to be installed, such that a minimum protection class of IP20 is achieved, in accordance with IEC 60529.

Operation, maintenance, repair

The device must not be repaired, changed or manipulated.

In the event of a fault, always return the device to Pepperl+Fuchs.

If there is a defect, the device must always be replaced with an original device from Pepperl+Fuchs.

Delivery, transport, disposal

Check the packaging and contents for damage.