

Electrical connection


Model number

VAN-115/230AC-K27


AS-Interface power supply, data decoupling, 4 A

Features

- Up to 4 A output load
- LED operating display ٠
- 100 V AC up to 240 V AC .
- AS-Interface filter integrated .
- Earth fault detection •



Indicating / Operating means



Release date: 2019-08-21 14:28 Date of issue: 2019-08-21 238626_eng.xml

fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



1

www.pepperl-fuchs.com

AS-Interface power supply

E223176

LED green:

100 a

Ue

l_e

1²t

Technical data

General specifications
UL File Number
MTBF
Indicators/operating means
Reset push-button switch
LED EFD
LED AS-i ok

Electrical specifications

Fusing Rated operating voltage Rated operating current Supply frequency Efficiency Galvanic isolation Peak inrush current

Output

Short-circuit protection/overload

Voltage Current Residual ripple

Overvoltage protected
Ambient conditions

Ambient temperature Storage temperature Shock and impact resistance

Vibration resistance

Pollution degree Mechanical specifications

Degree of protection Protection class Connection

Mass

Mounting Compliance with standards and directives

Directive conformity EMC Directive 2004/108/EC

Standard conformity Noise immunity Emitted interference

Galvanic isolation

Degree of protection Pollution degree Mech. capacity

Shock and impact resistance

OFF: overload or no supply voltage T3A 15/250 V HBC (not accessible) 85 ... 132 V_{AC} 184 ... 264 V_{AC} 240 ... 300 V_{DC} 2.7 A at 115 V_{AC} 1.3 A at 220 V_{AC}

earth fault simulation/reset of earth fault display

earth fault display; LED red

ON: AS-Interface voltage OK

 $\begin{array}{l} 1.3 \mbox{ A at } 230 \ V_{AC} \\ 47 \ ... \ 63 \ Hz \ (alternatively, DC \ possible) \\ typ. \ 90 \ \% \ (230 \ V_{AC}, 4 \ A) \\ \hline SELV/PELV \\ < 3.7 \ A^2s \ (120 \ V_{AC}) \\ < 4.6 \ A^2s \ (132 \ V_{AC}) \\ < 2.5 \ A^2s \ (230 \ V_{AC}) \\ < 3.3 \ A^2s \ (264 \ V_{AC}) \end{array}$

10g/11 ms Sine 2 - 17.8 Hz: ± 1.6 mm Sine 17.8 ... 500 Hz : 2 g Random 2 ... 500 Hz: 0.5 m² (s³)

IP20 1 (IEC 60536); Protective conductor connection necessary Connection terminals, max. conductor cross-section Flexible cable: 0.5 ... 4 mm² Rigid cable: 0.5 ... 6 mm² Stripping length 7 mm 650 g DIN mounting rail

EN 55022:2006, EN 55011:2009 Class B EN 61000-6-3:2001 , EN 61204-3:2001

EN 61000-6-2:2005 EN 61000-6-3:2007 EN 61000-3-2:2010 EN 61000-3-3:2009 IEC 60364-4-41:2005 (PELV) IEC 60950:1999 (SELV) IEC 60529:2001 EN 50178:1997 EN 60068-2-6:2008 (Sinus)

Notes

2

In an AS-Interface network only one device can be operated earth fault detection. If there are many devices in an AS-Interface network, this can lead to the earth fault monitoring response threshold becoming less sensitive.

EN 60068-2-27:1995

EN 60068-2-64:2009 (Random)

Function

The primary switched-mode power supply was designed for fieldbus applications that transfer energy and data together via a twowire cable

(AS-Interface concept). It supplies a fully extended AS-Interface system with a maximum output current of 4.0 A. Due to the sinusoidal current consumption of the network, harmonics are avoided.

The power supply assumes the function of supplying power, data decoupling for the power source and balancing both output lines (AS-Interface + and AS-Interface -) with respect to the machine ground (shielded connection). The transformer allows the use of unshielded load cables. The power supply is protected by an internal fuse that eliminates the need for additional device protection measures.

Ground fault monitor GF:

The switch output of the ground fault monitor evaluates any short circuits detected in the AS-Interface system. With the potential-free transistor output, the system can be shut down using the control program. The output is normally closed, but opens when a ground fault is detected. The "GF" LED also signals the presence of a ground fault. This output will close when the power supply is restarted the or reset button is pressed for (> 2 seconds). It is essential to connect the shield to PE or the machine ground to guarantee proper operation.

Checking the ground fault monitor:

Pressing the reset button briefly (< 2 seconds) simulates a ground fault in the device. Detection, evaluation and signaling of a ground fault and the switch output can be tested at suitable intervals. A ground fault generated in this way can be reset by pressing the reset button for (> 2 seconds).

Accessories

AS-Interface Power Calculator

AS-Interface Power supply and network checking utility

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

