Model Number

PL3-F25-SN4-K

Features

- **For installation in housing**
- **PL3... with valve and screen connection**
- **Pluggable cage clamp terminals**
- **Usable up to SIL 3 acc. to IEC 61508**
- **Satisfies machinery directive**

Connection

SN4



Accessories

BT32
Activator for F25 series

BT32XS
Activator for F25 series

BT32XAS
Activator for F25 series

BT33
Activator for F25 series

BT34
Activator for F25 series

Dimensions



Technical Data

General specifications		
Switching element function		DC Dual NC
Rated operating distance	s_n	3 mm
Installation		embeddable mountable
Output polarity		Safety Function
Assured operating distance	s_a	0 ... 2.43 mm
Reduction factor r_{Al}		0.38
Reduction factor r_{Cu}		0.43
Reduction factor r_{303}		1
Reduction factor r_{St37}		1.4
Reduction factor r_{Brass}		0.58
Nominal ratings		
Nominal voltage	U_0	8.2 V (R_i approx. 1 kΩ)
Operating voltage	U_B	5 ... 25 V
Switching frequency	f	0 ... 1500 Hz
Hysteresis	H	typ. 5 %
Reverse polarity protected		yes
Short-circuit protection		no
Suitable for 2:1 technology		yes , Reverse polarity protection diode not required
Current consumption		
Measuring plate not detected		≥ 3 mA
Measuring plate detected		≤ 1 mA
Valve status indication		LED, yellow can be switched off by of DB1
Ambient conditions		
Ambient temperature		-25 ... 100 °C (-13 ... 212 °F)
Storage temperature		-40 ... 100 °C (-40 ... 212 °F)
Mechanical specifications		
Connection (system side)		Cage tension spring terminals
Core cross-section (system side)		up to 2.5 mm²
Connection (valve side)		Cage tension spring terminals
Core cross-section (valve side)		up to 2.5 mm²
Housing material		Sensor: PBT
Sensing face		Sensor: PBT
General information		
Use in the hazardous area		see instruction manuals
Category		1G; 2G; 3G
Compliance with standards and directives		
Standard conformity		
NAMUR		EN 60947-5-6:2000
Standards		EN 60947-5-2:2007 IEC 60947-5-2:2007

Release date: 2011-07-29 08:34 Date of issue: 2011-07-29 182213_eng.xml

ATEX 1G

Instruction	**Manual electrical apparatus for hazardous areas**
Device category 1G	for use in hazardous areas with gas, vapour and mist
Directive conformity	94/9/EG
Standard conformity	EN 60079-0:2006, EN 60079-11:2007, EN 60079-26:2007 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions
CE symbol	CE 0102
Ex-identification	Ex II 1G Ex ia IIC T6
EC-Type Examination Certificate	TÜV 99 ATEX 1479 X
Appropriate type	PL.-F25.-SN4...
Effective internal capacitance C_i	≤ 100 nF A cable length of 10 m is considered. The value is applicable for the sensor circuit.
Effective internal inductance L_i	≤ 150 µH A cable length of 10 m is considered. The value is applicable for the sensor circuit.
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to! Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority. If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.
Highest permissible ambient temperature	The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate. Note: Use the temperature table for category 1 !!! The 20 % reduction in accordance with EN 1127-1:2007 has already been accounted for in the temperature table for category 1.
Installation, Comissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety. The associated apparatus must satisfy the requirements of category ia. Due to the possible danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation of the power supply and signal circuit is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met. The jumper, WJ, is detachable and must be completely removed to prevent contact with adjacent components.
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible. Only changes specifically described in these operating instructions are allowed.

Special conditions

Protection from mechanical danger	When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.
Electrostatic charging	When used in group IIB/IIC non-permissible electrostatic charges should be avoided on the plastic housing parts..
Lead insertion	The connection cables should either be fixed when laid and mechanically protected or installed in such a way, that a force of 30 N applied in the direction of the cable inlet for one hour, does not lead to any visible displacement of the cable connections, even though the cable sheathing is displaced, see also IEC 60079-11. Depending on the type of installation, a suitable cable in accordance with Type A oder B of IEC 60079-14, must be used.

Release date: 2011-07-29 08:34 Date of issue: 2011-07-29 182213_eng.xml

ATEX 2G

Instruction	**Manual electrical apparatus for hazardous areas**
Device category 2G	for use in hazardous areas with gas, vapour and mist
Directive conformity	94/9/EG
Standard conformity	EN 60079-0:2006, EN 60079-11:2007 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions
CE symbol	CE 0102
Ex-identification	Ex II 1G Ex ia IIC T6
EC-Type Examination Certificate	TÜV 99 ATEX 1479 X
Appropriate type	PL.-F25.-SN4...
Effective internal capacitance C_i	≤ 100 nF ; a cable length of 10 m is considered. The value is applicable for the sensor circuit.
Effective internal inductance L_i	≤ 150 µH ; a cable length of 10 m is considered. The value is applicable for the sensor circuit.
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to! Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority. If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.
Highest permissible ambient temperature	The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate.
Installation, Comissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety. The jumper, WJ, is detachable and must be completely removed to prevent contact with adjacent components.
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible. Only changes specifically described in these operating instructions are allowed.

Special conditions

Protection from mechanical danger	When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.
Electrostatic charging	When used in group IIC non-permissible electrostatic charges should be avoided on the plastic housing parts.
Lead insertion	The connection cables should either be fixed when laid and mechanically protected or installed in such a way, that a force of 30 N applied in the direction of the cable inlet for one hour, does not lead to any visible displacement of the cable connections, even though the cable sheathing is displaced, see also IEC 60079-11. Depending on the type of installation, a suitable cable in accordance with Type A oder B of IEC 60079-14, must be used.

Release date: 2011-07-29 08:34 Date of issue: 2011-07-29 182213_eng.xml

ATEX 3G (nA)

Special conditions

Protection from UV light

Release date: 2011-07-29 08:34 Date of issue: 2011-07-29 182213_eng.xml

Pepperl+Fuchs Group www.pepperl-fuchs.com
USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com
Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com
Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

ATEX 3G (nL)

Note	This instruction is only valid for products according to EN 60079-15:2003, valid until 31-May-2008
Instruction	**Manual electrical apparatus for hazardous areas**
Device category 3G (nL)	for use in hazardous areas with gas, vapour and mist
Directive conformity	94/9/EG
Standard conformity	EN 60079-15:2003 Ignition protection category "n" Use is restricted to the following stated conditions
CE symbol	CE 0102
Ex-identification	Ex II 3G EEx nL IIC T6 X
Effective internal capacitance C_i	≤ 100 nF ; A cable length of 10 m is considered. The value is applicable for the sensor circuit.
Effective internal inductance L_i	≤ 150 µH ; A cable length of 10 m is considered. The value is applicable for the sensor circuit.
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be observed!
Installation, Comissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The sensor must only be operated with energy-limited circuits, which satisfy the requirements of IEC 60079-15. The explosion group depends on the connected, energy-limited power supply circuits. The maximum values of the connected, energy-limited valve circuits, must be observed. The sensor must be installed in a housing in such a way, that a protection class of at least IP20 is achieved in accordance with IEC 60529. The jumper, WJ, is detachable and must be completely removed to prevent contact with adjacent components.
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible. Only changes specifically described in these operating instructions are allowed.

Special conditions

Maximum permissible ambient temperature T_{Umax} at Ui = 20 V	Each sensor circuit can be operated with the stated maximum values and with simultaneous operation of the valve circuits.
for Pi=34 mW, Ii=25 mA, T6	62 °C (143.6 °F)
for Pi=34 mW, Ii=25 mA, T5	77 °C (170.6 °F)
for Pi=34 mW, Ii=25 mA, T4-T1	95 °C (203 °F)
for Pi=64 mW, Ii=25 mA, T6	62 °C (143.6 °F)
for Pi=64 mW, Ii=25 mA, T5	77 °C (170.6 °F)
for Pi=64 mW, Ii=25 mA, T4-T1	95 °C (203 °F)
for Pi=169 mW, Ii=52 mA, T6	51 °C (123.8 °F)
for Pi=169 mW, Ii=52 mA, T5	66 °C (150.8 °F)
for Pi=169 mW, Ii=52 mA, T4-T1	87 °C (188.6 °F)
Maximum values of the valve circuit	U_i = 32 V; I_i = 240 mA; C_i = 10 nF; L_i = 20 µH The values are applicable to each valve circuit. A cable length of 10 m is taken into account.
Protection from mechanical danger	The sensor must not be mechanically damaged. When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.
Electrostatic charging	
Lead insertion	The connecting cable must be protected from tension and torsional loading or installed in such a way, that an applied force of 30 N, acting in the direction of the cable inlet for one hour, does not lead to any visible displacement of the cable connections, even though the cable sheathing is displaced, see also IEC 60079-11.

Release date: 2011-07-29 08:34 Date of issue: 2011-07-29 182213_eng.xml

ATEX 3G (ic)

Instruction	**Manual electrical apparatus for hazardous areas**
Device category 3G (ic)	for use in hazardous areas with gas, vapour and mist
Directive conformity	94/9/EG
Standard conformity	EN 60079-11:2007 Ignition protection category "ic" Use is restricted to the following stated conditions
CE symbol	CE 0102
Ex-identification	Ex II 3G Ex ic IIC T6 X
Effective internal capacitance C_i	≤ 100 nF ; A cable length of 10 m is considered. The value is applicable for the sensor circuit.
Effective internal inductance L_i	≤ 150 µH ; A cable length of 10 m is considered. The value is applicable for the sensor circuit.
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be observed! Directive 94/9EG is generally applicable only to the use of electrical apparatus operating at atmospheric conditions. If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.
Installation, Comissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The sensor must only be operated with energy-limited circuits, which satisfy the requirements of IEC 60079-11. The explosion group depends on the connected, energy-limited power supply circuits. The maximum values of the connected, energy-limited valve circuits, must be observed. The sensor must be installed in a housing in such a way, that a protection class of at least IP20 is achieved in accordance with IEC 60529. The jumper, WJ, is detachable and must be completely removed to prevent contact with adjacent components.
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible. Only changes specifically described in these operating instructions are allowed.

Special conditions

Maximum permissible ambient temperature T_{Umax} at Ui = 20 V	Each sensor circuit can be operated with the stated maximum values and with simultaneous operation of the valve circuits.
for Pi=34 mW, Ii=25 mA, T6	62 °C (143.6 °F)
for Pi=34 mW, Ii=25 mA, T5	77 °C (170.6 °F)
for Pi=34 mW, Ii=25 mA, T4-T1	95 °C (203 °F)
for Pi=64 mW, Ii=25 mA, T6	62 °C (143.6 °F)
for Pi=64 mW, Ii=25 mA, T5	77 °C (170.6 °F)
for Pi=64 mW, Ii=25 mA, T4-T1	95 °C (203 °F)
for Pi=169 mW, Ii=52 mA, T6	51 °C (123.8 °F)
for Pi=169 mW, Ii=52 mA, T5	66 °C (150.8 °F)
for Pi=169 mW, Ii=52 mA, T4-T1	87 °C (188.6 °F)
Maximum values of the valve circuit	U_i = 32 V; I_i = 240 mA; C_i = 10 nF; L_i = 20 µH The values are applicable to each valve circuit. A cable length of 10 m is taken into account.
Protection from mechanical danger	The sensor must not be mechanically damaged. When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.
Electrostatic charging	When used in group IIC non-permissible electrostatic charges should be avoided on the plastic housing parts.
Lead insertion	The connecting cable must be protected from tension and torsional loading or installed in such a way, that an applied force of 30 N, acting in the direction of the cable inlet for one hour, does not lead to any visible displacement of the cable connections, even though the cable sheathing is displaced, see also IEC 60079-11.

Release date: 2011-07-29 08:34 Date of issue: 2011-07-29 182213_eng.xml

Pepperl+Fuchs Group www.pepperl-fuchs.com
USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com
Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com
Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com