	Technical data	
	General specifications	
	Sensing range	200 1500 mm
	Adjustment range	200 1500 mm
	Dead band Standard target plate	0 200 mm 20 mm x 20 mm
	Transducer frequency	approx. 200 kHz
	Nominal ratings	
	Time delay before availability t_v	250 ms
	Limit data	may 200 m
	Permissible cable length Indicators/operating means	max. 300 m
	LED green	Power on
	LED yellow	solid: switching state switch output
		flashing: misadjustment
	Electrical specifications	24 V DC
	Rated operating voltage U _e Operating voltage U _B	15 30 V (including ripple)
c Us		In supply voltage interval 15 20 V sensitivity reduced to
		20% 0%
	Ripple No-load supply current In	≤ 10 % ≤ 60 mA
lodel Number	Input	≤ 60 IIIA
	Input type	1 Function input
C1500-F65-IE2R2-V15-Y235145	Input voltage	≤ Operating voltage
	Level	low level : 0 3 V
eatures	Switching output	high level : \geq 15 V
Level indication	Switching output Output type	1 switch output PNP, NO
	Default setting	200 1500 mm
1 analog output, 0-20 mA current source	Operating current IL	≤ 300 mA , short-circuit/overload protected
	Voltage drop	≤ 3 V
1 switch output	Analog output	
Programmable by means of Inter-	Output type Default setting	1 current output 0 20 mA , rising ramp 200 1500 mm
face (see accessories) and SON-	Linearity error	≤ 1.5 %
PROĠ	Load resistor	$\leq 300 \Omega$
Synchronization options	Ambient conditions	
-	Ambient temperature	-25 70 °C (-13 158 °F)
Temperature compensation	Storage temperature	-40 85 °C (-40 185 °F)
	Shock resistance Vibration resistance	30 g , 11 ms period 10 55 Hz , Amplitude ± 1 mm
liagrams	Mechanical specifications	10 33 Hz , Amplitude ± 1 mm
	Connection type	Connector M12 x 1 , 5-pin
haracteristic response curve	Degree of protection	IP65
	Material	207
anceY [mm]	Housing Transducer	PBT epoxy resin/hollow glass sphere mixture; polyurethane foar
	Installation position	any position
	Mass	500 g
	Compliance with standards and	5
	directives	
	Standard conformity	
	Standards	EN 60947-5-2:2007 + A1:2012 IEC 60947-5-2:2007 + A1:2012
		EN 60947-5-7:2003
		EN 60947-5-7:2003
	Approvals and certificates	EN 60947-5-7:2003
0 300 600 900 1200 1500 1800 2100 2400 2700 3000 Distance X [mm]	Approvals and certificates UL approval	EN 60947-5-7:2003
0 300 600 900 1200 1500 1800 2100 2400 2700 3000		EN 60947-5-7:2003 IEC 60947-5-7:2003
0 300 600 900 1200 1500 1800 2100 2400 2700 3000 Distance X [mm]	UL approval	EN 60947-5-7:2003 IEC 60947-5-7:2003 cULus Listed, General Purpose

 Pefer to "General Notes Relating to Pepperl+Fuchs Product Information".

 Pepperl+Fuchs Group
 USA: +1 330 486 0001
 G

 www.pepperl-fuchs.com
 fa-info@us.pepperl-fuchs.com
 fa-info@us.pepperl-fuchs.com


Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com




1

Dimensions



Electrical Connection



Pinout




Wire colors in accordance with EN 60947-5-2

1	BN	(brown)
2	WH	(white)
3	BU	(blue)
4	BK	(black)
5	GY	(gray)

Additional Information

Function of the outputs



Accessories

V15-G-2M-PUR

Female cordset, M12, 5-pin, PUR cable

V15-G-2M-PVC Female cordset, M12, 5-pin, PVC cable

V15-W-2M-PVC Female cordset, M12, 5-pin, PVC cable

3RX4000-PF PC interface

PC interface

Application ranges

The design and function of this ultrasonic sensor make it ideal for filling level applications in small containers. The device has a switch output and an analogue output. With the switch output, a specific filling level in a tank can be signalled directly. The analogue output represents the current level as an analogue output variable.

Assembly and connection

All components are contained in an encapsulated housing. The ultrasonic converter is in a slightly recessed position in the housing. The integrated circumferential seal allows the sensor to be used directly as a closure with integrated filling level measurement. The tank opening must have a diameter of 26 mm. It can be mounted on the tank using 2 M5 screws. The electrical connection is based on a 5-pin device connector, M12 x 1. The connections are protected against reverse polarity, short circuits and overloads. Shielded cables are recommended if there is electrical interference.

Setting

As delivered, the switch-on and switch-off point, the measuring range limits and the averaging are fixed (see Technical data). They can subsequently be adapted to the application via SONPROG using the interface (see Accessories).

SONPROG

The following parameters can be changed via SONPROG:

- Measuring range limits S_{min} and S_{max}
- Switch-on and switch-off points (A, E)
- Blind zone
- Averaging

Special programming options are available on request.

Operation

The filling level of a container is detected within the detection range. When the filling level reaches the switch-on or switch-off point (E or A), the switch output reacts according to its setting. The switching statuses of the switch output are signalled by the yellow LEDs. If the level is between the switching points A and E, the output is active. Filling levels between the measuring range limits (S_{min} , S_{max}) are displayed in the form of an analogue output signal at the analogue output. The analogue output delivers its minimum value at filling level S_{min} and its maximum value at filling level S_{max} . The characteristic between the two measuring range limits is linear.

Objects in the blind zone cause cause false signals. Install in such a way that the filling level cannot enter the blind zone.

Function input XI

The sensor is placed in standby mode by connecting a low level at the function input XI (blocked release). The sensors then performs no measurements. The outputs retain the most recent status. As soon as function input XI is disconnected from the low level or a high level is connected (release), the sensor resumes its normal function. The function input XI can be used during operation for the synchronisation of multiple sensors. This can be done by connecting external signals, e.g. from a controller (external synchronisation) or by simply connecting the function inputs of all sensors to be synchronised (internal synchronisation).

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

