










Model number

INY050D-F99-2U-Y266546

Features

- E1-Type approval
- Analog output 0.5 ... 4.5 V
- **Fixed evaluation limits**
- High shock resistance
- Increased noise immunity 100 V/m
- Measuring range -25° ... +25°

Electrical connection



Technical Data

Conoral	specifications
General	SUCCINCALIONS

Туре	Inclination sensor, 2-axis
Measurement range	-25 25 °
Absolute accuracy	≤ ± 0.2 °
Response delay	≤ 25 ms
Resolution	≤ 0.05 °
Repeat accuracy	≤ ± 0.1 °
Temperature influence	≤ 0.004 °/K

Functional safety related parameters

MTTF _d	390 a
Mission Time (T _M)	20 a
Diagnostic Coverage (DC)	0 %

Indicators/operating means

Operation indicator LED, green

Electrical specifications

Operating voltage U_B 10 ... 30 V DC No-load supply current I₀ ≤ 25 mA Time delay before availability t ≤ 200 ms

Analog output

Output type 2 voltage outputs 0.5 ... 4.5 V (one output for each axis)

≥ 1 kΩ

Load resistor Ambient conditions

Ambient temperature -40 ... 85 °C (-40 ... 185 °F) Storage temperature -40 ... 85 °C (-40 ... 185 °F)

Mechanical specifications

Connection type 0.35 m PUR cable 4 x 0.5 mm² Deutsch connector DTM04-

Housing material РΑ IP68 / IP69K Degree of protection Mass 240 g

Factory settings

Analog output (X) -25 ° ... 25 ° -25 ° ... 25 ° Analog output (Y)

Compliance with standards and

directives

Standard conformity Shock and impact resistance 100 g according to DIN EN 60068-2-27

EN 60947-5-2:2007 Standards IEC 60947-5-2:2007

Approvals and certificates

UL approval	cULus Listed, Class 2 Power Source
CSA approval	cCSAus Listed, General Purpose, Class 2 Power Source
CCC approval	CCC approval / marking not required for products rated ≤36 V
E1 Type approval	10R-04

EMC Properties

Interference immunity in accordance with DIN ISO 11452-2: 100 V/m

Frequency band 20 MHz up to 2 GHz

Mains-borne interference in accordance with ISO 7637-2: Pulse 1 2a 2b За 3b 4 Severity level Ш Ш Ш Ш Ш Ш

С Failure criterion C Α С Α Α EN 61000-4-2: CD: 8 kV AD: 15 kV

Severity level IV EN 61000-4-3: 30 V/m (80...2500 MHz)


Severity level IV EN 61000-4-4: 2 kV Severity level Ш

EN 61000-4-6: 10 V (0.01...80 MHz)

Severity level Ш

EN 55011: Klasse A

Dimensions



Sensor Orientation

In the default setting the zero position of the sensor is reached, when the sensor is mounted on a horizontal plane and electrical connection faces sidewards.

Mounting of the sensor

Sensors from the -F99 series consist of a sensor module and accompanying cast aluminum housing. Select a horizontal flat surface with minimum dimensions of 70 mm x 50 mm to mount the sensor. Mount the sensor as follows:



- Loosen the central screw under the sensor connection.
- Slide back the clamping element until you are able to remove the sensor module from the housing. Remove the sensor module from the housing
- Position the housing at the required mounting location and secure using four countersunk screws. Make sure that the heads of the screws do not protrude.

 Place the sensor module in the housing.

 Slide the clamping element flush into the housing. Check that the sensor element is seated correctly.

- 7. Finally tighten the central screw. The sensor is now mounted correctly.