

Control code tape PGV*-CC25-*

- High chemical resistance
- Low weight
- Self-adhesive mounting
- High temperature resistance
- High mechanical stability

Control code tape für PGV System

Dimensions



Technical Data

General specifications	
Start marker number	1 999
Number	1 999
Length	1 m per control code number
Width	25 mm (1 row version)
Ambient conditions	
Operating temperature	-40 100 °C (-40 212 °F)
Installation temperature	10 40 °C (50 104 °F)
Environmental resistance	UV radiation Humidity Salt spray (150 h / 5%)
Chemical resistance	Oils Grease Fuels Aliphatic solvents Weak acids
Mechanical specifications	
Material thickness	150 μm
Material	polyester laminate

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Release date: 2023-06-22 Date of issue: 2023-06-22 Filename: 299655_eng.pdf



1

Technical Data

Surface	polyester, matte
Mass	6.3 g / m
Tensile strength	≥ 150 N
Manufacturing tolerance	± 1 mm/m
Adhesive	Acrylate-based adhesive ; curing 72 h
Adhesive strength	Average values (FTM2) Aluminum : 24 N / 25 mm High grade stainless steel : 25 N / 25 mm ABS : 22 N / 25 mm PP : 18 N / 25 mm HD-PE : 12 N / 25 mm LD-PE : 12 N / 25 mm

Additional Information

Example for order information Control codes 150 to 199 are required. The order is placed using the start number for the number range and the end number for the number range.

This results in the order designation **PGV-CC25-150-050-SET**. The number **50** in the order designation represents the number of control code strips each measuring 1 m. The number **150** in the order designation represents the start number. NOTE: Control code numbers from 1 ... 999 can be ordered as required. In this example, the delivery consists of 50 control code strips, each measuring 1 m long. The control code tape is 1-meter long and can also be shortened if required. Please note that, depending on the travel speed and the measuring rate of the read head, the control code tape must have a minimum length to be detected reliably.

Type Code

Structure of the type code (Ordering information)

(Ordering informatio			
P G V -	C C 2 5 - (1) (1) (1) (1) - (2) (2) (2) (2) (2) - S E T		
PGV	Sensor Type		
PGV	Position Guided Vision		
CC	Code type		
С	Data Matrix ECC200, Symbol size 12x12		
С	Control code		
25	Width of the control code tape		
25	25 mm		
(1) (1) (1) (1) (1)	Start control code no.		
00001 00999	Start number of the control code tape		
(2) (2) (2) (2) (2)	Number		
00001 00999	Number of control code strips, each 1 m long.		

Matching System Components

	PGV100RS- F213-R4-1.5M	Read head for incident light positioning system
<u></u>	PGV100R-F213-R4-1.5M	Read head for incident light positioning system
	PGV100-F200A- B25-V1D-8438	Read head for incident light positioning system
	PGV150I-F200-B16-V15	Read head for incident light positioning system
()	PGV100R- F200-B16-V15-8482	Read head for incident light positioning system
	PGV100R- F200-B16-1,5M-7800	Read head for incident light positioning system

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Matchi	ng System Comp	onents
	PGV100RS- F200-B16-1,5M-8606	Read head for incident light positioning system
	PGV100RS- F200-B16-1,5M	Read head for incident light positioning system
	PGV100R-F200-B16-1,5M	Read head for incident light positioning system
	PGV100R- F200-B16-1,5M-KOL	Read head for incident light positioning system
	PGV100RS- F213-B16-1.5M	Read head for incident light positioning system
	PGV40RS- F213-B16-1.5M	Read head for incident light positioning system
	PGV40R-F213-B16-1.5M	Read head for incident light positioning system
))	PGV100R-F213-B16-1.5M	Read head for incident light positioning system
	PGV100-F200A-B16-V15	Read head for incident light positioning system
	PGV100-F200A- B16-V15-8438	Read head for incident light positioning system
	PGV100-F200A-B17-V1D	Read head for incident light positioning system
	PGV100-F200A-B25-V1D	Read head for incident light positioning system
	PGV100-F200A-B6-V15B	Read head for incident light positioning system
	PGV100-F200A-R4-V19	Read head for incident light positioning system
	PGV100-F200A- R4-V19-6829	Read head for incident light positioning system
	PGV100-F200-B17-V1D 7477	Read head for incident light positioning system
	PGV100-F200-R4-V19	Read head for incident light positioning system
	PGV100I-F200-B16-V15	Read head for incident light positioning system
	PGV100I-F200A-R4-V19	Read head for incident light positioning system
	PGV100SI-F200A-R4-V19	Read head for incident light positioning system

 Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

 Pepperl+Fuchs Group
 USA: +1 330 486 0001
 Get

 www.pepperl-fuchs.com
 fa-info@us.pepperl-fuchs.com
 fa-info@us.pepperl-fuchs.com

Matchi	ng System Comp	onents
	PGV100SI-F200A- R4-V19-7941	Read head for incident light positioning system
	PGV150I-F200A-B17-V1D	Read head for incident light positioning system
	PGV150I-F200A-B25-V1D	Read head for incident light positioning system
	PGV150I-F200A-R4-V19	Read head for incident light positioning system
	PGV100R-F200-R4-1,5M	Read head for incident light positioning system
	PGV100R- F200-B16-V15-7666	Read head for incident light positioning system
	PGV100R-F200-B16-CJD	Read head for incident light positioning system

Accessories

1	0	
1		

PGV25M-CD160-CLEAR Protective laminate for PGV code tape

PGV25M-CD100-CLEAR Protective laminate for PGV code tape

 Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

 Pepperl+Fuchs Group
 USA: +1 330 486 0001
 Gr

 www.pepperl-fuchs.com
 fa-info@us.pepperl-fuchs.com
 fa-info@us.pepperl-fuchs.com

